

User's Guide

NEC Express Server
Express5800 Series

Express5800/R120g-1M EXP801

Chapter 1 General Description



Chapter 2 Preparations






Chapter 3 Setup

Chapter 4 Appendix







Manuals

Manuals for this product are provided as booklets (📖) and electronic manuals (📄) in EXPRESSBUILDER (🔍).

	Safety Precautions and Regulatory Notices	Describes points of caution to ensure the safe use of this server. <u>Read these cautions before using this server.</u>
	Getting Started	Describes how to use this server, from unpacking to operations. See this guide first and read the outline of this product.

	EXPRESSBUILDER	
	User's Guide	
	Chapter 1: General Description	Overviews, names, and functions of the server's parts
	Chapter 2: Preparations	Installation of additional options, connection of peripheral devices, and suitable location for this server
	Chapter 3: Setup	System BIOS configurations and summary of EXPRESSBUILDER
	Chapter 4: Appendix	Specifications and other information
	Installation Guide (Windows)	
	Chapter 1: Installing Windows	Installation of Windows and drivers, and precautions for installation
	Chapter 2: Installing Bundled Software	Installation of NEC ESMPRO, Universal RAID Utility, and other bundled software
	Maintenance Guide	
	Chapter 1: Maintenance	Server maintenance and troubleshooting
	Chapter 2: Useful Features	Useful features and the detail of system BIOS settings, RAID Configuration Utility, and EXPRESSBUILDER
	Chapter 3: Appendix	Error messages and Windows Event Logs
	Other manuals	
	The detail of NEC ESMPRO, Universal RAID Utility, and the other features	

Contents

Manuals	2
Contents	3
Conventions Used in This Document	6
Signs and symbols for safety	6
Notations used in the text	7
Optical disk drive	7
Hard disk drive	7
Removable media	7
Abbreviations of Operating Systems (Windows)	8
POST	8
BMC	8
Trademarks	9
License Agreement Notice	10
Warnings and Additions to This Document	13
Latest editions	13
Safety notes	13
Warning label	14
Handling precautions (for proper operations)	15
Chapter 1 General Description	17
1. Introduction	18
2. Accessories	19
3. Features	20
3.1 Firmware and Software Version Management	23
4. Names and Functions of Parts	24
4.1 Front View (With Front Bezel)	24
4.2 Front View (Without Front Bezel)	25
4.3 Rear View	26
4.4 External View	27
4.5 Internal View	28
4.6 Motherboard	29
4.7 Status Indicators	31
4.7.1 POWER LED ()	31
4.7.2 STATUS LED 1,2 ()	31
4.7.3 LINK/ACT LED ( 1,  2,  3,  4)	33
4.7.4 Optical Disk Drive Access LED	33
4.7.5 UID LED (ID)	33
4.7.6 Power Capping LED	33
4.7.7 LED on a hard disk drive	34
4.7.8 LEDs for LAN connectors	35
4.7.9 AC POWER LED on Power Unit	37
Chapter 2 Preparations	38
1. Installing Internal Optional Devices	39
1.1 Safety Precautions	39
1.2 Overview of Installation and Removal	40
1.3 Identifying Servers (UID Switch)	42

1.4	Removing Front Bezel	43
1.5	Removing Top Cover	44
1.6	TPM Kit	45
1.6.1	Installation	45
1.7	Processor (CPU)	46
1.7.1	Maximum number of processor cores supported by this server	46
1.7.2	Installation	47
1.7.3	Replacement / Removal	52
1.8	DIMM	53
1.8.1	Maximum supported memory size	53
1.8.2	Memory Clock	54
1.8.3	Memory RAS Feature	56
1.8.4	DIMM installation order	57
1.8.5	Installation	58
1.8.6	Removal / Replacement	59
1.8.7	Cluster On Die and Early Snoop features	59
1.8.8	Using Memory RAS Feature	61
1.9	Flash Backup Unit for RAID Controller	69
1.9.1	Handling precautions	69
1.9.2	Installing N8103-181 Flash Backup Unit	69
1.9.3	Removal	72
1.9.4	Installing FBU for N8103-179	73
1.9.5	Removing FBU	75
1.10	LOM Card	76
1.10.1	Installation	76
1.10.2	Removal	78
1.11	PCI Riser Card	79
1.11.1	Notes	79
1.11.2	Installation	79
1.11.3	Removal	79
1.12	PCI Card	80
1.12.1	Notes	80
1.12.2	Supported PCI cards and available slots	81
1.12.3	Installation	86
1.12.4	Removal	87
1.12.5	Installing RAID Controller	88
1.13	Optical Disk Drive	91
1.13.1	Installation	91
1.13.2	Removal	92
1.14	Use of Internal Hard Disk Drives in the RAID System	93
1.14.1	Connecting cables	93
1.14.2	Notes on Building RAID System	94
1.15	Installing Top Cover	95
1.16	Hard Disk Drive	96
1.16.1	Installation	97
1.16.2	Removal	98
1.16.3	Replacing a hard disk drive in the RAID System (Auto Rebuild)	99
1.17	Power Supply Unit	100
1.17.1	Cold Redundant Feature	100
1.17.2	Installation	101
1.17.3	Replacing a failing power supply unit	102
1.18	Installing Front Bezel	103
2.	Installation and Connection	104
2.1	Installation	104
2.1.1	Installing Rack	104
2.1.2	Installing the server to the rack or removing it from the rack	106
2.2	Connection	111
2.2.1	Connecting to Uninterruptible Power Supply (UPS)	113
Chapter 3	Setup	114
1.	Turning on the Server	115
1.1	POST	116

1.1.1	POST sequence	116
1.1.2	POST error messages	118
2.	BIOS Setup Utility (SETUP)	119
2.1	Overview	119
2.2	Starting SETUP Utility	119
2.3	Description on On-Screen Items and Key Usage	120
2.4	Cases that Require Configuration	122
3.	EXPRESSSCOPE Engine 3	124
3.1	Overview	124
3.2	EXPRESSSCOPE Engine 3 Network Configuration	125
4.	EXPRESSBUILDER	127
4.1	Features of EXPRESSBUILDER	127
4.2	Usage of EXPRESSBUILDER	127
5.	Installing Software Components	128
6.	Turning Off the Server	129
Chapter 4	Appendix	130
1.	Specifications	131
2.	Interrupt Lines	134
3.	Glossary	135
4.	Revision Record	136

Conventions Used in This Document

Signs and symbols for safety

WARNING and CAUTION are used in this guide as following meaning.









Indicates there is a risk of death or serious personal injury



Indicates there is a risk of burns, other personal injury, or property damage

Precautions and notices against hazards are presented with one of the following three symbols. The individual symbols are defined as follows:

	Attention	This symbol indicates the presence of a hazard if the instruction is ignored. An image in the symbol illustrates the hazard type.	(Example) 
	Prohibited Action	This symbol indicates prohibited actions. An image in the symbol illustrates a particular prohibited action.	(Example) 
	Mandatory Action	This symbol indicates mandatory actions. An image in the symbol illustrates a mandatory action to avoid a particular hazard.	(Example)  (Disconnect a plug)

(Example in this guide)

Symbol to draw attention

Description of a warning

Term indicating a degree of danger

WARNING

Use only the specified outlet

Use a grounded outlet with the specified voltage. Use of an improper power source may cause a fire or a power leak.

Notations used in the text

In addition to safety-related symbols urging caution, three other types of notations are used in this manual. These notations have the following meanings.

Important	Indicates critical items that must be followed when handling hardware or operating software. If the procedures described are not followed, <u>server failure, data loss, and other serious malfunctions could occur.</u>
Note	Indicates items that must be confirmed when handling hardware or operating software.
Tips	Indicates information that is helpful to keep in mind when using this server.

Optical disk drive

This server is equipped with one of the following drives. These drives are referred to as *optical disk drive* in this manual.

- DVD-ROM drive
- DVD Super MULTI drive

Hard disk drive

Unless otherwise stated, *hard disk drive* described in this manual refer to both of the following.

- Hard disk drive (HDD)
- Solid state drive (SSD)

Removable media

Unless otherwise stated, *removable media* described in this manual refer to both of the following.

- USB flash drive
- Flash FDD

Abbreviations of Operating Systems (Windows)

Windows Operating Systems are referred to as follows.

See Chapter 1 (1.2 Supported Windows OS) in Installation Guide (Windows) for detailed information.

Notations in this manual	Official names of Windows
Windows Server 2012 R2	Windows Server 2012 R2 Standard
	Windows Server 2012 R2 Datacenter
Windows Server 2012	Windows Server 2012 Standard
	Windows Server 2012 Datacenter
Windows Server 2008 R2	Windows Server 2008 R2 Standard
	Windows Server 2008 R2 Enterprise

POST

POST described in this manual refers to the following.

- Power On Self-Test

BMC

BMC described in this manual refers to the following.

- Baseboard Management Controller

Trademarks

EXPRESSSCOPE and ExpressUpdate are registered trademark of NEC Corporation.

Microsoft, Windows, and Windows Server are registered trademarks or trademarks of Microsoft Corporation in the United States and other countries. Intel, Pentium, and Xeon are registered trademarks of Intel Corporation of the United States. AT is a registered trademark of International Business Machines Corporation of the United States and other countries. Adaptec, its logo, and SCSI Select are registered trademarks or trademarks of Adaptec, Inc. of the United States. Avago, LSI, and the LSI & Design logo are trademarks or registered trademarks of Avago Technologies in the United States and/or other countries. Adobe, the Adobe logo, and Acrobat are trademarks of Adobe Systems Incorporated. DLT and DLTape are trademarks of Quantum Corporation of the United States. PCI Express is a trademark of Peripheral Component Interconnect Special Interest Group. InfiniBand is a trademark or service mark of InfiniBand Trade Association. Mellanox, and its logo, and Connect-X, Switch-X, MLNX-OS products are trademarks or registered trademarks of Mellanox Technologies in Israel and other countries.

All other product, brand, or trade names used in this publication are the trademarks or registered trademarks of their respective trademark owners.

License Agreement Notice

Open source software of following license is included in the part of this product (system BIOS).

- EDK/EDKII
- UEFI Network Stack II and iSCSI
- Crypto package using WPA Supplicant

Open source software of following license is included in the part of this product (Off-line Tools).

- EDK/EDKII

EDK FROM TIANOCORE.ORG

BSD License from Intel

Copyright (c) 2012, Intel Corporation

All rights reserved.

Copyright (c) 2004, Intel Corporation

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the Intel Corporation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

UEFI NETWORK STACK II and iSCSI

OpenSSL License

Copyright (c) 1998-2011 The OpenSSL Project. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgment:
"This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit.
(<http://www.openssl.org/>)"
4. The names "OpenSSL Toolkit" and "OpenSSL Project" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact openssl-core@openssl.org.
5. Products derived from this software may not be called "OpenSSL" nor may "OpenSSL" appear in their names without prior written permission of the OpenSSL Project.
6. Redistributions of any form whatsoever must retain the following acknowledgment:
"This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit
(<http://www.openssl.org/>)"

THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT ``AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com).

This product includes software written by Tim Hudson (tjh@cryptsoft.com).

CRYPTO PACKAGE USING WPA SUPPLICANT

WPA Supplicant

Copyright (c) 2003-2012, Jouni Malinen <j@w1.fi> and contributors
All Rights Reserved.

This program is licensed under the BSD license (the one with advertisement clause removed).
If you are submitting changes to the project, please see CONTRIBUTIONS file for more instructions.

License

This software may be distributed, used, and modified under the terms of
BSD license:

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name(s) of the above-listed copyright holder(s) nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Warnings and Additions to This Document

1. Unauthorized reproduction of the contents of this manual, in part or in its entirety, is prohibited.
2. This manual is subject to change at any time without notice.
3. Do not make copies or alter the manual content without permission from NEC Corporation.
4. If you have any concerns, or discover errors or omissions in this manual, contact your sales representative.
5. Regardless of article 4, NEC Corporation assumes no responsibility for effects resulting from your operations.
6. The sample values used in this manual are not actual values.

Keep this manual for future use.

Latest editions

This manual was created based on the information available at the time of its creation. The screen images, messages, and procedures are subject to change without notice. Substitute as appropriate when content has been modified.

The most recent version of the guide, as well as other related manuals, is also available for download from the following website.

<http://www.nec.com/>

Safety notes

To use this server safely, read thoroughly the "*Safety Precautions and Regulatory Notices*" that comes with your server.

Warning label

Warning label are attached on or near the components with potential hazards. This label is either attached or printed on the component.

Do not remove or black out this label and keep it clean. If no label is attached or printed on the server, contact your sales representative.

重量物注意
WARNING: HEAVY ITEM

ぎっくり腰や落下事故防止のため移動のさいは2人以上で行って下さい。
To avoid the risk of personal injury or damage to the unit, move the unit with at least two or more people.

243-201192-001-A-1

警告
WARNING
AVERTISSEMENT

接続される電源ユニットは適切を確認すること。
Confirm the type of power supply and then connect to the corresponding power source.
请您确认供电单元类型并连接至相应的电源。
Veuillez confirmer le type d'alimentation électrique et de la connexion à la source électrique correspondante.

243-203517-001-A-1

注意
CAUTION
ATTENTION

注意：複数電源、複数電源、複数電源
オプションの取り付け、取り外し時は電源プラグをコンセントから外してください。
電源プラグの抜き差しは、電源プラグの抜き差しを必ず行ってください。
電源プラグの抜き差しは、電源プラグの抜き差しを必ず行ってください。

CAUTION - MULTIPLE POWER SUPPLY SOURCES
This unit have more than one power-supply source. Before servicing, confirm with manuals on number of power-source to disconnect, and disconnect them.
ATTENTION : ALIMENTATION ÉLECTRIQUE MULTIPLE
Cet appareil peut posséder plusieurs alimentations électriques. Avant toute intervention d'entretien, voir les manuels pour contrôler le nombre d'alimentations à interrompre, puis les débrancher.

注意 CAUTION ATTENTION	
高温になるコンポーネントがあります。十分に冷えてから触れるようにして下さい。 As some components may become very hot during system operation, give ample time to allow cooling as well as use precaution when handling internal components immediately after powering down. 有的部件可能会达到高温。请注意待其冷却之后再接触。	ネジは本体内部へ落とさない様、十分に注意下さい。 Do not drop any screws inside the system. 請一定注意不要让螺丝掉入设备内部。 请注意避免不要将螺丝掉入设备内部。
有的部件可能会达到高温。请注意待其冷却之后再接触。 Comme certains composants peuvent se réchauffer beaucoup pendant le fonctionnement du système, laissez-les se refroidir suffisamment et faites bien attention lorsque vous manipulez les composants internes juste après avoir désactivé le système.	ボード及びオプション機器の接続の際は、必ずユーザガイドを参照し、正しく接続して下さい。 誤った接続は、故障や火災の原因となります。 Refer to the "User's Guide" when option board or peripherals are installed. Incorrect installations may result in damage to the system and lead to accidents.
電源を切ってもバッテリーで稼働している部分があります。 Refer to instruction manuals for this system as well as options prior to maintenance. 即使切断电源，有的部件也会依靠电池运转。在进行维护之前，请认真阅读各组件的使用说明书。	接続板卡及可选设备时，请务必参照“用户指南”进行正确连接。 连接错误，有可能造成故障或火灾。 安装控制卡及可选设备时，请务必参照“用户指南”进行正确连接。 连接错误，有可能造成故障或火灾。
Some internal components may still be operational on battery power. as well as options prior to maintenance. 即使切断电源，有的部件也会依靠电池运转。在进行维护之前，请认真阅读各组件的使用说明书。	Référez-vous au <Guide de l'utilisateur> lorsque des cartes en option ou des périphériques sont installés. Une installation incorrecte risque d'endommager le système et de causer des accidents.
Quelques composants internes peuvent encore continuer à fonctionner avec l'alimentation de la batterie. Référez-vous aux manuels d'instruction pour ces systèmes aussi bien que les dispositifs en options avant d'effectuer les travaux d'entretien.	傷をばったり、ぶついたりしないように注意して下さい。 To avoid the risk of personal injury, be careful when accessing the inside of the system. 请小心不要夹伤或碰伤手指。 请注意避免夹伤手指，或碰撞碰面受傷。
オプションの取り付け、取り外し時はすべての電源プラグをコンセントから抜き、外装蓋と接続しているケーブルを抜いて下さい。 Disconnect all AC power cords from both system and external peripherals prior to installing/removing options.	装置を持ち上げ、移動の際は、装置の底面をしっかりと持ち上げて下さい。 Firmly hold the bottom of the system when required to lift and carry the system.
進行可選配件的安装和拆卸时，请先从插座下全部的电源插头并分离与外装设备有关的线缆。断电时请同时断开所有电源。否则无法断电。 進行選購設備的安裝和拆卸時，請先從全部的電源插頭從插座中拔出，並取下與外部設備連接的線纜。	抬站、搬運設備時，請牢抓住設備底部將其抬站。 抬站、搬運設備時，請牢抓住設備底部將其抬站。
Disconnect all AC power cords from both system and external peripherals prior to installing/removing options. Déconnectez tous les câbles CA du système et des périphériques externes avant d'installer/d'enlever les dispositifs en option.	Saisissez fermement le fond du système au cas où vous devez soulever et transporter le système.

243-201699-732-A-1 註 HY80

Handling precautions (for proper operations)

Be sure to observe the following precautions for the proper functioning of the server. Ignoring the precautions may cause server malfunction or failure.

- Do not use any cellphones and switch off them near the server. Electric waves from such devices can cause server to malfunction.
- Install the server in an appropriate place. For details about the installation location, see *Chapter 2 Preparations (2. Installation and Connection)*.
- Before connecting/removing cables to/from peripheral devices, make sure that the server is off and unplug the power cord, if they are non plug-and-play devices.
- Connect the provided power cord to a 100/200 VAC outlet.
- Do not press the POWER switch to turn on the server before the STATUS LED 2 (amber) is unlit.
- Make sure that the access LED on the server is off before turning off the power or ejecting an optical disk.
- Wait for at least 30 seconds before connecting power cord to power outlet after disconnecting it.
- If any Uninterruptible Power Supply (UPS) unit is connected, set it to wait for at least 30 seconds before turning on the server after power off.
- Wait for at least 30 seconds before turning on the server after turning off the server.
- Do not power off or reset the server, nor disconnect the power cord before POST completes.
- Turn off the server and unplug the power cord before moving it.
- Regularly clean the server to prevent various types of failure. See *Chapter 1 Maintenance (2. Daily Maintenance)* in "Maintenance Guide" for details about cleaning.
- Momentary voltage drop may occur due to lightning strike. To prevent this, use of UPS is recommended.
- We do not support that any copy-protected CD that does not conform to standards will play on the server's optical disk drive.
- In the following cases, check and adjust the system clock before operation.
 - After transportation
 - After storage
 - After the server is used following a period of disuse, in which storage conditions did not conform to those that guarantee server operations (temperature: 5 to 40°C; humidity: 20% to 80%).
- Check the system clock approximately once per month. Use of a time server (NTP server) is recommended if high accuracy timing is required by the system.
- Observe the storage conditions (Temperature: –10°C to 55°C, Humidity: 20% to 80%, No condensation of moisture) to store the server. **If this server, internal optional devices, and media set for the backup devices (tape cartridges) are moved from a cold place to a warm place in a short time, condensation will occur and cause malfunctions and failures when these are used in such state. To protect important stored data and property, make sure to wait for a sufficient period to use the server and components in the operating environment.**

Reference: Time effective at avoiding condensation in winter (more than 10°C differences between the room temperature and atmospheric temperature)

Disk devices: Approximately 2 to 3 hours Tape media: Approximately 1 day
- This server does not support hibernation/standby function.
- For optional devices, we recommend you use our NEC products. Even if they are successfully installed or connected, installation of unsupported devices can cause the server to malfunction or even failure. You will be charged to repair failure or damage caused by use of such products even within warranty period.

Tips for your health and safety

Using a computer extensively may affect different parts of your body. Here are tips you should follow while working on a computer to minimize strain on your body.

Keep proper posture


The basic body position for using a computer is sitting straight with your hands on the keyboard parallel with the floor, and your eyes directed slightly downward toward the monitor. With the proper posture described above, no unnecessary strain is applied on any part of your body, in other words when your muscles are most relaxed.

Working on the computer with bad posture such as hunching over or being too close to the monitor could cause fatigue or deteriorated eyesight.




Adjust the angle of your display

Most display units are designed for adjustment of the horizontal and vertical angles. This adjustment is important to prevent the screen from reflecting bright lights and to make the display contents easy to see. Working without adjusting the display to a comfortable angle makes it difficult for you to maintain a proper posture and you will get tired easily. Adjust the viewing angle before use.




Adjust the brightness and contrast of the display

Display screens have functions to control brightness and contrast. The most suitable brightness/contrast depends on age, individuals, and environment, so adjust it to suit your preferences. A too bright or too dark display is bad for your eyes.



Adjust the angle of keyboard

Some keyboards are ergonomically designed, which allow the angle to be adjusted. Adjusting the angle of the keyboard is effective to reduce tension on your shoulders, arms, and fingers.



Clean your equipment

Keeping your equipment clean is important not only for the appearance but also for functional and safety reasons. A dusty monitor makes it difficult to see the display contents, so clean it regularly.

Take rest breaks

When you feel tired, take a break. Light exercise is also recommended.



NEC Express5800 Series Express5800/R120g-1M

1

General Description

This chapter introduces the features of this server and the name of each part.

1. Introduction

2. Accessories

Describes the accessories of the server.

3. Features

Describes the features of the server and the server management.

4. Names and Functions of Parts

Describes the name of each part contained in this server.

1. Introduction

Thank you for purchasing this NEC Express5800 Series product.

This high performance server is powered by the latest microprocessor "Intel® Xeon® processor".

NEC's latest technology and architectures realize high-power and high-speed operation that cannot be matched by existing servers.

The server is designed with consideration of not only reliability but also expandability, which enables you to use it as a network server.

Read this manual before using the server thoroughly to fully understand handling of Express5800 Series Server and appreciate its functions to the maximum extent.

2. Accessories

The carton box contains various accessories which are required for setup or maintenance. **Make sure you have them all** for future use.

- **Front Bezel**
- **Bezel Lock Key (attached to Front Bezel)**
- **Slide Rails**
- **Safety Precautions and Regulatory Notices**
- **SAS/SATA cable**
- **Getting Started**


Make sure you have all accessories and inspect them. If an accessory is missing or damaged, contact your sales representative.

Important

The chassis serial number plate and maintenance label is located on the server. If the serial number does not match the number on the warranty, you may not be guaranteed against failure even within the warranty period. Contact your sales representative if they do not match.

3. Features

The server has the following features:



High performance

- Intel Xeon processor
 - N8101-1029F: E5-2603 v4 (1.70GHz 6Core)
 - N8101-1030F: E5-2620 v4 (2.10GHz 8Core)
 - N8101-1031F: E5-2623 v4 (2.60GHz 4Core)
 - N8101-1032F: E5-2630 v4 (2.20GHz 10Core)
 - N8101-1033F: E5-2637 v4 (3.50GHz 4Core)
 - N8101-1034F: E5-2640 v4 (2.40GHz 10Core)
 - N8101-1036F: E5-2650 v4 (2.20GHz 12Core)
 - N8101-1037F: E5-2650L v4 (1.70GHz 14Core)
 - N8101-1038F: E5-2667 v4 (3.20GHz 8Core)
 - N8101-1039F: E5-2680 v4 (2.40GHz 14Core)
 - N8101-1040F: E5-2690 v4 (2.60GHz 14Core)
 - N8101-1041F: E5-2697 v4 (2.30GHz 18Core)
 - N8101-1042F: E5-2697A v4 (2.60GHz 16Core)
 - N8101-1043F: E5-2698 v4 (2.20GHz 20Core)
 - N8101-1044F: E5-2699 v4 (2.20GHz 22Core)
- Turbo Boost Technology feature *1
- Hyper Threading Technology feature *1
- High-speed memory access (DDR4 1600/1866/2400 supported) *2
- High-speed disk access (SATA 6Gbps / SAS 12GB/s supported)
- High-speed 10GBASE-SFP+ / 10GBASE-T / 100GBASE-T/100BASE-TX / 10BASE-T interface (10Gbps / 1Gbps / 100Mbps / 10Mbps supported) can be selectable

High reliability

- Processor throttle-ring feature
- Memory monitoring feature (error correction/error detection)
- Memory degeneracy feature (logical isolation of a failed device)
- Memory x4 SDDC feature
- Memory mirroring, memory LockStep (x8 SDDC), memory sparing features
- Memory throttle-ring feature

- Bus parity error detection
- Temperature detection
- Error detection
- Internal fan monitoring feature
- Internal voltage monitoring feature
- Power redundant feature (hot swapping supported)
- RAID system (Disk Array) (An option card is required.)
- Auto rebuild feature (hot swapping supported)
- BIOS password feature
- The security lock that comes with Front Bezel
- Redundant fan (hot swapping supported)
- HDD (hot swapping supported)

Management Utilities

- NEC ESMPRO
- ExpressUpdate
- Remote controlling feature (EXPRESSSCOPE Engine 3)
- RAID system management utility (Universal RAID Utility)
- Hard disk drive monitoring
- Power supply monitoring

Power saving and noiseless design

- Selection of power unit appropriate to environment, work load, and configuration
- Power consumption monitoring feature
- Power control feature
- 80 PLUS® Platinum / Titanium certified high efficiency power supply *5
- Fan control appropriate to environment, work load, and configuration
- Silent sound design
- Enhanced Intel SpeedStep® Technology supported
- Cold redundant feature

Expandability

- PCI Express 3.0 (x8 lanes): 1 slot (Full height) *6
- PCI Express 3.0 (x8 lanes): 1 slot (Low profile) *7
- PCI Express 3.0 (x8 lanes): 1 slot (dedicated to RAID controller)
- LOM card slot (x8 lanes): 1 slot (dedicated to LOM card)
- Large capacity memory of up to 1.5TB *3
- Can upgrade to multi-processor system with up to two processors
- Expansion Bay (for hard disk drives): up to 16 slots *4
- Optical disk drive bay provided as standard
- USB3.0 interface (Front: 2 ports, rear: 2 ports, internal: 1 port)
- USB2.0 interface (Rear: 2 ports, internal: 2 ports)
- Management LAN port (1 port)
- With optional LOM card, two to four ports can be added.

Ready to use

- No cable connection is required to install a hard disk drive and additional power supply unit (hot swap supported).
- Slide rails for each installation

Many built-in Features

- Redundant power supply system supported (valid when optional power supply unit is installed)
- El Torito Bootable CD-ROM (no emulation mode) format supported
- Software power-off
- Remote power-on feature
- AC-Link feature
- Remote console feature
- Power switch mask
- Connector for display unit provided on front panel
- Baseboard Management Controller (BMC) conforming to IPMI v2.0

Self-diagnosis

- Power On Self-Test (POST)
- Test and Diagnosis (T&D) utility

Easy setup

- EXPRESSBUILDER (setup utility)
- BIOS Setup utility (SETUP)

Maintenance features

- Off-line Tools
- Memory dump feature using DUMP Switch
- Feature to back up and restore BIOS/BMC settings using EXPRESSSCOPE Profile Key

*1: Unsupported on Xeon processor E5-2603 v4 embedded models.

*2: Processor core speed depends on processor type, number and type of DIMMs installed.

*3: In 2-CPU configuration. Up to 768GB in 1-CPU configuration.

*4: When N8154-69 2.5-inch cage for additional HDD is installed: 8 slots for standard configuration.

*5: When N8181-118F power unit is installed. Power supply unit N8181-121F/122F is compliant to 80 Plus Platinum.

*6: Can be changed to PCI Express 3.0: 1 slot (x16 lanes) by using optional riser card.

*7: Can be changed to PCI Express 3.0: 1 slot (x16 lanes) by using optional riser card.

***3.1* Firmware and Software Version Management**


Use of NEC ESMPRO Manager and ExpressUpdate Agent allows you to manage versions of firmware and software as well as update them by applying update packages.

This feature automatically updates modules without stopping the system just by specifying the updating packages from NEC ESMPRO Manager.

4. Names and Functions of Parts

This section describes the names of the server parts.

4.1 Front View (With Front Bezel)



(1) Front Bezel

A cover for protecting the front of the server. This cover can be locked with the provided Bezel Lock Key.

(2) Key Slot

A slot for Bezel Lock Key that is used to lock Front Bezel.

(3) LINK/ACT LED

LEDs for showing the status of accessing to the network.
(See page 33)

(3)-1: LAN1 connector

(3)-2: LAN2 connector

(3)-3: LAN3 connector

(3)-4: LAN4 connector

LEDs for LAN3 and LAN4 are lit when optional LOM card (N8104-154F/156F) is installed.

(4) POWER CAPPING LED

An LED for showing the power capping of the server.
(See page 33)

(5) STATUS 1, 2 LED

LEDs for showing the server status. (See page 31)


(6) Unit ID (UID) LED

An LED for maintaining the server. This LED turns on when UID Switch is pressed. Commands from the software also cause it to turn on or flash.
(See page 33)

(7) POWER LED

An LED for showing the power status of server.
(See page 31)

4.2 Front View (Without Front Bezel)



(8) 2.5-inch Hard Disk Drive Bay

Bays for installing HDDs. The sequential numbers indicate the corresponding slot numbers. All bays include Dummy Trays.

(9) DISK Access LED

LEDs for showing the status of accessing to the hard disk drive.

(See page 34)

(10) DISK STATUS LED

LEDs for showing the hard disk status.

(See page 34)

(11) POWER Switch/LED

A switch for turning on/off the server. Press once to turn on the server. POWER LED lights when it is on. Press it again to turn off the server. Hold down the switch for four seconds or more to forcibly turn off the server.

(See page 31)

(12) Unit ID (UID) Switch/LED

A switch for turning on/off UID LED.

Pressing the switch once turns on UID LED and pressing again turns off the LED.

Commands from the software also cause it to turn on or flash. (See page 33)

(13) RESET Switch

A switch for resetting the server.

(14) DUMP Switch (NMI)

A switch for collecting the memory dump.

(15) BMC RESET Switch

A switch for resetting BMC of the server. Use this switch only when there is a problem with EXPRESSSCOPE Engine 3 (BMC). To use this switch, press it at least five seconds.

(16) STATUS 1, 2 LED

LEDs for showing the server status. (See page 31)

(17) POWER CAPPING LED

An LED for showing the power capping of the server.

(See page 33)

(18) LINK/ACT LED

LEDs for showing the status of accessing to the network.

(See (3) on the previous page.)

(19) USB Connectors (front)

Connectors for connecting USB interface devices.

(20) Pull-out Tab

A tab for showing the model number and serial number of the server.

(21) Display Connector

A connector for connecting a display. This connector cannot be used with the display connector on rear panel at the same time.


(22) Optical Disk Drive Bay

A bay for installing an optical disk drive.

Either of the following drive can be installed.

- DVD-ROM drive
- DVD SuperMULTI drive

4.3 Rear View



(1) Power Unit (Power supply slot 1)

A power supply for supplying the DC power to the server.

(2) AC Inlet

A socket for connecting the power cord.

(3) AC POWER LED

An LED for showing the power supply status.
(See page 37)

(4) Cap Screw

A screw for fixing the top cover.

(5) Slot for Full-height PCI Card

A slot for installing a full-height PCI card.
Assigned PCI slot number is "1C".

(6) Slot for Low-profile PCI Card

A slot for installing a low-profile PCI card.
Assigned PCI slot number is "1D".

(7) Blank Cover (for power supply #2)

A cover for protecting the bay of power supply #2.
Remove this cover to install an optional power unit.

(8) USB Connectors

Connectors for connecting USB interface devices.

(9) LINK/ACT LED *1

LEDs for showing the access status of LAN.
(See page 36)

(10) LAN Connectors *1

Connectors for connecting to a network
(1000BASE-T/100BASE-TX/10BASE-T) .

(10)-1: LAN1 connector

(10)-2: LAN2 connector

(10)-3: LAN3 connector

(10)-4: LAN4 connector

If Shared BMC LAN feature is enabled in ROM Utility,
LAN1 connector can also be used as the management
LAN. Sharing LAN is not recommended from the point of
performance and security.

(11) SPEED LED *1

LEDs for showing the transfer speed of LAN ports.
(See page 36)

(12) Management LAN Connector

A LAN connector which supports
1000BASE-T/100BASE-TX/10BASE-T.
This port cannot be used as a data LAN port.
This port is used for connecting to EXPRESSSCOPE
Engine 3.

(13) Serial Port A (COM) Connector

A connector for connecting serial interface devices.
This cannot directly connect to a network line.

(14) Display Connector


A connector for connecting a display.
This connector cannot be used with the display connector
on front panel at the same time.

(15) UID Switch/LED

A switch for turning on/off UID LED.
Pressing the switch once turns on UID LED and pressing
again turns off the LED.
Commands from the software also cause it to turn on or
flash. (See page.33)


*1 LOM card is optional. The figure above shows when
N8104-154F is installed.

4.4 External View



- (1) Top Cover
- (2) Release Button.
- (3) Fan Unit Top Cover
- (4) Latch for fixing Fan Unit Top Cover

4.5 Internal View



(1) **Front Panel Board**

(2) **Backplane**

(3) **Cooling Fan**

-1 FAN1F/R

-2 FAN2F/R

-3 FAN3F/R

-4 FAN4F/R

-5 FAN5F/R

-6 FAN6F/R (optional)

-7 FAN7F/R (optional)

-8 FAN8F/R (optional)

FAN1 to FAN5 are factory installed. FAN6 to FAN8 are required in 2-CPU configuration.

(4) **Processor (Optional)**

(mounted below the heat sink)

(5) **DIMM (optional)**

(6) **Support Bar**

(7) **Motherboard**

(8) **Slot for LOM Card**

Assigned PCI slot number is "1B".

(9) **PCI Riser Card**


(10) **Slot for RAID Controller**

Assigned PCI slot number is "1A".

(11) **Power Supply Unit**

(12) **Battery Tray for RAID Controller**

4.6 Motherboard



- (1) **Processor (CPU) Socket**
 - 1: Processor #1 (CPU #1)
 - 2: Processor #2 (CPU #2)
- (2) **DIMM Socket**
- (3) **Front Panel Connector**
- (4) **Fan Connector**
- (5) **Power Connector for Fan Unit**
- (6) **Power Connector for SATA Optical Disk Drive**
- (7) **Power Connector for HDD BP**
- (8) **Power Connector**
 - 1: Standard power unit (POW #1)
 - 2: Optional power unit (POW #2)
- (9) **LOM Card Connector**
- (10) **Lithium Battery**
- (11) **Clear NVRAM Jumper Switch**
- (12) **Clear Password Jumper Switch**
- (13) **Unused Connector**
- (14) **USB Memory Module Connector**
- (15) **HDD BP Connector**
- (16) **Connector for Option COM**

Connect an additional RS-232C connector kit N8117-01A to use this port as a serial port.
- (17) **SPI Mezzanine Connector**

EXPRESSSCOPE Profile Key (SPI memory) has been installed, where BIOS and BMC configuration data is stored. Relocate it when replacing motherboard to inherit configuration data.
- (18) **Front Video Connector**
- (19) **TPM Kit Connector**
- (20) **SATA Connector (for optical disk drive)**
- (21) **PCI Riser Card Connector (for low profile card)**

For the supported card specifications, see *Chapter 2 (1.12 PCI card)*.
- (22) **PCI Riser Card Connector (for full height card)**

For the supported card specifications, see *Chapter 2 (1.12 PCI card)*.
- (23) **SATA HDD Connector**
- (24) **Connectors for External Devices** (See page 26.)
- (25) **RAID Controller Connector**
- (26) **USB Connector (front)**
- (27) **USB Connector (device)**
- (28) **Power Connector (for expansion card)**

4.7 Status Indicators

4.7.1 POWER LED ()

POWER LED indicates power ON/OFF status of the server.

POWER LED pattern	Description
On (green)	The server is normally powered on.
Off	The server is off-powered. The server is in halt status.

4.7.2 STATUS LED 1,2 ()

While hardware is operating normally, STATUS LED 1 lights green. STATUS LED 2 is off.

STATUS LED 1 is off or STATUS LED 2 lights/flashes amber if there is a hardware failure.

Tips

If NEC ESMPRO is installed, you can view error logs to check the causes of failures.

If the LED indication does not change even if the action below is performed, contact your sales representative.

STATUS LED pattern		Description	Action
STATUS LED 1	STATUS LED 2		
On (green)	Off	The server is operating normally.	–
On (green)	On (amber)	Initialization of BMC is in progress.	Wait until initialization of BMC completes. If the status remains the same after several minutes pass, contact your sales representative.
Blinking (green)	Off	Memory is in a degraded state.	Check the electrical system such as power cords. If there is no problem with the system, contact your sales representative.
		Operating while CPU error is detected.	
		In redundant power configuration, power is not supplied to either of power unit.	
Off	Off	The power is off.	If the power is not on, Turn on the server. If POST is in progress, wait until POST completes. If DUMP switch is pressed, wait until the memory dump is completed. If a problem persists after taking these actions, contact your sales representative.
		POST is in progress.	
		Memory dump is being requested. Note: It remains green if the dump is caused by software.	
		CPU was not recognized.	
		Watchdog timer expired.	

STATUS LED pattern		Description	Action
STATUS LED 1	STATUS LED 2		
		An uncorrectable memory error was detected. A PCI system error occurred A PCI parity error occurred A PCI bus error occurred.	
Off	Blinking(amber)	Power Supply Unit is failing (in power redundant configuration). A fan alarm was detected. A temperature alarm was detected. A voltage alarm was detected One or more hard disk drives are failing (excluding RAID0 or non-RAID configuration). Log collection stopped: A correctable memory error has often occurred.	Check the internal fan or air inlets for dust. When dust clings to them, remove it. If the status remains the same after several minutes pass, contact your sales representative.
Off	On (amber)	Power anomaly was detected An abnormal temperature was detected. An abnormal voltage was detected. A CPU error was detected. A chipset error was detected. An uncorrectable memory error was detected. SMI Timeout was detected Sensor error was detected. An error occurred on Intel Node Manager (one of the features of EXPRESSSCOPE Engine 3).	

4.7.3 LINK/ACT LED (□□1, □□2, □□3, □□4)

LINK/ACT LED on front panel indicates the status of LAN port.

The number of ports depends on an optional LOM card installed.

LINK/ACT LED pattern	Description
On (green)	The server is connected with network normally.
Blinking (green)	The server is accessing network.
Off	The server is disconnected from network.

4.7.4 Optical Disk Drive Access LED

The LED for optical disk drive at the front of the server flashes when a CD or DVD is being accessed.

4.7.5 UID LED (ID)

UID LED is provided one each at the front and rear of the server. If you press UID Switch provided at the front or rear of the server, the light turns on. If you press it again, the light turns off. It flashes when commands from software are received.

This LED is used to identify the target server among multiple servers installed in a rack. Especially when performing maintenance from behind the server, lighting the LED will help you to identify which server to work with.

UID LED pattern	Description
On (blue)	The UID switch is pressed.
Off	The UID switch is not pressed.

4.7.6 Power Capping LED

Power Capping LED indicates enabled/disabled status of Power Capping feature as shown below.


Power Capping LED pattern	Description
On (green)	Power Capping feature is enabled.
Blinking (green)	Power Capping is enabled and power control (capping) is working.
Off	Power Capping feature is disabled.

Note

The Power Capping LED seems to be lit or blinking amber when STATUS LED is lit or blinking amber. The amber STATUS LED indicates a hardware failure. Contact your sales representative.

4.7.7 LED on a hard disk drive

Each HDD is equipped with DISK LED.



DISK LED pattern		Description	Action
DISK LED 1	DISK LED 2		
Blinking (green)	Off	Hard disk drive is being accessed.	—
Off	On (amber) (RAID system only)	Hard disk drive is failing.	Contact your sales representative.
Blinking (green)	Blinking (amber) (RAID system only)	Rebuilding is in progress. When the failed hard disk drive is replaced, rebuilding process starts automatically (auto rebuilding feature).	—
Off	Off	Hard disk drive is halted.	—

Important


Observe the following precautions whenever you use the auto rebuilding feature.

- Do not turn off or reboot the server while a HDD is being rebuilt.
- Wait for at least 90 seconds before installing a HDD after removing one.
- Do not replace a HDD while another HDD is being rebuilt.


4.7.8 LEDs for LAN connectors

The LAN connectors have LINK/ACT LED and SPEED LED.


When an optional LOM card N8104-154F is installed:



When an optional LOM card N8104-155F is installed:



When an optional LOM card N8104-156F is installed:



• **LINK/ACT LED** (1, 2, 3, 4, M)

This LED indicates the state of the LAN port.

LINK/ACT LED pattern	Description
On (green)	The server is connected with network normally.
Blinking (green)	The server is accessing network.
Off	The server is disconnected from network.

• **SPEED LED** (1, 2, 3, 4, M)

This LED indicates which network interface is used.

N8100-154F 1000BASE-T LOM Card (4ch)

SPEED LED pattern	Description
On (amber)	The port is operating with 1000BASE-T interface.
On (green)	The port is operating with 100BASE-TX interface.
Off	The port is operating with 10BASE-T interface.

N8104-155F 10GBASE-T LOM Card (2ch)

SPEED LED pattern	Description
On (green)	The port is operating with 10BASE-T interface.
On (amber)	The port is operating with 1000BASE-T interface.
Off	The port is operating with 10BASE-TX interface.

N8104-156F 10GBASE-SFP+(2ch)+1000BASE-T(2ch) LOM Card

- When operating in 10GBASE-SFP+


SPEED LED pattern	Description
On (green)	The port is operating with 10GBASE-SFP+.
On (amber)	The port is operating with 1000BASE-SFP+ interface.
Off	The port is not operating.

- When operating in 1000BASE-T

SPEED LED pattern	Description
On (amber)	The port is operating with 1000BASE-T interface.
On (green)	The port is operating with 100BASE-TX interface.
Off	The port is operating with 10BASE-T interface.

4.7.9 AC POWER LED on Power Unit

The power unit is equipped with AC POWER LED.



AC POWER LED pattern	Description	Action
On (green)	The server is powered on.	—
Blinking (green)	The power cable is connected and AC power is supplied.	—
	Cold Redundant feature is enabled. (See page 99)	—
On (amber)	The power cable is not connected in redundant power configuration.	Connect the power cable.
	Power unit is failing.	Contact your sales representative.
Blinking (amber)	Power unit is failing.	Contact your sales representative.
Off	The power is not supplied to the server.	Connect the power cable. If it is already connected, contact your sales representative.

Preparations

This chapter describes preparations for using this server.

1. Installing Internal Optional Devices

You can skip this section if you did not purchase any optional devices.

2. Installation and Connection

Place the server in a suitable location and connect cables following this section.

1. Installing Internal Optional Devices



This section describes the instructions for installing supported optional devices and precautions.



Important

Use only the devices and cables specified by NEC. You will be charged to repair damages, malfunctions, and failures caused by the use of any devices or cables not specified for use with this server even within the warranty period.

1.1 Safety Precautions


Be sure to observe the following precautions to install and remove optional devices properly and safely.


 WARNING	
	<p>Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause death or serious injury. For details, see <i>Safety Precautions and Regulatory Notices</i>.</p> <ul style="list-style-type: none"> • Do not disassemble, repair, or modify the server. • Do not remove the lithium battery, NiMH battery, or Li-ion battery. • Disconnect the power plug when installing and removing devices.

 CAUTION	
	<p>Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause burns, injury, and property damage. For details, see <i>Safety Precautions and Regulatory Notices</i>.</p> <ul style="list-style-type: none"> • Do not drop • Do not leave the server being pulled out. • Make sure to complete installation. • Do not install with the cover removed. • Do not get your fingers caught. • High temperature • Electrical shock

1.2 Overview of Installation and Removal

Install/remove components by using the following procedure.

 **CAUTION**



Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause burns, injury, and property damage. For details, see *Safety Precautions and Regulatory Notices*.

- Do not drop the server
- Do not leave the server pulled out of the rack
- Replace the cover after installing components
- Beware of high temperatures
- Do not get your fingers caught when installing components

1. If the server is mounted on a rack, use the UID switch to identify the target server.
See *Chapter 2 (1.3 Identifying Servers (UID Switch))*.
2. Remove Front Bezel.
See *Chapter 2 (1.4 Removing Front Bezel)*.
3. Turn off the server.
See *Chapter 3 (6. Turning Off the Server)*.
4. Disconnect the power cord from the outlet and the server.

Important

- After disconnecting the power cord from the server, wait for at least 30 seconds before installing/removing optional devices.
- Make sure AC POWER LED on power supply unit is unlit.

5. If you install a hard disk drive only, go to step 10, and if you install a power supply unit only, go to step 11.
If not, pull out the server from rack and put it on a flat rigid desk.
See *Chapter 2 (2.1 Installation)*.

Important

- Do not leave the server being pulled out from the rack.

6. Remove Top Cover.
See *Chapter 2 (1.5 Removing Top Cover)*.
7. Depending on the components to be installed or removed, follow the procedure in order.
See *Chapter 2 (1.6 TPM Kit) to (1.14 Use of Internal Hard Disk Drives in the RAID System)*.
8. Attach Top Cover.
See *Chapter 2 (1.15 Installing Top Cover)*.
9. Mount the server onto the rack.
See *Chapter 2 (2.1 Installation)*.
10. Install hard disk drives
See *Chapter 2 (1.16 Hard Disk Drive)*.
11. Install power supply units
See *Chapter 2 (1.17 Power Supply Unit)*.

12. Attach Front Bezel.

See *Chapter 2 (1.18 Installing Front Bezel)*.

Installation and removal for internal optional devices are now complete.


Continue the setup with reference to *Chapter 2 (2.2 Connection)*.

1.3 Identifying Servers (UID Switch)

Using UID (Unit ID) Switch helps you to identify the target server.

When the server is working, **be sure to identify the target server by using UID Switch first** before you turn off the server or disconnect a cable from the server.


To turn UID LED on, press UID Switch. When it is pressed again, the LED will be off.




1.4 Removing Front Bezel

Remove the front bezel when pressing the POWER switch or removing Top Cover.

1. To unlock the bezel, insert the attached Bezel Lock Key into the key slot and turn the key while pressing it lightly.



2. Hold the left end of front bezel and pull the right end toward you about 10 cm. Check that the hook in left is removed as illustrated in the figure below and remove the left end from the chassis.



Note

Be careful not to press the POWER Switch.


Important

If you fail to remove the front bezel properly, the front bezel might be damaged.

1.5 Removing Top Cover


Remove Top Cover when installing or removing the optional devices or change internal cable connection.

1. See steps 1 to 5 in *Chapter 2 (1.2 Overview of Installation and Removal)* for preparations.
2. Loosen the cap screw located on rear panel.
3. Slide Top Cover toward the rear of the server while pressing Release Button on the cover.
4. Lift the cover, and remove it from the server.



1.6 TPM Kit


This section describes the procedure for installing optional TPM Kit.



1.6.1 Installation

Install TPM Kit in the following procedure.

1. See steps 1 to 6 in *Chapter 2 (1.2 Overview of Installation and Removal)* for preparations.
2. Install TPM Kit and secure it by pushing the nylon rivet attached to TPM Kit.



Important TPM Kit once installed cannot be removed.
Ask your sales representative if you want to remove the TPM kit.

1.7 Processor (CPU)

You can configure the multi-processor system by adding an optional processor.

Important

- To avoid static electricity, see *Chapter 1 (1.8 Anti-static Measures) in Safety Precautions and Regulatory Notices*.
- Make sure to use the CPU authorized by NEC. Installing a third-party CPU may cause a failure of the CPU as well as the motherboard. Repair of the server due to failures or damage resulted from installing such a CPU will be charged.

Tips

After adding the CPU, Windows may record the event log to System category of Event Viewer, but it is no problem for operation.

1.7.1 Maximum number of processor cores supported by this server

The maximum number of processor cores (logical processors) available on the server depends on the architecture (x86 architecture) and OS specs.

Maximum number of processor cores

OS	The maximum number of logical processors supported by OS	The maximum number of logical processors supported by this server
Microsoft Windows Server 2008 R2 Standard (x64) Microsoft Windows Server 2008 R2 Enterprise (x64)	256 *1	88
Microsoft Windows Server 2012 Standard Microsoft Windows Server 2012 Datacenter Microsoft Windows Server 2012 R2 Standard Microsoft Windows Server 2012 R2 Datacenter	640 *1	88
VMware ESXi 5.5	320	88
VMware ESXi 6.0	480	88


*1: When Hyper-V is used, the maximum number of logical processors is as shown below:

- Windows Server 2008 R2: 64
- Windows Server 2012, Windows Server 2012 R2: 320


1.7.2 Installation

Follow the steps below to install the CPU.

1. See steps 1 to 6 in *Chapter 2 (1.2 Overview of Installation and Removal)* for preparations.
2. Locate the CPU socket to which you are going to install a CPU.




3. Remove the screws that secure the dummy cover, and remove the cover.

**Note**


Keep the removed dummy cover for future use.

4. Remove the protective cover from the CPU socket.


**Note**

Keep the removed protective cover for future use.


5. Push down the socket lever marked with "⏏ ① →" once to unlatch it from the hook, and then slowly open the lever until it stops.



6. Push down the socket lever marked with "⏏ ① ←" once to unlatch it from the hook, and then slowly open the lever until it stops.




7. Lift the plate.



Important Do not touch the socket contacts.

8. Put the additional CPU on the CPU socket slowly and gently.

For easy installation, hold edges of CPU with your thumb and index fingers so that the notch is aligned with the key on the CPU socket.


**Important**

- Be sure to hold the CPU only at the edges.
- Pay attention not to touch the bottom of the CPU.


Note

- Insert the CPU while aligning the notch on the CPU with the key on the CPU socket.
- Bring down the CPU straight without tilting or sliding it in the socket.


9. Lightly push the CPU to the CPU socket, and close the plate.



10. Close the socket lever marked with "← 🔒 ①" to fix it.




11. Close the socket lever marked with "① →" to fix it.




12. Put the heat sink on the CPU and temporarily tighten the four screws diagonally, and then tighten them securely.

Make sure that the screw aligns with the screw hole. If not, the screw may damage the motherboard.




13. Make sure that the heat sink is installed on a level with the motherboard.




Note

- If the heat sink is not level, remove it, and then install it again.
The following probably causes the heat sink not to be level:
 - The CPU is not positioned correctly.
 - All screws are not completely tightened.
- Do not move the secured heat sink.

14. Remove the fan cover from the slot where you are going to install an additional fan unit.



15. Install three additional fan units that comes with the additional CPU kit.



16. Continue to install or remove internal optional devices, mount and connect the server, and turn on the server.
17. Run BIOS Setup Utility (SETUP) to confirm the following settings. See *Chapter 3 (2 BIOS Setup Utility (SETUP))*.

Advanced → Processor Configuration → Processor Information

[CPU ID]
[L2 Cache RAM]
[L3 Cache RAM]

18. Select **Server → Power Measurement Policy**, set **One Time**, and then select **Save Changes and Exit**.

1.7.3 Replacement / Removal

Important

- Do not remove any CPU unless it is failed.
- To remove the heat sink from the CPU, first turn the heat sink to the left and right lightly to make sure that the heat sink can be apart from the CPU. Removing the heat sink with it adhering to the CPU may cause the CPU and/or CPU socket to be defected.

To remove CPU, reverse the installation procedure.

After replacement or removal, Select **Server** → **Power Measurement Policy**, set **One Time**, and then select **Save Changes and Exit**.

Also follow the steps below if the CPU was removed.

1. Mount the protective cover to CPU socket.
2. Secure the dummy cover to the socket with four screws.
3. Remove the additional fan unit.
4. Mount the fan cover.

1.8 DIMM

Install a Dual Inline Memory Module (DIMM) to a DIMM slot on the motherboard in the server. The motherboard provides 24 slots to install DIMMs.

Important

- To avoid static electricity, see *Chapter 1 (1.8 Anti-static Measures) in Safety Precautions and Regulatory Notices*.
- Use only the specified DIMMs. Installing a DIMM from a third party may damage not only the DIMM but the motherboard. You will be charged to repair failures or damages caused by the use of such products even within the warranty period.

Tips

Up to 1536 GB (64 GB x 24) can be installed in 2-CPU configuration. Up to 768 GB (64 GB x 12) can be installed in 1-CPU configuration. No DIMM is factory installed in standard configuration.

1.8.1 Maximum supported memory size

The maximum available memory size on the server depends on the architecture and OS specs.

Maximum memory sizes

OS	The maximum memory size supported on each OS	The maximum memory size supported on the server
Microsoft Windows Server 2008 R2 Standard *1	32GB	32GB
Microsoft Windows Server 2008 R2 Enterprise *1	2TB	1.5TB
Microsoft Windows Server 2012 Standard *1 Microsoft Windows Server 2012 Datacenter *1 Microsoft Windows Server 2012 R2 Standard *1 Microsoft Windows Server 2012 R2 Datacenter *1	4TB	1.5TB
VMware ESXi 5.5 *2	4TB	1.5TB
VMware ESXi 6.0 *3	6TB	1.5TB

*1: Shown below is the maximum memory size when Hyper-V is used:

- Windows Server 2008 R2 Standard : 32GB
- Windows Server 2008 R2 Enterprise : 1TB
- Windows Server 2012 , Windows Server 2012 R2: 4TB

*2: Up to 1 TB on virtual machine.

*3: Up to 4 TB on virtual machine.

1.8.2 Memory Clock

The actual memory clock speed depends on CPU and memory configuration.

Model number (CPU)	DIMM type	Clock speed
N8101-1029F (E5-2603v4)	N8102-663F 8GB DDR4-2400 REG Memory Kit (2x4GB)	1866 MHz
	N8102-664F 16GB DDR4-2400 REG Memory Kit (2x8GB)	
	N8102-665F 32GB DDR4-2400 REG Memory Kit (2x16GB)	
	N8102-666F 64GB DDR4-2400 REG Memory Kit (2x32GB)	
	N8102-667F 128GB DDR4-2400 TSV REG Memory Kit (2x64GB)	
	N8102-669 16GB DDR4-2400 REG Memory Kit (2x8GB)	
	N8102-670 32GB DDR4-2400 REG Memory Kit (2x16GB)	
	N8102-672 24GB DDR4-2400 REG Memory Kit (3x8GB)	
	N8102-673 48GB DDR4-2400 REG Memory Kit (3x16GB)	
N8101-1030F (E5-2620v4) N8101-1031F (E5-2623v4) N8101-1032F (E5-2630v4) N8101-1034F (E5-2640v4)	N8102-663F 8GB DDR4-2400 REG Memory Kit (2x4GB)	2133 MHz
	N8102-664F 16GB DDR4-2400 REG Memory Kit (2x8GB)	
	N8102-665F 32GB DDR4-2400 REG Memory Kit (2x16GB)	
	N8102-666F 64GB DDR4-2400 REG Memory Kit (2x32GB)	
	N8102-667F 128GB DDR4-2400 TSV REG Memory Kit (2x64GB)	
	N8102-669 16GB DDR4-2400 REG Memory Kit (2x8GB)	
	N8102-670 32GB DDR4-2400 REG Memory Kit (2x16GB)	
	N8102-672 24GB DDR4-2400 REG Memory Kit (3x8GB)	
	N8102-673 48GB DDR4-2400 REG Memory Kit (3x16GB)	

Model number (CPU)	DIMM type	Clock speed
N8101-1033F (E5-2637v4)	N8102-663F 8GB DDR4-2400 REG Memory Kit (2x4GB)	2400 MHz
N8101-1036F (E5-2650v4)	N8102-664F 16GB DDR4-2400 REG Memory Kit (2x8GB)	
N8101-1037F (E5-2650Lv4)	N8102-665F 32GB DDR4-2400 REG Memory Kit (2x16GB)	
N8101-1038F (E5-2667v4)	N8102-666F 64GB DDR4-2400 REG Memory Kit (2x32GB)	
N8101-1039F (E5-2680v4)	N8102-667F 128GB DDR4-2400 TSV REG Memory Kit (2x64GB)	
N8101-1040F (E5-2690v4)	N8102-669 16GB DDR4-2400 REG Memory Kit (2x8GB)	
N8101-1041F (E5-2697v4)	N8102-670 32GB DDR4-2400 REG Memory Kit (2x16GB)	
N8101-1042F (E5-2697Av4)	N8102-672 24GB DDR4-2400 REG Memory Kit (3x8GB)	
N8101-1043F (E5-2698v4)	N8102-673 48GB DDR4-2400 REG Memory Kit (3x16GB)	
N8101-1044F (E5-2699v4)		

1.8.3 Memory RAS Feature

The server supports the following RAS features. See *Chapter 2 (1.8.8 Using Memory RAS Feature)* for conditions of using each feature.

- Standard memory feature (x4 SDDC ECC memory)
- Memory Mirroring feature
- Memory LockStep feature (x8 SDDC ECC memory)
- Memory Sparing feature

Supported RAS features depend on additional memory board.

See the table below for RAS features supported by additional memory board.

Memory RAS features supported by additional memory board

Model number and Product name	Standard feature (x4 SDDC)	Memory Mirroring feature	Memory LockStep feature (x8 SDDC)	Memory Sparing feature
N8102-663F 8GB DDR4-2400 REG Memory Kit (2x4GB)	✓			
N8102-664F 16GB DDR4-2400 REG Memory Kit (2x8GB)	✓			
N8102-665F 32GB DDR4-2400 REG Memory Kit (2x16GB)	✓			
N8102-666F 64GB DDR4-2400 REG Memory Kit (2x32GB)	✓			
N8102-667F 128GB DDR4-2400 TSV REG Memory Kit (2x64GB)	✓			
N8102-669 16GB DDR4-2400 REG Memory Kit (2x8GB)		✓	✓	
N8102-670 32GB DDR4-2400 REG Memory Kit (2x16GB)		✓	✓	
N8102-672 24GB DDR4-2400 REG Memory Kit (3x8GB)				✓
N8102-673 48GB DDR4-2400 REG Memory Kit (3x16GB)				✓

✓: Supported

1.8.4 DIMM installation order

Note

See *Memory RAS features supported by additional memory board* in 1.8.3 *Memory RAS Feature* before using memory RAS feature.


In 1-CPU configuration, install two DIMMs starting from the smallest slot number. If CPU2 is not installed, CPU2_DIMM1 to CPU2_DIMM12 are not available.

In 2-CPU configuration, alternately install two DIMMs starting from the smallest slot number of each CPU.

See the table below to find allowable combination of DIMMs. Any other combination of DIMMs than described in this table is not allowed.

Code Number	N8102-								
	663F	664F	665F	666F	667F	669	670	672	673
N8102-663F	✓	✓	✓	✓					
N8102-664F	✓	✓	✓	✓					
N8102-665F	✓	✓	✓	✓					
N8102-666F	✓	✓	✓	✓					
N8102-667F					✓				
N8102-669						✓	✓		
N8102-670						✓	✓		
N8102-672								✓	
N8102-673									✓


✓: Allowed to be installed together.



1.8.5 Installation

Follow the steps below to install a DIMM.


1. See steps 1 to 6 in *Chapter 2 (1.2 Overview of Installation and Removal)* for preparations.
2. Open levers on left and right sides of DIMM slot, and remove the dummy cover.



Note

Keep the removed dummy cover for future use.

3. Push the DIMM straight into the slot.
When a DIMM is inserted into the slot, the lever automatically closes.



Important

- Make sure the orientation of the DIMM. The DIMM has a notch, preventing being incorrectly inserted.
- Do not apply too much pressure when you push a DIMM into the slot. Doing so can damage the slot or terminal part.

4. Continue to install or remove internal optional devices, mount and connect the server, and turn on the server.
5. Confirm that no error messages are displayed in POST screen.
If any error messages are displayed, see *Chapter 3 (1. POST Error Message)* in "Maintenance Guide".
6. Run BIOS Setup Utility, and select **Advanced** → **Memory Configuration** → **Memory Information**.
Make sure the capacity of added DIMM is displayed properly.
See *Chapter 3 (2. BIOS Setup Utility (SETUP))*.
7. Select **Advanced** → **Memory Configuration** → **Memory Retest**, and set **Yes**.
8. Select **Server** → **Power Measurement Policy**, set **One Time**, and then select **Save Changes and Exit**.
9. Set the size of Paging File to the recommended size (1.5x total memory size) or more.
If using a Windows OS, see *Chapter 1 (6.1 Specifying Memory Dump Settings (Debug Information))* in "Installation Guide (Windows)".
For other OS, follow the manual of the OS.

1.8.6 Removal / Replacement

To remove DIMM, reverse the installation procedure.

Be sure to install dummy cover to the slots from where DIMMs are removed.

Important

Failing to install dummy cover to vacant slot may cause malfunction of the server due to insufficient cooling effect.

Note

When removing a defective DIMM, check error messages displayed at POST or NEC ESMPRO and check the DIMM socket where the defective DIMM is installed.

Follow the steps below after replacing or removing DIMMs.

1. Confirm that no error messages are displayed on POST. If any error message is displayed, see *Chapter 3 (1. Post Error Message)* in "Maintenance Guide".
2. Run BIOS Setup Utility, select **Advanced** → **Memory Configuration** → **Memory Retest**, and set **Yes**.
3. Select **Server** → **Power Measurement Policy**, set **One Time**, and then select **Save Changes and Exit**.
4. Set the size of Paging File to the recommended size (1.5x total memory size) or more.
If using a Windows OS, see *Chapter 1 (6.1 Specifying Memory Dump Settings (Debug Information))* in "Installation Guide (Windows)".
For other OS, follow the manual of the OS.

1.8.7 Cluster On Die and Early Snoop features

Advanced → **Memory Configuration** submenu in BIOS Setup Utility has two options, listed in the following table.

Option	Parameter	Description
Cluster On Die	[Disabled] Enabled	Enables or disables the Cluster On Die feature. This option can be set to Enabled when NUMA is enabled and the processor supports the Cluster On Die feature. - Note: If you use the OS below, this item must be disabled. - VMware ESXi 5
Early Snoop	Disabled [Enabled]	Enables or disables the early snoop mode for processor snoop mode. This option can be set to Enabled when Cluster On Die is disabled.

[] : Factory setting

Read the following when enabling the Cluster On Die feature.

- 1CPU configuration

Memory RAS Mode: Independent / Mirroring / Lockstep

At least, all of CPU1_DIMM1 to DIMM4 must be filled by DIMM.

Memory RAS Mode: Sparing

At least, all of CPU1_DIMM1 to DIMM3, DIMM5 to DIMM7, DIMM9 to DIMM11 must be filled by DIMM.

- 2CPU configuration

Memory RAS Mode: Independent / Mirroring / Lockstep

At least, all of CPU1_DIMM1 to DIMM4 and CPU2_DIMM1 to DIMM4 must be filled by DIMM.

Memory RAS Mode: Sparing

At least, all of CPU1_DIMM1 to DIMM3, DIMM5 to DIMM7, DIMM9 to DIMM11 and CPU2_DIMM1 to DIMM3, DIMM5 to DIMM7, DIMM9 to DIMM11 must be filled by DIMM.

In order to effectively utilize the Cluster On Die feature, the following DIMM installed number is recommended.

- 1CPU configuration

Memory RAS Mode: Independent / Mirroring / Lockstep

Mount DIMMs to CPU1_DIMM1 to DIMM8 slot, or mount DIMMs to CPU1_DIMM1 to DIMM12 slot.

Memory RAS Mode: Sparing

Mount DIMMs to CPU1_DIMM1 to DIMM12 slot.

- 2CPU configuration

Memory RAS Mode: Independent / Mirroring / Lockstep

Mount DIMMs to CPU1_DIMM1 to DIMM8 and CPU2_DIMM1 to DIMM8 slot, or mount DIMMs to CPU1_DIMM1 to DIMM12 and CPU2_DIMM1 to DIMM12 slot.

Memory RAS Mode: Sparing

Mount DIMMs to CPU1_DIMM1 to DIMM12 and CPU2_DIMM1 to DIMM12 slot.

See 1.8.4 DIMM installation order .

In 1-CPU configuration (Memory RAS Mode: Independent / Mirroring / Lockstep)

DIMMs count	Cluster On Die feature	DIMM slot number to be installed
1 set	Not available	N/A
2 set	Available	CPU1_DIMM1 to DIMM4
3 set	Available	CPU1_DIMM1 to DIMM6
4 set	Available (recommended)	CPU1_DIMM1 to DIMM8
5 set	Available	CPU1_DIMM1 to DIMM10
6 set	Available (recommended)	CPU1_DIMM1 to DIMM12

In 1-CPU configuration (Memory RAS Mode: Sparing)

DIMMs count	Cluster On Die feature	DIMM Slot number to be installed
1 set	Not available	N/A
2 set	Not available	N/A
3 set	Available	CPU1_DIMM1 to DIMM3, CPU1_DIMM5 to DIMM7, CPU1_DIMM9 to DIMM11
4 set	Available (recommended)	CPU1_DIMM1 to DIMM12

In 2-CPU configuration (Memory RAS Mode : Independent / Mirroring / Lockstep)

DIMMs count	Cluster On Die feature	DIMM slot number to be installed
2 set	Not available	N/A
3 set	Not available	N/A
4 set	Available	CPU1_DIMM1 to DIMM4, CPU2_DIMM1 to DIMM4
5 set	Available	CPU1_DIMM1 to DIMM6, CPU2_DIMM1 to DIMM4
6 set	Available	CPU1_DIMM1 to DIMM6, CPU2_DIMM1 to DIMM6
7 set	Available	CPU1_DIMM1 to DIMM8, CPU2_DIMM1 to DIMM6
8 set	Available (recommended)	CPU1_DIMM1 to DIMM8, CPU2_DIMM1 to DIMM8
9 set	Available	CPU1_DIMM1 to DIMM10, CPU2_DIMM1 to DIMM8
10 set	Available	CPU1_DIMM1 to DIMM10, CPU2_DIMM1 to DIMM10
11 set	Available	CPU1_DIMM1 to DIMM12, CPU2_DIMM1 to DIMM10
12 set	Available (recommended)	CPU1_DIMM1 to DIMM12, CPU2_DIMM1 to DIMM12

In 2-CPU configuration (Memory RAS Mode: Sparing):

DIMMs count	Cluster On Die feature	DIMM Slot number to be installed
2 set	Not available	N/A
3 set	Not available	N/A
4 set	Not available	N/A
5 set	Not available	N/A
6 set	Available	CPU1_DIMM1 to DIMM3, CPU1_DIMM5 to DIMM7, CPU1_DIMM9 to DIMM11 CPU2_DIMM1 to DIMM3, CPU2_DIMM5 to DIMM7, CPU2_DIMM9 to DIMM11
7 set	Available	CPU1_DIMM1 to DIMM12, CPU2_DIMM1 to DIMM3, CPU2_DIMM5 to DIMM7, CPU2_DIMM9 to DIMM11
8 set	Available (recommended)	CPU1_DIMM1 to DIMM12, CPU2_DIMM1 to DIMM12


1.8.8 Using Memory RAS Feature

This server has RAS feature including Standard Memory feature (x4 SDDC ECC memory), Memory Mirroring feature, Memory Sparing feature, and Memory Lock Step (x8 SDDC ECC memory) feature. SDDC (Single Device Correction) allows automatic correction of memory error (multi-bit error).

Note

- See *Memory RAS features supported by additional memory board in 1.8.3 Memory RAS Feature* before using memory RAS feature.
- Only the features that additional memory board support can be used.

The memory area on the motherboard of the server is divided into four memory channels.



Memory Mirroring, Memory Lock Step, and Memory Sparing features keep memory redundancy between memory channels by monitoring or altering memory active/inactive status, respectively.


(1) Memory Mirroring Feature

Memory Mirroring feature writes the same data into two groups of DIMMs (mirror set) corresponding with each other between memory channels (channels 0 and 1 or channel 2 and 3) to provide data redundancy.

Note

- Memory Mirroring feature uses channels 0 and 1 or channels 2 and 3.
- To use Memory Mirroring feature, install N8102-669/670 additional memory board (two DIMMs of same model).
- DIMMs used in mirror set must be of the same model number.

Example: 2-CPU configuration




Tips

The operating system only recognizes a half of the total physical capacity.

Memory Mirroring feature can be used under the following conditions:

- Install DIMMs in DIMM slots to configure a mirror set.
- All the installed DIMMs should have the same capacity.
- Run BIOS Setup Utility (SETUP), change parameters as shown below, save the settings, and exit.
Advanced → Memory Configuration → Memory RAS Mode → Mirroring
Server → Power Measurement Policy → One Time
- After restart, run SETUP again, and check if "**Mirrored**" is displayed for the following parameter.
Advanced → Memory Configuration → Memory Information → CPUx_DIMMx Status
- Installation order depends on CPU configuration. See the figure below.



Memory Mirroring cannot be configured in the following case:

- Memory Mirroring within the same memory channel

Notes on Configuring Memory Mirroring

In Memory Mirroring configuration, **Memory RAS Mode** menu is changed from "**Mirroring**" to "**Independent**" in the following cases:


- When you additionally install DIMMs that unable to configure Memory Mirroring
- When you remove DIMMs that takes down Memory Mirroring

(2) Memory Lock Step Feature (x8 SDDC)

In Memory Lock Step feature, the DIMMs in two groups corresponding to two memory channels (channels 0 and 1, or channels 2 and 3) is multiplexed and operated in parallel to enable x8 SDDC (x8 Single Device Data Correction). With this feature, one DIMM can detect and correct one to eight-bit error.


Note

- Memory LockStep feature uses channels 0 and 1 or channels 2 and 3.
- To use Memory LockStep feature, install N8102-669/670 additional memory board (two DIMMs of same model).
- DIMMs used in LockStep set must be of the same model number.



Memory Lock Step feature can be used under the following conditions:

- Install DIMMs in DIMM slots to configure a Lock Step set.
- All the installed DIMMs should have the same capacity.
- Run BIOS Setup Utility (SETUP), change parameters as shown below, save the settings, and exit.
**Advanced → Memory Configuration → Memory RAS Mode → LockStep
Server → Power Measurement Policy → One Time**
- After restart, run SETUP again, and check if "Lock Step" is displayed for the following parameter.
Advanced → Memory Configuration → Memory Information → CPUx_DIMMx Status
- Installation order depends on CPU configuration. See the figure below.



Memory Lock Step cannot be configured in the following cases:

- Memory Lock Step between memory channels of different memory controllers (CPU)
- Memory Lock Step within the same memory channel

Notes on Configuring Lock Step

In Memory Lock Step configuration, **Memory RAS Mode** menu is changed from "Lock Step" to "Independent" in the following cases:

- When you additionally install DIMMs that unable to configure Memory Lock Step
- When you remove DIMMs that takes down Memory Lock Step

(3) Memory Sparing Feature

Memory Sparing feature puts a memory channel 2 of a memory controller in each CPU into standby status as spare devices. If a correctable error occurs in a DIMM in the running memory controller, the feature automatically changes the running DIMM from the failed one to a DIMM in the standby state to continue the processing.


Note

To use Memory Sparing feature, install N8102-672/673 additional memory board (three DIMMs of same model).

DIMMs installed in the system must be of the same model number.

The following table shows configuration allowable for memory sparing and system logical memory capacity.


Number of CPUs	Number of DIMMs	Memory capacity	
		8GB DIMM	16GB DIMM
1	3	20GB	40GB
	6	40GB	80GB
	9	60GB	120GB
	12	80GB	160GB
2	6	40GB	80GB
	12	80GB	160GB
	18	120GB	240GB
	24	160GB	320GB



Memory Sparing feature can be used under the following conditions:

- Install DIMMs in DIMM slots to configure a spare set.
- DIMMs to be installed should have the same capacity.
- Run BIOS Setup Utility (SETUP), change parameters as shown below, save settings, and exit.
Advanced → Memory Configuration → Memory RAS Mode → Sparing
Server → Power Measurement Policy → One Time
- After restart, run SETUP again, and check if "Spared" is displayed for the following parameter.
Advanced → Memory Configuration → Memory Information → CPUx_DIMMx Status

- Installation order depends on CPU configuration. See the figure below.



The following Memory Sparing cannot be configured.

- A DIMM of different capacity is installed.
- Sparing with DIMMs in different memory channel

Notes on Configuring Memory Sparing

In Memory Sparing configuration, **Memory RAS Mode** menu is changed to "Independent" in the following cases:

- When you additionally install DIMMs that unable to configure Memory Sparing
- When you remove DIMMs that takes down Memory Sparing

1.9 Flash Backup Unit for RAID Controller

If a RAID controller (N8103-176/177/178/179) is installed, use the flash backup unit (FBU) to avoid data loss caused by accidents including temporary blackout during a Write Back operation. The model of the flash backup unit to be used depends on RAID controller.

- For N8103-176/177/178, use N8103-181 Flash Backup Unit
- For N8103-179, use FBU provided with N8103-179.

1.9.1 Handling precautions


Observe the following when using FBU. Ignoring these precautions may cause damage to your data or other devices.

- Use the FBU appropriate to the RAID controller to be used.
- The FBU is an electronic device sensitive to static electricity. Before installation, touch the metal frame part of the server to discharge the static electricity from your body.
- Do not drop or bump the FBU.
- For recycling and disposing of the FBU, refer to the User's Guide that comes with the RAID controller or Flash Backup Unit.




1.9.2 Installing N8103-181 Flash Backup Unit

This section describes the procedure of installing an FBU for RAID controller.


1. See steps 1 to 6 in *Chapter 2 (1.2 Overview of Installation and Removal)* for preparations.
2. Remove the two screws, and then remove the support bar and PCI riser card unit.




3. Put the FBU on battery tray for RAID Controller. Secure the FBU bracket that comes with FBU with the screw.




4. Connect the FBU control cable (650 mm) that comes with FBU.




5. Remove the two screws from RAID Controller, and remove PCI bracket.




6. Mount the adapter to RAID Controller.




7. Connect the control cable of FBU to RAID Controller.




8. Remove the two screws from server chassis, and remove the RAID Controller bracket.




9. Install the RAID Controller bracket to RAID Controller using two screws you have removed in Step 6.




10. Install RAID Controller to the RAID Controller connector on motherboard, using two screws you have removed in Step 9.




11. Connect Mini SAS HD cable to RAID Controller.




12. Disconnect USB cable (for front) from motherboard.




13. Connect Mini SAS HD cable to RAID Controller.



14. Connect USB cable (for front) to motherboard.



15. Install support bar and PCI riser card unit you have removed in Step 2.




1.9.3 Removal

For removing the FBU for RAID Controller, reverse the installation procedure.


1.9.4 Installing FBU for N8103-179

Take the steps below to install FBU.


1. See steps 1 to 6 in *Chapter 2 (1.2 Overview of Installation and Removal)* for preparations.
2. Remove the two screws, and then remove the support bar and the PCI riser card unit.




3. Remove the battery tray for RAID Controller.




4. Turn the battery tray for RAID Controller inside out, and fix the FBU.




5. Install the battery tray for RAID Controller.




6. Connect the FBU control cable (750 mm), provided as the standard accessory of RAID Controller, to FBU.




7. Connect the FBU control cable (750 mm in length) and Mini SAS cable to RAID Controller.




8. Remove one screw from the blank cover on the PCI riser card unit (removed in Step 2) on which you are going to mount the RAID Controller, then remove the blank cover.



9. Mount the RAID Controller to PCI riser card unit, and secure it with one screw you have removed in Step 6.



10. Mount the support bar and the riser card unit you have removed in Step 2.

**Note**

Keep the removed blank cover for future use.

***1.9.5* Removing FBU**

Remove the FBU in reverse order of installation procedure.

1.10 LOM Card

The server supports LOM Card which is the replaceable onboard network adapter.

Install LOM card to the LOM Card slot on motherboard. The motherboard has one slot to install LOM Card.


Important

You must avoid static electricity to work with the procedure below. For details, see *Chapter 1 (1.8 Anti-static Measures) in Safety Precautions and Regulatory Notices*.


1.10.1 Installation

Follow steps below to install LOM Card.


1. See steps 1 to 6 in Chapter 2 (1.2 Overview of Installation and Removal) for preparations.
2. Remove the screw that secures the PCI riser card unit, and remove the PCI riser card unit.




3. Remove the screw from the bracket.




4. Undo two screws and then remove the bracket.




5. Align the pin terminals of LOM Card with the LOM Card slot, insert the card, and secure the card with three screws.



6. Secure the bracket of LOM Card with two screws you have removed in step 4.



7. Secure the bracket of LOM Card with two screws you have removed in step 3.



***1.10.2* Removal**

Remove LOM Card in reverse order of installation steps.

Important

To maintain the cooling effect in the server, install the blank cover in the vacant LOM Card slot.

1.1.1 PCI Riser Card

The PCI slot performance can be updated from x8 lane to x16 lane by exchanging the PCI riser card to which a PCI board is attached

Important You must avoid static electricity to work with the procedure below. For details, see *Chapter 1 (1.8 Anti-static Measures) in Safety Precautions and Regulatory Notices*.

1.1.1.1 Notes


Read the following notes when installing or removing a PCI riser card.

- Do not touch the terminals of the riser cards and the leads of electronic components with your bare hand. Fingerprints and dust left on them cause the server to malfunction due to a connection failure or damage to the leads.
- Available type of PCI card depends on the type of a PCI riser card. Make sure the card type before connecting it to riser card.

1.1.1.2 Installation

Follow steps below to install a PCI riser card.

1. See steps 1 to 6 in Chapter 2 (1.2 Overview of Installation and Removal) for preparations.
2. Remove the screw that secures the PCI riser card unit, and remove the PCI riser card unit.
3. Remove the two screws securing the PCI riser card. Slide the PCI riser card to the direction and lift it off.
4. Remove the two screws securing the PCI riser card. Slide the PCI riser card to the direction of the arrow and remove it.
5. Reverse the procedure in step 4 to install the PCI riser card to the PCI riser card unit.



1.1.1.3 Removal

To remove a PCI riser card, reverse the installation procedure.

1.12 PCI Card

This server provides PCI slots for two types of PCI riser cards (one Full Height PCI card and one Low Profile PCI card), a slot dedicated for a LOM card, and a slot dedicated for a RAID controller (total four PCI cards can be mounted).

Important You must avoid static electricity to work with the procedure below. For details, see *Chapter 1 (1.8 Anti-static Measures) in Safety Precautions and Regulatory Notices*.

1.12.1 Notes

Read the following notes when installing or removing a PCI card.

- Do not touch the terminals of the PCI riser cards and the leads of electronic components with your bare hand. Fingerprints and dust left on them cause the server to malfunction due to a connection failure or damage to the leads.
- Available type of PCI card depends on the type of a PCI riser card. Make sure the card type before connecting it to the PCI riser card.
- The server provides no connector to connect an LED connector which is supplied in RAID Controller used to indicate disk access.
- PCI slot number "1A" is assigned to the RAID controller slot, "1B" is assigned to LOM card slot, "1C" is assigned to the PCI riser card for Full Height PCI card, and "1D" is assigned to the PCI riser card for Low Profile PCI card.
- The search order for PCI bus slot on boot is as follows.
Slot 1A (dedicated to RAID Controller) → Slot 1B (LOM card slot) → Slot 1C (Full height card slot) → Slot 1D (Low profile card slot)
- The PCI devices of the same type (including onboard PCI device) may be recognized in different order from those described above, depending on OS or RAID Configuration Utility. Check the slot location of PCI device by PCI bus number, device number and function number shown in the table below.

PCI device	Bus number	Device number	Function number
LOM card LAN1 (when N8104-154F/155F/156F is installed)	05h	0	0
LOM card LAN2 (when N8104-154F/155F/156F is installed)	05h	0	1
LOM card LAN3 (when N8104-154F/156F is installed)	05h	0	2
LOM card LAN4 (when N8104-154F/156F is installed)	05h	0	3
Slot 1A dedicated for RAID Controller	01h	0	0
PCIe slot 1C (Full height)	0Ch	0	X
PCIe slot 1C (N8116-33)	83h	0	X
PCIe slot 1D (Low profile)	40h	0	X
PCIe slot 1D (N8116-33)	C0h	0	X

- If an additional LAN card is installed, it is hard to push the catch of the connector with your finger that is connected to the LAN card. Disconnect the connector pushing the catch with a standard screwdriver. At this time, be very careful for the screwdriver not to damage the LAN card.

- If a bootable device such as a PCI card or USB device is added, or boot mode is changed the boot order may change. Check priority for the boot device in BIOS Setup Utility.

[Boot] - [CD/DVD Priorities] → Check the display
 [Boot] - [Removable Priorities] → Check the display
 [Boot] - [HDD Priorities] → Check the display
 [Boot] - [Network Priorities] → Check the display

If the boot device is an HDD and located under an optional RAID Controller, the display is (Bus xx Dev 00) PCI RAID Adapter. Note that the value for xx changes depending on the PCI slot where a RAID Controller is installed.

- For a RAID Controller, LAN card (network boot), or Fibre Channel controller, if a hard disk drive on which an OS is installed is connected, set the option ROM for that slot to **Enabled**. See *Chapter 2 (1. System BIOS)* in "Maintenance Guide" for how to specify it.

1.12.2 Supported PCI cards and available slots

The following tables list supported cards and slots available for them. For details of the features of each card, see the manual supplied with the card.

Tips

If the operation performance of PCI card differs from that of PCI Slot, the PCI card operates at lower frequency.

(1) Standard PCI riser card

			Standard PCI riser card				Remarks
Model	Product name	Slot number	#1A	#1B	#1C	#1D	
		PCI standard	PCIe 3.0				
		PCI slot performance *1	x8 lane				
		PCI card type *2	x8 socket				
		Transfer bandwidth (per lane) *1	8Gb/s				
		Slot size	Dedicated to RAID Controller	Dedicated to LOM card	Full height	Low profile	
		Available card size			220 mm max.		
N8103-176	RAID Controller (1GB, RAID 0/1) [PCI Express 3.0(x8)]	○	—	—	—	Dedicated to connect with internal hard disk drive. Flash Backup Unit [N8103-181] can be mounted.	
N8103-177	RAID Controller (1GB, RAID 0/1/5/6) [PCI Express 3.0(x8)]	○	—	—	—		
N8103-178	RAID Controller (2GB, RAID 0/1/5/6) [PCI Express 3.0(x8)]	○	—	—	—		
N8103-179	RAID Controller (2GB, RAID 0/1/5/6) [PCI EXPRESS 3.0(x8)]	—	—	○	○	Dedicated to connect with external devices. Flash Backup Unit is factory installed. Up to 2 cards can be mounted including extra battery and FBU.	
N8103-142	SAS Controller [PCI Express 2.0(x8)]	—	—	○	○	Dedicated to connect with external devices.	
N8103-184	SAS Controller [PCI Express 3.0(x8)]	—	—	○	○		
N8118-300	2.5" PCIe SSD Installation Kit	—	—	○	○	For connecting PCIe SSD; Up to 1 card can be mounted.	

		Standard PCI riser card					Remarks
Model	Product name	Slot number	#1A	#1B	#1C	#1D	
		PCI standard	PCIe 3.0				
		PCI slot performance *1	x8 lane				
		PCI card type *2	x8 socket				
		Transfer bandwidth (per lane) *1	8Gb/s				
		Slot size	Dedicated to RAID Controller	Dedicated to LOM card	Full height	Low profile	
		Available card size			220 mm max.		
N8190-159	Fibre Channel Controller (8Gbps/Optical) [PCI Express 2.0(x8)]	—	—	○	○		
N8190-160	Fibre Channel Controller (2ch) (8Gbps/Optical) [PCI Express 2.0(x8)]	—	—	○	○		
N8190-157A	Fibre Channel Controller (16Gbps/Optical) [PCI Express 3.0(x8)]	—	—	○	○		
N8190-158A	Fibre Channel Controller (2ch) (16Gbps/Optical) [PCI Express 3.0(x8)]	—	—	○	○		
N8104-150	1000BASE-T Adapter (1ch) [PCI Express 2.0(x1)]	—	—	○	○	For additional LAN port. Card type: PCI Express 2.0 (x8)	
N8104-151	1000BASE-T Adapter (2ch) [PCI Express 2.0(x1)]	—	—	○	○	For additional LAN port. Card type: PCI Express 2.0 (x4)	
N8104-152	1000BASE-T Adapter (4ch) [PCI Express 2.0(x4)]	—	—	○	○	For additional LAN port.	
N8104-145	1000BASE-T Adapter (2ch) [PCI Express 2.0(x4)]	—	—	○	○	For additional LAN port (Intel NIC).	
N8104-149	10GBASE Adapter (SFP+/2ch) [PCI Express 2.0(x8)]	—	—	○	○	For additional LAN port. Prepare SFP+ module N8104-129 if needed.	
N8104-148	10GBASE Adapter (SFP+/2ch) [PCI Express 2.0(x8)]	—	—	○	○	For additional LAN port (Intel NIC). Prepare SFP+ module N8104-129 if needed.	
N8104-153	10GBASE-T Adapter (2ch) [PCI Express 2.0(x8)]	—	—	○	○	For additional LAN port	
N8104-157	10GBASE-T Adapter(2ch)	—	—	○	○	For additional LAN port (Intel NIC) Supports teaming (AFT/SFT/ALB) and bonding with additional 10GBASE-T adapter.	
N8104-158	10GBASE Adapter (SFP+/2ch)	—	—	○	○	For additional LAN port (Intel NIC). Prepare SFP+ module N8104-129 if needed. Supports teaming (AFT/SFT/ALB) and bonding with additional 10GBASE-SFP+ adapter.	
N8104-159	10GBASE Adapter (SFP+/4ch)	—	—	○	○	For additional LAN port (Intel NIC) Prepare QSFP+ module 8104-161 if needed. Supports teaming (AFT/SFT/ALB) and bonding with additional 10GBASE-SFP+ adapter.	
N8104-154F	1000BASE-T LOM Card (4ch) [PCI Express 2.0(x4)]	—	○	—	—	For additional LAN port Card type: PCI Express 2.0 (x8)	

			Standard PCI riser card				Remarks
Model	Product name	Slot number	#1A	#1B	#1C	#1D	
		PCI standard	PCIe 3.0				
		PCI slot performance *1	x8 lane				
		PCI card type *2	x8 socket				
		Transfer bandwidth (per lane) *1	8Gb/s				
		Slot size	Dedicated to RAID Controller	Dedicated to LOM card	Full height	Low profile	
		Available card size			220 mm max.		
N8104-155F	10GBASE-T LOM Card (2ch) [PCI Express 2.0(x8)]	—	○	—	—	For additional LAN port	
N8104-160F	10GBASE-T LOM Card (2ch) [PCI Express 2.0(x8)]	—	○	—	—	For additional LAN port	
N8104-156F	10GBASE-SFP+(2ch)+ 1000BASE-T(2ch) LOM Card [PCI Express 2.0(x8)]	—	○	—	—	For additional LAN port. Prepare SFP+ module N8104-129 if needed.	
N8104-146	InfiniBand Adapter (1ch) (FDR/Optical) [PCI Express 3.0(x8)]	—	—	○	○	For Infiniband connection. Cannot be used together with each other.	
N8104-147	InfiniBand Adapter (2ch) (FDR/Optical) [PCI Express 3.0(x8)]	—	—	○	○		
N8117-01A	Additional RS-232C connector *3	—	—	—	○	For additional serial port B (RS-232C)	

(2) N8116-33 PCI riser card (PClex16) (option)

		PCI Riser card (PCIex16)					Remarks
Model	Product name	Slot number	#1A	#1B	#1C	#1D	
		PCI standard	PCIe 3.0				
		PCI slot performance *1	x8 lane		X16 lane		
		PCI card type *2	x8 socket		X16 socket		
		Transfer bandwidth (per lane) *1	8Gb/s				
		Slot size	Dedicated to RAID Controller	Dedicated to LOM card	Full height	Low profile	
		Available card size			220 mm max.		
N8103-176	RAID Controller (1GB, RAID 0/1) [PCI Express 3.0(x8)]	○	—	—	—	Dedicated to connect with internal hard disk drive. Flash Backup Unit [N8103-181] can be mounted.	
N8103-177	RAID Controller (1GB, RAID 0/1/5/6) [PCI Express 3.0(x8)]	○	—	—	—		
N8103-178	RAID Controller (2GB, RAID 0/1/5/6) [PCI Express 3.0(x8)]	○	—	—	—		
N8103-179	RAID Controller (2GB, RAID 0/1/5/6) [PCI EXPRESS 3.0(x8)]	—	—	○	○	Dedicated to connect with external devices. Flash Backup Unit is factory installed Up to 2 cards can be mounted including extra battery and FBU.	
N8103-142	SAS Controller [PCI Express 2.0(x8)]	—	—	○	○	Dedicated to connect with external devices.	
N8103-184	SAS Controller [PCI Express 3.0(x8)]	—	—	○	○		
N8118-300	2.5" PCIe SSD Installation Kit	—	—	○	○	For connecting PCIe SSD; Up to 1 card can be mounted.	
N8190-159	Fibre Channel Controller (8Gbps/Optical) [PCI Express 2.0(x8)]	—	—	○	○		
N8190-160	Fibre Channel Controller (2ch) (8Gbps/Optical) [PCI Express 2.0(x8)]	—	—	○	○		
N8190-157A	Fibre Channel Controller (16Gbps/Optical) [PCI Express 3.0(x8)]	—	—	○	○		
N8190-158A	Fibre Channel Controller (2ch) (16Gbps/Optical) [PCI Express 3.0(x8)]	—	—	○	○		
N8104-150	1000BASE-T Adapter (1ch) [PCI Express 2.0(x1)]	—	—	○	○	For additional LAN port. Card type: PCI Express 2.0 (x8)	
N8104-151	1000BASE-T Adapter (2ch) [PCI Express 2.0(x1)]	—	—	○	○	For additional LAN port. Card type: PCI Express 2.0 (x4)	
N8104-152	1000BASE-T Adapter (4ch) [PCI Express 2.0(x4)]	—	—	○	○	For additional LAN port.	
N8104-145	1000BASE-T Adapter (2ch) [PCI Express 2.0(x4)]	—	—	○	○	For additional LAN port (Intel NIC).	
N8104-149	10GBASE Adapter (SFP+/2ch) [PCI Express 2.0(x8)]	—	—	○	○	For additional LAN port. Prepare SFP+ module N8104-129 if needed.	
N8104-148	10GBASE Adapter (SFP+/2ch) [PCI Express 2.0(x8)]	—	—	○	○	For additional LAN port (Intel NIC). Prepare SFP+ module N8104-129 if needed.	
N8104-153	10GBASE-T Adapter (2ch) [PCI Express 2.0(x8)]	—	—	○	○	For additional LAN port	

			PCI Riser card (PCIex16)				Remarks
Model	Product name	Slot number	#1A	#1B	#1C	#1D	
		PCI standard	PCIe 3.0				
		PCI slot performance *1	x8 lane		X16 lane		
		PCI card type *2	x8 socket		X16 socket		
		Transfer bandwidth (per lane) *1	8Gb/s				
		Slot size	Dedicated to RAID Controller	Dedicated to LOM card	Full height	Low profile	
		Available card size			220 mm max.		
N8104-154F	1000BASE-T LOM Card (4ch) [PCI Express 2.0(x4)]	—	○	—	—	For additional LAN port Card type: PCI Express 2.0 (x8)	
N8104-155F	10GBASE-T LOM Card (2ch) [PCI Express 2.0(x8)]	—	○	—	—	For additional LAN port	
N8104-160F	10GBASE-T LOM Card (2ch) [PCI Express 2.0(x8)]	—	○	—	—	For additional LAN port	
N8104-156F	10GBASE-SFP+(2ch)+ 1000BASE-T(2ch) LOM Card [PCI Express 2.0(x8)]	—	○	—	—	For additional LAN port. Prepare SFP+ module N8104-129 if needed.	
N8104-157	10GBASE-T Adapter (2ch)	—	—	○	○	For additional LAN port (Intel NIC) Supports teaming (AFT/SFT/ALB) and bonding with additional 10GBASE-T adapter.	
N8104-146	InfiniBand Adapter (1ch) (FDR/Optical) [PCI Express 3.0(x8)]	—	—	○	○	For Infiniband connection Up to two cards can be mounted.	
N8104-147	InfiniBand Adapter (2ch) (FDR/Optical) [PCI Express 3.0(x8)]	—	—	○	○	Cannot be used together with each other.	
N8104-158	10GBASE Adapter (SFP+/2ch)	—	—	○	○	For additional LAN port (Intel NIC). Prepare SFP+ module N8104-129 if needed. Supports teaming (AFT/SFT/ALB) and bonding with additional 10GBASE-SFP+ adapter.	
N8117-01A	Additional RS-232C connector *3	—	—	○	—	For additional serial port B (RS-232C)	

√: Can be mounted, —: Cannot be mounted

*1 Data transfer rate of PCI slot = Transfer bandwidth × Number of lanes

<Example> x8 lane = 64 Gbps (one-way)

*2 Connector size. Cards exceeding the number of sockets cannot be connected.

<Example> x4 socket can connect with x1 and x4 cards, but not x8 card.

*3 Use RS-232C cable (B).

- See Technical Guide for details of each card.
- Description within square brackets([]) indicates the highest standard that is available with each card.
- If the specification of a PCI slot and a PCI card differs, they work according to the lower standard.

1.12.3 Installation


Install a PCI card to the PCI riser card in the following procedure.

Important When installing a PCI card, make sure the connector of the card fits the connector of the riser card.


Note

- Check the card type (Low Profile or Full Height) which respective riser card supports and the type of PCI card to be installed.
- When installing an FBU, see *Chapter 2 (1.11 Flash Backup Unit for RAID Controller)*.

1. See steps 1 to 6 in Chapter 2 (1.2 Overview of Installation and Removal) for preparations.
2. Remove the two screws securing the PCI riser card unit. Hold the both ends of the PCI riser card unit and lift it off.




3. Confirm the installation position with the reference to the table on 1.12.2 *Supported PCI cards and available slots*.
4. Remove one screw from the PCI riser card unit and remove the blank cover.



Note Keep the removed blank cover for future use.

5. Install a PCI card to the PCI riser card unit. Position the terminal part of the PCI card to the PCI riser card slot and insert it.




Important Do not touch the terminal part of PCI riser card or PCI card and the signal pins of electric parts installed on the board. Installing boards with dirt or oil can cause malfunction.

Note

- Make sure that the edge of a PCI card bracket is seated into the fixed slot.
- Depending on type of PCI cards, the terminal part of the PCI card may be too large to fit in the connector.
- If you have trouble installing the card, remove the card once and try again. If you apply excessive pressure on the card, a PCI card or PCI riser card might break.


6. Secure the PCI card with the screw you removed in step 4.



Tips

To connect a PCI card to the connector on motherboard with cable, connect a cable to PCI card before installing PCI riser card.

7. Connect the PCI riser card unit to the slot on motherboard and secure the PCI riser card unit with two screws you removed in step 2.
Position the terminal part of the PCI riser card to the slot on the motherboard and insert it.



8. Continue to install or remove internal optional devices, mount and connect the server, and turn it on.
9. Make sure that no error messages are displayed on POST screen.
For details on POST error messages, see *Chapter 3 (1. POST Error Message)* in "Maintenance Guide".
10. Run the configuration utility of the card to set up the board as needed.
Availability or startup and operation procedure of the utility depends on card. For details, see the manual that comes with the card. **If a PCI card including RAID Controller and LAN adapter which connects to any bootable device is added, the boot priority might be changed to the default setting.** In that case, configure the boot priority in **Boot** menu of BIOS Setup Utility. For details, see *Chapter 2 (1. System BIOS)* in "Maintenance Guide".

1.12.4 Removal

To remove a PCI card, reverse the installation procedure.

Run SETUP and change boot order in **Boot** menu as needed. See *Chapter 2 (1. System BIOS)* in "Maintenance Guide" for how to specify it.

If using the server with the PCI card removed, attach the blank cover that comes with the PCI riser card.

1.12.5 Installing RAID Controller

This section describes how to install an optional RAID Controller to the slot dedicated to RAID Controller.

(1) When using the optional RAID controller (N8103-176/177/178)

For details, see the manual that comes with optional RAID Controller (N8103-176/177/178).

Important


- You must avoid static electricity to work with the procedure below. For details, see *Chapter 1 (1.8 Anti-static Measures) in Safety Precautions and Regulatory Notices*.
- Up to 31 logical drives can be created. Do not create 32 or more logical drives.

Note


- When installing an optional RAID Controller, run the BIOS Setup utility, select **PCI Configuration** from the **Advanced** menu, and then make sure that the parameter of **PCI Slot xx ROM** (xx is PCI slot number) is set to **Enabled**.
- When connecting a RAID Controller, set the boot priority to 8th or higher in the Boot menu of the BIOS Setup utility. If the setting is 9th or lower, the configuration menu for RAID Controllers cannot be launched.

Take the following procedure to install RAID Controller (N8103-176/177/178).


1. See steps 1 to 6 in Chapter 2 (1.2 Overview of Installation and Removal) for preparations.
2. Remove the two screws and remove PCI riser card unit.




3. Remove the support bar.
4. Remove the two screws from RAID Controller, and remove PCI bracket.




5. Remove the two screws from server chassis, and remove RAID Controller bracket.




6. Attach the RAID Controller bracket to RAID Controller with two screws you have removed in Step 4.




7. Insert the RAID Controller slightly into the dedicated slot while tilting the card.



8. Gently place the RAID Controller on bottom plate of chassis so that it become horizontal to the motherboard.



9. Insert the RAID Controller into the slot while keeping horizontal state.



10. Secure the RAID Controller bracket with two screws you have removed in Step 5.
11. Disconnect SAS/SATA cable from SATA connector on motherboard.

12. Perform the following according to the number of hard disk drive connected.

- When four or less hard disk drives are installed:
Connect SAS/SATA cable removed in Step 9 to connector (Ports 0-3) on RAID Controller.
- When five or more hard disk drives are installed:
Connect SAS/SATA cable removed in Step 9 to connector (Ports 0-3) on RAID Controller.
Connect SAS/SATA cable provided with the server to connector (Ports 4-7) on RAID Controller.
Remove a single screw from server chassis, and remove battery tray for RAID Controller.
Connect another end of SAS/SATA cable that has been connected to connector (Ports 4-7) on RAID Controller, to the connector on backplane.
Secure the battery tray for RAID Controller with a single screw.

13. Continue to install or remove internal optional devices, mount and connect the server, and turn it on.


(2) When using optional RAID Controller (N8103-179)

See *Chapter 2 (1.9.4 Installing FBU for N8103-179)*.

1.13 Optical Disk Drive

This section describes the procedure for installing the optional optical disk drive.


Important Do not install any unsupported optical disk drive.




1.13.1 Installation

Install an optical disk drive in the following procedure.

1. See steps 1 to 6 in Chapter 2 (1.2 Overview of Installation and Removal) for preparations.
2. Remove a screw from the bracket, and remove the bracket.




3. Remove the dummy cover.




Note Keep the removed dummy cover for future use.


4. Insert the optical disk drive.




5. Install the optical disk drive to the tray.



6. Align the hole in the bracket with the screw hole of the optical disk drive and secure the bracket to the optical disk drive with a screw removed in step 2.



7. Connect a cable to the optical disk drive.



1.13.2 Removal

To remove an optical disk drive, reverse the installation procedure above.

1.14 Use of Internal Hard Disk Drives in the RAID System

This section describes how to use the internal hard disk drives in the RAID System.

Important

If you use hard disk drives in the RAID System or change the RAID level, hard disk drives are initialized. If the hard disk drive contains valuable data, be sure to backup the hard disk drive before installing the RAID Controller and configuring the RAID System.


Tips

- Logical Drives can be created even with only one Physical Device.
- When using SAS hard disk drive, SAS SSD, or SATA SSD, it must be connected to RAID Controller.

1.14.1 Connecting cables

See the figures below for how to connect cables.

If using optional RAID Controller (1 to 8 hard disk drives)



Optional RAID Controller	Backplane	Hard Disk Drive
Ports 0-3	SATA 0-3	SLOT 0
		SLOT 1
		SLOT 2
		SLOT 3
Ports 4-7	SATA 4-7	SLOT 4
		SLOT 5
		SLOT 6
		SLOT 7

1.14.2 Notes on Building RAID System

Note the following points when building a RAID System.

- The number of hard disk drives required varies in each RAID level.
- If the optional RAID Controller N8103-176 is used, the RAID System cannot be built in RAID5/RAID6/RAID50/RAID60.

RAID level	The minimum number of hard disk drives required to set up a RAID System	
	N8103-176	N8103-177/178
RAID 0	1	1
RAID 1	2	2
RAID 5		3
RAID 6		3
RAID 10	4	4
RAID 50		6
RAID 60		6

- In the RAID System, all the hard disk drives in a group (pack) must have the same capacity, interface type, and rotational speed.
- Up to 31 logical drives can be created. Do not create 32 or more logical drives.
- If you intend to install the OS to the RAID System, the process from RAID configuration to OS installation can be easily completed by using EXPRESSBUILDER.
- If you wish to install the OS manually, use RAID System Configuration utility (Ctrl-R or HII). For details, see *Chapter 2 (4. RAID System Configuration)* in "Maintenance Guide" or the manual supplied with the optional RAID Controller (N8103-176/177/178).


Important

- Build a Disk Array in the RAID System using hard disk drives that have the same specifications (capacity, rotational speed, and standard).


1.15 Installing Top Cover

When all internal optional devices are installed, close the server with Top Cover.

1. Put Top Cover straight on the server chassis so that it can be surely engaged with the chassis frame.



2. Slide Top Cover toward the front of the server.



3. Tighten the thumb nut on rear of the server.

1.16 Hard Disk Drive

Bays for hard disk drives are provided at the front of the server.

A hard disk drive mounted in a dedicated drive tray can be purchased. Install the hard disk drive on the server with it mounted in the drive tray.

Important


Use hard disk drives specified by NEC. Installing a third-party hard disk drive might cause a failure of the server as well as the hard disk drive.

Note the following precautions to install hard disk drives.

- For onboard connection, hard disk drives having different capacities, types, or rotational speeds cannot be installed together.
- In the RAID System, all the hard disk drives in a group (pack) must have the same capacity, type, and rotational speed.
- If using hard disk drives in a RAID System, jumper settings or a change of cables may be required.

Bays can contain up to 8 hard disk drives.

Unique slot numbers have been assigned to each slot.




1.16.1 Installation

Install a hard disk drive by using the following procedure.

Note


In the RAID System, use hard disk drives that have the same specifications (capacity, rotational speed, and standard) for each Disk Array.

1. See Chapter 2 (1.2 Overview of Installation and Removal) for preparations.
2. Locate the slot where you install the hard disk drive.
The server has 8 slots. Install hard disk drives in ascending order of port number.
3. Remove the dummy tray.
Dummy trays are installed in every slot.


**Note**

Keep the removed dummy trays for future use.

4. Unlock the handle of the tray.



5. Hold the tray firmly and insert it into the slot.

**Note**

- Push it all the way until the handle's lock touches the frame.
- Hold the tray firmly with both hands.

6. Slowly close the handle.
The tray is locked making a clicking sound.

Note

When you push the drive into the slot, confirm the handle got hooked on the frame.

7. Run BIOS Setup Utility, and then specify the boot order from **Boot** menu.
For details, see *Chapter 2 (1. System BIOS)* in "Maintenance Guide"

Tips

The saved boot order is cleared when a hard disk drive is added.

1.16.2 Removal

To remove hard disk drive, reverse the installation procedure.


If you transfer or dispose of the removed hard disk drive, see *Chapter 1 (1. Relocation and Storage)* in "Maintenance Guide" to erase data.

Important

NEC assumes no liability for data leakage should the product be transferred to a third party without erasing the data.

Note

- If you remove a hard disk drive due to a failure, check the slot with its DISK LED 2 lit in amber.



- Do not hold handle to pull the drive out. Doing so may damage the handle.

Run the BIOS Setup Utility, and then specify the boot order from **Boot** menu.
For details, see *Chapter 2 (1. System BIOS)* in "Maintenance Guide".

Tips

The saved boot order is cleared when a hard disk drive is added.

***1.16.3* Replacing a hard disk drive in the RAID System (Auto Rebuild)**

In the RAID System, you can use the auto rebuild feature to restore data back to the state before a failure occurred.

The auto rebuild feature is enabled in logical drives set to RAID 1, RAID 5, RAID 6, RAID 10, RAID 50, and RAID60.

The disk array is automatically rebuilt when hot swapping (replacing a hard disk drive while the power on) a failed hard disk drive.

During the auto rebuild, DISK LEDs 1 and 2 on the hard disk drive blink green and amber respectively to indicate that the auto rebuild is being performed.

Observe the following precautions whenever executing the auto rebuild

- Do not turn off the server until the auto build completes after a hard disk drive fails.
- Leave an interval of at least 90 seconds between a hard disk drive removal and a hard disk drive installation.
- Do not replace a disk during the auto rebuilding of another hard disk drive (during an auto rebuild, DISK LEDs 1 and 2 on the hard disk drive blink green and amber respectively).

1.17 Power Supply Unit

This server can contain two power supply units. The server provides a redundant power configuration that ensures continued operation of the system in the unlikely event one of the power supply units fails.

Tips

AC power supply unit has a cable tie to prevent AC cable from slipping out.

1.17.1 Cold Redundant Feature

The server supports the feature to optimize power efficiency as described below:

- Cold redundant feature can run the system with optimum power efficiency by raising operating efficiency of primary power supply unit and lowering that of redundant power supply unit in redundant power configuration.
- If power efficiency of power units is not optimized due to system configuration, this feature is disabled automatically.

Cold redundant feature can be used under the following conditions:

- Two power supply units must be installed for redundant configuration.
- See *Chapter 2 (1. System BIOS) in "Maintenance Guide"*, change parameters as shown below, save the settings and exit from SETUP.


Server → Power Control Configuration → Cold Redundant Mode → Enabled

Run SETUP again, and check if the status of **Cold Redundant Mode** shows **Enabled** in **Server** menu.

1.17.2 Installation

Follow steps below to install a power supply unit:


1. See steps 1 to 4 in Chapter 2 (1.2 Overview of Installation and Removal) for preparations.
2. Remove the blank cover.



Note


Keep the removed blank cover for future use.

3. Insert the power supply unit until it is locked with clicking sound.




4. Connect power cords.

Use the specified power cords.



AC POWER LED blinks green when the power cord is connected to either of power supply units and the other power supply unit's AC POWER LED goes on amber.

When the power cord is connected to it, AC POWER LEDs on both power supply units blink green.



5. Power on the server.

AC POWER LEDs go on green.

6. Confirm, by STATUS LED or on POST screen, that there are no errors related to the power supply units.

See *Chapter 3 (1. POST Error Message)* in “Maintenance Guide” for details on POST error messages.

If AC POWER LEDs are off, reinstall the power supply units. If the same error occurs, contact with your sales representative.

1.17.3 Replacing a failing power supply unit

Replace only when the power supply unit fails.

To remove power supply unit, reverse the installation procedure.

⚠ CAUTION	
	<p>Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause burns, injury, and property damage. For details, refer to <i>Safety Precautions and Regulatory Notices</i>.</p> <ul style="list-style-type: none"> • Pay attention to electric hazard.

Important

- Do not remove a power supply unit operating normally.
- To maintain the cooling effect in the server, be sure to install the blank cover in the vacant slot.


Tips

In the redundant power configuration (with two power supply units) and if either one of power supply units fails, the failing power supply unit can be replaced with the system power on.

Install the new power supply unit taking steps 3 to 6 of “*Installation*”, and confirm that the power supply unit is installed normally.

1.18 Installing Front Bezel

When installing Front Bezel, set it in the correct position and push it straight. After installing Front Bezel, lock it with Bezel Lock Key.



Important Be careful not to press the POWER Switch.

2. Installation and Connection



This section describes how to install the server and connect cables.



2.1 Installation

This server must be mounted to a rack which conforms to EIA standards for use.

2.1.1 Installing Rack

Refer to the manual that comes with your rack for how to install the rack, or consult with your sales representative.

 WARNING	
	<p>Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause death or serious injury. For details, refer to <i>Safety Precautions and Regulatory Notices</i>.</p> <ul style="list-style-type: none"> • Use only in the specified environment. • Do not connect the ground wire to a gas pipe.


 CAUTION	
	<p>Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause burns, injury, and property damage. For details, refer to <i>Safety Precautions and Regulatory Notices</i>.</p> <ul style="list-style-type: none"> • Do not carry or install the server only by a single person. • Do not install the server so that the load may be concentrated on a specific point. • Do not install any components only by a single person. Confirm that hinge pins of the door are completely secured in place. • Do not pull out the server from the rack when the rack is unstable. • Do not leave more than one device being pulled out from the rack. • Do not provide the wiring for the server to exceed the rating of the power supply. • Do not use the server in the environment where corrosive gas is generated.



Do not install the rack or server under the following environment. Doing so may cause malfunction of the server.

- Narrow space from which devices cannot be pulled out from the rack completely
- Place that cannot bear the total weights of the rack and devices mounted on the rack
- Place where stabilizers cannot be installed or where the rack can be installed only after the practice of proper earthquake-resistant construction
- Place of uneven or slanting floor
- Place of drastic temperature change (near a heater, air conditioner, or refrigerator)
- Place where intense vibration may be generated
- Place where corrosive gases (sulfur dioxide, hydrogen sulfide, nitrogen dioxide, chlorine, ammonia, ozone, etc) exist
Place where the air (or dust) includes components accelerating corrosion (ex. sulfur, sodium chloride) or conductive metals
- Place where chemicals may be accidentally sprayed over
- Place where a carpet not subject to anti-static process is laid
- Place where some objects may be fallen on the rack
- Place near a device generating intense magnetic field (such as TVs, radios, broadcast/communication antennas, power transmission wires, and electromagnetic cranes) is placed.
- Place where the power cord of the server must be connected to an AC outlet that shares the outlet of another device with large power consumption
- Place near equipment that generates power noise (e.g., contact spark at power-on/power-off of commercial power supply through a relay).
- Environment where operation of the server is not guaranteed

2.1.2 Installing the server to the rack or removing it from the rack


Mount the server to the rack. (This section also describes the removal procedure.)



**WARNING**



Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause death or serious injury. For details, refer to *Safety Precautions and Regulatory Notices*.

- Do not use any racks out of standards.
- Use only under the specified environment.

**CAUTION**



Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause burns, injury, and property damage. For details, refer to *Safety Precautions and Regulatory Notices*.

- Do not drop.
- Do not leave the server being pulled out.
- Do not install with the cover removed.
- Do not get your fingers caught.

Important

Temperature increases and airflow in the rack

If multiple devices are installed, or if the inside of the rack is not sufficiently ventilated, the internal temperature rises due to the heat emitted from each device, which may result in a malfunction. Review airflow in the rack and room and take sufficient measures so that the internal temperature will not exceed the operational temperature during operation.


Air enters the server from the front and exits from the rear.

Preparation

- Checking rails
- Installing inner and outer rails


Checking rails

Make sure the orientation of inner and outer rails by viewing labels on each rail.




Installing inner rails

1. Mount an inner rail marked as "R" to the right side of the server and "L" to the left side when viewed the server from front.
2. Align the locks and holes, and insert the inner rails until it clicks.



Installing outer rails

1. Mount an outer rail marked as "R" to the right side of the rack and "L" to the left side when viewed the rack from front.
2. Fit the square-shaped protrusions of outer rail to the square holes of a 19-inch rack. Make sure that it makes a clicking sound indicating that it is locked. The image on the right shows the front left side of the rack. Install to the rear left side and front and rear right sides following the same procedure. Make sure that the rail is installed at the same height as the other rail already installed.




Important Confirm that the rail are securely locked so that they will not fall off.

Tips Although the rail may be somewhat unsteady, it is not defective.

Installing/Removing the Server

⚠ CAUTION



Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause burns, injury, and property damage. For details, refer to *Safety Precautions and Regulatory Notices*.


- Do not attempt to lift the server with single person.
- Do not drop.
- Do not leave the server being pulled out.
- Do not install with the cover removed.
- Do not get your fingers caught.

(1) Installation


Mount the server to a rack in the following procedure.

Important Always install the server with two or more persons.

1. Pull the slide rail from the outer rail until the slide rail is locked.

**Note**


Make sure that locking mechanism work normally.




Locked state

Locking mechanism


2. With two or more persons, firmly hold the server and mount it to the rack.



- When the server is pushed into the rack and is locked, push the server to the end while pulling the rail stopper (blue) on both sides of the server.



- Push the server until its lock on front panel clicks.




(2) Removal procedure


Remove the server from the rack in the following procedure.

Important At least two persons are required to remove the server from rack.


- Make sure that the server is turned off and then disconnect the power cord or all interface cables from the server.
- Remove the front bezel.



- Slowly pull the server out while pressing the buttons located on both sides of the front of the server.



4. The server will come to a stop halfway.
Press and hold Rail Stoppers on the rail and pull the server out of the rack.



Important Be careful not to get your fingers caught in the rails or lever.

5. Hold the server firmly and remove it from the rack.

Important


- While more than one person is supporting the bottom part of the server, slowly pull out the server.
- Do not apply pressure on the server from top when it is being pulled out. Doing so cause the server to drop.

(3) Removing Outer Rail


Remove outer rails from the rack in the following procedure.

1. See Chapter 2 (2.1.2 *Installing the server to the rack or removing it from the rack, (2) Removal procedure*) to remove the server from the rack.

2. Push the unlock lever on outer rail to the direction shown by arrow to house the slide rail.





3. While pressing the lever on outer rail, push the outer rail toward inside of the rack, then remove it.






2.2 Connection

Connect peripheral devices to the server.

Connectors that allow a variety of peripheral devices to be connected are provided at the front and rear of the server. Images on the following pages show the peripheral devices that can be connected in their standard state and their respective connector positions.

 WARNING	
	<p>Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause death or serious injury. For details, refer to <i>Safety Precautions and Regulatory Notices</i>.</p> <ul style="list-style-type: none"> Do not hold the power plug with wet hands Do not connect the ground wire to a gas pipe

 CAUTION	
	<p>Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause burns, injury, and property damage. For details, refer to <i>Safety Precautions and Regulatory Notices</i>.</p> <ul style="list-style-type: none"> Use only the specified outlet to insert. Do not connect the power cord to an outlet that has an illegal number of connections. Insert the power plug into the outlet as far as it goes. Use only the specified power cord Do not connect or disconnect the interface cable with the power plugged in the outlet. Use only the specified interface cable



*1 Connect the power cord to a circuit breaker of up to 15 A.

*2 Either one can connect with a display unit.

Note

The serial port cannot be used to connect with leased line.


Note the following precautions to connect cables.

- When the device is not Plug and Play device, turn off the server and devices to be connected before connecting.
- If connecting any peripheral device and its interface cable made by other companies (a third party), contact your sales representative to check if they can be used with the server beforehand.
- Fix the power cord or interface cable with cable ties.
- Make sure that no pressure is applied on the plug of power cord.

2.2.1 Connecting to Uninterruptible Power Supply (UPS)

To connect the power cord of the server to a UPS, use the connector output on the rear of the UPS. For details, refer to the manual supplied with the UPS.

Example



When the power cord is connected to a UPS, change the BIOS settings in order to link the server with the power supply from the UPS.

To change the settings, select **Server** and then **AC-LINK** in BIOS Setup Utility, and change the displayed parameters. Select **Power On** to perform automatic operations by using the UPS. For details, see *Chapter 3* (2 BIOS Setup Utility (SETUP)).

NEC Express5800 Series Express5800/R120g-1M

3

Setup

This chapter describes how to set up the server.

1. Turning on the Server

Power-On Self-Test (POST) is explained in this section.

2. BIOS Setup Utility (SETUP)

You can customize the BIOS settings by following the instructions in this section.

3. EXPRESSSCOPE Engine 3

EXPRESSSCOPE Engine 3 provides useful features through Baseboard Management Controller (BMC).

4. EXPRESSBUILDER

EXPRESSBUILDER helps you to install Windows and maintain the server.

5. Installing Software Components

You can install Windows and bundled software by following the instructions in "*Installation Guide (Windows)*".

6. Turning off the Server

Turn off power when not using the server.

1. Turning on the Server

Pressing POWER Switch at the front of the server turns on the server.

Turn on the server by using the following procedure.


Tips

Wait for at least 30 seconds before turning on the server after turning it off.

1. Turn on a display, an Uninterruptible Power Supply (UPS), and other peripherals.
2. Remove Front Bezel.
3. If STATUS LED is lighting green or amber, wait until it goes off.
4. Press POWER Switch at the front of the server.
POWER LED is turned on green and after a while, logo appears on the display.

Important

Do not connect or disconnect USB device while POST is running.



1.1 POST

Power-On Self-Test (POST) is a self-diagnostic program stored in the server as standard. POST automatically runs immediately after the server is turned on and checks the motherboard, memory, and processor (CPU). POST also displays the start-up messages of different utilities during the operation.

Usually, you do not need to check the contents of POST. However, check messages displayed at POST in the following cases:

- When introducing a server
- If you suspect a failure
- When you hear beep many times during the time between power ON and OS startup
- When any error message is displayed

1.1.1 POST sequence

Explains how POST runs in order.

1. When the server is turned on, POST starts, and an initialization message is displayed. The message to tell initialization of a memory and a PCI device. After an initialization message was displayed, a logo appears on the screen.



Note

- Keyboard becomes operable after the logo appears.
- While an initialization message is displayed, a screen is sometimes switched over to the screen by which nothing is displayed (black screen) several times. It's no problem for operation.
- An initialization message or a logo are not sometimes displayed by the occasion with which an option VGA controller was connected and setting of a BIOS setup utility (SETUP).
- An initialization message isn't displayed on the console redirection screen of a serial port.

2. If **Enabled** is specified for **Password On Boot** in **Security** menu of SETUP, you will be prompted to enter password after the logo is displayed. If you enter the incorrect password three times consecutively, POST aborts. (You can no longer proceed.) In this case, power off the server, and power it on.

Important

Do not set a password before OS is installed.

3. If <Esc> key is pressed, the logo disappears and the details of POST are displayed.

Tips

If **Quiet Boot** is **Disabled** from **Boot** menu in BIOS settings, the logo is not displayed and POST execution result is displayed..

4. After a while, the following message is displayed on the screen. (The on-screen message depends on your environment.)

Press <F2> SETUP, <F3> Internal Flash Memory, <F4> ROM Utility, <F12> Network

By pressing the function key following messages, you can call the functions below upon completion of POST.

<F2> key: Run BIOS Setup Utility (SETUP). For information on the SETUP, see *Chapter 2 (1. System BIOS) in "Maintenance Guide"*.

<F3> key: Run EXPRESSBUILDER from Internal Flash Memory. For details, see *Chapter 3 (4. EXPRESSBUILDER)*.

Note

If bootable CD/DVD is inserted into optical disk drive, the system starts from CD/DVD even if <F3> key is pressed.

<F4> key: Run Offline Tools. For information on Offline Tools, see *Chapter 1 Maintenance (9. Offline Tools) in "Maintenance Guide"*.

<F12> key: Boot from network.

Tips

If **One time** or **Always** is specified for **Power Management Policy** in **Server** menu of BIOS SETUP, a message indicating power consumption is being measured is displayed instead of the message shown above. Wait for a while until measurement is complete.

5. When **Legacy** is specified for **Boot Mode**, a message that prompts you to start the utility is displayed depending on the installed controller.

Example of RAID controller :

Press <Ctrl> <R> to Run MegaRAID Configuration Utility

The utility starts by pressing <Ctrl> + <R> keys.

For details on the utility, refer to the manual supplied with each optional board.

Depending on the hardware configuration, the message "Press Any Key" might appear to prompt a key entry. This is a behavior of the BIOS of the optional board. Continue to operate after checking the manual of the optional board.

6. When **Secure Boot** is set to **Enabled** in **Security** menu and **Invalid Signature Detection** is set to **Halt** in BIOS Setup Utility(SETUP), the message will be displayed saying that the invalid signature was detected in the folloing cases:

- The boot image in a bootable device is unsigned
- The signature of the Boot image in a bootable device is illegal

In such cases, turn off the server and check that the signature of the boot image in a bootable device is correct. Connect the device for which Secure Boot is enabled to the server and restart.

7. The OS starts when POST is completed.

Tips

- When no bootable device is connected, the following message is displayed by terminating POST.
Bootable media is not found.
Press <F2> to enter SETUP.
Press the <F2> key to boot the BIOS setup utility (SETUP).
- Even when any bootable device is connected, the following message may displayed by stopping the utility.
Bootable media is not found.
Please restart this computer.
In this case, you cannot boot the BIOS setup utility (SETUP).

1.1.2 POST error messages

When POST detects an error, it displays an error message on the screen or beeps for some errors. For descriptions of error messages, causes, and countermeasures, see *Chapter 3 (1. POST Error Message) in "Maintenance Guide"*.

Note

Take notes on the indication displayed on display unit before consulting with your sales representative. Alarm messages are useful information for maintenance.

2. BIOS Setup Utility (SETUP)

This section describes how to configure Basic Input Output System (BIOS).

Make sure you have read and understood this section to configure properly.

2.1 Overview

BIOS Setup Utility (SETUP) is a utility to do basic hardware settings. This utility is installed in a flash memory in the server as standard and can be run without requiring a media for boot.

BIOS settings were configured with optimal settings before the server was shipped to you. Therefore, in most of cases, you should not need to use the SETUP. **Use only when the case applies to any of cases described in Chapter 3 (2.4 Cases that Require Configuration).**

2.2 Starting SETUP Utility

Run POST following *Chapter 3 (1.1.1 POST sequence)*.

After a while, the following message will be displayed on the lower left of the screen. (The on-screen message depends on your environment.)

Press <F2> SETUP, <F3> Internal Flash Memory, <F4> ROM Utility, <F12> Network

If you press the <F2> key, SETUP starts upon completion of POST, and the **Main** menu is displayed.

Tips

In **Legacy** boot mode, you can also launch SETUP by pressing the <F2> key while expanding option ROM.

Password

If you have set a password, a message prompt you to enter password will be displayed.

Enter password [

You can attempt password entry up to 3 times. If you entered an incorrect password 3 times, operation stops. (You cannot operate further.) Turn off the power.

Saving changes

If you finish configuration, select **Save & Exit** and then **Save Changes and Exit** to save changes and exit.


If you wish to exit without saving the changed parameters, select **Save & Exit** and then **Discard Changes and Exit**.

Tips

- If you wish to restore the setting to default values, select **Save & Exit** and then **Load Setup Defaults**.
- The default value might be different from the factory setting.
- You cannot restore the default value in the following submenus in **Advanced** menu:
 - **iSCSI Configuration** submenu
 - **UEFI Driver Configuration** submenu

2.3 Description on On-Screen Items and Key Usage

This section shows display examples and how to control the key. Use the keyboard to work with SETUP.



- ☐ Cursor keys (<↑>, <↓>)
Select an item displayed on the screen. If characters of an item are highlighted, that means the item is currently selected.
- ☐ Cursor keys (<←>, <→>)
Select menus including **Main**, **Advanced**, **Security**, **Server**, **Boot**, and **Save & Exit**.
- ☐ <→> key/<+> key
Change the value (parameter) of the selected item. You cannot use this key when a menu which has ► on the left is selected.
- ☐ <Enter> key
Press this key to determine the selected parameter.
- ☐ <Esc> key
Pressing this key cancels pop-up window. On the submenu, pressing this key takes you to the previous screen. On the top menu, the following window is displayed. If you select **Yes**, SETUP closes without saving the changed parameters.

Quit without saving?	
[Yes]	No

- ☐ <F1> key
Press this key to display help information. If you need help using SETUP, press this key. Press <Esc> key to go back to the original screen.

☐ <F2> key

If you press this key, the following window appears. If you select **Yes**, the previous parameter(s) are restored. If you have saved changes by selecting **Save & Changes**, pressing the <F2> key restores the saved value.

Load Previous Values?
[Yes] No

☐ <F3> key

If you press this key, the following window appears. If you select **Yes**, restore the parameters of the currently selected item to the default setting. (**This might be different from the parameters configured before shipment.**)

Load Setup Defaults?
[Yes] No

Note

The values set on **iSCSI Configuration** submenu and **UEFI Driver Configuration** submenu are not returned to the default setting.

☐ <F4> key

If you press this key, the following window appears. If you select **Yes**, the parameter you configured is saved and SETUP closes.

After exiting SETUP, the server restarts automatically.

Save configuration and exit?
[Yes] No

2.4 Cases that Require Configuration

Only if a case applies to any of following cases, use SETUP to change a parameter which was configured as factory setting. Other than cases described below, do not change the settings. A list of SETUP parameters and factory settings are described in **Chapter 2 (1. System BIOS) in "Maintenance Guide"**.

Category	Description	To be changed	Remark
Basic	Change date and time	Main → System Date Main → System Time	Configurable on OS
	On/Off NumLock on power ON	Boot → Bootup Numlock State → ON or OFF	
	On/Off the function to display NEC logo during POST	Boot → Quite Boot → Disabled	By pressing <Esc> key during POST, prevent the display of the logo.
Memory	Configure memory after adding or changing DIMM.	Advanced → Memory Configuration → Memory Retest → Yes	After rebooting, Memory Retest changes No automatically.
	Use memory RAS feature	Advanced → Memory Configuration → Memory RAS Mode → change to RAS mode	Some of RAS features may not be used depending on DIMM configuration.
Optional board	Start the system from installed option board.	Advanced → PCI Configuration → PCI Device Controller and Option ROM Settings → PCIXX Slot Option ROM → Enabled	XX is PCI slot number of the installed option board
Boot	Set the boot mode to UEFI mode according to your OS.	Boot → Boot Mode → UEFI*1 Select UEFI mode for the following OS. – Windows Server 2012 – Windows Server 2012 R2	See "Before Starting Setup" in Chapter 1 (Installing Windows) in <i>Installation Guide</i> to determine the boot mode.
	Set the boot mode to Legacy BIOS mode according to your OS.	Boot → Boot Mode → Legacy*1 Select Legacy mode for the following OS. – Windows Server 2008R2 – VMware ESXi 5 – VMware ESXi 6	See "Before Starting Setup" in Chapter 1 (Installing Windows) in <i>Installation Guide</i> to determine the boot mode.
	Change the boot order of devices	Boot → Boot Option Priorities → Change the boot priority	When you use EXPRESSBUILDER, set CD/DVD to the highest priority.
	Use remote power on feature (via modem)	Advanced → Advanced Chipset Configuration → Wake On Ring → Enabled	
	Use remote power on feature (via RTC alarm)	Advanced → Advanced Chipset Configuration → Wake On RTC Alarm → Enabled	
	Use console redirection feature	Advanced → Serial Port Configuration → Console Redirection Settings → Change respective setting.	In console redirection connection, if the corrupted text is displayed on terminal screen, change font type (character code) appropriate to your environment.
	Enable X2APIC feature according to your OS.	Advanced → Processor Configuration → X2APIC → Enabled*1 Enable X2APIC for the following OS. – Windows Server 2012 – Windows Server 2012 R2	See "Before Starting Setup" in Chapter 1 (Installing Windows) in <i>Installation Guide</i> to select Enabled or Disabled .
	Disable X2APIC feature according to your OS.	Advanced → Processor Configuration → X2APIC → Disabled*1 Disable X2APIC for the following OS. – Windows Server 2008R2 – VMware ESXi 5 – VMware ESXi 6	See "Before Starting Setup" in Chapter 1 (Installing Windows) in <i>Installation Guide</i> to select Enabled or Disabled .

Category	Description	To be changed	Remark
Security	Set a password	Security → Administrator Password → Enter a password (Set a password for Administrator first and then User)	There are two types of password; Administrator and User. Settings for User password is limited compared to for Administrator.
	Restrict bootup by entering password	Security → Password on Boot → Enabled	Can be selected when password is set.
	Execute TBOOT (Trusted Boot) using the option TPM kit.	Mount the option TPM kit, select [Security] and set the following items under the [Trusted Computing] submenu to [Enabled]. <ul style="list-style-type: none"> • [TPM Support] • [TPM State] • [TXT Support] 	Do not disable TPM with the TPM management module after setting [TXT Support] to [Enabled] to start OS. You may not be able to change [TPM Support] and [TXT Support]. In that case, execute [Save & Exit] and [Load Setup Defaults].
UPS Powerlink	When the server is supplied with power from UPS, always turn on the power.	Server → Power Control Configuration → AC-LINK → Power On	
	If it is turned off by using POWER switch, leave it OFF even when UPS supplies power.	Server → Power Control Configuration → AC-LINK → Last State	
	Keep the power OFF even when UPS supplies power.	Server → Power Control Configuration → AC-LINK → Stay off	

*1 The factory setting is that "the Boot Mode menu" is set as "UEFI" and "the X2APCI menu" is set as "Enabled".

3. EXPRESSSCOPE Engine 3

3.1 Overview

EXPRESSSCOPE Engine 3 provides a variety of features using BMC (Baseboard Management Controller), which is a system management LSI.

See *EXPRESSSCOPE Engine 3 User's Guide* for detailed information.

EXPRESSSCOPE Engine 3 monitors the power supply unit, fans, temperature, and voltage of the server. If you have the management LAN port connected to the network, you can remotely perform the following over a web browser or SSH client:

- Manage the server
- Remotely control the keyboard, video, and mouse (KVM)*
- Remotely access a CD/DVD/floppy disk/ISO image/USB memory*.

* To enable this feature, the optional license for remote management (N8115-04) is required.

To actualize these functions, virtual USB mass storage (Remote FD, Remote CD/DVD, Remote USB Memory, or Virtual Flash) is always connected as USB mass storage.


3.2 EXPRESSSCOPE Engine 3 Network Configuration

Take the steps below to use EXPRESSSCOPE Engine 3 through the Web browser.

1. Run POST following *Chapter 3 (1.1.1 POST sequence)*. Wait until the following message appears on the lower left of the screen.

Press <F2> SETUP, <F3> Internal Flash Memory, <F4> ROM Utility, <F12> Network

2. Press the <F4> key while the message is being displayed to launch ROM Utility.
3. Select your keyboard type on Keyboard Selection screen.
4. On Off-line TOOL MENU, select **Server Configuration Utility** → **EXPRESSSCOPE Engine 3** → **Configuration** → **Network** → **IPv4 Property** or **IPv6 Property**.



- On the following screen, select **Enable** when you use DHCP, or select **Disable** and specify IP Address (Required), Subnet Mask (Required), Default Gateway, and DNS Server when you do not use DHCP.

Tips

If **Shared BMC LAN** is enabled, Web feature, remote media/KVM feature, or command line interface feature may be interrupted. In this case, wait for a while, and connect with network again.

Item Name	Setup Value
Management LAN	Management LAN
Connection Type	Auto Negotiation
BMC MAC Address	00:11:22:AA:BB:CC
DHCP	[Disable]
IP Address [Required]	[192.168.0.1]
Subnet Mask [Required]	[255.255.255.0]
Default Gateway	[192.168.0.2]
DNS Server	[192.168.0.3]
Host Name	[HostName]
Domain Name	[Domain.Name]

< OK >
< Cancel >
< Load Default Value >

Select:[Enter] Cancel:[ESC] Help:[Home or ?]

When **IPv4 Property** is selected

- Connect the LAN cable to the management LAN connector in order to connect to the network. It will be available for use if you access EXPRESSSCOPE Engine 3 via Web browser from management PC according to the setting.

4. EXPRESSBUILDER

EXPRESSBUILDER helps you to install Windows or maintain the server.

4.1 Features of EXPRESSBUILDER

EXPRESSBUILDER provides the following features.

Feature	Description
Setup (Windows reinstallation)	Installs Windows on your server. Easily completes the process from RAID configuration to installation of applications. To use this feature, choose OS installation in Boot Selection Menu.
Bundled software	Stores NEC ESMPRO, Universal RAID Utility, and other bundled software.
Maintenance	Diagnoses the server. To use this feature, choose Tool menu in Boot Selection Menu.
Manuals	Stores <i>User's Guide</i> , <i>Installation Guide</i> , <i>Maintenance Guide</i> , and other manuals.

4.2 Usage of EXPRESSBUILDER

Run EXPRESSBUILDER by the following way:

Internal Flash Memory:

Ensure a CD/DVD is removed from the server, turn on the server, and then press <F3> key during POST.

Windows Application

You can run EXPRESSBUILDER by clicking the shortcut of NEC EXPRESSBUILDER on the desktop after installing Windows and Starter Pack.

EXPRESSBUILDER DVD:

DVD does not come with the product. Purchase the option or download it from the following website

<http://www.nec.com/>

- Support & Downloads

Set the DVD to an optical disk drive and restart this server, or set the DVD to a computer running Windows.

5. Installing Software Components

Continue to install software components such as OS.

See the instructions below.

- [Installation Guide \(Windows\)](#)

6. Turning Off the Server

Turn off the server by using the following procedure. If the power cord of the server is connected to a UPS, refer to the documentation supplied with the UPS or the documentation for the application controlling the UPS.

1. Shut down the OS.
2. The server automatically turns off after the OS shuts down.
Confirm that POWER LED is OFF.
3. Turn off peripheral devices.

NEC Express5800 Series Express5800/R120g-1M

4

Appendix

1. **Specifications**
2. **Interrupt Lines**
3. **Glossary**
4. **Revision Record**

I. Specifications

Code Number			N8101-				
			1029F	1030F	1031F	1032F	1033F
CPU	CPU		Intel Xeon processor				
			E5-2603 v4	E5-2620 v4	E5-2623 v4	E5-2630 v4	E5-2637 v4
	Clock speed		1.70GHz	2.10GHz	2.60GHz	2.20GHz	3.5GHz
	Number of CPUs, standard / maximum		1/2				
	Intel Smart Cache (Last Level Cache)		15MB	20MB	10MB	35MB	15MB
	Number of cores (C) / Number of threads (T) per CPU		6C/6T	8C/16T	4C/8T	10C/20T	4C/8T
Chipset			Intel C612 chipset				
Memory	Capacity, standard/maximum		Not pre-installed (selectable option) / Registered DIMM : 1536GB (24x 64GB)				
	Memory module		DDR4-2400 Registered DIMM (4/8/16/32/64GB)				
	Maximum operating frequency		1866MHz	2133MHz			2400 MHz
	Error check, correction		ECC, x4 SDDC, Memory LockStep (x8 SDDC)				
	Memory sparing		Supported				
	Memory mirroring		Supported				
Storage	Hard disk drive	Internal (standard)	N/A				
		Internal (maximum)	2.5-inch HDD: SATA 8TB (8x 1TB), SAS 14.4TB (8x 1.8TB), 2.5-inch SSD: SATA 6.4TB (8x 800GB), SAS 3.2TB (8x 400GB)				
		Hot swap	Supported				
	Interface / RAID level		SATA 6Gb/s : RAID 0/1/5/6/10/50/60 (option), SAS 12Gb/s : RAID 0/1/5/6/10/50/60 (option)				
	Optical disk drive		Internal or external drive (option) *1				
	FDD		Option: Flash FDD (1.44MB) *2				
	Expansion bay		N/A				
	Expansion slots	Supported slots		1x PCI Express 3.0 (x8 lane, x8 socket)(Full hight, length 220 mm) 1x PCI Express 3.0 (x8 lane, x16 socket)(Full hight, length 220 mm)(option) 1x PCI Express 3.0 (x8 lane, x8 socket) (Low profile, length 220 mm) 1x PCI Express 3.0 (x16 lane, x16 socket) (Low profile, length 220 mm) (option) 1x PCI Express 3.0 (x8 lane, x8 socket) (Dedicated to RAID controller) 1x PCI Express 3.0 (x8 lane, x8 socket) (Dedicated to LOM card)			
Chip / VideoRAM		Embedded management controller chip / 32 MB					
	Graphic display / resolution		16,770,000 colors: 640x840, 800x600, 1,024x768, 1,280x1,024, 1,600x1,200				
Interface			5x USB3.0 (2x front, 2x rear, 1x internal), 3x USB2.0 (2x rear, 1x internal) 2x Analog RGB (Mini D-Sub15 pin, 1x front, 1x rear) 1x Serial port (RS-232C compliant / D-Sub 9 pin, Serial port A, 1x rear, optional port can be used (up to two ports in total), 1x Management LAN connector (1000BASE-T/100BASE-TX/10BASE-T supported, RJ45, 1x rear) (With optional LOM card, 4x 1000BASE-T, 2x 10GBASE-T, 2x 10GBASE-SFP+, or 2x 1000BASE-T can be added)				
Redundant power supply			Supported (option, hot-plug available)				
Redundant fan			Supported (standard, hot-plug available)				
External dimensions (width × depth × height)			439.8 mm × 722.0 mm × 43.4 mm (front bezel / protrusions / inner rails excluded) 482.4 mm x 766.1 mm x 43.4 mm (front bezel / protrusions / inner rails included)				
Weight (Minimum *3/ Max.)			13.8 kg / 21.0 kg (including rails)				
Power supply unit			Not pre-installed (selectable option), AC power supply unit 460 W/800 W 80 PLUS Platinum compliant (bipolar grounded outlet) (hot-plug available) (Max: 2) 100 VAC/200 VAC ± 10%, 50/60 Hz ± 3 Hz (Power cable is a required option) 800 W 80 PLUS Titanium compliant (bipolar grounded outlet) (hot-plug available) (Max: 2) 100 VAC/200 VAC ± 10%, 50/60 Hz ± 3 Hz (Power cable is a required option)				
Power consumption (100V at maximum configuration, at maximum power)			329VA/327W	417VA/414W	412VA/410W	435VA/432W	529VA/525W
Power consumption (200V at maximum configuration, at maximum power)			526VA/523W	588VA/584W	586VA/582W	613VA/609W	665VA/660W
Environmental requirements			Operating: 5 to 40°C / 20 to 80%, Storage: -10 to 55°C / 20 to 80% (no condensation either when operating or when stored)				
Temperature/Humidity							
Main accessories			Getting Started, Safety Precautions and Regulatory Notices, one-touch rack rail, Front bezel				
Installed OS			N/A				
Supported OSs			Microsoft Windows Server 2008 R2 Standard, Microsoft Windows Server 2008 R2 Enterprise, Microsoft Windows Server 2012 Standard, Microsoft Windows Server 2012 Datacenter, Microsoft Windows Server 2012 R2 Standard, Microsoft Windows Server 2012 R2 Datacenter, VMware ESXi™ 5.5 Update 2, VMware ESXi™ 6.0				

*1 If you do not intend to install an internal DVD-ROM or an internal DVD SuperMULTI in all systems, prepare at least one external DVD-ROM per system for maintenance and OS reinstallation purposes.

*2 For the principal uses of a Flash FDD, see *Maintenance Guide*.

*3 Minimum configuration for operation (1x CPU, 2x DIMM, 1x HDD, 1x Power supply unit).

Code Number			N8100-				
			1034F	1036F	1037F	1038F	1039F
CPU	CPU		Intel Xeon processor				
			E5-2640 v4	E5-2650 v4	E5-2650L v4	E5-2667 v4	E5-2680 v4
	Clock speed		2.40GHz	2.20GHz	1.70GHz	3.20GHz	2.40GHz
	Number of CPUs, standard / maximum		1/2				
	Intel Smart Cache (Last Level Cache)		25MB	30MB	35MB	25MB	35MB
Number of cores (C) / Number of threads (T) per CPU		10C/20T	12C/24T	14C/28T	8C/16T	14C/28T	
Chipset			Intel C612 chipset				
Memory	Capacity, standard/maximum		Not pre-installed (selectable option) / Registered DIMM : 1536GB (24x 64GB)				
	Memory module		DDR4-2400 Registered DIMM (4/8/16/32/64GB)				
	Maximum operating frequency		2133MHz	2400MHz			
	Error check, correction		ECC, x4 SDDC, Memory LockStep (x8 SDDC)				
	Memory sparing		Supported				
	Memory mirroring		Supported				
Storage	Hard disk drive	Internal (standard)	N/A				
		Internal (maximum)	2.5-inch HDD: SATA 8TB (8x 1TB), SAS 14.4TB (8x 1.8TB), 2.5-inch SSD: SATA 6.4TB (8x 800GB), SAS 3.2TB (8x 400GB)				
		Hot swap	Supported				
	Interface / RAID level		SATA 6Gb/s : RAID 0/1/5/6/10/50/60 (option), SAS 12Gb/s : RAID 0/1/5/6/10/50/60 (option)				
	Optical disk drive		Internal or external drive (option) *1				
	FDD		Option: Flash FDD (1.44MB) *2				
	Expansion bay		N/A				
	Expansion slots	Supported slots		1x PCI Express 3.0 (x8 lane, x8 socket)(Full hight, length 220 mm) 1x PCI Express 3.0 (x8 lane, x16 socket)(Full hight, length 220 mm)(option) 1x PCI Express 3.0 (x8 lane, x8 socket) (Low profile, length 220 mm) 1x PCI Express 3.0 (x16 lane, x16 socket) (Low profile, length 220 mm) (option) 1x PCI Express 3.0 (x8 lane, x8 socket) (Dedicated to RAID controller) 1x PCI Express 3.0 (x8 lane, x8 socket) (Dedicated to LOM card)			
Chip / VideoRAM		Embedded management controller chip / 32 MB					
Graphic display / resolution		16,770,000 colors: 640x840, 800x600, 1,024x768, 1,280x1,024, 1,600x1,200					
Interface			5x USB3.0 (2x front, 2x rear, 1x internal), 3x USB2.0 (2x rear, 1x internal) 2x Analog RGB (Mini D-Sub15 pin, 1x front, 1x rear) 1x Serial port (RS-232C compliant / D-Sub 9 pin, Serial port A, 1x rear, optional port can be used (up to two ports in total), 1x Management LAN connector (1000BASE-T/100BASE-TX/10BASE-T supported, RJ45, 1x rear) (With optional LOM card, 4x 1000BASE-T, 2x 10GBASE-T, 2x 10GBASE-SFP+, or 2x 1000BASE-T can be added)				
Redundant power supply			Supported (option, hot-plug available)				
Redundant fan			Supported (standard, hot-plug available)				
External dimensions (width × depth × height)			439.8 mm × 722.0 mm × 43.4 mm (front bezel / protrusions / inner rails excluded) 482.4 mm x 766.1 mm x 43.4 mm (front bezel / protrusions / inner rails included)				
Weight (Minimum *3/ Max.)			13.8 kg / 21.0 kg (including rails)				
Power supply unit			Not pre-installed (selectable option) AC power supply unit 460 W/800 W 80 PLUS Platinum compliant (bipolar grounded outlet) (hot-plug available) (Max: 2) 100 VAC/200 VAC ± 10%, 50/60 Hz ± 3 Hz (Power cable is a required option) 800 W 80 PLUS Titanium compliant (bipolar grounded outlet) (hot-plug available) (Max: 2) 100 VAC/200 VAC ± 10%, 50/60 Hz ± 3 Hz (Power cable is a required option)				
Power consumption (100V at maximum configuration, at maximum power)			442VA/439W	492VA/488W	393VA/391W	582VA/578W	529VA/525W
Power consumption (200V at maximum configuration, at maximum power)			630VA/625W	663VA/658W	564VA/560W	691VA/686W	726VA/721W
Environmental requirements Temperature/Humidity			Operating: 5 to 40°C / 20 to 80%, Storage: -10 to 55°C / 20 to 80% (no condensation either when operating or when stored)				
Main accessories			Getting Started, Safety Precautions and Regulatory Notices, one-touch rack rail, Front bezel				
Installed OS			N/A				
Supported OSs			Microsoft Windows Server 2008 R2 Standard, Microsoft Windows Server 2008 R2 Enterprise, Microsoft Windows Server 2012 Standard, Microsoft Windows Server 2012 Datacenter, Microsoft Windows Server 2012 R2 Standard, Microsoft Windows Server 2012 R2 Datacenter, VMware ESXi™ 5.5 Update 2, VMware ESXi™ 6.0				

*1 If you do not intend to install an internal DVD-ROM or an internal DVD SuperMULTI in all systems, prepare at least one external DVD-ROM per system for maintenance and OS reinstallation purposes.

*2 For the principal uses of a Flash FDD, see *Maintenance Guide*.

*3 Minimum configuration for operation (1x CPU, 2x DIMM, 1x HDD, 1x Power supply unit)

Code Number			N8100-				
			1040F	1041F	1042F	1043F	1044F
CPU	CPU	Intel Xeon processor					
			E5-2690 v4	E5-2697 v4	E5-2697A v4	E5-2698 v4	E5-2699 v4
	Clock speed		2.60GHz	2.30GHz	2.60GHz	2.20GHz	2.20GHz
	Number of CPUs, standard / maximum		1/2				
	Intel Smart Cache (Last Level Cache)		2.60GHz	2.30GHz	2.60GHz	2.20GHz	2.20GHz
	Number of cores (C) / Number of threads (T) per CPU		14C/28T	18C/36T	16C/32T	20C/40T	22C/44T
Chipset			Intel C612 chipset				
Memory	Capacity, standard/maximum		Not pre-installed (selectable option) / Registered DIMM : 1536GB (24x 64GB)				
	Memory module		DDR4-2400 Registered DIMM (4/8/16/32/64GB)				
	Maximum operating frequency		2400 MHz				
	Error check, correction		ECC, x4 SDDC, Memory LockStep (x8 SDDC)				
	Memory sparing		Supported				
	Memory mirroring		Supported				
Storage	Hard disk drive	Internal (standard)	N/A				
		Internal (maximum)	2.5-inch HDD: SATA 8TB (8x 1TB), SAS 14.4TB (8x 1.8TB), 2.5-inch SSD: SATA 6.4TB (8x 800GB), SAS 3.2TB (8x 400GB)				
		Hot swap	Supported				
	Interface / RAID level		SATA 6Gb/s : RAID 0/1/5/6/10/50/60 (option), SAS 12Gb/s : RAID 0/1/5/6/10/50/60 (option)				
	Optical disk drive		Internal or external drive (option) *1				
	FDD		Option: Flash FDD (1.44MB) *2				
	Expansion bay		N/A				
	Supported slots		1x PCI Express 3.0 (x8 lane, x8 socket)(Full hight, length 220 mm) 1x PCI Express 3.0 (x8 lane, x16 socket)(Full hight, length 220 mm)(option) 1x PCI Express 3.0 (x8 lane, x8 socket) (Low profile, length 220 mm) 1x PCI Express 3.0 (x16 lane, x16 socket) (Low profile, length 220 mm) (option) 1x PCI Express 3.0 (x8 lane, x8 socket) (Dedicated to RAID controller) 1x PCI Express 3.0 (x8 lane, x8 socket) (Dedicated to LOM card)				
Graphics	Chip / VideoRAM		Embedded management controller chip / 32 MB				
	Graphic display / resolution		16,770,000 colors: 640x840, 800x600, 1,024x768, 1,280x1,024, 1,600x1,200				
Interface			5x USB3.0 (2x front, 2x rear, 1x internal), 3x USB2.0 (2x rear, 1x internal) 2x Analog RGB (Mini D-Sub15 pin, 1x front, 1x rear) 1x Serial port (RS-232C compliant / D-Sub 9 pin, Serial port A, 1x rear, optional port can be used (up to two ports in total), 1x Management LAN connector (1000BASE-T/100BASE-TX/10BASE-T supported, RJ45, 1x rear) (With optional LOM card, 4x 1000BASE-T, 2x 10GBASE-T, 2x 10GBASE-SFP+, or 2x 1000BASE-T can be added)				
Redundant power supply			Supported (option, hot-plug available)				
Redundant fan			Supported (standard, hot-plug available)				
External dimensions (width × depth × height)			439.8 mm × 722.0 mm × 43.4 mm (front bezel / protrusions / inner rails excluded) 482.4 mm × 766.1 mm × 43.4 mm (front bezel / protrusions / inner rails included)				
Weight (Minimum *3/ Max.)			13.8 kg / 21.0 kg (including rails)				
Power supply unit			Not pre-installed (selectable option), AC power supply unit 460 W/800 W 80 PLUS Platinum compliant (bipolar grounded outlet) (hot-plug available) (Max: 2) 100 VAC/200 VAC ± 10%, 50/60 Hz ± 3 Hz (Power cable is a required option) 800 W 80 PLUS Titanium compliant (bipolar grounded outlet) (hot-plug available) (Max: 2) 100 VAC/200 VAC ± 10%, 50/60 Hz ± 3 Hz (Power cable is a required option)				
Power consumption (100V at maximum configuration, at maximum power)			585VA/581W	603VA/599W	603VA/599W	575VA/571W	603VA/599W
Power consumption (200V at maximum configuration, at maximum power)			747VA/742W	752VA/746W	751VA/745W	742VA/736W	758VA/753W
Environmental requirements Temperature/Humidity			Operating: 5 to 40°C / 20 to 80%, Storage: -10 to 55°C / 20 to 80% (no condensation either when operating or when stored)				
Main accessories			Getting Started, Safety Precautions and Regulatory Notices, one-touch rack rail, Front bezel				
Installed OS			N/A				
Supported OSs			Microsoft Windows Server 2008 R2 Standard, Microsoft Windows Server 2008 R2 Enterprise, Microsoft Windows Server 2012 Standard, Microsoft Windows Server 2012 Datacenter, Microsoft Windows Server 2012 R2 Standard, Microsoft Windows Server 2012 R2 Datacenter, VMware ESXi™ 5.5 Update 2, VMware ESXi™ 6.0				

*1 If you do not intend to install an internal DVD-ROM or an internal DVD SuperMULTI in all systems, prepare at least one external DVD-ROM per system for maintenance and OS reinstallation purposes.

*2 For the principal uses of a Flash FDD, see *Maintenance Guide*.

*3 Minimum configuration for operation (1x CPU, 2x DIMM, 1x HDD, 1x Power supply unit)

2. Interrupt Lines

Interrupt lines are assigned as factory settings as shown below. Use this table as a reference when you add optional devices.

- **Interrupt lines**

As factory settings, interrupt lines are assigned as follows.

IRQ	Peripheral Device (Controller)	IRQ	Peripheral Device (Controller)
0	System timer	12	SM Bus
1	–	13	Numeric data processor
2	–	14	–
3	COM 2 serial port	15	–
4	COM 1 serial port	16	SATA
5	PCI	17	
6	–	18	USB
7	PCI	19	USB
8	Real-time clock	20	
9	Microsoft ACPI-Compliant System	21	
10	PCI	22	
11	Motherboard resource	23	

3. Glossary

Terms	Description
BIOS Setup Utility (SETUP)	Software for setting BIOS. You can run this software by pressing <F2> key during POST.
BMC	Baseboard Management Controller (BMC) is a built-in controller that supports the IPMI version 2.0 protocol. BMC can manage the server hardware.
BMC RESET Switch	A switch for resetting the BMC of the server. This resets the BMC without clearing the BMC settings. Use the switch if the problem on the BMC occurs.
DUMP Switch	A switch that is used for collecting the memory dump if an error occurs. You can specify the destination of the dump by using the OS function.
EXPRESSBUILDER	Standard software for setting up the server easily. This also includes several useful applications and instruction manuals.
EXPRESSSCOPE ENGINE 3	A name of BMC for NEC Express5800 series.
EXPRESSSCOPE Profile Key	A removable flash memory that stored the settings of BIOS and BMC. If the motherboard of the server is replaced, you can use former settings when moving this flash memory from the former motherboard.
Express Report Service	Software that can report the server failure to the contact center by E-mail or modem. This software is installed with NEC ESMPRO ServerAgentService to the server.
Express Report Service (HTTPS)	Software that can report the server failure to the contact center by HTTPS. This software is installed with NEC ESMPRO ServerAgentService to the server.
Express Report Service (MG)	Software that can report the server failure to the contact center by E-mail, modem or HTTPS without NEC ESMPRO ServerAgentService. This software is installed with NEC ESMPRO Manager to "PC for Management".
ExpressUpdate	A feature for updating BIOS, firmware, driver, or software of the server. This feature is available when NEC ESMPRO Manager cooperates with EXPRESSSCOPE ENGINE 3 and ExpressUpdate Agent.
ExpressUpdate Agent	Software for performing ExpressUpdate. This is installed to the server.
Flash FDD	An optional USB device that can use as a floppy disk drive.
Internal Flash Memory	A built-in flash memory that stored EXPRESSBUILDER as standard. You can start EXPRESSBUILDER from it without DVD when pressing <F3> key during POST.
NEC ESMPRO	Standard software for the server management. This consists of several applications for managing or monitoring.
NEC ESMPRO Agent Extension	Software for performing the scheduled operations. This works with NEC ESMPRO Manager.
NEC ESMPRO Manager	Software for managing plural servers on network.
NEC ESMPRO ServerAgentService	Software for monitoring the server. This works with NEC ESMPRO Manager. You can choose Service Mode or Non-Service Mode when installing this software. Service Mode resides as the OS service and Non-Service Mode does not use the OS service to reduce the OS resources such as memory or CPU.
OEM driver	A Windows driver for the mass storage device.
OS standard installer	An installer that stored in Windows installation disc. Use this installer if you want to install the OS manually.
Offline tools	Software that can confirm or change IPMI data such as SEL, SDR, or FRU. You can start Offline tools when pressing <F4> key during POST.
PC for Management	A computer for managing the server on network. A general Windows/Linux computer can be used as "PC for Management".
Product Info Collection Utility	Software for collecting several hardware/software statuses or event logs. You can easily collect the data for the server maintenance by using this software.
RAID Configuration Utility	Software for configuring RAID arrays. You can run this software during POST.
Server Configuration Utility	Software for setting BIOS or BMC. You can use as Windows application or run this software when pressing <F4> key during POST. This software is the same as BMC Configuration of former models.
Starter Pack	Software package for the server. This software includes the customized drivers for Windows. This must be installed before using Windows on the server.
TPM Kit	An optional product of Trusted Platform Module for the server.
Universal RAID Utility	Software for setting RAID arrays on Windows/Linux. This software is operated on "PC for Management" with NEC ESMPRO Manager.
Windows OS parameter file	A file that saved settings for installing Windows. You can install with the saved settings in this file when setting Windows with EXPRESSBUILDER.

4. Revision Record

Document Number	Date Issued	Description
10.112.01-101.01	April 2016	Newly created
10.112.01-101.02	May 2016	Thoroughly revised

[MEMO]

NEC Express Server

Express5800/R120g-1M
User's Guide

May 2016

NEC Corporation
7-1 Shiba 5-Chome, Minato-Ku
Tokyo 108-8001, Japan

© NEC Corporation 2016

The contents of this manual may not be copied or altered without the prior written permission of NEC Corporation.