

User's Guide

NEC Express Server
Express5800 Series

Express5800/R120f-2M EXP802




Chapter 1 General Description

Chapter 2 Preparations

Chapter 3 Setup

Chapter 4 Appendix

Documents Provided with This Product

Documents for this product are provided as accompanying booklets () and as electronic manuals () stored within EXPRESSBUILDER DVD ()



Safety Precautions and
Regulatory Notices

Describes points of caution to ensure the safe use of this server.
Read these cautions before using this server.



Getting Started

Describes how to use this server, from unpacking to operations.
Refer to this guide as you begin for an overview of this server.



EXPRESSBUILDER



User's Guide

Chapter 1: General Description

Overviews, names, and functions of the server's parts

Chapter 2: Preparations

Installation of additional options, connection of peripheral devices,
and ideal location for this server

Chapter 3: Setup

System BIOS configurations and summary of EXPRESSBUILDER

Chapter 4: Appendix

Specifications and other information



Installation Guide (Windows)

Chapter 1: Installing Windows

Installation of Windows and drivers, and important information for
installation

Chapter 2: Installing Bundled
Software

Installation of bundled software, such as NEC ESMPRO and
Universal RAID Utility



Maintenance Guide

Chapter 1: Maintenance

Server maintenance and troubleshooting

Chapter 2: Useful Features

Useful features and the detail of system BIOS settings, RAID
Configuration Utility, and EXPRESSBUILDER

Chapter 3: Appendix







Error messages and Windows Event Logs



Other documents

Provides the detail of NEC ESMPRO, Universal RAID Utility, and the other features.

Contents

Documents Provided with This Product.....	2
Contents	3
Notations Used in This Document	6
Notations used in the text.....	6
Optical disk drives.....	6
Hard disk drives	6
Removable media	6
Abbreviations of Operating Systems (Windows)	7
POST	7
BMC	7
Trademarks	8
License Agreement Notice.....	9
Warnings and Additions to This Document	12
Latest editions.....	12
Safety notes	12
Safety precautions	13
Handling precautions (for proper operations).....	15
Handling precautions (for anti-static measures).....	16
Chapter 1 General Description.....	18
1. Introduction	19
2. Accessories.....	20
3. Features.....	21
3.1 Firmware and Software Version Management	24
4. Names and Functions of Parts.....	25
4.1 Front View (With Front Bezel).....	25
4.2 Front View (Without Front Bezel).....	26
4.3 Rear View	27
4.4 External View.....	28
4.5 Internal View	29
4.6 Motherboard	30
4.7 Status Indicators	32
4.7.1 POWER LED ()	32
4.7.2 STATUS LED 1,2 ().....	32
4.7.3 LINK/ACT LED ( ,  ,  , )	34
4.7.4 Optical Disk Drive Access LED (option).....	34
4.7.5 UID LED (ID).....	34
4.7.6 Power Capping LED	34
4.7.7 LED on a hard disk drive	35
4.7.8 LEDs for LAN connectors	36
4.7.9 AC POWER LED on Power Unit.....	37

Chapter 2	Preparations	38
1.	Installing Internal Optional Devices	39
1.1	Safety Precautions	39
1.2	Anti-static Measures	40
1.3	Overview of Installation and Removal	41
1.4	Confirming Servers (UID Switch)	43
1.5	Removing Front Bezel	44
1.6	Removing Top Cover	45
1.7	Removing PCI Riser Card	46
1.8	Removing Support Bar	47
1.9	Removing Air Duct	48
1.10	TPM Kit	49
1.10.1	Installation	49
1.11	Processor (CPU)	50
1.11.1	Maximum number of processor cores supported by this server	50
1.11.2	Installation	51
1.11.3	Replacement / Removal	54
1.12	DIMM	55
1.12.1	Maximum supported memory size	55
1.12.2	Memory Clock	56
1.12.3	Memory RAS Feature	57
1.12.4	DIMM installation order	58
1.12.5	Installation	60
1.12.6	Removal / Replacement	61
1.12.7	Using Memory RAS Feature	62
1.13	Flash Backup Unit for RAID Controller	70
1.13.1	Handling precautions	70
1.13.2	Installing N8103-181 Flash Backup Unit	70
1.13.3	Removal	72
1.13.4	Installing FBU for N8103-179	73
1.13.5	Removing FBU	74
1.14	LOM Card	75
1.14.1	Installation	75
1.14.2	Removal	76
1.15	Additional / Redundant Fan Unit	77
1.15.1	Installation	78
1.15.2	Replacement / Removal	79
1.16	Backup Device	80
1.16.1	Installation	80
1.16.2	Removal	82
1.17	PCI Card	83
1.17.1	Notes	83
1.17.2	Supported PCI cards and available slots	85
1.17.3	Installation	89
1.17.4	Removal	90
1.17.5	Installing RAID Controller	91
1.18	Additional 2.5-inch HDD Cage	93
1.18.1	Installation	93
1.18.2	Removal	96
1.19	Optical Disk Drive	97
1.19.1	Installation	97
1.19.2	Removal	98
1.20	Use of Internal Hard Disk Drives in the RAID System	99
1.20.1	Connecting cables	100
1.20.2	Notes on Building RAID System	102
1.21	Installing Air Duct	103
1.22	Installing Support Bar	103
1.23	Installing PCI Riser Card	103
1.24	Installing Top Cover	103

1.25	Hard Disk Drive.....	104
1.25.1	Installation.....	105
1.25.2	Removal	106
1.25.3	Replacing a hard disk drive in the RAID System (Auto Rebuild)	107
1.26	Power Supply Unit	108
1.26.1	Cold Redundant Feature	108
1.26.2	Installation.....	109
1.26.3	Replacing a failing power supply unit.....	111
1.27	Installing Front Bezel	112
2.	Installation and Connection	113
2.1	Installation.....	113
2.1.1	Installing Rack	113
2.1.2	Installing the server to the rack or removing it from the rack.....	115
2.2	Connection.....	122
2.2.1	Connecting to Uninterruptible Power Supply (UPS).....	124
Chapter 3	Setup.....	125
1.	Turning on the Server	126
1.1	POST.....	127
1.1.1	POST sequence	127
1.1.2	POST error messages	128
2.	BIOS Setup Utility (SETUP)	129
2.1	Overview.....	129
2.2	Starting SETUP Utility	129
2.3	Description on On-Screen Items and Key Usage	130
2.4	Cases that Require Configuration.....	132
3.	EXPRESSSCOPE Engine 3	134
3.1	Overview.....	134
3.2	EXPRESSSCOPE Engine 3 Network Configuration.....	134
4.	EXPRESSBUILDER.....	136
4.1	Features of EXPRESSBUILDER	136
4.2	Starting EXPRESSBUILDER	136
5.	Installing Software Components.....	137
6.	Turning Off the Server.....	138
Chapter 4	Appendix	139
1.	Specifications	140
2.	Interrupt Lines	146
3.	Glossary.....	147

Notations Used in This Document

Notations used in the text

In addition to safety-related symbols urging caution, 3 other types of notations are used in this document. These notations have the following meanings.

Important	Indicates critical items that must be followed when handling the server or operating software. If the procedures described are not followed, <u>server failure, data loss, and other serious malfunctions could occur.</u>
Note	Indicates items that must be confirmed when handling the server or operating software.
Tips	Indicates information that is helpful to keep in mind when using this server.

Optical disk drives

This server is equipped with one of the following drives, depending on the order at the time of purchase. These drives are referred to as *optical disk drives* in this document.

- DVD-ROM drive
- DVD Super MULTI drive

Hard disk drives

Unless otherwise stated, hard disk drives described in this document refer to both of the following.

- Hard disk drives (HDD)
- Solid state drive (SSD)

Removable media

Unless otherwise stated, removable media described in this document refer to both of the following.

- USB memory
- Flash FDD

Abbreviations of Operating Systems (Windows)

Windows Operating Systems are referred to as follows.

Refer to Chapter 1 (1.2 Supported Windows OS) in Installation Guide (Windows) for detailed information.

Notations in this document	Official names of Windows
Windows Server 2012 R2	Windows Server 2012 R2 Standard
	Windows Server 2012 R2 Datacenter
Windows Server 2012	Windows Server 2012 Standard
	Windows Server 2012 Datacenter
Windows Server 2008 R2	Windows Server 2008 R2 Standard
	Windows Server 2008 R2 Enterprise
Windows Server 2008 *	Windows Server 2008 Standard
	Windows Server 2008 Enterprise

* Includes 32-bit Edition unless otherwise stated.

POST

POST described in this document refers to the following.

- Power On Self-Test

BMC

BMC described in this document refers to the following.

- Baseboard Management Controller

Trademarks

EXPRESSSCOPE and ExpressUpdate are registered trademark of NEC Corporation.

Microsoft, Windows, Windows Server, Windows Vista, and MS-DOS are registered trademarks or trademarks of Microsoft Corporation in the United States and other countries. Intel, Pentium, and Xeon are registered trademarks of Intel Corporation of the United States. AT is a registered trademark of International Business Machines Corporation of the United States and other countries. Adaptec, its logo, and SCSI Select are registered trademarks or trademarks of Adaptec, Inc. of the United States. Avago, LSI, and the LSI & Design logo are trademarks or registered trademarks of Avago Technologies in the United States and/or other countries. Adobe, the Adobe logo, and Acrobat are trademarks of Adobe Systems Incorporated. DLT and DLTape are trademarks of Quantum Corporation of the United States. PCI Express is a trademark of Peripheral Component Interconnect Special Interest Group.

All other product, brand, or trade names used in this publication are the trademarks or registered trademarks of their respective trademark owners.

License Agreement Notice

Open source software of following license is included in the part of this product (system BIOS).

- EDK from Tianocore.org
- UEFI Network Stack 2
- Crypto package using WPA Supplicant

Open source software of following license is included in the part of this product (Off-line Tools).

- EDK from Tianocore.org

EDK FROM TIANOCORE.ORG

BSD License from Intel

Copyright (c) 2012, Intel Corporation

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the Intel Corporation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (c) 2004 - 2007, Intel Corporation

All rights reserved. This program and the accompanying materials are licensed and made available under the terms and conditions of the BSD License which accompanies this distribution. The full text of the license may be found at <http://opensource.org/licenses/bsd-license.php>

THE PROGRAM IS DISTRIBUTED UNDER THE BSD LICENSE ON AN "AS IS" BASIS, WITHOUT WARRANTIES OR REPRESENTATIONS OF ANY KIND, EITHER EXPRESS OR IMPLIED.

UEFI NETWORK STACK 2

OpenSSL License

Copyright (c) 1998-2011 The OpenSSL Project. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgment:
"This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit.
(<http://www.openssl.org/>)"
4. The names "OpenSSL Toolkit" and "OpenSSL Project" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact openssl-core@openssl.org.
5. Products derived from this software may not be called "OpenSSL" nor may "OpenSSL" appear in their names without prior written permission of the OpenSSL Project.
6. Redistributions of any form whatsoever must retain the following acknowledgment:
"This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit
(<http://www.openssl.org/>)"

THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT ``AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com).

This product includes software written by Tim Hudson (tjh@cryptsoft.com).

CRYPTO PACKAGE USING WPA SUPPLICANT

WPA Supplicant

Copyright (c) 2003-2012, Jouni Malinen <j@w1.fi> and contributors
All Rights Reserved.

This program is licensed under the BSD license (the one with advertisement clause removed).
If you are submitting changes to the project, please see CONTRIBUTIONS file for more instructions.

License

This software may be distributed, used, and modified under the terms of
BSD license:

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name(s) of the above-listed copyright holder(s) nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Warnings and Additions to This Document

1. Unauthorized reproduction of the contents of this document, in part or in its entirety, is prohibited.
2. The contents of this document may change without prior notice.
3. Do not make copies or alter the document content without permission from NEC Corporation.
4. Every effort has been made to ensure the completeness of this document. However, if you have any concerns, or discover errors or omissions, please contact your retailer.
5. Regardless of these 4 items, NEC Corporation does not take responsibility for effects resulting from operations.
6. The sample values used in this document are not the actual values.

Keep this document nearby so that you may refer to it as necessary.

Latest editions

This document was created based on the information available at the time of its creation. The screen images, messages, and procedures **may differ from the actual screens, messages, and procedures**. Substitute as appropriate when content has been modified.

The most recent version of User's Guide, as well as other related documents, is also available for download from the following website.

<http://www.nec.com/>

Safety notes

To use this server safely, read thoroughly the "Safety Precautions and Regulatory Notices" that comes with your server. For symbols used in this document, refer to "Safety precautions".

Safety precautions

Follow the instructions in this document for the safe use of NEC Express server.

This User's Guide describes hazardous parts of the server, possible hazards, and how to avoid them. Server components with possible danger are indicated with a warning label placed on or around them (or, in some cases, by printing the warnings on the server).

In User's Guide or on warning labels, **WARNING** or **CAUTION** is used to indicate a degree of danger. These terms are defined as follows:









Indicates there is a risk of death or serious personal injury




Indicates there is a risk of burns, other personal injury, or property damage


Precautions and notices against hazards are presented with one of the following three symbols. The individual symbols are defined as follows:

	Attention	This symbol indicates the presence of a hazard if the instruction is ignored. An image in the symbol illustrates the hazard type.	(Example)  (Electric shock risk)
	Prohibited Action	This symbol indicates prohibited actions. An image in the symbol illustrates a particular prohibited action.	(Example)  (Do not disassemble)
	Mandatory Action	This symbol indicates mandatory actions. An image in the symbol illustrates a mandatory action to avoid a particular hazard.	(Example)  (Disconnect a plug)

(A label example used in this User's Guide)



Warning label are attached on or near the components with potential hazards. (This label is either attached or printed on the component.) Do not remove or black out this label and keep it clean. If no label is attached or printed on the server, or if there is a label coming off or stained, contact your sales representative.



Handling precautions (for proper operations)

Be sure to observe the following precautions for the proper functioning of the server. Ignoring the precautions may cause server malfunction or failure.

- Do not use any cell phone or PHS and switch off them near the server. Electric waves from such devices can cause server to malfunction.
- Install the server in an appropriate place. For details about the installation location, refer to *Chapter 2 Preparations (2. Installation and Connection)*.
- Before connecting/removing cables to/from peripheral devices, make sure that the server is off and unplug the power cord, if they are non plug-and-play devices.
- Connect the provided power cord to a 100/200 VAC outlet.
- Make sure that the access LED on the server is off before turning off the power or ejecting an optical disk.
- Wait for at least 30 seconds before connecting power cord to power outlet after disconnecting it.
- If any Uninterruptible Power Supply unit is connected, set it to wait for at least 30 seconds before turning on the server after power off.
- Do not press the POWER switch to turn on the server before the STATUS LED (amber) is unlit.
- Wait for at least 30 seconds before turning on the server after turning off the server.
- Turn off the server and unplug the power cord before moving it.
- Regularly clean the server to prevent various types of failure. (Refer to *Chapter 1 Maintenance (2. Daily Maintenance)* in "Maintenance Guide" for details about cleaning.)
- Momentary voltage drop may occur due to lightning strike. To prevent this, use of UPS is recommended.
- We do not guarantee that any copy-protected CD that does not conform to standards will play on the server's optical disk drive.
- In the following cases, check and adjust the system clock before operation.
 - After transportation
 - After storage
 - After the server is used following a period of disuse, in which storage conditions did not conform to those that guarantee server operations (temperature: 10 to 40°C; humidity: 20% to 80%).
- Check the system clock approximately once per month. Use of a time server (NTP server) is recommended if high accuracy timing is required by the system.
- Observe the storage conditions (Temperature: -10°C to 55°C, Humidity: 20% to 80%, No condensation of moisture) to store the server.
- Do not power off or reset the server, nor disconnect the power cord before POST completes.
- If this server, internal optional devices, and media set for the backup devices (tape cartridges) are moved from a cold place to a warm place in a short time, condensation will occur and cause malfunctions and failures when these are used in such state. To protect important stored data and property, make sure to wait for a sufficient period to use the server and components in the operating environment.

Reference: Time effective at avoiding condensation in winter (more than 10°C differences between the room temperature and atmospheric temperature)

Disk devices: Approximately 2 to 3 hours Tape media: Approximately 1 day
- For optional devices, we recommend you use our NEC products. Even if they are successfully installed or connected, installation of unsupported devices can cause the server to malfunction or even failure. You will be charged to repair failure or damage caused by use of such products even within warranty period.

Handling precautions (for anti-static measures)

The server contains electronic components sensitive to static electricity. Avoid failures caused by static electricity when installing or removing any optional devices.

- **Wearing Anti-static Wrist Strap Or Anti-static Gloves**
Wear a wrist strap on your wrist and connect the wire to the chassis. If there is no wrist strap, touch an unpainted metal surface of the chassis connected to the ground to discharge static electricity from your body before touching the component. Touch the metal part occasionally to discharge the static electricity while working on the component.
- **Checking the Workplace**
 - Work on an anti-static floor or concrete floor.
 - If you work on a place where static electricity is likely to be generated (e.g. carpet), be sure to provide anti-static protection.
- **Using the Work Table**
Place the server on a mat with Electrostatic Discharge (ESD) protection.
- **Clothing**
 - Do not wear wool or synthetic clothes.
 - Wear anti-static shoes.
 - Remove any kind of metal accessories such as a ring, bracelet or wrist watch.
- **Handling of Components**
 - Keep the component in an anti-static bag until you install it to the server.
 - Hold the component by the edges to avoid touching any terminals or mounting parts.
 - Place the component in an anti-static bag when storing or moving them.
- **Handling of Cables**
When connecting a cable (e.g., LAN cable), static electricity may also be charged due to friction against the floor. Connecting the charged cable with an I/O device may cause damage to the devices in the system. It is recommended to use a product such as electrostatic discharge kit to eliminate the static charge before connecting the cable.
- **Installing and Uninstalling the Optional Device**
 - To avoid electric hazard and malfunction, be sure to turn off the power switch of the server and unplug the power cord from the outlet before installing or uninstalling any optional device.
 - If the device is hot-swappable, you do not need to turn off the power switch.
 - The device contains static-sensitive electronic components. When installing or uninstalling the optional device, wear an anti-static wrist strap on your wrist to avoid a failure caused by the static electricity. To use the strap, connect the wire to the chassis.

Tips for your health and safety

Using a computer extensively may affect different parts of your body. Here are tips you should follow while working on a computer to minimize strain on your body.

Keep proper posture


The basic body position for using a computer is sitting straight with your hands on the keyboard parallel with the floor, and your eyes directed slightly downward toward the monitor. With the proper posture described above, no unnecessary strain is applied on any part of your body, in other words when your muscles are most relaxed.

Working on the computer with bad posture such as hunching over or being too close to the monitor could cause fatigue or deteriorated eyesight.




Adjust the angle of your display

Most display units are designed for adjustment of the horizontal and vertical angles. This adjustment is important to prevent the screen from reflecting bright lights and to make the display contents easy to see. Working without adjusting the display to a comfortable angle makes it difficult for you to maintain a proper posture and you will get tired easily. Adjust the viewing angle before use.




Adjust the brightness and contrast of the display

Display screens have functions to control brightness and contrast. The most suitable brightness/contrast depends on age, individuals, and environment, so adjust it to suit your preferences. A too bright or too dark display is bad for your eyes.



Adjust the angle of keyboard

Some keyboards are ergonomically designed, which allow the angle to be adjusted. Adjusting the angle of the keyboard is effective to reduce tension on your shoulders, arms, and fingers.



Clean your equipment

Keeping your equipment clean is important not only for the appearance but also for functional and safety reasons. A dusty monitor makes it difficult to see the display contents, so clean it regularly.

Take rest breaks

When you feel tired, take a break. Light exercise is also recommended.



NEC Express5800 Series Express5800/R120f-2M

1

General Description

This chapter introduces the features of this server and the name of each part.

1. Introduction

2. Accessories

Verify the condition of your server's accessories.

3. Standard Features

This section describes the server's features and the server management.

4. Names and Functions of Parts

This section describes the name of each part contained in this server.

1. Introduction

Thank you for purchasing this NEC Express5800 Series product.

This high performance server is powered by the latest microprocessor "Intel® Xeon® processor.

NEC's latest technology and architectures realize high-power and high-speed operation that cannot be matched by existing servers.

The server is designed with consideration of not only reliability but also expandability, which enables you to use it as a network server.

Read this document before using the server thoroughly to fully understand handling of Express5800 Series Server and appreciate its functions to the maximum extent.

2. Accessories

The carton box contains various accessories which are required for setup or maintenance. **Make sure you have them all** for future use.

- **Front Bezel**
- **Bezel Lock Key (attached to Front Bezel)**
- **Slide Rails**
- **EXPRESSBUILDER^{*1}**
- **Safety Precautions and Regulatory Notices**
- **SAS/SATA cable (RAID controller is unmounted)**
- **Getting Started**
- **Fixing screws for internal backup device (x6)**

^{*1} Instruction manuals are stored in EXPRESSBUILDER. Adobe Reader is required to read or print them.

Make sure you have all accessories and inspect them. If an accessory is missing or damaged, contact your sales representative.

Important


The chassis serial number plate and maintenance label is located on the server. If the serial number does not match the number on the warranty, you may not be guaranteed against failure even within the warranty period. Contact your sales representative if they do not match.

3. Features

The server has the following features:

High performance

- Intel® Xeon® processor
 - N8101-768F : E5-2603 v3 (1.60GHz 6Core)
 - N8101-769F : E5-2609 v3 (1.90GHz 6Core)
 - N8101-770F : E5-2620 v3 (2.40GHz 6Core)
 - N8101-771F : E5-2623 v3 (3GHz 4Core)
 - N8101-772F : E5-2637 v3 (3.50GHz 4Core)
 - N8101-773F : E5-2640 v3 (2.60GHz 8Core)
 - N8101-774F : E5-2643 v3 (3.40GHz 6Core)
 - N8101-776F : E5-2660 v3 (2.60GHz 10Core)
 - N8101-777F : E5-2667 v3 (3.20GHz 8Core)
 - N8101-778F : E5-2670 v3 (2.30GHz 12Core)
 - N8101-779F : E5-2690 v3 (2.60GHz 12Core)
 - N8101-931F : E5-2697 v3 (2.60GHz 14Core)
 - N8101-933F : E5-2699 v3 (2.30GHz 18Core)
- Turbo Boost Technology feature *1
- Hyper Threading Technology feature *1
- High-speed memory access (DDR4 1600/1866/2133 supported) *2
- High-speed disk access (SATA 6Gb/s, SAS 12Gb/s supported)
- High-speed 10GBASE-SFP+ / 10GBASE-T / 1000BASE-T/100BASE-TX / 10BASE-T interface (10Gbps / 1Gbps / 100Mbps / 10Mbps supported) can be selected



High reliability

- Processor throttle-ring feature
- Memory monitoring feature (error correction/error detection)
- Memory degeneracy feature (logical isolation of a failed device)
- Memory x4 SDDC feature
- Memory mirroring, memory LockStep (x8 SDDC), memory sparing features
- Memory throttle-ring feature
- Bus parity error detection
- Temperature detection
- Error detection
- Internal fan monitoring feature
- Internal voltage monitoring feature
- Power redundant feature (hot swapping supported)
- RAID System (Disk Array) (An option card is required.)
- Auto rebuild feature (hot swapping supported)
- BIOS password feature
- The security lock that comes with Front Bezel
- Redundant fan configuration
- Fan (hot swapping supported)
- HDD (hot swapping supported)

Management Utilities

- NEC ESMPRO
- ExpressUpdate
- Remote controlling feature (EXPRESSSCOPE Engine 3)
- RAID System management utility (Universal RAID Utility)
- Hard disk drive monitoring
- Power supply monitoring

Power saving and noiseless design

- Selection of power unit appropriate to environment, work load, and configuration
- Power consumption monitoring feature
- Power control feature
- 80 PLUS® Platinum / Titanium certified high efficiency power supply *5
- Fan control appropriate to environment, work load, and configuration
- Silent sound design
- Enhanced Intel SpeedStep® Technology supported
- Cold redundant feature

Expandability

- PCI Express 3.0 (x8 lanes): 3 slots (Full height) *6
- PCI Express 3.0 (x8 lanes): 3 slots (Low profile)
- PCI Express 3.0 (x8 lanes): 1 slot (dedicated to RAID Controller)
- PCI Express 3.0 (x8 lanes): 1 slot (dedicated to LOM card)
- Large capacity memory of up to 768 GB *3
- Can upgrade to multi-processor system with up to two processors
- Expansion Bay (for hard disk drives): 16 slots *4
- Optical disk drive bay provided as standard
- Expansion Bay (for backup unit) provided as standard
- USB3.0 interface (Front: 2 ports, rear: 2 ports, internal: 1 port)
- USB2.0 interface (Rear: 2 ports, internal: 1 port)
- Management LAN port (1 port)
- With optional LOM card, two to four LAN ports can be added.

Ready to use

- No cable connection is required to install a hard disk drive, additional power supply unit, and redundant fan unit (hot swap supported).
- Slide rails for each installation

Many built-in Features

- Redundant power supply system supported (valid when optional power supply unit is installed)
- El Torito Bootable CD-ROM (no emulation mode) format supported
- Software power-off
- Remote power-on feature
- AC-Link feature
- Remote console feature
- Power switch mask
- Connector for display unit provided on front panel
- Baseboard Management Controller (BMC) conforming to IPMI v2.0

Self-diagnosis

- Power On Self-Test (POST)
- Test and Diagnosis (T&D) utility

Easy setup

- EXPRESSBUILDER (setup utility)
- BIOS Setup utility (SETUP)

Maintenance features

- Off-line Tools
- Memory dump feature using DUMP Switch
- Feature to backup and restore BIOS/BMC settings using EXPRESSSCOPE Profile Key

*1: Unsupported on Xeon® processor E5-2603 v3, E5-2609 v3 embedded models.

*2: Processor core speed depends on processor type, number and type of DIMMs installed.

*3: In 2-CPU configuration. Up to 384 GB in 1-CPU configuration.

*4: When N8154-69 2.5-inch HDD cage is installed. 8 slots in standard configuration.

*5: When N8181-118F power unit is installed. Power supply unit N8181-121F/122F/123F is compliant to 80 Plus® Platinum.

*6: Can be changed to PCI Express 3.0: 1 slot (x16 lanes) + PCI Express 3.0: 1 slot (x8 lane) by using optional riser card.

***3.1* Firmware and Software Version Management**


Use of NEC ESMPRO Manager, ExpressUpdate Agent, and EXPRESSSCOPE Engine 3 allows you to manage versions of firmware and software as well as update them by applying update packages.

This feature automatically updates modules without stopping the system just by specifying the updating packages from NEC ESMPRO Manager.

4. Names and Functions of Parts

This section describes the names of the server parts.

4.1 Front View (With Front Bezel)



(1) Front Bezel

The cover to protect the front of the server. This cover can be locked with the provided Bezel Lock Key.

(2) Key Slot

The slot for Bezel Lock Key that is used to lock Front Bezel.

(3) LINK/ACT LED

This LED turns on when the server is connected to the network. (See page 34.)

(3)-1: LAN connector 1

(3)-2: LAN connector 2

(3)-3: LAN connector 3

(3)-4: LAN connector 4

LEDs for LAN3 and LAN4 are lit when optional LOM card (N8104-154/156) is installed.

(4) Power Capping LED

This LED indicates ECO status of the server.

(5) STATUS LED 1,2

This LED indicates the server status. (See page 32.)


(6) Unit ID (UID) LED

This LED turns on when UID Switch is pressed. Commands from the software also cause it to turn on or flash. (See page 34.)

(7) POWER LED

This LED indicates power status of server. (See page 32.)

4.2 Front View (Without Front Bezel)



(8) DISK LED

DISK LED 1 (green), DISK LED 2 (amber)
The LED provided for each HDD.
This LED indicates hard disk drive status. (See page 35.)

(9) 2.5-inch hard disk drive bay

The bay where HDD are installed. The sequential numbers indicate the corresponding slot numbers. All bays include Dummy Trays.

(10) USB connectors (front)

These connectors are used to connect devices that support the USB interface.

(11) RESET switch

Press this switch to reset the server.

(12) DUMP Switch (NMI)

When DUMP Switch is pressed, memory dump is performed.

(13) BMC RESET Switch

The switch to reset BMC of this server. Use the switch only when there is a problem with EXPRESSSCOPE Engine 3 (BMC).

To use this switch, press it at least five seconds.

(14) POWER Switch/LED

The switch to turn the server on and off. Press once to turn on the server. POWER LED lights when it is on. Press it again to turn off the server. Hold down the switch for 4 seconds or longer to forcibly turn off the server.
(See page 32.)

(15) Unit ID (UID) Switch/LED

The switch to turn on and off UID LED.
Pressing the switch once turns on UID LED and pressing again turns off the LED.
Commands from the software also cause it to turn on or flash. (See page 34.)

(16) Display connector *1

Connect a display unit. This connector is exclusively used with the display connector on rear panel.

(17) Pull-out Tab

A label indicating the part number and serial number of the server is located on Pull-out Tab.

(18) 2.5-inch additional HDD cage bay

Install N8154-68 2.5-inch HDD cage in this bay.

(19) Additional bay (for file backup unit)


Install an optional RDX drive in this bay.

(20) Optical disk drive bay

Bay to install an optical disk drive.
Either of the following drive can be installed.
– DVD-ROM drive
– DVD SuperMULTI drive

*1 The tray of optical disk drive may not open depending on the connector of display cable. In this case, disconnect the display cable and then open/close the tray.

4.3 Rear View



(1) Power unit (Power supply slot 1)

The power unit supplies DC power to the server.

(2) AC Inlet

This socket is used to connect the power cord.

(3) AC POWER LED

The LED indicates power supply status. (See page 37.)

(4) Thumbscrew

Used to secure the top cover.

(5) Slot for full-height PCI card

Slot to install a full-height PCI card. "1C", "2C", and "3C" indicate PCI slot number.

(6) Slot for low-profile PCI card

Slot to install a low-profile PCI card. "1D" and "2D" indicate PCI slot number..

(7) Blank cover (for power unit #2)

Remove this cover to install an additional power unit.

(8) USB connectors

These connectors are used to connect devices that support the USB interface.

(9) LINK/ACT LED *1

The LED indicates the access status of LAN. (See page 36.)

(10) LAN connectors *1

1000BASE-T/100BASE-TX/10BASE-T supported network connectors

(10)-1: LAN port connector 1

(10)-2: LAN port connector 2

(10)-3: LAN port connector 3

(10)-4: LAN port connector 4

If Shared BMC LAN feature is enabled in ROM Utility, LAN connector 1 can also be used as the management LAN port. Sharing port is not recommended from the point of performance and security.

(11) SPEED LED *1

The LED indicates the transfer speed of LAN ports. (See page 36.)

(12) Management LAN connector

A LAN connector which supports 1000BASE-T/100BASE-TX/10BASE-T. This port cannot be used as a data transmission port. This port is used for connecting to EXPRESSSCOPE Engine 3.

(13) Serial port A (COM) connector

This connector is used to connect devices that support a serial interface. Note that it is not possible to directly connect to a leased line.

(14) Display connector

The connector to connect a display unit. This connector is exclusively used with the display connector on front panel.

(15) UID Switch/LED


The switch to turn on and off UID LED.

Pressing the switch once turns on UID LED and pressing again turns off the LED.

Commands from the software also cause it to turn on or flash. (See page .34)

*1 LOM card is optional. The figure above shows when N8104-154 is installed.


4.4 External View



- (1) Top Cover (front)
- (2) Release Button.
- (3) Top Cover (rear)

4.5 Internal View

The duct is not shown in the figure below.



(1) Front Panel Board

(mounted beneath the protective cover)

(2) Protective cover

(3) Backplane

(4) Cooling Fan

- 1 FAN1R
- 2 FAN2R
- 3 FAN3R
- 4 FAN4R
- 5 FAN5R (option)
- 6 FAN1F (option)
- 7 FAN2F (option)
- 8 FAN3F (option)
- 9 FAN4F (option)
- 10 FAN5F (option)

FAN1 to FAN4 are factory installed. FAN 5 is required in 2-CPU configuration. FAN6 to FAN10 are used when optional redundant fan unit is installed.

(5) Support bar

Can install battery unit on this bar.

(6) Processor (CPU)

Mounted beneath the heat sink.

(7) DIMM (optional)

(8) Motherboard

(9) Slot dedicated to LOM Card

Assigned PCI slot number if "1B".

(10) Riser Card


(11) Power Supply Unit

(12) Slot dedicated to RAID Controller

Assigned PCI slot number if "1A".

(13) Expansion bay

4.6 Motherboard



- (1) **Processor (CPU) socket**
 - 1: Processor #1 (CPU #1)
 - 2: Processor #2 (CPU #2)
- (2) **DIMM socket**
- (3) **Front panel connector**
- (4) **Fan board connector**
- (5) **Power connector for fan unit**
- (6) **Power connector for SATA optical disk drive**
- (7) **Power connector for HDD cage**
- (8) **Power connector**
 - 1: Standard power unit (POW #1)
 - 2: Optional power unit (POW #2)
- (9) **LAN mezzanine card connector**
- (10) **Lithium battery**
- (11) **Clear CMOS Jumper switch**
- (12) **Clear Password Jumper switch**
- (13) **Unused connector**
- (14) **USB memory module connector**
- (15) **HDD BP connector**
- (16) **Connector for option COM**

Connect an additional RS-232C connector kit N8117-01A to use this port as a serial port.
- (17) **SPI Mezzanine connector**

EXPRESSSCOPE Profile Key (SPI memory) has been installed, where BIOS and BMC configuration data is stored. Relocate it when replacing motherboard to inherit configuration data.
- (18) **Power connector for optional HDD cage**
- (19) **Front video connector**
- (20) **TPM kit connector**
- (21) **SATA connector (for optical disk drive)**
- (22) **SATA connector**
- (23) **PCI Riser Card connector**

For the supported card specifications, refer to *Chapter 2 (1.11 PCI card)*.
- (24) **Connectors for external devices** (See page 27.)
- (25) **RAID Controller connector**
- (26) **USB connector (front)**
- (27) **USB connector for file backup unit**
- (28) **Power connector for expander board**

4.7 Status Indicators

4.7.1 POWER LED ()

POWER LED indicates power ON/OFF status of the server.

POWER LED pattern	Description
On (green)	The server is normally powered on.
Off	The server is off-powered. The server is in halt status.

4.7.2 STATUS LED 1,2 ()

While hardware is operating normally, STATUS LED 1 lights green. STATUS LED 2 is off. STATUS LED 1 is off or STATUS LED 2 lights/flashes amber if there is a hardware failure.

Tips

If NEC ESM PRO is installed, you can view error logs to check the causes of failures.

STATUS LED 1,2 pattern		Description	Solution
STATUS LED 1	STATUS LED 2		
On (green)	Off	The server is operating normally.	—
On (green)	On (amber)	Initialization of BMC is in progress.	Wait until initialization completes.
Flashing (green)	Off	Memory is in a degraded state	Identify the device in degraded state by using BIOS Setup Utility (SETUP), and replace it as soon as possible.
		A correctable memory error has often occurred.	
		Operating while CPU error is detected.	
		In redundant power configuration, power is not supplied to either of power unit.	
Off	Off	The power is off.	Turn on the server.
		POST is in progress.	Wait for a while. STATUS LED will turn green after POST completes.
		Watchdog timer expired.	Turn the power off and then turn it on. If POST screen displays any error message, take notes of the message, and contact your sales representative.
		Memory dump is being requested. (e.g. when DUMP Switch is pressed) Note: It remains green if the dump is caused by software.	Wait until the memory dump is completed.

STATUS LED 1,2 pattern		Description	Solution
STATUS LED 1	STATUS LED 2		
Off	On (amber)	A temperature alarm was detected.	Check the internal fan for dusts. Also check if the fan unit is properly connected. If the LED indication does not change, contact your sales representative.
		A CPU error occurred.	Turn the power off and then turn it on.
		Abnormal CPU temperature is detected.	If POST displays any error message, take notes of the message, and contact your sales representative.
		A PCI system error occurred	
		A PCI parity error occurred	
		A PCI bus error occurred.	Contact your sales representative.
		A voltage alarm was detected.	
		Fan error was detected.	
		Sensor error was detected.	
		A CPU temperature alarm was detected.	
Off	Flashing (amber)	An error occurred on Intel Node Manager (one of the features of EXPRESSSCOPE Engine 3).	
		Power Supply Unit is failing (in power redundant configuration).	Contact your sales representative.
		A fan alarm was detected.	Check if the internal fan cable is properly connected. If the LED indication does not change, contact your sales representative.
		A temperature warning was detected.	Check the internal fan for dusts. Also check if the fan unit is properly connected. If the LED indication does not change, contact your sales representative.
		A voltage warning was detected	Contact your sales representative.
		One or more hard disk drives are failing (excluding RAID0 or non-RAID configuration).	

4.7.3 LINK/ACT LED (□□1, □□2, □□3, □□4)

LINK/ACT LED on front panel indicates the status of LAN port.

LEDs □□3 and □□4 turns on, off, or flashes when an optional LAN riser card is installed.

LINK/ACT LED pattern	Description
On (green)	The server is connected with network normally.
Flashing (green)	The server is accessing network.
Off	The server is disconnected from network.

4.7.4 Optical Disk Drive Access LED (option)

The LED for optical disk drive at the front of the server flashes when a CD or DVD is being accessed.

4.7.5 UID LED (ID)

UID LED is provided one each at the front and rear of the server. If you press UID Switch provided at the front or rear of the server, the light turns on. If you press it again, the light turns off. It flashes when commands from software are received. This LED is used to identify the target server among multiple servers installed in a rack. Especially when performing maintenance from behind the server, lighting the LED will help you to identify which server to work with.

UID LED pattern	Description
On (blue)	The UID switch is pressed.
Off	The UID switch is not pressed.

4.7.6 Power Capping LED

Power Capping LED indicates enabled/disabled status of PowerCapping feature as shown below.


Power Capping LED pattern	Description
On (green)	Power Capping feature is enabled.
Flashing (green)	Power Capping is enabled and power control (capping) is working.
Off	Power Capping feature is disabled.

Note

The Power Capping LED seems to be lit or flashing amber when STATUS LED is lit or flashing amber. The amber STATUS LED indicates a hardware failure. Contact your service representative.

4.7.7 **LED on a hard disk drive**

Each HDD is equipped with DISK LED.



DISK1,2 LED pattern		Description	Solution
DISK LED 1	DISK LED 2		
Flashing (green)	Off	Hard disk drive is being accessed.	—
Off	On (amber) (only when RAID system is configured)	Hard disk drive is failing.	Contact your sales representative.
Flashing (green)	Flashing (amber) (only when RAID system is configured)	Rebuild is in progress. When the failed hard disk drive is replaced, rebuild process starts automatically (auto rebuild feature).	—
Off	Off	Hard disk drive is halted.	—

Important


Observe the following precautions whenever you use the auto rebuild feature.

- Do not turn off or reboot the server while a HDD is being rebuilt.
- Wait at least 90 seconds before installing a HDD after removing one.
- Do not replace a HDD while another HDD is being rebuilt.

4.7.8 LEDs for LAN connectors

The LAN connectors on rear panel have LINK/ACT LED and SPEED LED.

The figure below shows when an optional LOM card N8104-154 is installed.



• LINK/ACT LED (Gb1, Gb2, Gb3, Gb4, GbM)

This LED indicates the state of the LAN port.

LINK/ACT LED pattern	Description
On (green)	The server is connected with network normally.
Flashing (green)	The server is accessing network.
Off	The server is disconnected from network.


• SPEED LED (Gb1, Gb2, Gb3, Gb4, GbM)

This LED indicates which network interface is used.

SPEED LED pattern	Description
On (amber)	The port is operating with 1000BASE-T interface.
On (green)	The port is operating with 100BASE-TX interface.
Off	The port is operating with 10BASE-T interface.

4.7.9 **AC POWER LED on Power Unit**

The power unit is equipped with AC POWER LED.



The following table lists LINK/ACT LED patterns.

AC POWER LED pattern	Description	Solution
On (green)	The server is powered on.	—
Flashing (green)	The power cable is connected and AC power is supplied.	—
	Cold Redundant feature is enabled.	—
On (amber)	The power cable is not connected in redundant power configuration.	Connect the power cable.
	Power unit is failing.	Contact your sales representative.
Flashing (amber)	Power unit is failing.	Contact your sales representative.
Off	The power is not supplied to the server.	Connect the power cable. If it is already connected, contact your sales representative.

NEC Express5800 Series Express5800/R120f-2M

2

Preparations

This chapter describes preparations for using this server.

1. Installing Internal Optional Devices

You can skip this section if you did not purchase any optional devices.

2. Installation and Connection

Place the server in a suitable location and connect cables following this section.

1. Installing Internal Optional Devices

This section describes the instructions for installing supported optional devices and precautions. If you did not purchase any optional device requiring installation, you may skip this section.


Important

- We recommend that optional devices be installed by a maintenance service staff from your maintenance service company authorized by NEC.
- Use only the devices and cables specified by NEC. You will be charged to repair damages, malfunctions, and failures caused by the use of any devices or cables not specified for use with this server even within the warranty period.

1.1 Safety Precautions

Be sure to observe the following precautions to install and remove optional devices properly and safely.


⚠ WARNING



Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause death or serious injury. For details, refer to *Safety Precautions and Regulatory Notices*.

- Do not disassemble, repair, or modify the server.
- Do not remove the lithium battery, NiMH battery, or Li-ion battery.
- Disconnect the power plug when installing and removing devices.

⚠ CAUTION



Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause burns, injury, and property damage. For details, refer to *Safety Precautions and Regulatory Notices*.

- Do not drop
- Do not leave the server being pulled out.
- Make sure to complete installation.
- Do not install with the cover removed.
- Do not get your fingers caught.
- High temperature
- Electrical shock

1.2 Anti-static Measures



The server contains electronic components sensitive to static electricity. Avoid failures caused by static electricity when installing or removing any optional devices.

- **Wearing Anti-static Wrist Strap Or Anti-static Gloves**
Wear a wrist strap on your wrist and connect the wire to the chassis. If there is no wrist strap, touch an unpainted metal surface of the chassis connected to the ground to discharge static electricity from your body before touching the component. Touch the metal part occasionally to discharge the static electricity while working on the component.
- **Checking the Workplace**
 - Work on an anti-static floor or concrete floor.
 - If you work on a place where static electricity is likely to be generated (e.g. carpet), be sure to provide anti-static protection.
- **Using the Work Table**
Place the server on a mat with Electrostatic Discharge (ESD) protection.
- **Clothing**
 - Do not wear wool or synthetic clothes.
 - Wear anti-static shoes.
 - Remove any kind of metal accessories such as a ring, bracelet or wrist watch.
- **Handling of Components**
 - Keep the component in an anti-static bag until you install it to the server.
 - Hold the component by the edges to avoid touching any terminals or mounting parts.
 - Place the component in an anti-static bag when storing or moving them.
- **Handling of Cables**
When connecting a cable (e.g., LAN cable), static electricity may also be charged due to friction against the floor. Connecting the charged cable with an I/O device may cause damage to the devices in the system. It is recommended to use a product such as electrostatic discharge kit to eliminate the static charge before connecting the cable.
- **Installing and Uninstalling the Optional Device**
 - To avoid electric hazard and malfunction, be sure to turn off the power switch of the server and unplug the power cord from the outlet before installing or uninstalling any optional device.
 - If the device is hot-swappable, you do not need to turn off the power switch.
 - The device contains static-sensitive electronic components. When installing or uninstalling the optional device, wear an anti-static wrist strap on your wrist to avoid a failure caused by the static electricity. To use the strap, connect the wire to the chassis.

1.3 Overview of Installation and Removal

Install/remove components by using the following procedure.

Installing/removing internal components except for hard disk drives, fan unit, and power supply unit should be done after dismounting the server from the rack. It is recommended that more than one person removes the server from the rack.

 CAUTION	
	<p>Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause burns, injury, and property damage. For details, refer to <i>Safety Precautions and Regulatory Notices</i>.</p> <ul style="list-style-type: none"> • Do not drop the server • Do not leave the server pulled out of the rack • Replace the cover after installing components • Beware of high temperatures • Do not get your fingers caught when installing components

1. If the server is mounted on a rack, use the UID switch to identify the target server.
See *Chapter 2 (1.4 Confirming Servers (UID Switch))*.
2. Remove Front Bezel.
See *Chapter 2 (1.5 Removing Front Bezel)*.
3. If the server is ON, turn it off.
See *Chapter 3 (6. Turning Off the Server)*.
4. Disconnect the power cord from the outlet and the server.

Important

- After disconnecting the power cord from the server, wait for at least 30 seconds before continuing to work because the components such as cooling fan on the motherboard might still be operating for about 30 seconds even after the power cord was disconnected.
- Make sure the AC POWER LED on power supply unit is unlit.

5. You need to pull out the server from rack and put it on a flat rigid desk when installing or removing the optional components. See *Chapter 2 (2.1 Installation)* for details.

Important

- Do not leave the server being pulled out from the rack.

6. Remove Top Cover.
See *Chapter 2 (1.6 Removing Top Cover)*.
7. Remove PCI riser card.
See *Chapter 2 (1.7 Removing PCI Riser Card)*.
8. Remove the support bar.
See *Chapter 2 (1.8 Removing Support Bar)*.
9. Depending on the components to be installed or removed, follow the procedure in order.
See *Chapter 2 (1.7 TPM Kit)* to *(1.16 Use of Internal Hard Disk Drives in the RAID System)*.

10. Mount the support bar.
See *Chapter 2 (1.22 Installing Support Bar)*.
11. Mount PCI riser card.
See *(1.23 Installing PCI Riser Card)*.
12. Attach Top Cover.
See *Chapter 2 (1.17 Installing Top Cover)*.
13. Mount the server onto the rack.
See *Chapter 2 (2.1.2 (1) Installation)*.
14. Install hard disk drives.
See *Chapter 2 (1.18 Hard Disk Drive)*.
15. Install power supply units
See *Chapter 2 (1.19 Power Supply Unit)*.
16. Attach Front Bezel.
See *Chapter 2 (1.20 Installing Front Bezel)*.

This is the end of the installation or removal procedures for internal optional devices.


Continue the setup with reference to *Chapter 2 (2.2 Connection)*.

1.4 Confirming Servers (UID Switch)

Using UID (Unit ID) Switch helps you to identify the target server.

When the server is working, before you turn the server off or disconnect a cable from the server, **be sure to identify the target server by using UID Switch first.**


To turn UID LED on, press UID Switch. When it is pressed again, the LED will be off.



1.5 Removing Front Bezel


You need to remove the front bezel when pressing the POWER switch or removing the top cover.

1. Insert the attached Bezel Lock Key into the key slot and turn the key to the front bezel side while pressing it lightly to release the lock.



2. Hold the right end of front bezel and pull it toward you, and remove the right end from the chassis.
3. Next, hold the left end of front bezel and pull it toward you, and remove the left end from the chassis.

If you fail to remove the front bezel properly, the front bezel might be damaged. See "Safety Precautions and Regulatory Notices" that comes with your server for proper procedure for removal.


**Note**

Be careful not to press the POWER Switch.

1.6 Removing Top Cover

You need to remove top cover when installing or removing the optional component or change internal cable connection.


1. See steps 1 to 5 in *Chapter 2 (1.3 Overview of Installation and Removal)* for preparations.
2. Slide Top Cover (front) toward the front of the server while pressing Release Button on the cover.
3. Lift the top cover (front), and remove it from the server.




Tips

The screw hole on the place where front and rear top covers overlap each other, is not used.

4. Loosen the thumbscrew of the top cover (rear) by a screwdriver, and slide the top cover (rear) toward the rear of the server.



5. Lift the top cover (rear) and remove it from the server.




1.7 Removing PCI Riser Card


You need to remove PCI riser card when installing or removing the following component:

LOM card	DIMM (memory module)
Processor (CPU)	TPM kit
2.5-inch additional HDD cage	RAID Controller
PCI card	Flash Backup Unit for RAID Controller
3.5-inch Backup device	

1. See steps 1 to 6 in *Chapter 2 (1.3 Overview of Installation and Removal)* for preparations.
2. Remove the four screws from PCI riser card.



3. Lift the PCI riser card, and remove it from the server.




1.8 Removing Support Bar


You need to remove support bar when installing or removing the following component:

DIMM (memory module)	Processor (CPU)
2.5-inch additional HDD cage	PCI card
Flash Backup Unit for RAID Controller	3.5-inch Backup device

1. See steps 1 to 7 in *Chapter 2 (1.3 Overview of Installation and Removal)* for preparations.
2. Remove the two screws from support bar.



3. Lift the support bar, and remove it from the server.




1.9 Removing Air Duct

You need to remove air duct when installing or removing the following component or changing internal cable connection:

- DIMM (memory module)
- Processor (CPU)
- 2.5-inch additional HDD cage


1. See steps 1 to 8 in *Chapter 2 (1.3 Overview of Installation and Removal)* for preparations.
2. Lift the air duct, and remove it from the server.



Important Before removing the air duct, put cables aside. Otherwise, cables may be damaged if they are pulled together with air duct.

1.10 TPM Kit


This section describes the procedure for installing optional TPM Kit.



1.10.1 Installation

Install TPM Kit in the following procedure.

1. See steps 1 to 7 in *Chapter 2 (1.3 Overview of Installation and Removal)* for preparations.
2. Install TPM Kit and secure it by pushing the nylon rivet attached to TPM Kit.



Note

The TPM kit once installed cannot be removed.
Ask your service representative for removal of TPM Kit.

1.1.1 Processor (CPU)

You can configure the multi-processor system by adding an optional processor (called CPU hereafter).

Important

- You must avoid static electricity to work with the procedure below. For details, see *Chapter 2 (1.2 Anti-static Measures)*.
- Make sure to use the CPU authorized by NEC. Installing a third-party CPU may cause a failure of the CPU as well as the motherboard. Repair of the server due to failures or damage resulted from installing such a CPU will be charged.

Tips

After adding the processor, Windows may record the event log to System category of Event Viewer, but it is no problem for operation.

1.1.1.1 Maximum number of processor cores supported by this server

The maximum number of processor cores (logical processors) available on the server depends on the architecture (x86 architecture) and OS specs.

Maximum number of processor cores

OS	The maximum number of logical processors supported by OS	The maximum number of logical processors supported by this server
Microsoft Windows Server 2008 Standard Microsoft Windows Server 2008 Enterprise	32 *1	32
Microsoft Windows Server 2008 R2 Standard (x64) Microsoft Windows Server 2008 R2 Enterprise (x64)	256 *1	72
Microsoft Windows Server 2012 Standard Microsoft Windows Server 2012 Datacenter Microsoft Windows Server 2012 R2 Standard Microsoft Windows Server 2012 R2 Datacenter	640 *1	72
VMware ESXi 5.1	160	72
VMware ESXi 5.5	320	72

*1: When Hyper-V is used, the maximum number of logical processors is as shown below:

Windows Server 2008: 24


Windows Server 2008 R2: 64

Windows Server 2012, Windows Server 2012 R2: 320

1.11.2 Installation

Follow steps below to install the CPU.


1. See steps 1 to 6 in *Chapter 2 (1.3 Overview of Installation and Removal)* for preparations.
2. Locate the CPU socket to which you are going to install a CPU.
3. Remove the screws that secure the dummy cover, and remove it.



Note

Keep the removed dummy cover for future use.


4. Remove the protective cover from the CPU socket.





Note

Keep the removed protective cover for future use.


5. Push down the socket lever marked with "① →" once to unlatch it from the hook, then slowly open the lever until it stops.



6. Push down the socket lever marked with "←  ①" once to unlatch it from the hook, then slowly open the lever until it stops.




7. Lift the plate.



Important Do not touch the socket contacts.

8. Put the additional CPU on the CPU socket slowly and gently.

For easy installation, hold edges of CPU with your thumb and index fingers so that the notch is aligned with the key on the CPU socket.




Important

- Be sure to hold the CPU only at the edges.
- Pay attention not to touch the bottom of the CPU (pin section).


Note

- Insert the CPU while aligning the notch on the CPU with the key on the CPU socket.
- Bring down the CPU straight without tilting or sliding it in the socket.


9. Lightly push the CPU to the CPU socket, and close the plate.



10. Close the socket lever marked with "← ①" to fix it.



11. Close the socket lever marked with "⇐ ① →" to fix it.




12. Put the heat sink on the CPU and fix the heat sink with four screws.

Temporarily tighten the four screws diagonally, then tighten them securely.

Make sure that the screw aligns with the screw hole. If not, the screw may damage the motherboard.

Also pay attention not to touch the component around the CPU socket when putting the heat sink.



13. Make sure that the heat sink is installed on a level with the motherboard.

Note

- If the heat sink is not level, remove it, and then install it again.
The following probably causes the heat sink not to be level:
 - The CPU is not positioned correctly.
 - All screws are not completely tightened.
- Do not move the secured heat sink.

14. Install an additional fan unit provided with additional CPU board.
See *Chapter 2 (1.15 Additional / Redundant Fan Unit)* for how to install an additional fan unit.
15. Continue to install or remove internal optional devices, mount and connect the server, and turn it on.
16. Run BIOS Setup Utility (SETUP) to confirm the following settings. See *Chapter 2 (1. System BIOS)* in "Maintenance Guide".

Advanced → Processor Configuration → Processor Information

[CPU ID]
[L2 Cache RAM]
[L3 Cache RAM]

1.11.3 Replacement / Removal

Important

- Do not remove any CPU unless it is failed.
- To remove the heat sink from the CPU, first turn the heat sink to the left and right lightly to make sure that the heat sink can be apart from the CPU. Removing the heat sink with it adhering to the CPU may cause the CPU and/or CPU socket to be defected.
- If you fail to mount protective cover and dummy cover to the slot where CPU is removed, the cooling effect in the server will deteriorate. It may cause a malfunction of the server.

To remove CPU, reverse the installation procedure.

Perform the following steps if using the server with the CPU being removed.

1. Mount the protective cover to CPU socket.
2. Secure the dummy cover to the slot with four screws.
3. Remove the additional fan unit.
4. Mount the fan cover.

Perform the following steps after replacing or removing the CPU.

1. Run BIOS Setup Utility (SETUP) to confirm the following settings. See *Chapter 2 (1. System BIOS)* in "Maintenance Guide".

Advanced → Processor Configuration → Processor Information

[CPU ID]
[L2 Cache RAM]
[L3 Cache RAM]

1.12 DIMM

Install a DIMM (Dual Inline Memory Module) to a DIMM socket on the motherboard in the server. The motherboard provides 24 sockets to install DIMMs.

Important

- You must avoid static electricity to work with the procedure below. For details, see *Chapter 2 (1.2 Anti-static Measures)*.
- Use only the specified DIMMs. Installing a DIMM from a third party may damage not only the DIMM but the motherboard. You will be charged to repair failures or damages caused by the use of such products even within the warranty period.

Tips

Up to 768 GB (32 GB x 24) can be installed in 2-CPU configuration. Up to 384 GB (32 GB x 12) can be installed in 1-CPU configuration. No DIMM is factory installed in standard configuration.

1.12.1 Maximum supported memory size

The maximum available memory size on the server depends on the architecture and OS specs.

List of maximum memory sizes

OS	The maximum memory size supported on each OS	The maximum memory size supported on the server
Microsoft Windows Server 2008 Standard *1	4GB	4 GB (If using HW-DEP feature) * Default factory settings
		About 2 GB (If not using HW-DEP feature) Note: If you are not using the HW-DEP feature, set Execute Disable Bit (XD Bit) to Disabled in the BIOS settings.
Microsoft Windows Server 2008 R2 Standard *1	32GB	32GB
Microsoft Windows Server 2008 Enterprise *1	64GB	64GB
Microsoft Windows Server 2008 R2 Enterprise *1	2TB	768 GB
Microsoft Windows Server 2012 Standard *1 Microsoft Windows Server 2012 Datacenter *1 Microsoft Windows Server 2012 R2 Standard *1 Microsoft Windows Server 2012 R2 Datacenter *1	4TB	768 GB
VMware ESXi 5.1 *2	2TB	768 GB
VMware ESXi 5.5 *2	4TB	768 GB

*1: Shown below is the maximum memory size when Hyper-V is used:

- Windows Server 2008 Standard, Windows Server 2008 R2 Standard : 32GB
- Windows Server 2008 Enterprise, Windows Server 2008 R2 Enterprise : 1TB
- Windows Server 2012 ,Windows Server 2012 R2: 4TB

*2: Up to 1 TB on virtual machine.

1.12.2 Memory Clock

The server supports the memory clock speed of DDRL4-1600/1866/2133MHz. However, the actual memory clock speed depends on CPU and memory configuration. (The all of DIMMs operate at the same clock speed.)

N code (CPU)	DIMM type	Number of DIMMs (per 1 CPU)	Clock speed
N8101-768F (E5-2603v3) N8101-769F (E5-2609v3)	N8102-610 4GB additional memory board (1x4GB/R)	Up to 8 sets (16 DIMMs)	1600 MHz
	N8102-611F 8GB additional memory board (2x4GB/R) N8102-612F 16GB additional memory board (2x8GB/R) N8102-613F 32GB additional memory board (2x16GB/R)	Up to 4 sets (8 DIMMs)	1600 MHz
		5 sets (10 DIMMs) or more	1600 MHz
		5 sets (10 DIMMs) or more	1600 MHz
	N8102-614F 64GB additional memory board (2x32GB/LR)	Up to 4 sets (8 DIMMs)	1600 MHz
		5 sets (10 DIMMs) or more	1600 MHz
	N8102-618 16GB additional memory board (2x8GB/R) N8102-619 32GB additional memory board (2x16GB/R)	Up to 2 sets (4 DIMMs)	1600 MHz
	N8102-622 24GB additional memory board (3x8GB/R) N8102-623 48GB additional memory board (3x16GB/R)	—	1600 MHz
N8101-770F (E5-2620v3) N8101-771F (E5-2623v3) N8101-773F (E5-2640v3)	N8102-610 4GB additional memory board (1x4GB/R)	Up to 8 sets (16 DIMMs)	1866 MHz
	N8102-611F 8GB additional memory board (2x4GB/R) N8102-612F 16GB additional memory board (2x8GB/R) N8102-613F 32GB additional memory board (2x16GB/R)	Up to 4 sets (8 DIMMs)	1866 MHz
		5 sets (10 DIMMs) or more	1600 MHz
		5 sets (10 DIMMs) or more	1600 MHz
	N8102-614F 64GB additional memory board (2x32GB/LR)	Up to 4 sets (8 DIMMs)	1866 MHz
		5 sets (10 DIMMs) or more	1600 MHz
	N8102-618 16GB additional memory board (2x8GB/R) N8102-619 32GB additional memory board (2x16GB/R)	Up to 2 sets (4 DIMMs)	1866 MHz
	N8102-622 24GB additional memory board (3x8GB/R) N8102-623 48GB additional memory board (3x16GB/R)	—	1600 MHz
N8101-772F (E5-2637v3) N8101-774F (E5-2643v3) N8101-776F (E5-2660v3) N8101-777F (E5-2667v3) N8101-778F (E5-2670v3) N8101-779F (E5-2690v3) N8101-931F (E5-2697Y) N8101-933F (E5-2699v3)	N8102-610 4GB additional memory board (1x4GB/R)	Up to 8 sets (16 DIMMs)	2133 MHz
	N8102-611F 8GB additional memory board (2x4GB/R) N8102-612F 16GB additional memory board (2x8GB/R) N8102-613F 32GB additional memory board (2x16GB/R)	Up to 4 sets (8 DIMMs)	2133 MHz
		5 sets (10 DIMMs) or more	1600 MHz
		5 sets (10 DIMMs) or more	1600 MHz
	N8102-614F 64GB additional memory board (2x32GB/LR)	Up to 4 sets (8 DIMMs)	2133 MHz
		5 sets (10 DIMMs) or more	1600 MHz
	N8102-618 16GB additional memory board (2x8GB/R) N8102-619 32GB additional memory board (2x16GB/R)	Up to 2 sets (4 DIMMs)	2133 MHz
	N8102-622 24GB additional memory board (3x8GB/R) N8102-623 48GB additional memory board (3x16GB/R)	—	1600 MHz

1.12.3 Memory RAS Feature

The server supports the following RAS features. Some restrictions (e.g., DIMM installation location) are imposed on using the Memory Mirroring or Memory LockStep feature. See *Chapter 2 (1.10.7 Using Memory RAS Feature)* for conditions appropriate to your requirements.

- Standard memory feature (x4 SDDC ECC memory) *1
- Memory Mirroring feature (restrictions imposed on DIMM configuration)
- Memory LockStep feature (x8 SDDC ECC memory) (restrictions imposed on DIMM configuration)
- Memory Sparing feature (restrictions imposed on DIMM configuration)

*1: x4SDDC is not supported on N8102-610/611

Supported RAS features depend on additional memory board.

See the table below for RAS features supported by additional memory board.

List of features supported by additional memory board

N code Product name	Standard feature (x4 SDDC)	Memory Mirroring feature	Memory LockStep feature (x8 SDDC)	Memory Sparing feature
N8102-610 4GB additional memory board (1x4GB/R)	×	×	×	×
N8102-611F 8GB additional memory board (2x4GB/R)	×	×	×	×
N8102-612F 16GB additional memory board (2x8GB/R)	○	×	×	×
N8102-613F 32GB additional memory board (2x16GB/R)	○	×	×	×
N8102-614F 64GB additional memory board (2x32GB/LR)	○	×	×	×
N8102-618 16GB additional memory board (2x8GB/R)	×	○	○	×
N8102-619 32GB additional memory board (2x16GB/R)	×	○	○	×
N8102-622 24GB additional memory board (3x8GB/R)	×	×	×	○
N8102-623 48GB additional memory board (3x16GB/R)	×	×	×	○

○: Supported, ×: Not supported

1.12.4 DIMM installation order

Note

See *List of features supported by additional memory board* in 1.10.3 *Memory RAS Feature* before using memory RAS feature.

In 1-CPU configuration, install two DIMMs starting from the smallest slot number. If CPU2 is not installed, CPU2_DIMM1 to CPU2_DIMM12 are disabled.

In 2-CPU configuration, alternately install two DIMMs starting from the smallest slot number of each CPU.


See the table below to find allowable combination of DIMMs. Any other combination of DIMMs than described in this table is not allowed.

When N8102-610 4GB additional memory board is installed, any other supported memory board cannot be installed together.

N code	N8102-								
	610	611F	612F	613F	614F	618	619	622	623
N8102-610	○	×	×	×	×	×	×	×	×
N8102-611F	×	○	○	○	×	×	×	×	×
N8102-612F	×	○	○	○	×	×	×	×	×
N8102-613F	×	○	○	○	×	×	×	×	×
N8102-614F	×	×	×	×	○	×	×	×	×
N8102-618	×	×	×	×	×	○	○	×	×
N8102-619	×	×	×	×	×	○	○	×	×
N8102-622	×	×	×	×	×	×	×	○	×
N8102-623	×	×	×	×	×	×	×	×	○

○: Allowed to be install together.


×: Not allowed to be install together.



1.12.5 Installation

Install a DIMM by using the following procedure.


1. See steps 1 to 6 in *Chapter 2 (1.3 Overview of Installation and Removal)* for preparations.
2. Open levers on left and right sides of DIMM slot, and remove the dummy cover.



Note

Keep the removed dummy cover for future use.

3. Push the DIMM straight into the socket. When a DIMM is inserted into the socket, the lever automatically closes.



Important

- Make sure the orientation of the DIMM. The DIMM has a notch, preventing being incorrectly inserted.
- Do not apply too much pressure when you push a DIMM into the socket. Doing so can damage the socket or terminal part.

4. Continue to install or remove internal optional devices, mount and connect the server, and turn it on.
5. Confirm that no error messages are displayed in POST screen.
If any error messages are displayed, see *Chapter 3 (1. POST Error Message)* in "Maintenance Guide".
6. Run BIOS Setup Utility, and select **Memory Configuration** and then **Memory Information** from the **Advanced** menu. Make sure the capacity of added DIMM is displayed properly.
See *Chapter 2 (1. System BIOS)* in "Maintenance Guide".
7. Select **Memory Configuration** from the **Advanced** menu, and then specify **Yes** for **Memory Retest**.
After that, select **Save Changes and Exit** to reboot.
8. Set the size of Paging File to the recommended value (Total memory size x 1.5) or more.
If using a Windows OS, see *Chapter 1 (7.1 Specifying Memory Dump Settings (Debug Information))* in "Installation Guide (Windows)".
For other OS, follow the manual of the OS.

1.12.6 Removal / Replacement

To remove DIMM, reverse the installation procedure.

Be sure to install dummy cover to the slots from where DIMMs are removed.

Important Failing to install dummy cover to vacant slot may cause malfunction of the server due to insufficient cooling effect.

Note When removing a defective DIMM, check error messages displayed at POST or NEC ESM PRO and check the DIMM socket where the defective DIMM is installed.

Take the steps below after replacing or removing DIMMs.


1. Confirm that no error messages are displayed on POST. If any error message is displayed, see *Chapter 3 (1. Post Error Message)* in "Maintenance Guide".
2. Run BIOS Setup Utility, select **Memory Configuration** from the **Advanced** menu, and then specify **Yes** for **Memory Retest**. After that, select **Save Changes and Exit** to reboot.
3. Set the size of Paging File to the recommended value (Total memory size x 1.5) or more.
If using a Windows OS, see *Chapter 1 (7.1 Specifying Memory Dump Settings (Debug Information))* in "Installation Guide (Windows)".
For other OS, follow the manual of the OS.

1.12.7 Using Memory RAS Feature

This server has RAS feature including Standard Memory feature (x4 SDDC ECC memory), Memory Mirroring feature, Memory Sparing feature, and Memory Lock Step (x8 SDDC ECC memory) feature. SDDC (Single Device Correction) allows automatic correction of memory error (multi-bit error).

- Note
- See *List of features supported by additional memory board* in 1.10.3 Memory RAS Feature before using memory RAS feature.
 - Only the features that additional memory board support can be used.

The memory area on the motherboard of the server is divided into four memory channels.




Memory Mirroring, Memory Lock Step, and Memory Sparing features keep memory redundancy between memory channels by monitoring or altering memory active/inactive status, respectively.

(1) Memory Mirroring Feature

Memory Mirroring feature writes the same data into two groups of DIMMs (mirror set) corresponding with each other between memory channels (channels 0 and 1 or channel 2 and 3) to provide data redundancy.

- Note
- Memory Mirroring feature uses channels 0 and 1 or channels 2 and 3.
 - To use Memory Mirroring feature, install N8102-618/619 additional memory board (two DIMMs of same model).
 - DIMMs used in mirror set must be of the same model number.


Example: 2-CPU configuration



- Tips
- The operating system recognizes a half of the total physical capacity.

Memory Mirroring feature can be used under the following conditions:

- Install DIMMs in DIMM sockets to configure a mirror set.
- All the installed DIMMs should have the same capacity.
- See *Chapter 2 (1. System BIOS)* in "Maintenance Guide", check if your server supports Memory Mirroring feature.
Select **Advanced** → **Memory Configuration** → **Memory Information**, and check if **Supported** is displayed in **Mirroring**.
- See *Chapter 2 (1. System BIOS)* in "Maintenance Guide", run SETUP, change parameters as shown below, save the settings, and exit from SETUP.
Advanced → **Memory Configuration** → **Memory RAS Mode** → Change to **Mirroring**.
- After restart, run SETUP again, and check if "**Mirrored**" is displayed for the following parameter.
Advanced → **Memory Configuration** → **Memory Information** → **CPUx_DIMMx Status**
- Installation order depends on CPU configuration. See the figure below.



Memory Mirroring cannot be configured in the following case:

- Memory Mirroring within a specific memory channel

Notes on Configuring Memory Mirroring


In Memory Mirroring configuration, [Memory RAS Mode] menu is changed from "Mirroring" to "Independent" in the following cases:

- When you additionally install DIMMs that unable to configure Memory Mirroring
- When you remove DIMMs that takes down Memory Mirroring

(2) Memory Lock Step Feature (x8 SDDC)


In Memory Lock Step feature, the DIMMs in two groups corresponding to two memory channels (channels 0 and 1, or channels 2 and 3) is multiplexed and operated in parallel to enable x8 SDDC (x8 Single Device Data Correction). With this feature, a single device can detect and correct one to eight-bit error.

- Note
- Memory LockStep feature uses channels 0 and 1 or channels 2 and 3.
 - To use Memory LockStep feature, install N8102-618/619 additional memory board (two DIMMs of same model).
 - DIMMs used in LockStep set must be of the same model number.



Memory Lock Step feature can be used under the following conditions:

- Install DIMMs in DIMM socket to configure a Lock Step set.
- All the installed DIMMs should have the same capacity.
- See *Chapter 2 (1. System BIOS)* in "Maintenance Guide", run SETUP, change parameters as shown below, save the settings, and exit from SETUP.
Advanced → Memory Configuration → Memory RAS Mode → Change to LockStep.
- After restart, run SETUP again, and check if "Lock Step" is displayed for the following parameter.
Advanced → Memory Configuration → Memory Information → CPUx_DIMMx Status
- Installation order depends on CPU configuration. See the figure below.



Memory Lock Step cannot be configured in the following cases:

- Memory Lock Step between memory channels of different memory controllers (CPU)
- Memory Lock Step within the same memory channel

Notes on Configuring Lock Step

In Memory Lock Step configuration, **Memory RAS Mode** menu is changed from "Lock Step" to "Independent" in the following cases:

- When you additionally install DIMMs that unable to configure Memory Lock Step
- When you remove DIMMs that takes down Memory Lock Step

(3) Memory Sparing Feature

Memory Sparing feature puts a memory channel 2 of a memory controller in each CPU into standby status as spare devices. If a correctable error occurs in a DIMM in the running memory controller, the feature automatically changes the running DIMM from the failed one to a DIMM in the standby state to continue the processing.

Note

To use Memory Sparing feature, install N8102-622/623 additional memory board (three DIMMs of same model).


DIMMs installed in the system must be of the same model number.

Tips

The operating system recognizes the DIMMs as those with capacities less than the actual physical capacities. (The recognized capacities vary depending on the number of DIMMs and the physical capacity per DIMM.)


The following table shows configuration allowable for memory sparing and system logical memory capacity.

Number of CPUs	Number of DIMMs	Capacity of DIMM installed	
		8GB	16GB
1	3	16GB	40GB
	6	32GB	80GB
	9	48GB	120GB
	12	64GB	160GB
2	6	32GB	80GB
	12	64GB	160GB
	18	96GB	240GB
	24	128GB	320GB



Memory Sparing feature can be used under the following conditions:

- Install DIMMs in DIMM socket to configure a spare set.
- DIMMs to be installed should have the same capacity.
- See *Chapter 2 (1. System BIOS) in "Maintenance Guide"*, check if your server supports Memory Sparing feature.
Select **Advanced** → **Memory Configuration** → **Memory Information**, and check if **Supported** is displayed in **Sparing**.
- See *Chapter 2 (1. System BIOS) in "Maintenance Guide"*, run SETUP, change parameters as shown below, save the settings, and exit from SETUP.
Advanced → **Memory Configuration** → **Memory RAS Mode** → Change to **Sparing**.
- After restart, run SETUP again, and check if "**Spared**" is displayed for the following parameter.
Advanced → **Memory Configuration** → **Memory Information** → **CPUx_DIMMx Status**
- Installation order depends on CPU configuration. See the figure below.



The following Memory Sparing cannot be configured.

- A DIMM of different capacity is installed.
- Sparing with DIMMs in different memory channel

Notes on Configuring Memory Sparing

In Memory Sparing configuration, **Memory RAS Mode** menu is changed to "Independent" in the following cases:

- When you additionally install DIMMs that unable to configure Memory Sparing
- When you remove DIMMs that takes down Memory Sparing

1.13 Flash Backup Unit for RAID Controller

If a RAID Controller (N8103-176/177/178/179) is installed, use the flash backup unit (FBU) to avoid data loss caused by accidents including temporary blackout during a Write Back operation. The model of the flash backup unit to be used depends on RAID Controller.

- For N8103-176/177/178, use N8103-181 Flash Backup Unit
- For N8103-179, use FBU provided with N8103-179.

1.13.1 Handling precautions




Observe the following when using FBU. Ignoring these precautions may cause damage to your data or other devices.

- Use the FBU appropriate to the RAID Controller to be used.
- The FBU is an electronic device sensitive to static electricity. Before installation, touch the metal frame part of the server to discharge the static electricity from your body.
- Do not drop or bump the FBU.
- For recycling and disposing of the FBU, refer to the User's Guide that comes with the RAID Controller or Flash Backup Unit.


1.13.2 Installing N8103-181 Flash Backup Unit

This section describes the procedure of installing an FBU for RAID Controller.


1. See steps 1 to 6 in *Chapter 2 (1.3 Overview of Installation and Removal)* for preparations.
2. Put the FBU on support bar. Secure the FBU bracket that comes with FBU with the screw.




3. Connect the FBU control cable (650 mm) that comes with FBU.




4. Remove the two screws from RAID Controller, and remove the PCI bracket.




5. Mount the adapter to RAID Controller.




6. Connect the control cable of FBU to RAID Controller.
Align the connector on FBU control cable with the black marking on RAID Controller, then connect the FBU control cable.




7. Remove the two screws from server chassis, and remove the RAID Controller bracket.




8. Install the RAID Controller bracket to RAID Controller using two screws you have removed in Step 7.




9. Install RAID Controller to the RAID Controller connector on motherboard, using two screws you have removed in Step 7.




10. Connect Mini SAS HD cable to RAID Controller.




11. Disconnect USB cable (for front) from motherboard.




12. Connect Mini SAS HD cable to RAID Controller.



13. Connect USB cable (for front) to motherboard.



14. Install support bar and PCI riser card you have removed in Steps 2 and 3.






1.13.3 Removal

For removing the FBU for RAID Controller, reverse the installation procedure.


1.13.4 Installing FBU for N8103-179

Take the steps below to install FBU.


1. See steps 1 to 6 in *Chapter 2 (1.3 Overview of Installation and Removal)* for preparations.
2. Put the FBU, provided as the standard accessory of RAID Controller, on the support bar. Then, mount the FBU bracket, provided as the standard accessory of RAID Controller, and secure it with a screw.




3. Connect the FBU control cable (750 mm), provided as the standard accessory of RAID Controller, to FBU.




4. Connect the FBU control cable (750 mm in length) and Mini SAS cable to RAID Controller. Align the black marking on connector of FBU control cable with that on connector of RAID Controller.




5. Remove one screw from the blank cover on the PCI riser card on which you are going to mount the RAID Controller, then remove the blank cover.



6. Mount the RAID Controller to PCI riser card, and secure it with one screw you have removed in Step 5.



7. Connect the PCI riser card to the slot on motherboard, and secure it with screws.



1.13.5 Removing FBU

Remove the FBU in reverse order of installation procedure.

1.14 LOM Card

The server supports LOM Card which is the replaceable onboard network adapter.


Install LOM Card to the LOM Card slot on motherboard. The motherboard has one slot to install LOM Card.

Important You must avoid static electricity to work with the procedure below. For details, see *Chapter 2 (1.2 Anti-static Measures)*.


1.14.1 Installation

Follow steps below to install LOM Card.

1. See steps 1 to 6 in *Chapter 2 (1.3 Overview of Installation and Removal)* for preparations.
2. Remove the screw from the bracket.




3. Remove two screws from the motherboard.




4. Remove the bracket.


5. Align the pin terminals of LOM Card with the LOM Card slot, insert the card firmly, and secure the card with three screws.



6. Mount the LOM Card bracket to motherboard and secure it with two screws you have removed in step 3.



7. Use the two screws you have removed in Step 2 to mount the port cover that comes with LOM Card.



1.14.2 Removal

Remove LOM Card in reverse order of installation steps.

Important To maintain the cooling effect in the server, install the blank cover in the vacant LOM Card slot.


1.15 Additional / Redundant Fan Unit

This server can work with additional redundant cooling fan system by adding an additional fan unit.

The fan units are hot-swappable even while the system is powered-on and running.

Adding an additional CPU requires additional fan unit to be installed.

The figure below shows the slot numbers assigned to the slots of standard cooling fans and optional cooling fans.



*1 Slots to install additional fan unit when additional CPU board is installed.

*2 Slots to install redundant (additional) fan unit.

Install fan units in the slot FAN1F to 4F in 1-CPU configuration.

Install fan units in the slot FAN1F to 5F in 2-CPU configuration.

Important

If adding a fan unit along with additional CPU, see *Chapter 2 (1.11 Processor (CPU))* for preparation.

1.15.1 Installation

Take the steps below to install the fan unit.


(1) Additional fan unit for additional CPU

1. See steps 1 to 6 in *Chapter 2 (1.3 Overview of Installation and Removal)* for preparations.
2. Remove the fan cover.
3. Locate the slot to install an additional fan unit (FAN 5R).
4. Insert fan unit straight into slot.
When the fan unit is inserted to the end, it is locked with clicking sound.

Important Keep the removed fan cover for future use.

(2) Additional fan unit for redundant configuration

1. See steps 1 to 6 in *Chapter 2 (1.3 Overview of Installation and Removal)* for preparations.
2. Locate the slots to install an additional (redundant) fan unit.
In 1-CPU configuration: Install redundant fan units to slots FAN 1F to 4F.
In 2-CPU configuration: "Install redundant fan units to slots FAN 1F to 5F.
3. Insert fan unit straight into the slot for additional fan unit.
When the fan unit is inserted to the end, it is locked with clicking sound.





1.15.2 Replacement / Removal

To remove additional/redundant fan unit, reverse the installation procedure.

The fan units are hot-swappable even while the system is powered-on and running.

You can identify the failing fan unit by using the management tool such as EXPRESSSCOPE Engine 3.

While the system is powered-on or running, the LED of failed fan unit is lit.

 CAUTION	
	<p>Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause burns, injury, and property damage. For details, refer to <i>Safety Precautions and Regulatory Notices</i>.</p> <ul style="list-style-type: none">• Pay attention to electric hazard.

1.16 Backup Device

The server supports backup device such as magnetic tape drive.


Important

- Use only the backup device specified by NEC.
- Available unit size is 3.5 inch (about 9 cm) in width, 1.6 inch (about 4 cm) in height.


1.16.1 Installation

Take the steps below to install the backup device.

1. See steps 1 to 8 in *Chapter 2 (1.3 Overview of Installation and Removal)* for preparations.
2. Push the lever to unlatch the expansion bay, and remove the carrier toward the front of chassis.




3. Push the blank cover to remove it.


**Important**

Keep the removed blank cover for future use.

4. Insert the backup device into the carrier.




5. Secure the backup device with the four screws that come with the server.

**Important**


- Be sure to use the screws that come with your server.
- Adjust the mounting position of backup file unit so that their screw holes are aligned with those on the carrier.
- If you feel difficult to connect a cable because the depth of backup device is too long, move the device toward front, then connect the cable.

6. Insert the carrier into expansion bay.
When the device is completely inserted, it is locked with clicking sound.

**Note**

Pay attention not to pinch the cable when inserting the device.

7. Connect an interface cable and power cable that come with the backup device.



Note Use the power cable that extends to the expansion bay of the server.

8. Connect the USB cable to the connector on motherboard.

Note Make sure that the USB cable does not come in contact with electronic component on motherboard.

9. Continue to install or remove internal optional devices, mount and connect the server, and power on the server.

Important When N8151-125 Internal RDX (USB) is connected, the boot device priority may be changed. On the Boot menu of BIOS SETUP, specify the boot priority of removable device lower than that of boot device.

10. Make sure that no error messages are displayed on POST screen.

For details on POST error messages, refer to *Chapter 3 (1. POST Error Message)* in "Maintenance Guide".

11. Install the driver for backup device.

1.16.2 Removal

Remove the backup device in reverse order of installation steps.

1.17 PCI Card

This server provides PCI slots for riser card (2 types), a slot dedicated for LOM card, and a slot dedicated for RAID controller (total four PCI cards can be mounted).

Riser card can connect with two or three full-height PCI cards and three low-profile PCI cards. A slot dedicated for LOM card can contain one LOM card. A slot dedicated for RAID controller can contain one RAID Controller. (Seven or eight PCI cards can be mounted in total.)

Important You must avoid static electricity to work with the procedure below. For details, see *Chapter 2 (1.2 Anti-static Measures)*.

1.17.1 Notes

Read the following notes when installing or removing a PCI card.

- Do not touch the terminals of the riser cards and the leads of electronic components with your bare hand. Fingerprints and dust left on them cause the server to malfunction due to a connection failure or damage to the leads.
- Available type of PCI card depends on riser card. Make sure the card type before connecting it to riser card.
- The server provides no connector to connect an LED connector which is supplied in RAID Controller used to indicate disk access.
- PCI slot number "1A" is assigned to the RAID controller slot, "1B" is assigned to the LOM card slot. "1C, 2C, 3C" (from bottom slot) are assigned to the riser card for full-height PCI card. "1C, 2C" (from bottom slot) are assigned to full-height optional riser card (PCIe x16), and "1D, 2D, 3D" (from bottom slot) are assigned to low-profile optional riser card.
- The search order for PCI bus slot on boot is as follows.
Slot 1A (dedicated to RAID Controller) → Slot 1B (LOM card slot) → Slot 1C (Full height card slot) → Slot 1D (Low profile card slot) → 2C (Full height) card slot → 3C (Full height card slot) → 2D (Low profile card slot) → 3D (Low profile card slot)
- The PCI devices of the same type (including onboard PCI device) may be recognized in different order from those described above, depending on OS or RAID Configuration Utility. Check the slot location of PCI device by PCI bus number, device number and function number shown in the table below.

PCI device	Bus number	Device number	Function number
LOM card LAN1 (when N8104-154/155/156 is installed)	05h	0	0
LOM card LAN2 (when N8104-154/155/156 is installed)	05h	0	1
LOM card LAN3 (when N8104-154/156 is installed)	05h	0	2
LOM card LAN4 (when N8104-154/156 is installed)	05h	0	3
Slot 1A dedicated for RAID Controller	01h	0	X
PCIe slot 1C (Full height)	0Ch	0	X
PCIe slot 2C (Full height)	81h	0	X
PCIe slot 3C (Full height)	A0h	0	X
PCIe slot 1C (N8116-34)	0Ch	0	X
PCIe slot 2C (N8116-34)	81h	0	X
PCIe slot 1D (Low profile)	40h	0	X
PCIe slot 2D (Low profile)	C0h	0	X
PCIe slot 3D (Low profile)	E0h	0	X

- If an additional LAN card is installed, it is hard to push the catch of the connector with your finger that is connected to the LAN card. Disconnect the connector pushing the catch with a standard screwdriver. At this time, be very careful for the screwdriver not to damage the LAN card.
- If a bootable device such as a PCI card or USB device is added, the boot order may change. In BIOS Setup Utility, select **HDD Priorities** from **Boot** menu and confirm the boot order.
Boot → **HDD Priorities** → Check the display
If the boot device is an HDD and located under an optional RAID Controller, the display is (Bus xx Dev 00) PCI RAID Adapter. Note that the value for xx changes depending on the PCI slot where a RAID Controller is installed.
- For a RAID Controller, LAN card (network boot), or Fibre Channel controller, if a hard disk drive on which an OS is installed is connected, set the option ROM for that slot to **Enabled**. See *Chapter 2 (1. System BIOS)* in "Maintenance Guide" for how to specify it.

1.17.2 Supported PCI cards and available slots

The following tables list supported cards and slots available for them. For details of the features of each card, see the manual supplied with the card.

Tips

- Different cards mounted on the same bus operate at the lower frequency.
- If the operation performance of PCI card differs from that of PCI Slot, the PCI card operates at lower frequency.

(1) Standard riser card

Product number	Product name	Slot number	#1A	#1B	#1C	#2C	#3C	#1D	#2D	#3D	Remarks	
		CPU connected	CPU1			CPU2		CPU1	CPU2			
		PCI standard	PCIe 3.0									
		PCI slot performance *1	x8 lane									
		Transfer bandwidth (per lane) *1	8Gb/s									
		PCI card type *2	x8 socket									
		Slot size	Dedicated to RAID Controller	Dedicated to LOM card	Full height			Low profile				
		Available card size			220 mm max.	220 mm max. *4	312 mm max.	220 mm max.				
N8103-176	RAID Controller (1GB, RAID 0/1) [PCI Express 3.0(x8)]	√	—	—	—	—	—	—	—	Dedicated to connect with internal hard disk drive. Flash Backup Unit [N8103-181] can be mounted.		
N8103-177	RAID Controller (1GB, RAID 0/1/5/6) [PCI Express 3.0(x8)]	√	—	—	—	—	—	—	—			
N8103-178	RAID Controller (2GB, RAID 0/1/5/6) [PCI Express 3.0(x8)]	√	—	—	—	—	—	—	—			
N8103-179	RAID Controller (2GB, RAID 0/1/5/6) [PCI Express 3.0(x8)]	—	—	√	√	√	√	√	√	Dedicated to connect with external devices. Up to 2 cards can be mounted. Flash Backup Unit is factory installed		
N8103-142	SAS Controller [PCI Express 2.0(x8)]	—	—	√	√	√	√	√	√	Dedicated to connect with external devices. Up to 3 cards can be mounted.		
N8103-184	SAS Controller [PCI Express 3.0(x8)]	—	—	√	√	√	√	√	√			
N8118-01	PCI SSD Adapter [PCI Express 2.0(x4)]	—	—	√	√	√	√	√	√	For storing data. Cannot be used as OS boot area. Card type: PCI Express 2.0 (x8)		
N8190-159	Fibre Channel Controller (8Gbps/Optical) [PCI Express 2.0(x8)]	—	—	√	√	√	√	√	√			
N8190-160	Fibre Channel Controller (2ch)(8Gbps/Optical) [PCI Express 2.0(x8)]	—	—	√	√	√	√	√	√			
N8190-157A	Fibre Channel Controller (16Gbps/Optical) [PCI Express 3.0(x8)]	—	—	√	√	√	√	√	√			
N8190-158A	Fibre Channel Controller (2ch)(16Gbps/Optical) [PCI Express 3.0(x8)]	—	—	√	√	√	√	√	√			

Product number	Product name	Slot number	#1A	#1B	#1C	#2C	#3C	#1D	#2D	#3D	Remarks	
		CPU connected	CPU1			CPU2		CPU1	CPU2			
		PCI standard	PCIe 3.0									
		PCI slot performance *1	x8 lane									
		Transfer bandwidth (per lane) *1	8Gb/s									
		PCI card type *2	x8 socket									
		Slot size	Dedicated to RAID Controller	Dedicated to LOM card	Full height			Low profile				
		Available card size			220 mm max.	220 mm max. *4	312 mm max.	220 mm max.				
N8104-150	1000BASE-T Adapter (1ch) [PCI Express 2.0(x1)]	—	—	√	√	√	√	√	√	√	For additional LAN port. Card type: PCI Express 2.0 (x4)	
N8104-151	1000BASE-T Adapter (2ch) [PCI Express 2.0(x1)]	—	—	√	√	√	√	√	√	√		
N8104-152	1000BASE-T Adapter (4ch) [PCI Express 2.0(x4)]	—	—	√	√	√	√	√	√	√	For additional LAN port.	
N8104-145	1000BASE-T Adapter (2ch) [PCI Express 2.0(x4)]	—	—	√	√	√	√	√	√	√	For additional LAN port.	
N8104-149	10GBASE Adapter(SFP+/2ch) [PCI Express 2.0(x8)]	—	—	√	√	√	√	√	√	√	For additional LAN port. Prepare SFP+ module N8104-129 if needed.	
N8104-148	10GBASE Adapter(SFP+/2ch) [PCI Express 2.0(x8)]	—	—	√	√	√	√	√	√	√	For additional LAN port. Prepare SFP+ module N8104-129 if needed.	
N8104-153	10GBASE-T Adapter(2ch) [PCI Express 2.0(x8)]	—	—	√	√	√	√	√	√	√		
N8104-154	1000BASE-T LOM Card (4ch) [PCI Express 2.0(x4)]	—	√	—	—	—	—	—	—	—	For additional LAN port. Card type: PCI Express 2.0 (x8)	
N8104-155	10GBASE-T LOM Card (2ch) [PCI Express 2.0(x8)]	—	√	—	—	—	—	—	—	—	For additional LAN port.	
N8104-156	10GBASE-SFP+(2ch) + 1000BASE-T(2ch) LOM Card [PCI Express 2.0(x8)]	—	√	—	—	—	—	—	—	—	For additional LAN port. Prepare SFP+ module N8104-129 if needed.	
N8104-146	InfiniBand Adapter(1ch) (FDR/Optical) [PCI Express 3.0(x8)]	—	—	√	√	√	√	√	√	√	For Infiniband connection Cannot be used together with each other..	
N8104-147	InfiniBand Adapter(2ch) (FDR/Optical) [PCI Express 3.0(x8)]	—	—	√	√	√	√	√	√	√	Up to two cards can be mounted.	
N8117-01A	Additional RS-232C connector *3	—	—	√	√	√	√	√	√	√	For additional serial port B (RS-232C). Only one card can be mounted.	

√: Can be mounted, —: Cannot be mounted

*1 Data transfer rate of PCI slot = Transfer bandwidth × Number of lanes

<Example> x8 lane = 64 Gbps (one-way)

*2 Connector size. Cards exceeding the number of sockets cannot be connected.

<Example> x4 socket can connect with x1 and x4 cards, but not x8 card.

*3 Use RS-232C cable (B).

*4 To install a 312 mm full-length PCI card into slot #2C, the N8116-37 Full Length PCI Card Installation Kit must be prepared in advance.

- For functional details of each card, refer to the technical guide.

- The text in square brackets in the Product name column indicates the maximum performance of the card.

- If the performance of the PCI slot and the installed PCI card differs, the PCI card operates with a lower performance.

(2) N8116-34 riser card (PCIe16) (option)

Product number	Product name	Slot number	#1A	#1B	#1C	#2C	#1D	#2D	#3D	Remarks	
		CPU connected	CPU1			CPU2	CPU1	CPU2			
		PCI standard	PCIe 3.0								
		PCI slot performance *1	x8 lane								
		Transfer bandwidth (per lane) *1	8Gb/s								
		PCI card type *2	x8 socket		x16 socket		x8 socket				
		Slot size			Full height		Low profile				
		Available card size	Dedicated to RAID Controller	Dedicated to LOM card	220 mm max.	220 mm max. (312 mm max.) *4	220 mm max.				
N8103-176	RAID Controller (1GB, RAID 0/1) [PCI Express 3.0(x8)]	√	—	—	—	—	—	—	Dedicated to connect with internal hard disk drive. Flash Backup Unit [N8103-181] can be mounted.		
N8103-177	RAID Controller (1GB, RAID 0/1/5/6) [PCI Express 3.0(x8)]	√	—	—	—	—	—	—			
N8103-178	RAID Controller (2GB, RAID 0/1/5/6) [PCI Express 3.0(x8)]	√	—	—	—	—	—	—			
N8103-179	RAID Controller (2GB, RAID 0/1/5/6) [PCI Express 3.0(x8)]	—	—	√	√	√	√	√	Dedicated to connect with external devices. Up to 2 cards can be mounted. Flash Backup Unit is factory installed		
N8103-142	SAS Controller [PCI Express 2.0(x8)]	—	—	√	√	√	√	√	Dedicated to connect with external devices. Up to 3 cards can be mounted.		
N8103-184	SAS Controller [PCI Express 3.0(x8)]	—	—	√	√	√	√	√			
N8118-01	PCI SSD Adapter [PCI Express 2.0(x4)]	—	—	√	√	√	√	√	For storing data. Cannot be used as OS boot area. Card type: PCI Express 2.0 (x8)		
N8190-159	Fibre Channel Controller (8Gbps/Optical) [PCI Express 2.0(x8)]	—	—	√	√	√	√	√			
N8190-160	Fibre Channel Controller (2ch)(8Gbps/Optical) [PCI Express 2.0(x8)]	—	—	√	√	√	√	√			
N8190-157A	Fibre Channel Controller (16Gbps/Optical) [PCI Express 3.0(x8)]	—	—	√	√	√	√	√			
N8190-158A	Fibre Channel Controller (2ch)(16Gbps/Optical) [PCI Express 3.0(x8)]	—	—	√	√	√	√	√			
N8104-150	1000BASE-T Adapter (1ch) [PCI Express 2.0(x1)]	—	—	√	√	√	√	√	For additional LAN port. Card type: PCI Express 2.0 (x4)		
N8104-151	1000BASE-T Adapter (2ch) [PCI Express 2.0(x1)]	—	—	√	√	√	√	√			
N8104-152	1000BASE-T Adapter (4ch) [PCI Express 2.0(x4)]	—	—	√	√	√	√	√	For additional LAN port.		
N8104-145	1000BASE-T Adapter (2ch) [PCI Express 2.0(x4)]	—	—	√	√	√	√	√	For additional LAN port.		

Product number	Product name	Slot number	#1A	#1B	#1C	#2C	#1D	#2D	#3D	Remarks	
		CPU connected	CPU1			CPU2	CPU1	CPU2			
		PCI standard	PCIe 3.0								
		PCI slot performance *1	x8 lane								
		Transfer bandwidth (per lane) *1	8Gb/s								
		PCI card type *2	x8 socket		x16 socket		x8 socket				
		Slot size			Full height		Low profile				
		Available card size	Dedicated to RAID Controller	Dedicated to LOM card	220 mm max.	220 mm max. (312 mm max.) *4	220 mm max.				
N8104-149	10GBASE Adapter(SFP+/2ch) [PCI Express 2.0(x8)]	—	—	√	√	√	√	√	For additional LAN port. Prepare SFP+ module N8104-129 if needed.		
N8104-148	10GBASE Adapter(SFP+/2ch) [PCI Express 2.0(x8)]	—	—	√	√	√	√	√	For additional LAN port.		
N8104-153	10GBASE-T Adapter(2ch) [PCI Express 2.0(x8)]	—	—	√	√	√	√	√	Prepare SFP+ module N8104-129 if needed.		
N8104-154	1000BASE-T LOM Card (4ch) [PCI Express 2.0(x4)]	—	√	—	—	—	—	—	For additional LAN port. Card type: PCI Express 2.0 (x8)		
N8104-155	10GBASE-T LOM Card (2ch) [PCI Express 2.0(x8)]	—	√	—	—	—	—	—	For additional LAN port.		
N8104-156	10GBASE-SFP+(2ch) + 1000BASE-T(2ch) LOM Card [PCI Express 2.0(x8)]	—	√	—	—	—	—	—	For additional LAN port. Prepare SFP+ module N8104-129 if needed.		
N8104-146	InfiniBand Adapter(1ch) (FDR/Optical) [PCI Express 3.0(x8)]	—	—	√	—	√	√	√	For Infiniband connection Cannot be used together with each other.		
N8104-147	InfiniBand Adapter(2ch) (FDR/Optical) [PCI Express 3.0(x8)]	—	—	√	—	√	√	√	Up to two cards can be mounted.		
N8117-01A	Additional RS-232C connector *3	—	—	√	√	√	√	√	For additional serial port B (RS-232C). Only one card can be mounted.		

√: Can be mounted, —: Cannot be mounted

*1 Data transfer rate of PCI slot = Transfer bandwidth × Number of lanes

<Example> x8 lane = 64 Gbps (one-way)

*2 Connector size. Cards exceeding the number of sockets cannot be connected.

<Example> x4 socket can connect with x1 and x4 cards, but not x8 card.

*3 Use RS-232C cable (B).

*4 To install a 312 mm full-length PCI card into slot #2C, the N8116-37 Full Length PCI Card Installation Kit must be prepared in advance.

- For functional details of each card, refer to the technical guide.

- The text in square brackets in the Product name column indicates the maximum performance of the card.

- If the performance of the PCI slot and the installed PCI card differs, the PCI card operates with a lower performance.

1.17.3 Installation


Install a PCI card to the riser card in the following procedure.

Important When installing a PCI card, make sure the connector of the card fits the connector of the riser card.

Note


- Check the card type (Low Profile or Full Height) which respective riser card supports and the type of PCI card to be installed.
- When installing an FBU, see *Chapter 2 (1.13 Flash Backup Unit for RAID Controller)*.

1. See steps 1 to 6 in Chapter 2 (1.3 Overview of Installation and Removal) for preparations.
2. Remove one screw from the PCI riser card and remove the blank cover.



Note Keep the removed blank cover for future use.

3. Install a PCI card to the PCI riser card.
Position the terminal part of the PCI card to the PCI riser card slot and insert it.





Important Do not touch the terminal part of riser card or PCI card and the signal pins of electric parts installed on the board. Installing boards with dirt or oil can cause malfunction.

Note

- Make sure that the edge of a PCI card bracket is seated into the fixed slot.
- Depending on type of PCI cards, the terminal part of the PCI card may be too large to fit in the connector.
- If you have trouble installing the card, remove the card once and try again. If you apply excessive pressure on the card, a PCI card or riser card might break.


4. Secure the PCI card with the screw you removed in step 4.



Tips

To connect a PCI card to the connector on motherboard with cable, connect a cable to PCI card before installing PCI riser card.

5. Connect the PCI riser card to the slot on motherboard and secure the card with the screw you removed in step 2. Position the terminal part of the PCI riser card to the slot on the motherboard and insert it.



6. Continue to install or remove internal optional devices, mount and connect the server, and turn it on.
7. Make sure that no error messages are displayed on POST screen.
For details on POST error messages, see *Chapter 3 (1. POST Error Message)* in "*Maintenance Guide*".
8. Run the configuration utility of the card to set up the board as needed.
Availability or startup and operation procedure of the utility depends on card. For details, see the manual that comes with the card. **If a PCI card including RAID Controller, SAS controller, and LAN adapter which connects to any bootable device is added, the boot priority might or changed to the default setting.** In that case, configure the boot priority in **Boot** menu of BIOS Setup Utility. For details, see *Chapter 2 (1. System BIOS)* in "*Maintenance Guide*".

1.17.4 Removal

To remove a PCI card, reverse the installation procedure.

Run SETUP and change boot order in **Boot** menu as needed. See *Chapter 2 (1. System BIOS)* in "*Maintenance Guide*" for how to specify it.

If using the server with the PCI card removed, attach the blank cover that comes with the riser card.

1.17.5 Installing RAID Controller

This section describes how to install an optional RAID Controller to the slot dedicated to RAID Controller.

(1) When using the optional RAID controller (N8103-176/177/178)

For details, see the manual that comes with optional RAID Controller (N8103-176/177/178).

Important

- You must avoid static electricity to work with the procedure below. For details, see *Chapter 2 (1.2 Anti-static Measures)*.
- Do not change the mode to hibernate while building a RAID System.


Note

- When installing an optional RAID Controller, run the BIOS Setup utility, select **PCI Configuration** from the **Advanced** menu, and then make sure that the parameter of **PCI Slot xx ROM** (xx is PCI slot number) is set to **Enabled**.
- When connecting a RAID Controller, set the boot priority to 8th or higher in the **Boot** menu of the BIOS Setup utility. If the setting is 9th or lower, the configuration menu for RAID Controllers cannot be launched.


Installation

Take the following procedure to install RAID Controller (N8103-176/177/178).


1. See steps 1 to 6 in *Chapter 2 (1.3 Overview of Installation and Removal)* for preparations.
2. Remove the four screws and remove PCI riser card.




3. Remove the two screws from RAID Controller, and remove PCI bracket.




4. Remove the two screws from server chassis, and remove RAID Controller bracket.




5. Attach the RAID Controller bracket to RAID Controller with two screws you have removed in Step 3.




6. Insert the RAID Controller slightly into the dedicated slot while tilting the card.



7. Gently place the RAID Controller on bottom plate of chassis so that it become horizontal to the motherboard.



8. Insert the RAID Controller into the slot while keeping horizontal state.



9. Secure the RAID Controller bracket with two screws you have removed in Step 4.
10. Disconnect SAS/SATA cable from SATA connector on motherboard.
 - When four or less hard disk drives are installed:
Connect SAS/SATA cable removed in Step 8 to connector (Ports 0-3) on RAID Controller.
 - When five or more hard disk drives are installed:
Connect SAS/SATA cable removed in Step 8 to connector (Ports 0-3) on RAID Controller.
Connect SAS/SATA cable provided with the server to connector (Ports 4-7) on RAID Controller.
Remove a single screw from server chassis, and remove battery tray for RAID Controller.
Connect another end of SAS/SATA cable that has been connected to connector (Ports 4-7) on RAID Controller, to the connector on backplane.
Secure the battery tray for RAID Controller with a single screw.
11. Continue to install or remove internal optional devices, mount and connect the server, and turn it on.

(2) When using optional RAID Controller (N8103-179)

See *Chapter 2 (1.10.4 Installing FBU)*.


1.18 Additional 2.5-inch HDD Cage

This server can have additional 2.5-inch HDD cage for installing additional hard disk drives.


1.18.1 Installation

Follow steps below to install an additional HDD cage.


1. See steps 1 to 6 in *Chapter 2 (1.3 Overview of Installation and Removal)* for preparations.
2. Remove the six screws from protective cover, and remove the protective cover.




3. Remove the blank cover of 2.5-inch HDD cage by pulling it toward you.




4. Install the additional 2.5-inch HDD cage.




5. Secure the protective cover with six screws you have removed in Step 2.




6. Disconnect SAS cable from the factory-installed HDD cage.




7. Install expander board to Expansion Bay and secure it with four screws provided with 2.5-inch HDD cage.




8. Connect the SAS cable (short) provided with 2.5-inch additional HDD cage to RAID Controller and Expander board.




9. Connect the provided DC cable to Expander board and additional HDD cage.




10. Connect the SAS cable (long) provided with 2.5-inch additional HDD cage to Expander Board, factory-installed HDD cage, and additional HDD cage.



11. Connect the provided SGPIO cable to factory-installed HDD cage and additional HDD cage.



12. Install support bar, PCI riser card, and then install the top cover.
13. Attach the ID label to the front face of chassis.

**Note**

Keep the removed blank cover for future use.

1.18.2 Removal

To remove an additional HDD cage, reverse the installation procedure above.

Important

To maintain the cooling effect in the server, install the blank cover in the vacant slot.

1.19 Optical Disk Drive



This section describes the procedure for installing the optional optical disk drive.

Important Do not install any unsupported optical disk drive.


1.19.1 Installation

Install an optical disk drive in the following procedure.

1. See steps 1 to 6 in Chapter 2 (1.3 Overview of Installation and Removal) for preparations.
2. Push the lock on optical disk drive to unlatch it, and pull the tray out.




3. Remove a single screw from the tray you have removed in Step 2, and remove the bracket.




4. Remove the dummy cover.

Note Keep the removed screws and dummy cover for future use.


5. Install the optical disk drive to the tray.




6. Secure the bracket to optical disk drive with a screw.



7. Insert the optical disk drive and secure the drive tray.



8. Connect a cable to the optical disk drive.



1.19.2 Removal

To remove an optical disk drive, reverse the installation procedure above.

1.20 Use of Internal Hard Disk Drives in the RAID System

This section describes how to use the internal hard disk drives in the RAID System.

Important

If you use hard disk drives in the RAID System or change the RAID level, hard disk drives are initialized. If the hard disk drive contains valuable data, be sure to backup the hard disk drive before installing the RAID Controller and configuring the RAID System.

Note

Build a Disk Array in the RAID System using hard disk drives that have the same specifications (capacity, rotational speed, and standard).


Tips

- Logical Drives can be created even with only one Physical Device.
- When using SAS hard disk drive, SAS SSD, or SATA SSD, it must be connected to RAID Controller.

1.20.1 Connecting cables

See the figures below for how to connect cables.


If using optional RAID Controller (1 to 8 hard disk drives)



Optional RAID Controller	Backplane	Hard Disk Drive
Ports 0-3	MINISAS1	SLOT 0
		SLOT 1
		SLOT 2
		SLOT 3
Ports 4-7	MINISAS2	SLOT 4
		SLOT 5
		SLOT 6
		SLOT 7

< If optional 2.5-inch HDD cage is installed and RAID Controller is used (1 to 16 hard disk drives) >

Connect cables according to the figure below.



Optional RAID Controller	Expander Card		Backplane	Hard Disk Drive
Ports 0 to 3	MINISAS1 (1A1, 1A9)	MINISAS2	Standard HDD cage MINISAS1	Slot 0
				Slot 1
				Slot 2
				Slot 3
		MINISAS3	Standard HDD cage MINISAS2	Slot 4
				Slot 5
				Slot 6
Ports 4 to 7	MINISAS2 (2A1, 2A9)	MINISAS4	Additional 2.5-inch HDD cage MINISAS1	Slot 7
				Slot 8
				Slot 9
				Slot 10
		MINISAS5	Additional 2.5-inch HDD cage MINISAS2	Slot 11
				Slot 12
				Slot 13
				Slot 14
				Slot 15

1.20.2 Notes on Building RAID System

Note the following points when building a RAID System.

- The number of hard disk drives required varies in each RAID level.
- If the optional RAID Controller N8103-176 is used, the RAID System cannot be built in RAID5/RAID6/RAID50/RAID60.

RAID level	The minimum number of hard disk drives required to set up a RAID System	
	N8103-176	N8103-177/178
RAID 0	1	1
RAID 1	2	2
RAID 5		3
RAID 6		3
RAID 10	4	4
RAID 50		6
RAID 60		6

- In the RAID System, all the hard disk drives in a group (pack) must have the same capacity, interface type, and rotational speed.
- If you intend to install the OS to the RAID System, the process from RAID configuration to OS installation can be easily completed by using EXPRESSBUILDER.
- If you wish to install the OS manually, use RAID System Off-line Utility (Ctrl-R or HII). For details, see *Chapter 2 (4. RAID System Configuration)* in "Maintenance Guide" or the manual supplied with the optional RAID Controller (N8103-176/177/178).

Important

- Do not change the mode to hibernate while building a RAID System.
- Build a Disk Array in the RAID System using hard disk drives that have the same specifications (capacity, rotational speed, and standard).

1.21 Installing Air Duct

Install air duct in reverse order of removal. Refer to *Chapter 2 (1.9 Removing Air Duct)*.

Important

Before removing the air duct, put cables aside. Otherwise, cables may be damaged if they are pulled together with air duct.

1.22 Installing Support Bar

Install support bar in reverse order of removal. Refer to *Chapter 2 (1.8 Removing Support Bar)*.

1.23 Installing PCI Riser Card

Install PCI riser card in reverse order of removal. Refer to *Chapter 2 (1.7 Removing PCI Riser Card)*.

1.24 Installing Top Cover

When all internal optional devices are installed, close the server with Top Cover.

1. Put the Top Cover straight on the server chassis so that it can be surely engaged with the chassis frame.
2. Slide the Top Cover toward the front of the server.
3. Tighten the fixing screw on rear of the server.

1.2.5 Hard Disk Drive

Bays for hard disk drives are provided at the front of the server.

A hard disk drive mounted in a dedicated drive tray can be purchased. Install the hard disk drive on the server with it mounted in the drive tray.

Important

Use hard disk drives specified by NEC. Installing a third-party hard disk drive might cause a failure of the server as well as the hard disk drive.

Note the following precautions to install hard disk drives.

- For onboard connection, hard disk drives having different capacities, types, or rotational speeds cannot be installed together.
- In the RAID System, all the hard disk drives in a group (pack) must have the same capacity, type, and rotational speed.

Bays can contain up to 8 hard disk drives.

Unique slot numbers have been assigned to each slot.


1.25.1 Installation

Install a hard disk drive by using the following procedure.

Note

In the RAID System, use hard disk drives that have the same specifications (capacity, rotational speed, and standard) for each Disk Array.


1. See Chapter 2 (1.3 Overview of Installation and Removal) for preparations.
2. Locate the slot where you install the hard disk drive.
The server has 8 slots (or 16 slots if 2.5-inch HDD cage is connected). Install hard disk drives in ascending order of port number.
3. Remove the dummy tray.
Dummy trays are installed in every slot.




Note

Keep the removed dummy trays for future use.

4. Unlock the handle of the tray.



5. Hold the tray firmly and insert it into the slot.



Note

- Push it all the way until the handle's lock touches the frame.
- Hold the tray firmly with both hands.

6. Slowly close the handle.
The tray is locked making a clicking sound.

Note

When you push the drive into the slot, confirm the handle got hooked on the frame.

7. Run BIOS Setup Utility, and then specify the boot order from **Boot** menu.
For details, see *Chapter 2 (1. System BIOS)* in "Maintenance Guide"

Tips

The saved boot order is cleared when a hard disk drive is added.

1.25.2 Removal

To remove hard disk drive, reverse the installation procedure.


If you transfer or dispose of the removed hard disk drive, see *Chapter 1 (1. Transfer, Relocation, and Disposal)* in "Maintenance Guide" to erase data.

Important

NEC assumes no liability for data leakage should the product be transferred to a third party without erasing the data.

Note

- If you remove a hard disk drive due to a failure, check the slot with its lower DISK LED lit in amber.



- Do not hold handle to pull the drive out. Doing so may damage the handle.

Run the BIOS Setup Utility, and then specify the boot order from **Boot** menu.
For details, see *Chapter 2 (1. System BIOS)* in "Maintenance Guide".

Tips

The saved boot order is cleared when a hard disk drive is added.

1.25.3 Replacing a hard disk drive in the RAID System (Auto Rebuild)

In the RAID System, you can use the auto rebuild feature to restore data back to the state before a failure occurred.

The auto rebuild feature is enabled in logical drives set to RAID 1, RAID 5, RAID 6, RAID 10, RAID 50, and RAID60.

The disk array is automatically rebuilt when hot swapping (replacing a hard disk drive while the power on) a failed hard disk drive.

During the auto rebuild, DISK LEDs 1 and 2 on the hard disk drive blink green and amber respectively to indicate that the auto rebuild is being performed.

Observe the following precautions whenever executing the auto rebuild

- Do not turn off the server until the auto build completes after a hard disk drive fails.
- Leave an interval of at least 90 seconds between a hard disk drive removal and a hard disk drive installation.
- Do not replace a disk during the auto rebuilding of another hard disk drive (during an auto rebuild, DISK LEDs 1 and 2 on the hard disk drive blink green and amber respectively).

1.26 Power Supply Unit

This server can contain two power supply units. The server provides a redundant power configuration that ensures continued operation of the system in the unlikely event one of the power supply units fails.

Tips

AC power supply unit has a cable tie to prevent AC cable from slipping out.

1.26.1 Cold Redundant Feature

The server supports the feature to optimize power efficiency as described below:

- Cold redundant feature can run the system with optimum power efficiency by raising operating efficiency of primary power supply unit and lowering that of redundant power supply unit in redundant power configuration.
- If power efficiency of power units is not optimized due to system configuration, this feature is disabled automatically.

Cold redundant feature can be used under the following conditions:

- Two power supply units must be installed for redundant configuration.
- See *Chapter 2 (1. System BIOS) in "Maintenance Guide"*, change parameters as shown below, save the settings and exit from SETUP.


Server → Power Control Configuration → Cold Redundant Mode → Enabled

Run SETUP again, and check if the status of **Cold Redundant Mode** shows **Enabled** in **Server** menu.

1.26.2 Installation


Follow steps below to install a power supply unit:

1. See steps 1 to 4 in Chapter 2 (1.3 Overview of Installation and Removal) for preparations.
2. Remove the blank cover.

**Note**

Keep the removed blank cover for future use.

3. Insert the power supply unit until it is locked with clicking sound.




4. Connect power cords.

Use the specified power cords.

AC POWER LED blinks green when the power cord is connected to either of power supply units and the other power supply unit's AC POWER LED goes on amber.

When the power cord is connected to it, AC POWER LEDs on both power supply units blink green.



5. Power on the server.

AC POWER LEDs go on green.

6. Confirm, by STATUS LED or on POST screen, that there are no errors related to the power supply units.


See *Chapter 3 (1. POST Error Message)* in “Maintenance Guide” for details on POST error messages.

If AC POWER LEDs are off, reinstall the power supply units. If the same error occurs, contact with your sales representative.

1.26.3 Replacing a failing power supply unit

Replace only when the power supply unit fails.

⚠ CAUTION



Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause burns, injury, and property damage. For details, refer to *Safety Precautions and Regulatory Notices*.


- Pay attention to electric hazard.

Important Do not remove a power supply unit operating normally.

1. Locate the failing power supply unit by the AC POWER LED on the power supply unit. (The LED of the failing power supply unit is lit amber or blinking amber.)
2. Power off the server.

Tips In the redundant power configuration (with two power supply units) and if either one of power supply units fails, the failing power supply unit can be replaced with the system power on.

3. Disconnect the AC power cord from the failing power supply unit.
4. Push the lever of the failing power supply unit toward inside, and pull the power supply unit while holding the handle.



5. If operating the server with a single power supply unit without installing a new one, install the blank cover you removed in step 2 of installation procedure.

Important To maintain the cooling effect in the server, be sure to install the blank cover in the vacant slot.


6. Install the new power supply unit taking steps 3 to 6 of "Installation", and confirm that the power supply unit is installed normally.

1.27 Installing Front Bezel

When installing Front Bezel, engage the left end of front bezel with chassis. Then, engage the right end of front bezel with chassis.

After installing Front Bezel, lock it with Bezel Lock Key.

If you fail to mount the front bezel properly, the front bezel might be damaged. See "Safety Precautions and Regulatory Notices" that comes with your server for proper procedure for mounting.



Important Be careful not to press the POWER Switch.

2. Installation and Connection


This section describes how to install the server and connect cables.


2.1 Installation

This server must be mounted to a rack which conforms to EIA standards for use.

2.1.1 Installing Rack


Refer to the manual that comes with your rack for how to install the rack, or consult with your sales representative.


 **WARNING**



Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause death or serious injury. For details, refer to *Safety Precautions and Regulatory Notices*.

- Use only in the specified environment.
- Do not connect the ground wire to a gas pipe.

 **CAUTION**



Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause burns, injury, and property damage. For details, refer to *Safety Precautions and Regulatory Notices*.


- Do not carry or install the server only by a single person.
- Do not install the server so that the load may be concentrated on a specific point.
- Do not install any components only by a single person.
Confirm that hinge pins of the door are completely secured in place.
- Do not pull out the server from the rack when the rack is unstable.
- Do not leave more than one device being pulled out from the rack.
- Do not provide the wiring for the server to exceed the rating of the power supply.
- Do not use the server in the environment where corrosive gas is generated.


Do not install the rack or server under the following environment. Doing so may cause malfunction of the server.

- Narrow space from which devices cannot be pulled out from the rack completely
- Place that cannot bear the total weights of the rack and devices mounted on the rack
- Place where stabilizers cannot be installed or where the rack can be installed only after the practice of proper earthquake-resistant construction
- Place of uneven or slanting floor
- Place of drastic temperature change (near a heater, air conditioner, or refrigerator)
- Place where intense vibration may be generated
- Place where corrosive gases (sulfur dioxide, hydrogen sulfide, nitrogen dioxide, chlorine, ammonia, ozone, etc) exist
Place where the air (or dust) includes components accelerating corrosion (ex. sulfur, sodium chloride) or conductive metals
- Place where chemicals may be accidentally sprayed over
- Place where a carpet not subject to anti-static process is laid
- Place where some objects may be fallen on the rack
- Place near a device generating intense magnetic field (such as TVs, radios, broadcast/communication antennas, power transmission wires, and electromagnetic cranes) is placed.
- Place where the power cord of the server must be connected to an AC outlet that shares the outlet of another device with large power consumption
- Place near equipment that generates power noise (e.g., contact spark at power-on/power-off of commercial power supply through a relay).
- Environment where operation of the server is not guaranteed

2.1.2 Installing the server to the rack or removing it from the rack


Mount the server to the rack. (This section also describes the removal procedure.)


 **WARNING**



Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause death or serious injury. For details, refer to *Safety Precautions and Regulatory Notices*.

- Do not use any racks out of standards.
- Use only under the specified environment.

 **CAUTION**



Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause burns, injury, and property damage. For details, refer to *Safety Precautions and Regulatory Notices*.

- Do not drop.
- Do not leave the server being pulled out.
- Do not install with the cover removed.
- Do not get your fingers caught.

Important

Temperature increases and airflow in the rack

If multiple devices are installed, or if the inside of the rack is not sufficiently ventilated, the internal temperature rises due to the heat emitted from each device, which may result in a malfunction. Review airflow in the rack and room and take sufficient measures so that the internal temperature will not exceed the operational temperature during operation.

Air enters the server from the front and exits from the rear.

(1) Installation

This server can be mounted to a rack made by NEC or other companies. Mount the server to a rack in the following procedure.


Preparation

- Checking rails
- Installing inner and outer rails


Important Rail for left side has different shape from that for right side. Make sure the orientation of rails to properly install them.

Checking inner rails

Make sure the orientation of inner rails.




Inner rail (L)



Inner rail (R)

Installing inner rails


1. Mount an inner rail marked as "R" to the right side of the server and "L" to the left side when viewed the server from front.
2. Align inner rail with three protrusions on side of server chassis, and slide the inner rail toward rear of the server. Make sure the lock at around the center of inner rail clicks to indicate the rail is surely locked. Install another inner rail to opposite side in similar way.




Checking outer rails

Make sure the orientation of outer rails by viewing "L" or "R" marked on rail.

Mount an outer rail marked as "R" to the right side of the server and "L" to the left side when viewed the server from front.



Outer rail (L)




Outer rail (R)

Installing outer rails

1. Fit the square-shaped protrusions of outer rail to the square holes of a 19-inch rack. Make sure that it makes a clicking sound indicating that it is locked.

The image on the right shows the front left side of the rack. Install to the rear left side and front and rear right sides following the same procedure.

Make sure that the rail is installed at the same height as the other rail already installed.



Important Confirm that the rail are securely locked so that they will not fall off.

Tips Although the rail may be somewhat unsteady, it is not defective.

Installing the Server

CAUTION



Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause burns, injury, and property damage. For details, refer to *Safety Precautions and Regulatory Notices*.


- Do not attempt to lift the server with single person.
- Do not drop.
- Do not leave the server being pulled out.
- Do not install with the cover removed.
- Do not get your fingers caught.

(1) Installation

Mount the server to a rack in the following procedure.


Important Always install the server with two or more persons.

1. Pull the slide rail from the outer rail until the slide rail is locked.



Note


Make sure that locking mechanism work normally.




Locked state

Locking mechanism

2. With two or more persons, firmly hold the server and mount it to the rack.



3. When the server is pushed into the rack and is locked, push the server to the end while pulling the release levers (blue) on both sides of the server.




4. Push the server until its lock on front panel clicks.

(2) Removal procedure


Remove the server from the rack in the following procedure.

Important At least two persons are required to remove the server from rack.


1. Make sure that the server is turned off and then disconnect the power cord or all interface cables from the server.
2. Remove the front bezel.



3. Slowly pull the server out while pressing the buttons located on both sides of the front of the server.



4. The server will come to a stop halfway. Press and hold Rail Stoppers (blue) on the rail and pull the server out of the rack.



Important Be careful not to get your fingers caught in the rails or lever.

5. Hold the server firmly and remove it from the rack.


Important

- While more than one person is supporting the bottom part of the server, slowly pull out the server.
- Do not apply pressure on the server from top when it is being pulled out. Doing so cause the server to drop.



(3) Removing Outer Rail

Remove outer rails from the rack in the following procedure.

1. See Chapter 2 (2.1.2 *Installing the server to the rack or removing it from the rack, (2) Removal procedure*) to remove the server from the rack.
2. Push the unlock lever on outer rail to the direction shown by arrow to house the slide rail.




3. While pressing the lever on outer rail, push the outer rail toward inside of the rack, then remove it.




2.2 Connection

Connect peripheral devices to the server.


Connectors that allow a variety of peripheral devices to be connected are provided at the front and rear of the server. Images on the following pages show the peripheral devices that can be connected in their standard state and their respective connector positions.


**WARNING**



Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause death or serious injury. For details, refer to *Safety Precautions and Regulatory Notices*.



- Do not hold the power plug with wet hands
- Do not connect the ground wire to a gas pipe

**CAUTION**



Be sure to observe the following precautions to use the server safely. Failure to observe the precautions may cause burns, injury, and property damage. For details, refer to *Safety Precautions and Regulatory Notices*.

- Use only the specified outlet to insert.
- Do not connect the power cord to an outlet that has an illegal number of connections.
- Insert the power plug into the outlet as far as it goes.
- Use only the specified power cord
- Do not connect or disconnect the interface cable with the power plugged in the outlet.
- Use only the specified interface cable



*1 Connect the power cord to a circuit breaker of up to 15 A.

*2 Either one can connect with a display unit.

Note

The serial port cannot be used to connect with leased line.


Note the following precautions to connect cables.

- When the device is not Plug and Play device, turn off the server and devices to be connected before connecting.
- If connecting any peripheral device and its interface cable made by other companies (a third party), contact your sales representative to check if they can be used with the server beforehand.
- Fix the power cord or interface cable with cable ties.
- Make sure that no pressure is applied on the plug of power cord.

2.2.1 Connecting to Uninterruptible Power Supply (UPS)

To connect the power cord of the server to a UPS, use the connector output on the rear of the UPS. For details, refer to the manual supplied with the UPS.

Example



When the power cord is connected to a UPS, change the BIOS settings in order to link the server with the power supply from the UPS.

To change the settings, select **Server** and then **AC-LINK** in BIOS Setup Utility, and change the displayed parameters. Select **Power On** to perform automatic operations by using the UPS. For details, see *Chapter 2 (1. System BIOS)* in "Maintenance Guide".

NEC Express5800 Series Express5800/R120f-2M

3

Setup

This chapter describes how to set up the server.

1. Turning on the Server

POST (Power-On Self-Test) is explained in this section.

2. BIOS Setup Utility (SETUP)

You can customize the BIOS settings by following the instructions in this section.

3. EXPRESSSCOPE Engine 3

EXPRESSSCOPE Engine 3 provides useful features through Baseboard Management Controller (BMC).

4. EXPRESSBUILDER

EXPRESSBUILDER helps you to install Windows and maintain the server.

5. Installing Software Components

You can install Windows and bundled software by following the instructions in "*Installation Guide (Windows)*".

6. Turning off the Server

Turn off power when not using the server.

1. Turning on the Server

Pressing POWER Switch at the front of the server turns on the server.

Turn on the server by using the following procedure.

Tips

Wait for at least 30 seconds before turning on the server after turning it off.

1. Turn on the peripheral devices and display unit.


Note

If the power cord is connected to power control system such as an Uninterruptible Power Supply (UPS), make sure that the power control system is turned on.

2. Remove Front Bezel.
3. If STATUS LED is lighting green or amber, wait until it goes off.
4. Press POWER Switch at the front of the server.
POWER LED is turned on green and after a while, logo appears on the display.

Important

Do not connect or disconnect USB device while POST is running.



While logo is being displayed, the self-diagnostic program (POST) runs and diagnoses the hardware. For details, see *Chapter 3 (1.1 POST)*.

1.1 POST

POST (Power-On Self-Test) is a self-diagnostic program stored in the server as standard. POST automatically runs immediately after the server is turned on and checks the motherboard, DIMM, and processor (CPU). POST also displays the start-up messages of different utilities during the operation.

Usually, you do not need to check the contents of POST. However, check messages displayed at POST in the following cases.

- When introducing a server
- If you suspect a failure
- When you hear beep many times during the time between power ON and OS startup
- When any error message is displayed

1.1.1 POST sequence

Explains how POST runs in order.

1. When the server is turned on, POST starts, and an initialization message is displayed. The message to tell initialization of a memory and a PCI device. After an initialization message was displayed, a logo appears on the screen.



Note

- Keyboard becomes operable after the logo appears.
- While an initialization message is displayed, a screen is sometimes switched over to the screen by which nothing is displayed (black screen) several times. It's no problem for operation.
- An initialization message and logo may not be displayed by the occasion with which an option VGA controller was connected and setting of a BIOS setup utility (SETUP).
- An initialization message is not displayed on the console redirection screen of a serial port.

2. If **Enabled** is specified for **Password On Boot** in **Security** menu of SETUP, you will be prompted to enter password after the logo is displayed. If you enter the incorrect password three times consecutively, POST aborts. (You can no longer proceed.) In this case, power off the server, and power it on.

Important

Do not set a password before OS is installed.

3. If <Esc> key is pressed, the logo disappears and the details of POST are displayed.

Tips

If **Quiet Boot** is **Disabled** from **Boot** menu in BIOS settings, the logo is not displayed and POST execution result is displayed..

4. After a while, the following message is displayed on the screen. (The on-screen message depends on your environment.)

Press <F2> SETUP, <F3> Internal Flash Memory, <F4> ROM Utility, <F12> Network

By pressing the designated function key following messages, you can call the functions below upon completion of POST.

<F2> key: Run BIOS Setup Utility (SETUP). For information on the SETUP, see *Chapter 2 (1. System BIOS) in "Maintenance Guide"*.

<F3> key: Run EXPRESSBUILDER from Internal Flash Memory. For information on EXPRESSBUILDER, see *Chapter 3 (4. EXPRESSBUILDER)*.

Note

- <F3> key is acceptable only for 5 seconds after the message is displayed.
- If bootable CD/DVD is inserted into optical disk drive, the system starts from CD/DVD even if <F3> key is pressed.

<F4> key: Run Offline Tools. For information on Offline Tools, see *Chapter 1 Maintenance (9. Offline Tools) in "Maintenance Guide"*.

<F12> key: Boot from network.

Tips

If **One time** or **Always** is specified for **Power Management Policy** in **Server** menu of BIOS SETUP, a message indicating power consumption is being measured is displayed instead of the message shown above. Wait for a while until measurement is complete.

5. When **Legacy** is specified for **Boot Mode**, if a controller which has its dedicated BIOS such as a RAID Controller is installed, a message that prompts you to start the dedicated utility to configure the card is displayed.

Example: If an optional RAID Controller is installed

Press <Ctrl> <R> to Run MegaRAID Configuration Utility

The utility starts by pressing <Ctrl> + <R> keys.

For details on the utility, refer to the manual supplied with each optional board.

Depending on the configuration, the message "Press Any Key" might appear to prompt a key entry. This is a behavior of the BIOS of the optional board. Continue to operate after checking the manual of the optional board.

6. The OS starts when POST is completed.

1.1.2 POST error messages

When POST detects an error, it displays an error message on the screen or beeps for some errors. For descriptions of error messages, causes, and countermeasures, see *Chapter 3 (1. POST Error Message) in "Maintenance Guide"*.

Note

Take notes on the indication displayed on display unit before consulting with your sales representative. Alarm messages are useful information for maintenance.

2. BIOS Setup Utility (SETUP)

This section describes how to configure Basic Input Output System (BIOS).

Make sure you have read and understood this section to configure properly.

2.1 Overview

BIOS Setup Utility (SETUP) is a utility to do basic hardware settings. This utility is installed in a flash memory in the server as standard and can be run without requiring a media for boot.

BIOS settings were configured with optimal settings before the server was shipped to you. Therefore, in most of cases, you should not need to use the SETUP. **Use only when the case applies to any of cases described in Chapter 3 (2.4 Cases that Require Configuration).**

2.2 Starting SETUP Utility

Run POST following *Chapter 3 (1.1.1 POST sequence)*.

After a while, the following message will be displayed on the lower left of the screen. (The on-screen message depends on your environment.)

Press <F2> SETUP, <F3> Internal Flash Memory, <F4> ROM Utility, <F12> Network

If you press the <F2> key, SETUP starts upon completion of POST, and the **Main** menu is displayed.

Tips

In Legacy boot mode, you can also launch SETUP by pressing the <F2> key while expanding option ROM.

Password

If you have set a password, a message prompt you to enter password will be displayed.

Enter password [

You can attempt password entry up to 3 times. If you entered an incorrect password 3 times, operation stops. (You cannot operate further.) Turn off the power.

Saving changes

If you finish configuration, select **Save & Exit** and then **Save Changes and Exit** to save changes and exit.


If you wish to exit without saving the changed parameters, select **Save & Exit** and then **Discard Changes and Exit**.

Tips

- If you wish to restore the setting to default values, select **Save & Exit** and then **Load Setup Defaults**.
- The default value might be different from the factory setting.
- You cannot restore the default value in the following submenus in **Advanced** menu:
 - **iSCSI Configuration** submenu
 - **UEFI Driver Configuration** submenu

2.3 Description on On-Screen Items and Key Usage

This section shows display examples and how to control the key. Use the keyboard to work with SETUP.



- ☐ Cursor keys (<↑>, <↓>)
Select an item displayed on the screen. If characters of an item are highlighted, that means the item is currently selected.
- ☐ Cursor keys (<←>, <→>)
Select menus including **Main**, **Advanced**, **Security**, **Server**, **Boot**, and **Save & Exit**.
- ☐ <→> key/<+> key
Change the value (parameter) of the selected item. You cannot use this key when a menu which has ► on the left is selected.
- ☐ <Enter> key
Press this key to determine the selected parameter.
- ☐ <Esc> key
Pressing this key cancels pop-up window. On the submenu, pressing this key takes you to the previous screen. On the top menu, the following window is displayed. If you select **Yes**, SETUP closes without saving the changed parameters.

Quit without saving?	
[Yes]	No

- ☐ <F1> key
Press this key to display help information. If you need help using SETUP, press this key. Press <Esc> key to go back to the original screen.

☐ <F2> key

If you press this key, the following window appears. If you select **Yes**, the previous parameter(s) are restored. If you have saved changes by selecting **Save & Changes**, pressing the <F2> key restores the saved value.

Load Previous Values?
[Yes] No

☐ <F3> key

If you press this key, the following window appears. If you select **Yes**, restore the parameters of the currently selected item to the default setting. **(This might be different from the parameters configured before shipment.)**

Load Setup Defaults?
[Yes] No

Note

The values set on **iSCSI Configuration** submenu and **UEFI Driver Configuration** submenu are not returned to the default setting.

☐ <F4> key

If you press this key, the following window appears. If you select **Yes**, the parameter you configured is saved and SETUP closes.

Save configuration and exit?
[Yes] No

2.4 Cases that Require Configuration

Only if a case applies to any of following cases, use SETUP to change a parameter which was configured as factory setting. Other than cases described below, do not change the settings. A list of SETUP parameters and factory settings are described in **Chapter 2 (1. System BIOS) in "Maintenance Guide"**.

Category	Description	To be changed	Remark
Basic	Change date and time	Main → System Date Main → System Time	Configurable on OS
	On/Off NumLock on power ON	Boot → Bootup Numlock State → ON or OFF	
	On/Off the function to display NEC logo during POST	Boot → Quite Boot → Disabled	By pressing <Esc> key, prevent the display of the logo.
Memory	Add or change DIMM	Advanced → Memory Configuration → Memory Retest → Yes	After rebooting, Memory Retest changes No automatically.
	Use memory RAS feature	Advanced → Memory Configuration → Memory RAS Mode → change to RAS mode	Some of RAS features may not be used depending on DIMM configuration.
Optional board	Start the system from installed option board.	Advanced → PCI Configuration → PCI Device Controller and Option ROM Settings → PCIX Slot Option ROM → Enabled	XX is PCI slot number of the installed option board
Boot	Set the boot mode to UEFI mode according to your OS.	Boot → Boot Mode → UEFI Select UEFI mode for the following OS. – Windows Server 2012 – Windows Server 2012 R2	See "Before Starting Setup" in Chapter 1 (Installing Windows) in <i>Installation Guide</i> to determine the boot mode.
	Set the boot mode to Legacy BIOS mode according to your OS.	Boot → Boot Mode → Legacy Select Legacy mode for the following OS. – Windows Server 2008 – Windows Server 2008R2	See "Before Starting Setup" in Chapter 1 (Installing Windows) in <i>Installation Guide</i> to determine the boot mode.
	Change the boot order of devices	Boot → Boot Option Priorities → Change the boot priority	When you use EXPRESSBUILDER, set CD/DVD to the highest priority.
	Use remote power on feature (via modem)	Advanced → Advanced Chipset Configuration → Wake On Ring → Enabled	
	Use remote power on feature (via RTC alarm)	Advanced → Advanced Chipset Configuration → Wake On RTC Alarm → Enabled	
	Use console redirection feature	Advanced → Serial Port Configuration → Console Redirection Settings → Change respective setting.	In console redirection connection, if the corrupted text is displayed on terminal screen, change font type (character code) appropriate to your environment.
	Enable X2APIC feature according to your OS.	Advanced → Processor Configuration → X2APIC → Enabled Enable X2APIC for the following OS. – Windows Server 2012 – Windows Server 2012 R2	See "Before Starting Setup" in Chapter 1 (Installing Windows) in <i>Installation Guide</i> to select Enabled or Disabled .
	Disable X2APIC feature according to your OS.	Advanced → Processor Configuration → X2APIC → Disabled Disable X2APIC for the following OS. – Windows Server 2008 – Windows Server 2008R2	See "Before Starting Setup" in Chapter 1 (Installing Windows) in <i>Installation Guide</i> to select Enabled or Disabled .

Category	Description	To be changed	Remark
Security	Set a password	Security → Administrator Password → Enter a password (Set a password for Administrator first and then User)	There are two types of password; Administrator and User. Settings for User password is limited compared to for Administrator.
	Restrict bootup by entering password	Security → Password on Boot → Enabled	Can be selected when password is set.
UPS Powerlink	When the server is supplied with power from UPS, always turn on the power.	Server → Power Control Configuration → AC-LINK → Power On	
	If it is turned off by using POWER switch, leave it OFF even when UPS supplies power.	Server → Power Control Configuration → AC-LINK → Last State	
	Keep the power OFF even when UPS supplies power.	Server → Power Control Configuration → AC-LINK → Stay off	

3. EXPRESSSCOPE Engine 3

3.1 Overview

EXPRESSSCOPE Engine 3 provides a variety of features using BMC (Baseboard Management Controller), which is a system management LSI.

See *EXPRESSSCOPE Engine 3 User's Guide* for detailed information.

EXPRESSSCOPE Engine 3 monitors the power supply unit, fans, temperature, and voltage of the server. If you have the management LAN port connected to the network, you can remotely perform the following over a web browser or SSH client:

- Manage the server
- Remotely control the keyboard, video, and mouse (KVM)*
- Remotely access a CD/DVD/floppy disk/ISO image/USB memory*.

* To enable this feature, the optional license for remote management (N8115-04) is required.

To actualize these functions, virtual USB mass storage (Remote FD, Remote CD/DVD, Remote USB Memory, or Virtual Flash) is always connected as USB mass storage.

3.2 EXPRESSSCOPE Engine 3 Network Configuration


Take the steps below to use EXPRESSSCOPE Engine 3 through the Web browser.

1. Run POST following *Chapter 3 (1.1.1 POST sequence)*. Wait until the following message appears on the lower left of the screen.

Press <F2> SETUP, <F3> Internal Flash Memory, <F4> ROM Utility, <F12> Network

2. Press the <F4> key while the message is being displayed to launch ROM Utility.
3. Select your keyboard type on Keyboard Selection screen.


4. On Off-line TOOL MENU, select **Server Configuration Utility** → **EXPRESSSCOPE Engine 3** → **Configuration** → **Network** → **IPv4 Property** or **IPv6 Property**.



5. On the following screen, select **Enable** when you use DHCP, or select **Disable** and specify IP Address (Required), Subnet Mask (Required), Default Gateway, and DNS Server when you do not use DHCP.

Tips

If **Shared BMC LAN** is enabled, Web feature, remote media/KVM feature, or command line interface feature may be interrupted. In this case, wait for a while, and connect with network again.



When **IPv4 Property** is selected

6. Connect the LAN cable to the management LAN connector in order to connect to the network. It will be available for use if you access EXPRESSSCOPE Engine 3 via Web browser from management PC according to the setting.

4. EXPRESSBUILDER

EXPRESSBUILDER helps you to install Windows or maintain the server.

4.1 Features of EXPRESSBUILDER

EXPRESSBUILDER provides the following features.

Features	Descriptions
Setup (Windows reinstallation)	Installs Windows on your server. Easily completes the process from RAID configuration to installation of applications. To use this feature, select OS installation in the menu after boot.
Bundled software	Stores various bundled software (such as NEC ESM PRO ServerAgentService).
Maintenance	Diagnoses your server system. To use this feature, select Tool menu in the menu after boot.
Documents	Stores various documents (including "User's Guide", "Installation Guide" and "Maintenance Guide").

4.2 Starting EXPRESSBUILDER

If you need to configure RAID system or install an OS, launch EXPRESSBUILDER in one of the following ways:

EXPRESSBUILDER DVD:

Set the DVD on the drive and either turn on the server or restart the server by pressing <Ctrl> + <Alt> + <Delete>. EXPRESSBUILDER is booted from DVD.

If you want to install any bundled software or read documents, set the DVD to a computer running Windows. Autorun menu appears automatically.

Internal Flash Memory:

Press <F3> key during POST. **Make sure that the media must be removed from the drive** when using this option.

Windows Application

If EXPRESSBUILDER is installed in Windows, you can use it as a Windows application. See *Chapter 2 (5. Details of EXPRESSBUILDER)* in *Maintenance Guide* for detail.

5. Installing Software Components

Continue to install software components such as OS.

See the instructions below.

- [Installation Guide \(Windows\)](#)

6. Turning Off the Server

Turn off the server by using the following procedure. If the power cord of the server is connected to a UPS, refer to the documentation supplied with the UPS or the documentation for the application controlling the UPS.

1. Shut down the OS.
2. The server automatically turns off after the OS shuts down.
Confirm that POWER LED is OFF.
3. Turn off peripheral devices.

Tips

Hibernate function of Windows Server cannot be used. Do not set Hibernate at Windows shutdown.

NEC Express5800 Series Express5800/R120f-2M

4

Appendix

1. **Specifications**
2. **Interrupt Lines**
3. **Glossary**

1. Specifications

N code			N8100-				
			768F	769F	770F	771F	772F
CPU	CPU		Intel ®Xeon® processor				
			E5-2603 v3	E5-2609 v3	E5-2620 v3	E5-2623 v3	E5-2637 v3
	Clock speed		1.60GHz	1.90GHz	2.40GHz	3GHz	3.50GHz
	Number of CPUs, standard / maximum		1/2				
	Intel® Smart Cache (Last Level Cache)		15MB			10MB	15MB
	Number of cores (C) / Number of threads (T) per CPU		6C/6T		6C/12T	4C/8T	
Chipset			Intel® C612 chipset				
Memory	Capacity, standard/maximum		Not pre-installed (selectable option) / Registered DIMM : 384GB (24x 16GB), Load Reduced DIMM : 768MB (24x 32GB)				
	Memory module		DDR4-2133 Registered DIMM (4/8/16GB), DDR4-2133 Load Reduced DIMM (32GB)				
	Maximum operating frequency		1600MHz			1866MHz	2133MHz
	Error check, correction		ECC, x4 SDDC, Memory LockStep (x8 SDDC)				
	Memory sparing		Supported				
	Memory mirroring		Supported				
Auxiliary storage	Hard disk drive	Internal (standard)	—				
		Internal (maximum)	2.5-inch HDD: SATA 16TB (16x 1TB), SAS 28.8TB (16x 1.8TB), 2.5-inch SSD: SATA 12.8TB (16x 800GB), SAS 6.4TB (16x 400GB) (When optional HDD cage is installed)				
		Hot swap	Supported				
	Interface / RAID level		SATA 6Gb/s : RAID 0/1/5/6/10/50/60 (option), SAS 12Gb/s : RAID 0/1/5/6/10/50/60 (option)				
	Optical disk drive		Internal or external drive (option) *1				
	FDD		Optional: Flash FDD (1.44MB) *2				
	Expansion bay		1x 3.5-inch bay				
	Expansion slots	Supported slots		1x PCI Express 3.0 (x8 lane, x8 socket) (Full height, length 312mm) (Required in 2-CPU configuration) 2x PCI Express 3.0 (x8 lane, x8 socket) (Full height, length 220mm (1 slot is required in 2-CPU configuration) *5) 3x PCI Express 3.0 (x8 lane, x8 socket) (Low profile, length 220mm) (2 slots are required in 2-CPU configuration) 1x PCI Express 3.0 (x8 lane, x8 socket) (dedicated to RAID Controller) 1x PCI Express 3.0 (x8 lane, x8 socket) (dedicated to LOM Card) (With optional riser card, slot can be changed to PCI Express 3.0 (x16 lane, x16 socket + x8 lane, x16 socket, Full height)			
Graphics	Chip / VideoRAM		Embedded management controller chip / 32 MB				
	Graphic display / resolution		16,770,000 colors: 640x840, 800x600, 1,024x768, 1,280x1,024				
Interface			5x USB3.0 (2x front, 2x rear, 1x internal), 3x USB2.0 (2x rear, 1x internal) 2x Analog RGB (Mini D-Sub15 pin, 1x front, 1x rear) 1x Serial port (RS-232C compliant / D-Sub 9 pin, Serial port A, 1x rear, optional port can be used (up to two ports in total), 1x Management LAN connector (1000BASE-T/100BASE-TX/10BASE-T supported, RJ45, 1x rear) (With optional LOM card, 4x 1000BASE-T, 2x 10GBASE-T, 2x 10GBASE-SFP+, or 2x 1000BASE-T can be added)				
Redundant power supply			Supported (option, hot-plug available)				
Redundant fan			Supported (standard *5, hot-plug available)				
External dimensions (width × depth × height)			448.0mm × 734.7mm × 87.2mm (front bezel / protrusions / inner rails excluded) 482.6mm × 776.4mm × 87.5mm (front bezel / protrusions / inner rails included)				
Weight (Minimum *3/ Max.)			20.5kg / 33.0kg (including rails)				

N code	N8100-				
	768F	769F	770F	771F	772F
Power supply unit	Not pre-installed (selectable option), AC power supply unit 460W/800W/1000W 80 PLUS® Platinum compliant (bipolar grounded outlet) (hot-plug available) (Max: 2) AC100V/200V±10%, 50/60Hz±3Hz (Power cable is a required option.) 1000W 80 PLUS® Titanium compliant (bipolar grounded outlet) (hot-plug available) (Max: 2) AC100V/200V±10%, 50/60Hz±3Hz (Power cable is a required option.)				
Power consumption (100V at maximum configuration, at 25°C high-load state)	526VA/522W	545VA/541W	627VA/623W	651VA/646W	684VA/679W
Power consumption (100V at maximum configuration, at maximum power)	717VA/712W	746VA/741W	798VA/792W	839VA/834W	885VA/879W
Environmental requirements Temperature/Humidity	Operating: 10 to 40°C / 20 to 80%, Storage: -10 to 55°C / 20 to 80% (no condensation either when operating or when stored)				
Main accessories	EXPRESSBUILDER (NEC ESMPro Manager) (Windows), NEC ESMPro ServerAgentService (Windows), User's Guide (electronic document) included, Getting Started, Safety Precautions and Regulatory Notices, one-touch rack rail, and front bezel				
Installed OS	—				
Supported OSs	Microsoft® Windows Server® 2008 Standard (RTM, SP2 or later), Microsoft® Windows Server® 2008 Enterprise (RTM, SP2 or later), Microsoft® Windows Server® 2008 R2 Standard, Microsoft® Windows Server® 2008 R2 Enterprise, Microsoft® Windows Server® 2012 Standard, Microsoft® Windows Server® 2012 Datacenter, Microsoft® Windows Server® 2012 R2 Standard, Microsoft® Windows Server® 2012 R2 Datacenter, VMware ESXi™ 5.1 Update 2, VMware ESXi™ 5.5 Update 2				

- *1 If you do not intend to install an internal DVD-ROM or an internal DVD SuperMULTI in all systems, prepare at least one external DVD-ROM per system for maintenance and OS reinstallation purposes.
- *2 Prepare this if required. For the principal uses of a Flash FDD, refer to the notes on Flash FDD in the Maintenance Guide.
- *3 Minimum configuration for operation (1x CPU, 2x DIMM, 1x HDD, 1x Power supply unit)
- *4 To install PCI card of full length (312 mm) in slot #2C, N8116-37 Full-length PCI Card Kit is required.
- *5 Redundant fan configuration is available in an environment where ambient temperature is 10 to 35°C. If you want to use the server in an environment where ambient temperature is 40°C, you need to prepare N8181-125 Additional Redundant Fan Unit.

N code			N8100-					
			773F	774F	776F	777F	778F	
CPU	CPU		Intel ®Xeon® processor					
			E5-2640 v3	E5-2643 v3	E5-2660 v3	E5-2667 v3	E5-2670 v3	
	Clock speed		2.60GHz	3.40GHz	2.60GHz	3.20GHz	2.30GHz	
	Number of CPUs, standard / maximum		1/2					
	Intel® Smart Cache (Last Level Cache)		20MB		25MB	20MB	30MB	
		Number of cores (C) / Number of threads (T) per CPU		8C/16T	6C/12T	10C/20T	8C/16T	12C/24T
Chipset			Intel® C612 chipset					
Memory	Capacity, standard/maximum		Not pre-installed (selectable option) / Registered DIMM : 384GB (24x 16GB), Load Reduced DIMM : 768MB (24x 32GB)					
	Memory module		DDR4-2133 Registered DIMM (4/8/16GB), DDR4-2133 Load Reduced DIMM (32GB)					
	Maximum operating frequency		1866MHz	2133MHz				
	Error check, correction		ECC, x4 SDDC, Memory LockStep (x8 SDDC)					
	Memory sparing		Supported					
	Memory mirroring		Supported					
Auxiliary storage	Hard disk drive	Internal (standard)	—					
		Internal (maximum)	2.5-inch HDD: SATA 16TB (16x 1TB), SAS 28.8TB (16x 1.8TB), 2.5-inch SSD: SATA 12.8TB (16x 800GB), SAS 6.4TB (16x 400GB) (When optional HDD cage is installed)					
		Hot swap	Supported					
	Interface / RAID level		SATA 6Gb/s : RAID 0/1/5/6/10/50/60 (option), SAS 12Gb/s : RAID 0/1/5/6/10/50/60 (option)					
	Optical disk drive		Internal or external drive (option) *1					
	FDD		Optional: Flash FDD (1.44MB) *2					
	Expansion bay		1x 3.5-inch bay					
	Expansion slots	Supported slots		1x PCI Express 3.0 (x8 lane, x8 socket) (Full height, length 312mm) (Required in 2-CPU configuration) 2x PCI Express 3.0 (x8 lane, x8 socket) (Full height, length 220mm (1 slot is required in 2-CPU configuration) *5) 3x PCI Express 3.0 (x8 lane, x8 socket) (Low profile, length 220mm) (2 slots are required in 2-CPU configuration) 1x PCI Express 3.0 (x8 lane, x8 socket) (dedicated to RAID Controller) 1x PCI Express 3.0 (x8 lane, x8 socket) (dedicated to LOM Card) (With optional riser card, slot can be changed to PCI Express 3.0 (x16 lane, x16 socket + x8 lane, x16 socket, Full height)				
Graphics	Chip / VideoRAM		Embedded management controller chip / 32 MB					
	Graphic display / resolution		16,770,000 colors: 640x840, 800x600, 1,024x768, 1,280x1,024					
Interface			5x USB3.0 (2x front, 2x rear, 1x internal), 3x USB2.0 (2x rear, 1x internal) 2x Analog RGB (Mini D-Sub15 pin, 1x front, 1x rear) 1x Serial port (RS-232C compliant / D-Sub 9 pin, Serial port A, 1x rear, optional port can be used (up to two ports in total), 1x Management LAN connector (1000BASE-T/100BASE-TX/10BASE-T supported, RJ45, 1x rear) (With optional LOM card, 4x 1000BASE-T, 2x 10GBASE-T, 2x 10GBASE-SFP+, or 2x 1000BASE-T can be added)					
Redundant power supply			Supported (option, hot-plug available)					
Redundant fan			Supported (standard *5, hot-plug available)					
External dimensions (width × depth × height)			448.0mm × 734.7mm × 87.2mm (front bezel / protrusions / inner rails excluded) 482.6mm × 776.4mm × 87.5mm (front bezel / protrusions / inner rails included)					
Weight (Minimum *3/ Max.)			20.5kg / 33.0kg (including rails)					

N code	N8100-				
	773F	774F	776F	777F	778F
Power supply unit	Not pre-installed (selectable option), AC power supply unit 460W/800W/1000W 80 PLUS® Platinum compliant (bipolar grounded outlet) (hot-plug available) (Max: 2) AC100V/200V±10%, 50/60Hz±3Hz (Power cable is a required option.) 1000W 80 PLUS® Titanium compliant (bipolar grounded outlet) (hot-plug available) (Max: 2) AC100V/200V±10%, 50/60Hz±3Hz (Power cable is a required option.)				
Power consumption (100V at maximum configuration, at 25°C high-load state)	646VA/642W	795VA/790W	714VA/709W	809VA/803W	763VA/758W
Power consumption (100V at maximum configuration, at maximum power)	817VA/811W	998VA/991W	885VA/879W	994VA/987W	973VA/966W
Environmental requirements Temperature/Humidity	Operating: 10 to 40°C / 20 to 80%, Storage: -10 to 55°C / 20 to 80% (no condensation either when operating or when stored)				
Main accessories	EXPRESSBUILDER (NEC ESMPro Manager) (Windows), NEC ESMPro ServerAgentService (Windows), User's Guide (electronic document) included, Getting Started, Safety Precautions and Regulatory Notices, one-touch rack rail, and front bezel				
Installed OS	—				
Supported OSs	Microsoft® Windows Server® 2008 Standard (RTM, SP2 or later), Microsoft® Windows Server® 2008 Enterprise (RTM, SP2 or later), Microsoft® Windows Server® 2008 R2 Standard, Microsoft® Windows Server® 2008 R2 Enterprise, Microsoft® Windows Server® 2012 Standard, Microsoft® Windows Server® 2012 Datacenter, Microsoft® Windows Server® 2012 R2 Standard, Microsoft® Windows Server® 2012 R2 Datacenter, VMware ESXi™ 5.1 Update 2, VMware ESXi™ 5.5 Update 2				

- *1 If you do not intend to install an internal DVD-ROM or an internal DVD SuperMULTI in all systems, prepare at least one external DVD-ROM per system for maintenance and OS reinstallation purposes.
- *2 Prepare this if required. For the principal uses of a Flash FDD, refer to the notes on Flash FDD in the Maintenance Guide.
- *3 Minimum configuration for operation (1x CPU, 2x DIMM, 1x HDD, 1x Power supply unit)
- *4 To install PCI card of full length (312 mm) in slot #2C, N8116-37 Full-length PCI Card Kit is required.
- *5 Redundant fan configuration is available in an environment where ambient temperature is 10 to 35°C. If you want to use the server in an environment where ambient temperature is 40°C, you need to prepare N8181-125 Additional Redundant Fan Unit.

N code			N8100-			
			779F	931F	933F	
CPU	CPU		Intel ®Xeon® processor			
			E5-2690 v3	E5-2697 v3	E5-2699 v3	
	Clock speed		2.60GHz	2.60GHz	2.30GHz	
	Number of CPUs, standard / maximum		1/2			
	Intel® Smart Cache (Last Level Cache)		30MB	35MB	45MB	
		Number of cores (C) / Number of threads (T) per CPU		12C/24T	14C/28T	18C/36T
Chipset			Intel® C612 chipset			
Memory	Capacity, standard/maximum		Not pre-installed (selectable option) / Registered DIMM : 384GB (24x 16GB), Load Reduced DIMM : 768MB (24x 32GB)			
	Memory module		DDR4-2133 Registered DIMM (4/8/16GB), DDR4-2133 Load Reduced DIMM (32GB)			
	Maximum operating frequency		2133MHz			
	Error check, correction		ECC, x4 SDDC, Memory LockStep (x8 SDDC)			
	Memory sparing		Supported			
	Memory mirroring		Supported			
Auxiliary storage	Hard disk drive	Internal (standard)	—			
		Internal (maximum)	2.5-inch HDD: SATA 16TB (16x 1TB), SAS 28.8TB (16x 1.8TB), 2.5-inch SSD: SATA 12.8TB (16x 800GB), SAS 6.4TB (16x 400GB) (When optional HDD cage is installed)			
		Hot swap	Supported			
	Interface / RAID level		SATA 6Gb/s : RAID 0/1/5/6/10/50/60 (option), SAS 12Gb/s : RAID 0/1/5/6/10/50/60 (option)			
	Optical disk drive		Internal or external drive (option) *1			
	FDD		Optional: Flash FDD (1.44MB) *2			
	Expansion bay		1x 3.5-inch bay			
	Expansion slots	Supported slots		1x PCI Express 3.0 (x8 lane, x8 socket) (Full height, length 312mm) (Required in 2-CPU configuration) 2x PCI Express 3.0 (x8 lane, x8 socket) (Full height, length 220mm (1 slot is required in 2-CPU configuration) *5) 3x PCI Express 3.0 (x8 lane, x8 socket) (Low profile, length 220mm) (2 slots are required in 2-CPU configuration) 1x PCI Express 3.0 (x8 lane, x8 socket) (dedicated to RAID Controller) 1x PCI Express 3.0 (x8 lane, x8 socket) (dedicated to LOM Card) (With optional riser card, slot can be changed to PCI Express 3.0 (x16 lane, x16 socket + x8 lane, x16 socket, Full height)		
Graphics	Chip / VideoRAM		Embedded management controller chip / 32 MB			
	Graphic display / resolution		16,770,000 colors: 640x840, 800x600, 1,024x768, 1,280x1,024			
Interface			5x USB3.0 (2x front, 2x rear, 1x internal), 3x USB2.0 (2x rear, 1x internal) 2x Analog RGB (Mini D-Sub15 pin, 1x front, 1x rear) 1x Serial port (RS-232C compliant / D-Sub 9 pin, Serial port A, 1x rear, optional port can be used (up to two ports in total), 1x Management LAN connector (1000BASE-T/100BASE-TX/10BASE-T supported, RJ45, 1x rear) (With optional LOM card, 4x 1000BASE-T, 2x 10GBASE-T, 2x 10GBASE-SFP+, or 2x 1000BASE-T can be added)			
Redundant power supply			Supported (option, hot-plug available)			
Redundant fan			Supported (standard *5, hot-plug available)			
External dimensions (width × depth × height)			448.0mm × 734.7mm × 87.2mm (front bezel / protrusions / inner rails excluded) 482.6mm × 776.4mm × 87.5mm (front bezel / protrusions / inner rails included)			
Weight (Minimum *3/ Max.)			20.5kg / 33.0kg (including rails)			

N code	N8100-		
	779F	931F	933F
Power supply unit	Not pre-installed (selectable option), AC power supply unit 460W/800W/1000W 80 PLUS® Platinum compliant (bipolar grounded outlet) (hot-plug available) (Max: 2) AC100V/200V±10%, 50/60Hz±3Hz (Power cable is a required option.) 1000W 80 PLUS® Titanium compliant (bipolar grounded outlet) (hot-plug available) (Max: 2) AC100V/200V±10%, 50/60Hz±3Hz (Power cable is a required option.)		
Power consumption (100V at maximum configuration, at 25°C high-load state)	800VA/794W	836VA/830W	841VA/835W
Power consumption (100V at maximum configuration, at maximum power)	997VA/990W	1004VA/997W	1006VA/999W
Environmental requirements Temperature/Humidity	Operating: 10 to 40°C / 20 to 80%, Storage: -10 to 55°C / 20 to 80% (no condensation either when operating or when stored)		
Main accessories	EXPRESSBUILDER (NEC ESMPro Manager) (Windows), NEC ESMPro ServerAgentService (Windows), User's Guide (electronic document) included, Getting Started, Safety Precautions and Regulatory Notices, one-touch rack rail, and front bezel		
Installed OS	—		
Supported OSs	Microsoft® Windows Server® 2008 Standard (RTM, SP2 or later), Microsoft® Windows Server® 2008 Enterprise (RTM, SP2 or later), Microsoft® Windows Server® 2008 R2 Standard, Microsoft® Windows Server® 2008 R2 Enterprise, Microsoft® Windows Server® 2012 Standard, Microsoft® Windows Server® 2012 Datacenter, Microsoft® Windows Server® 2012 R2 Standard, Microsoft® Windows Server® 2012 R2 Datacenter, VMware ESXi™ 5.1 Update 2, VMware ESXi™ 5.5 Update 2		

- *1 If you do not intend to install an internal DVD-ROM or an internal DVD SuperMULTI in all systems, prepare at least one external DVD-ROM per system for maintenance and OS reinstallation purposes.
- *2 Prepare this if required. For the principal uses of a Flash FDD, refer to the notes on Flash FDD in the Maintenance Guide.
- *3 Minimum configuration for operation (1x CPU, 2x DIMM, 1x HDD, 1x Power supply unit)
- *4 To install PCI card of full length (312 mm) in slot #2C, N8116-37 Full-length PCI Card Kit is required.
- *5 Redundant fan configuration is available in an environment where ambient temperature is 10 to 35°C. If you want to use the server in an environment where ambient temperature is 40°C, you need to prepare N8181-125 Additional Redundant Fan Unit.

2. Interrupt Lines

Interrupt lines are assigned as factory settings as shown below. Use this table as a reference when you add optional devices.

- **Interrupt lines**

As factory settings, interrupt lines are assigned as follows.

IRQ	Peripheral Device (Controller)	IRQ	Peripheral Device (Controller)
0	System timer	12	SM Bus
1	–	13	Numeric data processor
2	–	14	–
3	COM 2 serial port	15	–
4	COM 1 serial port	16	SATA
5	PCI	17	
6	–	18	USB
7	PCI	19	USB
8	Real-time clock	20	
9	Microsoft ACPI-Compliant System	21	
10	PCI	22	
11	Motherboard resource	23	

3. Glossary

Terms	Description
BIOS Setup Utility (SETUP)	Software for setting BIOS. You can run this software by pressing <F2> key during POST.
BMC	Baseboard Management Controller (BMC) is a built-in controller that supports the IPMI version 2.0 protocol. BMC can manage the server hardware.
BMC RESET Switch	A switch for resetting the BMC of the server. This resets the BMC without clearing the BMC settings. Use the switch if the problem on the BMC occurs.
DUMP Switch	A switch that is used for collecting the memory dump if an error occurs. You can specify the destination of the dump by using the OS function.
EXPRESSBUILDER	Standard software for setting up the server easily. This also includes several useful applications and instruction manuals.
EXPRESSSCOPE ENGINE 3	A name of BMC for NEC Express5800 series.
EXPRESSSCOPE Profile Key	A removable flash memory that stored the settings of BIOS and BMC. If the motherboard of the server is replaced, you can use former settings when moving this flash memory from the former motherboard.
Express Report Service	Software that can report the server failure to the contact center by E-mail or modem. This software is installed with NEC ESMPRO ServerAgentService to the server.
Express Report Service (HTTPS)	Software that can report the server failure to the contact center by HTTPS. This software is installed with NEC ESMPRO ServerAgentService to the server.
Express Report Service (MG)	Software that can report the server failure to the contact center by E-mail, modem or HTTPS without NEC ESMPRO ServerAgentService. This software is installed with NEC ESMPRO Manager to "PC for Management".
ExpressUpdate	A feature for updating BIOS, firmware, driver, or software of the server. This feature is available when NEC ESMPRO Manager cooperates with EXPRESSSCOPE ENGINE 3 and ExpressUpdate Agent.
ExpressUpdate Agent	Software for performing ExpressUpdate. This is installed to the server.
Flash FDD	An optional USB device that can use as a floppy disk drive.
Internal Flash Memory	A built-in flash memory that stored EXPRESSBUILDER as standard. You can start EXPRESSBUILDER from it without DVD when pressing <F3> key during POST.
NEC ESMPRO	Standard software for the server management. This consists of several applications for managing or monitoring.
NEC ESMPRO Agent	Software for monitoring the server. This works with NEC ESMPRO Manager and resides as the OS service.
NEC ESMPRO Agent Extension	Software for performing the scheduled operations. This works with NEC ESMPRO Manager.
NEC ESMPRO Manager	Software for managing plural servers on network.
NEC ESMPRO ServerAgentService	Software for monitoring the server. This works with NEC ESMPRO Manager. You can choose Service Mode or Non-Service Mode when installing this software. Service Mode resides as the OS service and Non-Service Mode does not use the OS service to reduce the OS resources such as memory or CPU.
OEM driver	A Windows driver for the mass storage device.
OS standard installer	An installer that stored in Windows installation disc. Use this installer if you want to install the OS manually.
Offline tools	Software that can confirm or change IPMI data such as SEL, SDR, or FRU. You can start Offline tools when pressing <F4> key during POST.
PC for Management	A computer for managing the server on network. A general Windows/Linux computer can be used as "PC for Management".
Product Info Collection Utility	Software for collecting several hardware/software statuses or event logs. You can easily collect the data for the server maintenance by using this software.
RAID Configuration Utility	Software for configuring RAID arrays. You can run this software during POST.
Server Configuration Utility	Software for setting BIOS or BMC. You can use as Windows application or run this software when pressing <F4> key during POST. This software is the same as BMC Configuration of former models.
Starter Pack	Software package for the server. This software includes the customized drivers for Windows. This must be installed before using Windows on the server.
TPM Kit	An optional product of Trusted Platform Module for the server.
Universal RAID Utility	Software for setting RAID arrays on Windows/Linux. This software is operated on "PC for Management" with NEC ESMPRO Manager.
Windows OS parameter file	A file that saved settings for installing Windows. You can install with the saved settings in this file when setting Windows with EXPRESSBUILDER.

NEC Express Server

Express5800/R120f-2M
User's Guide

September 2014

NEC Corporation
7-1 Shiba 5-Chome, Minato-Ku
Tokyo 108-8001, Japan

©NEC Corporation 2014

The contents of this manual may not be copied or altered without the prior written permission of NEC Corporation.