



N8800-124F, EXP320J

NEC Express5800/320Fd-LR

N8800-125F, EXP320K

NEC Express5800/320Fd-MR

User's Guide

2nd Edition
10-2008

856-127506-121- B

PROPRIETARY NOTICE AND LIABILITY DISCLAIMER

The information disclosed in this document, including all designs and related materials, is the valuable property of NEC Corporation (NEC) and /or its licensors. NEC and/or its licensors, as appropriate, reserve all patent, copyright and other proprietary rights to this document, including all design, manufacturing, reproduction, use, and sales rights thereto, except to the extent said rights are expressly granted to others.

The NEC product(s) discussed in this document are warranted in accordance with the terms of the Warranty Statement accompanying each product. However, actual performance of each such product is dependent upon factors such as system configuration, customer data, and operator control. Since implementation by customers of each product may vary, the suitability of specific product configurations and applications must be determined by the customer and is not warranted by NEC.

To allow for design and specification improvements, the information in this document is subject to change at any time, without notice. Reproduction of this document or portions thereof without prior written approval of NEC is prohibited.

Second Printing, Oct 2008
Copyright 2008
NEC Corporation
7-1 Shiba 5-Chome, Minato-Ku
Tokyo 108-8001, Japan
All Rights Reserved
Printed in Japan

Keep this User's Guide handy for quick reference when necessary.

SAFETY INDICATIONS

To use NEC Express5800 series safely, follow the instructions in this User's Guide.

This guide explains components that pose a danger, types of dangers, and actions taken to prevent them; such components are labeled with warnings.

This guide and warning labels use "WARNING" and "CAUTION" to indicate a danger depending on the degree. These terms are defined as follows:

	Indicates a danger that could lead to a death or serious injury.
	Indicates a danger that could lead to a burn, other injuries or damage to physical assets.

This guide uses the following three types of symbols to give indications and precautions against a danger. They are defined as follows:

	Indicates that there is a risk of danger. Each image symbolizes a particular type of danger. (Attention)
	Indicates what you must not do. Each image symbolizes a particular type of prohibition. (Prohibited actions)
	Indicates what you must do. Each image symbolizes a particular type of action necessary to avoid a danger. (Mandatory actions)

(Example)

	
<p>Symbol indicating a prohibited action (may not always be indicated)</p>	<p>Symbol to draw attention Term indicating a degree of danger</p>
<p>High temperature. Immediately after the power-off, system components such as hard disk are very hot. Wait the server to cool down completely before adding/removing some component.</p>	<p>CAUTION</p>

Symbol indicating a prohibited action (may not always be indicated)

Description of a danger

SYMBOLS USED IN THIS USER'S GUIDE AND WARNING LABELS

Attention

	Indicates a risk of an electric shock.
	Indicates a risk of a personal injury due to heat.
	Indicates a risk of catching your fingers.
	Indicates a risk of a fire or smoke.
	Indicates a general precaution or warning that is not defined herein.
	Indicates a risk of losing eyesight due to laser beam.
	Indicates a risk of an explosion.
	Indicates a risk of a personal injury.

Prohibited actions

	Indicates a general prohibition that is not defined herein.
	Do not touch the indicated area. There is a risk of an electric shock or fire.
	Do not touch with wet hands. There is a risk of an electric shock.
	Keep from flame. There is a risk of a fire.
	Avoid using water or liquid nearby. If it spills on the equipment, there is a risk of an electric shock or fire.
	Do not disassemble, repair, or modify the equipment. There is a risk of an electric shock or fire.

Mandatory actions

	<p>Unplug the server. There is a risk of an electric shock or fire.</p>
	<p>Indicates a general action to take that is not defined herein. Make sure to follow the instructions.</p>

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

이 기기는 업무용으로 전자파적합등록을
한 기기이오니 판매자 또는 사용자는
이 점을 주의하시기 바라며 만약 잘못
판매 또는 구입하였을 때에는 가정용으
로 교환하시기 바랍니다.

This class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

CE Statement

Warning: This is a Class A product. In residential environment, this product may cause radio interference, in which case the user may be required to take adequate measures (EN55022).

**CLASS 1
LASER PRODUCT**

This system is classified as a CLASS 1 LASER PRODUCT. This label is located on the internal DVD-ROM installed in your system.

NOTE: This product provides resistance against hardware faults with its redundant hardware modules. However, this does not mean complete fault-tolerance is assured. For example, there is a risk of system down when:

- A fatal fault occurs in software.
- Both modules within a redundant hardware pair break down.
- A fatal fault occurs in a non-redundant component, such as the clock generator circuitry or the interconnect backplane.
- The entire system is cut off from AC power.

安全注意事項

安全標示

請參考本用戶指南中的指示以安全使用NEC Express5800系列伺服器。

本用戶指南說明了設備何處有危險、危險類型、如何避免危險等。在設備可預計到的危險之處或其附近貼有警告標籤。

用戶指南及警告標籤中，根據危險程度不同，使用“警告”、“注意”等詞，含義如下：

	表示如不遵守該指示，可能引發人員傷亡。
	表示如不遵守該指示，可能發生燒傷等身體損傷或造成物質損失。

對危險的提示表示有如下三種符號，具體含義如下所述：

	表示該處可能發生危險。符號為危險內容的圖案。（注意）
	表示禁止行爲。符號中或其附近的圖案為禁止行爲內容。（禁止行爲）
	表示強制行爲。符號中的圖案為強制必須做的行爲內容。即為避免危險必需的行爲。（強制行爲）

(用戶指南中範例)

	注意符號
	表示危險程度的用語
⚠ CAUTION	
注意高溫。 本產品關閉電源後，內置硬碟等內部設備仍然處於高溫狀態。請在充分冷卻之後進行拆裝。	

禁止行爲的提示符號（有可能沒有此類提示）

危險提示內容

本書及警告標籤中使用的符號

注意

	表示有觸電的危險。
	表示有因高溫而負傷的危險。
	表示有手指等被夾住的危險。
	表示有冒煙或者著火的危險。
	表示非特定的一般的提醒警告。
	表示有因雷射導致失明的危險。
	表示有爆炸的危險。
	表示有受傷的危險。

禁止行爲

	表示非特定的一般禁止。
	不要觸摸指定區域。有觸電或著火的危險。
	不要用濕手觸摸。有觸電的危險。
	遠離火源。有著火的危險。
	遠離液體。如果沾到液體，有觸電或著火的危險。
	請不要對本設備進行拆卸、修理、改造。有觸電和發生火災的危險。

強制行爲

	請將本設備的電源插頭從伺服器上拔下。有發生火災和觸電的危險。
	對非特定的一般使用者的行爲進行指示。請按照說明進行操作。

警告使用者：

這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。

CLASS 1 LASER PRODUCT

這是CLASS 1 LASER PRODUCT。該標籤貼於系統的內部光碟。

注意：本產品通過多餘的硬體模組提供硬體容錯性能。但是這並不能夠保證完全容錯。如，在以下情況下可能發生宕機：

- 軟體發生致命故障。
- 多餘硬體雙方均發生故障，不能運行。
- 時鐘產生器線路或內部連接背板等非多餘元件發生致命故障。
- 切斷了整個系統的AC電源

Trademarks

NEC EXPRESSBUILDER, NEC ESMPRO and NEC DianaScope are trademarks of NEC Corporation.

Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and other countries.

Microsoft Windows Server 2003 R2 Standard x64 edition operating system and Microsoft Windows Server 2003 R2 Enterprise x64 Edition operating system or Microsoft Windows Server 2003 Enterprise x64 Edition operating system are called Windows Server 2003 x64 Edition for short. Microsoft Windows Server 2003 R2 32-bit Standard Edition operating system, Microsoft Windows Server 2003 R2 32-bit Enterprise Edition operating system, Microsoft Windows Server 2003 Standard Edition operating system and Microsoft Windows Server 2003 Enterprise Edition operating system are called Windows Server 2003 for short. Microsoft Windows 2000 Server operating system, Microsoft Windows 2000 Advanced Server operating system and Microsoft Windows 2000 Professional operating system are called Windows 2000 for short. Microsoft Windows Vista Business operating system is called Windows Vista for short. Microsoft Windows XP Professional x64 Edition operating system is called Windows XP x64 Edition for short. Microsoft Windows XP Home Edition operating system and Microsoft Windows XP Professional operating system are called Windows XP for short. Microsoft Windows NT Server network operating system version 3.51/4.0 and Microsoft Windows NT Workstation operating system version 3.51/4.0 are called Windows NT for short. Microsoft Windows Millennium Edition Operating System is called Windows Me for short. Microsoft Windows 98 operating system is called Windows 98 for short. Microsoft Windows 95 operating system is called Windows 95 for short. Names used with sample applications are all fictitious. They are unrelated to any existing product names, names of organizations, or individual names.

All other product, brand, or trade names used in this publication are the trademarks or registered trademarks of their respective trademark owners.

Trademarks and Patents

DianaScope is trademarks of NEC Corporation. AVOCENT and DVC (DAMBRACKAS VIDEO COMPRESSION) are registered trademarks of US AVOCENT in the United States and other countries. Mozilla is a registered trademark of Mozilla Foundation.

Netscape is a registered trademark of Netscape Communications Corporation in the United States and other countries. Java is a registered trademark of Sun Microsystems, Inc in the United States and other countries.

N8815/006, ft remote management card, adopts the DVC technology of AVOCENT US.

US Patent Number: 5,732,212/5,937,176/6,633,905/6,681,250/6,701,380 (other patents pending)

Taiwanese Patent Number: 173784

European Patent Number: 0 740 811

Notes:

- (1) No part of this manual may be reproduced in any form without prior written permission of NEC Corporation.
- (2) The contents of this manual are subject to change without prior notice.
- (3) The contents of this manual shall not be copied or altered without prior written permission of NEC Corporation.
- (4) All efforts have been made to ensure the accuracy of all information in this manual. If you find any part unclear, incorrect, or omitted in this manual, contact the sales agent where you purchased this product.
- (5) NEC assumes no liability arising from the use of this product, nor any liability for incidental or consequential damage arising from the use of this manual regardless of (4) above.

© NEC Corporation 2008

(THIS PAGE IS INTENTIONALLY LEFT BLANK.)

PREFACE

Welcome to the NEC Express5800/ft series.

NEC Express5800/ft series is a “fault-tolerant (ft)” server focusing on “high reliability” in terms of fault-tolerance, in addition to “high performance,” “scalability,” and “general versatility” provided by NEC Express5800 series. In the event of trouble, its dual configuration will allow the system to instantaneously isolate the failed parts to assure non-stop running; operation will be moved smoothly from one module to the other, minimizing damage to it. You can use this NEC Express5800/ft series in a mission-critical system where high availability is required. By the use of Linux operating system, it also provides outstanding openness for general-purpose applications, etc.

To make the best use of these features, read this User's Guide thoroughly to understand how to operate NEC Express5800/ft series.

開始

這次，請購買敝社的 Express5800/ft 服務器，實在謝謝。

Express5800/ft 服務器系列，是 Express5800 系列的「高性能」，「擴展性」，「通用性」的特長之外又加上，考慮與耐故障性出色的「高(貴)的可靠性」，被開發了的「Fault Tolerant 服務器」。在要求是把向從不給予由於在萬一障礙的發生中根據也雙重化，把障礙地方做為瞬間割開的事業務影響繼續做動作，一邊的組件已經一方的組件業務交待順暢地進行，業務給予的損壞做為最小限度控制住的事可能的系統的本裝置，高(貴)的可用性的基幹業務中也可以放心使用。再根據 Linux 操作系統的採用，能適用通用應用軟件等，開放性也出色。

爲了到最大限度拉出本裝置有的機能，很好地變成爲變成使用之前正式文本爲念，充分地裝置的對待也請理解。

ABOUT THIS USER'S GUIDE

This User's Guide helps a user to properly setup and use the product.

Consult this guide to ensure safety as well as to cope with trouble during a system setup and daily operation.

Keep this manual handy.

This User's Guide is intended for users who have a good knowledge on the basic use of Linux operating systems and general I/O devices such as a keyboard and mouse.

How to Use This User's Guide

This guide consists of eight chapters and appendices. To help you find a solution quickly, the guide contains the following information:

For descriptions on setting up this product, see the separate volume "User's Guide (Setup)." Read "Precautions for Use" first.

Before going on to main chapters, be sure to read "Precautions for Use." These precautions are very important for using the product safely.

Chapter 1 Precautions for Use

This chapter describes precautions necessary to use the product safely and properly. Be sure to read this chapter before using the product. It also provides information on user support. It will be helpful when you need maintenance service, support, etc.

Chapter 2 General Description

This chapter describes what you should know about the product: its component names, functions, operating procedures as well as handling of devices and other parts.

Chapter 3 Linux Setup and Operation

This chapter describes setup and operation specific to the product when it is on Linux.

Chapter 4 System Configuration

This chapter describes how to make settings of built-in basic input/output system. It also describes factory-shipped parameters.

Chapter 5 Installing and Using Utilities

This chapter describes features and operating procedures of a standard utility "NEC EXPRESSBUILDER." It also describes procedures to install and operate various software programs contained in its DVD.

Chapter 6 Maintenance

This chapter describes maintenance procedures and use of maintenance tools. If you need to move the product for maintenance purposes, follow the steps provided in this chapter.

Chapter 7 Troubleshooting

If the product does not work properly, see this chapter before deciding that it is a breakdown.

Chapter 8 System Upgrade

This chapter describes procedures to add options and precautions. See also this chapter when you replace failed components.

Appendix A Specifications

This appendix lists specifications of the product.

Appendix B I/O Port Addresses

This appendix lists factory-assigned I/O port addresses.

Additional symbols

The following symbols are used throughout this User's Guide in addition to the caution symbols describe at the beginning.

- IMPORTANT:** Important points or instructions to keep in mind when using the server or software
- CHECK:** Something you need to make sure when using the server of software
- TIPS:** Helpful information, something useful to know

About our Web Service

Information on NEC Express5800/ft series including modification modules is also available on our web site, NEC Express5800 Web Site Asia Pacific:

<http://www.nec.co.jp/express/index.html>

Accessories

This product is shipped with various accessories. See the packing list to make sure everything is included and check the individual items. If some component is missing or damaged, contact your sales agent.

- Keep the accessories in a safe place. You will need them when you perform setup, addition of options, or replacement of failed components.
- To check NEC EXPRESSBUILDER components, see the attached list.
- Be sure to fill out and mail the software registration card that is attached to your operating system.
- Make backup copies of included floppy disks, if any. Keep the original disks as the master disks; use these copies in operation.
- Improper use of an included floppy disk or DVD may alter your system environment. If you find something unclear, stop using them and contact your sales agent.

關於正式文本

正式文本，是爲了確實使用本裝置的輔導。在日常使用上，不知道的發生了事和情形壞事的時候，包含對待上的安全性請利用。使正式文本與另冊的用戶指南(安裝編輯)一起請經常放置在實體旁邊無論什麼時候被看。

正式文本，作爲所說的關於 Linux 等的操作系統和鍵盤，鼠標的一般的輸入輸出設備等的基本的對待有了充分的知識的用戶對象被記載。

關於正式文本的構成

正式文本與 8 個章從附錄被構成。各自的章象下面一樣的說明被記載。再者，卷末有索引。按照必要請有效的利用。關於有關本裝置的安裝的說明請參照另冊的用戶指南(安裝編輯)。

第 1 章 爲了安全確

實辦理使用上的注意本裝置必要的注意事項被記載。處理本裝置之前必定請讀。同時，關於用戶支持也記載著。保守和各種各樣的服務，請希望支持的時候讀。

第 2 章 想預先知道的事

本裝置的各部分的名稱和那個功能，一般的操作和設備，關於零部件的處理說明著。

第 3 章 關於 Linux 的設定和在操作 Linux 上的本裝置固有的安裝和操作說明。

第 4 章 關於系統的構成

本裝置內部被容納的基本輸入輸出系統的設定方法說明著。同時，關於出貨的時候的參數價值也記載著。

第 5 章 關於實用程序的安裝和操作

本裝置用標準添加的「EXPRESSBUILDER」提供的功能和操作方法，和被「EXPRESSBUILDER」光碟容納的各種軟件的安裝次序和操作方法說明著。

第 6 章 保守

關於本裝置的保守方法和保守工具的用法說明著。同時，需要如果移動裝置到保守時候，請遵從用這個章說明的次序移動裝置。

第 7 章 故障嗎？想的時候

本裝置確實不做動作，「故障嗎？想」的時候，請懷疑實體的故障之前參照。

第 8 章 系統的升級

關於關於本裝置用的選擇的增設方法的注意事項和增設次序說明著。也請交換出現故障了的零部件的時候參照。

附錄 A 方法

記載著本裝置的方法。

附錄 B I/O 端口地址

用一覽顯示著本裝置內部的 I/O 端口地址的分配。

附錄 C 保守服務網一覽

是 NEC 守備株式會社的服務據點的地址和電話號碼的一覽。受到保守的時候參照，請聯絡到附近的保守據點。

關於本文中的記號

除了正式文本卷頭表現了的安全有關的注意記號以外使用者 3 種記號。變成這些的記號和意義為理解，請確實處理裝置。關於正式文本的

重要:

裝置的對待，表現必須用軟件的操作保持的事情和特別應該做注意點。

檢查:

需要在操縱裝置和軟件上預先做確認表示的點。

暗示:

預先知道的話對錶現有用的信息，方便的事等。

關於正式文本的再購買

如果被遺失了正式文本，最近的銷售店，或購買的銷售店請諮詢。能從用戶指南，和添加的光碟收納的在綠文獻的一部分，下面的主頁下載。

關於附屬品

本產品的捆包箱子的其中，對實體以外種種的附屬品進入著。確認參照添加的構成部品全部齊(整)的事，請各自檢查。萬一不足的如果有東西和損傷的東西，請與購買的銷售店聯繫。

重要: 關於附屬品

- 添加品因為做安裝的時候和選擇的增設，實體成為出現故障了的時候必要最後一幕請保管。
- 關於添加品的「EXPRESSBUILDER」光碟的構成部品，請參照包裝中有的構成部品表。
- 操作系統添加的軟件登記卡，請所定事項記入之後，必定投進郵筒。
- 如果軟盤被添加，請採用軟盤的接應。同時，作為主人軟盤最後一幕保管添加的軟盤，請使用備份盤。
- 添加的軟盤再光碟，有在使用方法上犯錯誤的話變更了顧客的系統環境的可能。如果關於使用有不明
的點，不做困難的操作請對購買的銷售店，或保守服務公司詢問。

CONTENTS

PREFACE.....	i
ABOUT THIS USER'S GUIDE	i
How to Use This User's Guide	iii
Additional symbols	iv
Accessories	v
CHAPTER 1 PRECAUTIONS FOR USE	1-1
WARNING LABELS	1-3
PRECAUTIONS FOR SAFETY	1-5
General	1-5
Use of Power Supply and Power Cord	1-6
Installation, Relocation, Storage and Connection	1-7
Cleaning and Handling of Internal Devices	1-9
During Operation	1-10
Rack-mount Model	1-11
For Proper Operation	1-12
DISPOSAL OF EQUIPMENT AND CONSUMABLES	1-14
IF SYSTEM TROUBLE IS SUSPECTED	1-15
ABOUT REPAIR PARTS.....	1-15
ABOUT OUR WEB SERVICE.....	1-15
CHAPTER 2 GENERAL DESCRIPTION	2-1
STANDARD FEATURES.....	2-2
NAMES AND FUNCTIONS OF COMPONENTS.....	2-6
Front View	2-7
Rear View.....	2-9
DVD-ROM drive.....	2-12
CPU/IO Module.....	2-13
Mother Board	2-14
ft Remote Management Card.....	2-15
LEDs.....	2-16
BASIC OPERATION	2-22
Installing/removing the front bezel.....	2-22
Power ON.....	2-23
Power OFF	2-24
POST Check.....	2-24
Floppy Disk Drive (Option)	2-28
DVD-ROM drive.....	2-30
CHAPTER 3 LINUX SETUP AND OPERATION	3-1
DISK OPERATIONS.....	3-2
Operable Disk Configuration.....	3-2
Replacing a Hard Disk Drives.....	3-4
DUPLEX LAN CONFIGURATION.....	3-9
Functional Overview	3-9

Operable Network Configuration	3-9
Configuring Duplication.....	3-9
CHECKING THE DUPLICATING OPERATION OF MODULES.....	3-12
Evaluate Startup and Stop of PCI Modules	3-12
Evaluate Start and Stop of CPU Modules.....	3-15
FT SERVER SERVICE	3-18
NOTES ON ACCESS TO USB FDD	3-19
CONFIGURING THE VIDEO MODE.....	3-20
CHAPTER 4 SYSTEM CONFIGURATION.....	4-1
SYSTEM BIOS –SETUP–.....	4-2
Starting SETUP Utility	4-3
Description of On-Screen Items and Key Usage	4-4
Configuration Examples	4-6
Menu and Parameter Descriptions.....	4-8
SAS BIOS –Adaptec SAS/SATA Configuration Utility–.....	4-34
FORCED SHUTDOWN AND CLEAR.....	4-43
Forced Shutdown.....	4-43
Clear CMOS/Password.....	4-44
REMOTE MANAGEMENT FUNCTION	4-49
Network Default Values.....	4-49
Settings on the Server.....	4-50
Initial Settings on the Server	4-50
Setting a Management PC.....	4-51
Using Remote Management.....	4-53
Troubleshooting.....	4-84
CHAPTER 5 INSTALLING AND USING UTILITIES	5-1
NEC EXPRESSBUILDER	5-2
Start Menu.....	5-2
Autorun Menu.....	5-4
NEC ESMPRO AGENT AND MANAGER.....	5-5
Overview	5-5
NEC ESMPRO Agent.....	5-12
NEC ESMPRO Manager.....	5-20
Maintenance of NEC Express5800/ft series	5-32
CHAPTER 6 MAINTENANCE	6-1
DAILY MAINTENANCE	6-2
Checking Alert.....	6-2
Checking STATUS LEDs.....	6-2
Making Backup Copies	6-3
Cleaning.....	6-3
SYSTEM DIAGNOSTICS	6-7
Test Items	6-7
Startup and Exit of System Diagnostics.....	6-7
MAINTENANCE TOOLS.....	6-10
Starting the Off-line Maintenance Utility	6-10
Function of Maintenance Tools.....	6-12
TO THE ACCIDENT OF PCI MODULE	6-16

Procedure to Confirm.....	6-16
Procedure to Recover	6-17
Procedure to Check.....	6-19
CHAPTER 7 TROUBLESHOOTING.....	7-1
TO LOCATE THE ERRORS.....	7-2
ERROR MESSAGES.....	7-2
Error Messages by LED Indication.....	7-3
POST Error Messages.....	7-4
Server Management Application Error Message.....	7-10
TRUBLESHOOTING.....	7-8
Problems with NEC Express5800/ft series	7-8
Problems with NEC EXPRESSBUILDER.....	7-16
Problems with Master Control Menu.....	7-17
Problems with NEC ESMPRO.....	7-18
COLLECTING TROUBLE LOGS.....	7-19
Collection of System Information	7-19
Collection of the Memory Dump.....	7-19
CHAPTER 8 SYSTEM UPGRADE.....	8-1
SAFETY PRECAUTIONS.....	8-2
ANTI-STATIC MEASURES.....	8-3
PRE-UPGRADE VERIFICATION.....	8-4
PREPARING YOUR SYSTEM FOR UPGRADE.....	8-5
3.5-INCH HARD DISK DRIVE.....	8-6
Installing 3.5-inch Hard Disk Drive	8-7
Removing 3.5-inch Hard Disk Drive.....	8-9
Replacing 3.5-inch Hard Disk Drive.....	8-10
CPU/IO MODULE.....	8-11
Precautions.....	8-11
Removing CPU/IO Module.....	8-12
Installing CPU/IO Module.....	8-15
DIMM.....	8-17
Precautions.....	8-18
Installing DIMM.....	8-19
Removing DIMM.....	8-22
Replacing DIMM.....	8-24
PROCESSOR (CPU).....	8-25
Installing CPU	8-26
Removing CPU.....	8-28
PCI BOARD.....	8-29
Installing PCI Board.....	8-31
Removing PCI Board.....	8-35
Replacing PCI Board.....	8-35
Setup of Optional PCI Board.....	8-36
APPENDIX A SPECIFICATIONS.....	A-1
APPENDIX B I/O PORT ADDRESSES.....	B-1

(This page is intentionally left blank.)

Chapter 1

Precautions for Use

This chapter includes information necessary for proper and safe operation of the server.

使用上的注意


本章包含著對服務器恰當安全的操作必要的信息。

WARNING LABELS

Warning label is placed in the certain part of the system so that the user stays alert to possible risks. Do not remove or damage the label.

If this label is missing, about to peel off, or illegible, contact your sales agent.

The figures below show the location of this label on the server.



Front of Device

PRECAUTIONS FOR SAFETY

This section provides precautions for using the server safely. Read this section carefully to ensure proper and safe use of the server. For symbol meanings, see "SAFETY INDICATIONS" described in the previous section.

General

 WARNING	
	<p>Do not use the equipment in an operation where human lives are involved or high reliability is required.</p> <p>This equipment is not intended for use and control in facilities/systems where human lives are involved or high reliability is required, including medical devices or nuclear, aerospace, transportation, and traffic control facilities. NEC assumes no liability for any accidents or damage to physical assets resulting from the use of this equipment in such systems or facilities.</p>
	<p>Do not continue to use the equipment if you detect smoke, odor, or noise. If the equipment emits smoke, odor, or noise, immediately flip off the POWER switch, unplug the cord, and contact your sales agent. There is a risk of a fire.</p>
	<p>Do not insert a wire or metal object.</p> <p>Do not insert a wire or metal objects into a vent or disk drive slot. There is a risk of an electric shock.</p>
	<p>Do not use the equipment in an unsuitable place.</p> <p>Do not install a server rack in an unsuitable environment. Other systems also may be affected, and the rack may fall over to cause a fire or injuries. For details about installation environment and quake-resistant engineering, see the attached manual or contact your sales agent.</p>
 CAUTION	
 	<p>Prevent water or foreign objects from getting into the equipment.</p> <p>Do not let water or foreign objects (e.g., pins or paper clips) enter the equipment. There is a risk of a fire, electric shock, and breakdown. When such things accidentally enter the equipment, immediately turn off the power and unplug the cord. Contact your sales agent instead of trying to disassemble it yourself.</p>

Use of Power Supply and Power Cord

⚠ WARNING	
	<p>Do not handle a power plug with a wet hand.</p> <p>Do not plug/unplug a power cord with a wet hand. There is a risk of an electric shock.</p>
	<p>Do not connect the ground wire to a gas pipe.</p> <p>Never connect the ground wire to a gas pipe. There is a risk of a gas explosion.</p>
⚠ CAUTION	
	<p>Do not plug the attached cord in a nonconforming outlet.</p>
	<p>Use a wall outlet with specified voltage and power type. There is a risk of a fire or current leakage.</p> <p>Avoid installing the equipment where you may need an extension cord. If the cord that does not meet the power specifications, there is a risk of overheating that could lead to a fire.</p>
	<p>Do not plug multiple cords in a single outlet.</p> <p>If the rated current is exceeded, there is a risk of overheating that could lead to a fire.</p>
	<p>Do not plug the cord insecurely.</p> <p>Insert the plug firmly into an outlet. There is a risk of heat or fire due to poor contact. If dust settles on the slots and it absorbs moisture, there is also a risk of heat or fire.</p>
 	<p>Do not use nonconforming power cords.</p> <p>AC cord is to spend the thing of the next specifications. You also have to observe the following prohibitions about handling and connecting interface cables.</p> <ul style="list-style-type: none">■ Do not pull on the cord.■ Do not pinch the cord.■ Do not bend the cord.■ Keep chemicals away from the cord.■ Do not twist the cord.■ Do not tread on the cord.■ Do not place any object on the cord.■ Do not use cords as bundled.■ Do not alter, modify, or repair the cord.■ Do not staple the cord.■ Do not use any damaged cord. (Replace it with a new one of the same specifications. For replacement procedures, contact your sales agent.)

Installation, Relocation, Storage and Connection

	<p data-bbox="353 619 398 833">⚠ WARNING</p> <p data-bbox="443 1200 510 1264"></p> <p data-bbox="448 220 481 1129">Disconnect the power cord(s) before installing or removing the equipment.</p> <p data-bbox="510 156 609 1129">Be sure to power off the equipment and unplug its power cords from the wall outlet before installation/relocation. All voltage is removed only when the power cords are unplugged.</p>
	<p data-bbox="701 619 745 833">⚠ CAUTION</p> <p data-bbox="795 1200 862 1264"></p> <p data-bbox="795 402 828 1129">Do not install or store the equipment in an unsuitable place.</p> <p data-bbox="857 172 922 1129">Install or store the equipment in such a place as specified in this User's Guide. Avoid the following, or there is a risk of a fire.</p> <ul data-bbox="922 609 1048 1129" style="list-style-type: none">■ a dusty place■ a humid place located near a boiler, etc■ a place exposed to direct sunlight■ an unstable place <p data-bbox="1079 1200 1146 1264"></p> <p data-bbox="1079 715 1113 1129">Be careful not to hurt your fingers.</p> <p data-bbox="1142 347 1207 1129">Exercise great care not to hurt your fingers on the rail when you mount/dismount the equipment into/from the rack.</p> <p data-bbox="1238 1200 1305 1264"></p> <p data-bbox="1238 427 1272 1129">Do not use or store this product in corrosive environment.</p> <p data-bbox="1290 210 1355 1129">Avoid the usage or storage of this product in an environment which may be exposed to corrosive gases, such as those including but not limited to: sulfur dioxide, hydrogen sulfide, nitrogen dioxide, chlorine, ammonia and/or ozone.</p> <p data-bbox="1415 156 1480 1129">Avoid installing this product in a dusty environment or one that may be exposed to corrosive materials such as sodium chloride and/or sulfur.</p> <p data-bbox="1480 156 1545 1129">Avoid installing this product in an environment which may have excessive metal flakes or conductive particles in the air.</p> <p data-bbox="1545 194 1644 1129">Such environments may cause corrosion or short circuits within this product, resulting in not only damage to this product, but may even lead to be a fire hazard.</p> <p data-bbox="1644 220 1709 1129">If there are any concerns regarding the environment at the planned site of installation or storage, please contact your sales agent.</p>

⚠ CAUTION



Do not connect any interface cable with the power cord of the server plugged to a power source.



Make sure to power off the server and unplug the power cord from a power outlet before installing/removing any optional internal device or connecting/disconnecting any interface cable to/from the server. If the server is off-powered but its power cord is plugged to a power source, touching an internal device, cable, or connector may cause an electric shock or a fire resulted from a short circuit.



Do not use any non-designated interface cable.

Use only interface cables designated by NEC; identify which component or connector to attach beforehand. If you use a wrong cable or make a wrong connection, there is a risk of short-circuit that could lead to a fire. You also have to observe the following prohibitions about handling and connecting interface cables:

- Do not use any damaged cable connector.
- Do not step on the cable.
- Do not place any object on the cable.
- Do not use the equipment with loose cable connections.
- Do not use any damaged cable.

Cleaning and Handling of Internal Devices

 WARNING	
	Do not disassemble, repair, or alter the server.
 	Unless described herein, never attempt to disassemble, repair, or alter the equipment. There is a risk of an electric shock or fire as well as malfunction.
	Do not look into the optical disk drive.
	The optical disk drive uses a laser beam. Do not look or insert a mirror inside while the system is on. A laser beam is invisible; if your eyes are exposed to the laser beam, there is a risk of losing eyesight.
	Do not detach a lithium battery yourself.
	This equipment has a lithium battery. Do not detach it yourself. If the battery is exposed to fire or water, it could explode.
	When the lithium battery is running down and the equipment doesn't work correctly, contact your sales agent. Do not disassemble or recharge the battery yourself.
	Disconnect the power plug before cleaning the server.
	Make sure to power off the server and disconnect the power plug from a power outlet before cleaning or installing/removing internal optional devices. Touching any internal device of the server with its power cord connected to a power source may cause an electric shock even if the server is off-powered.
	Disconnect the power plug from the outlet occasionally and clean the plug with a dry cloth. Heat will be generated if condensation is formed on a dusty plug, which may cause a fire.
 CAUTION	
	High temperature Immediately after powering off the system, system components such as hard disk may be very hot. Wait for the server to cool down completely before adding/removing components.
	Make sure to complete installation. Firmly install all power cords, interface cables and/or boards. An incompletely installed component may cause a contact failure, resulting in fire and/or smoke.

⚠ CAUTION



Protect the unused connectors with the protective cap.

The unused power cord connectors are covered with the protective cap to prevent short circuits and electrical hazards. When removing the power cord connector from the internal devices, attach the protective cap to the connector. Failure to follow this warning may cause a fire or an electric shock.

During Operation

⚠ CAUTION



Do not pull out a device during operation.

Do not pull out or remove a device while it works. There is a risk of malfunction and injuries.



Do not touch the equipment when it thunders.

Unplug the equipment when it threatens to thunder. If it starts to thunder before you unplug the equipment, do not touch the equipment and cables. There is a risk of a fire or electric shock.



Keep animals away.

Animal's waste or hair may get inside the equipment to cause a fire or electric shock.



Do not place any object on top of the server.

The object may fall off to cause injuries, damage to hardware and/or a fire.



Do not leave the DVD tray ejected.

Dust may get in the equipment to cause malfunction. The ejected tray may also become a cause of injuries.

Rack-mount Model

CAUTION



Do not install the equipment on a nonconforming rack.

Install the equipment on a 19-inch rack conforming to the EIA standard. Do not use the equipment without a rack or install it on a nonconforming rack. The equipment may not function properly, and there is a risk of damage to physical assets or injuries. For suitable racks, contact your sales agent.



Do not attempt to install the server yourself.

To avoid a risk of injuries, users should not attempt to install the equipment into a rack. Installation should be performed by trained maintenance personnel.

< For Maintenance Personnel Only >



Do not install the equipment in such a manner that its weight is imposed on a single place.

To distribute the weight, attach stabilizers or install two or more racks. It may fall down to cause injuries.



Do not assemble parts alone.

It takes at least two people to mount doors and trays to a rack. You may drop some parts to cause a breakage or injuries.



Do not pull a device out of the rack if it is unstable.

Before pulling out a device, make sure that the rack is fixed (by stabilizers or quake-resistant engineering).



Do not leave two or more devices pulled out from the rack.

If you pull out two or more devices the rack may fall down. You can only pull out one device at a time.



Do not install excessive wiring.

To prevent burns, fires, and damage to the equipment, make sure that the rated load of the power branch circuit is not exceeded. For more information on installation and wiring of power-related facilities, contact your electrician or local power company.



Do not pull out a device from the rack during operation.

Do not pull out a device while it works. There is a risk of malfunction and injuries.

For Proper Operation

Observe the following instructions for successful operation of the server. Failure to observe them could lead to malfunction or breakdown.

- Do not use a cellular phone or pager around the equipment. Turn off your cellular phone or pager when you use the equipment. Their radio waves may cause the equipment to malfunction.
 - Perform installation in a place where the system can operate correctly. For details, see the separate volume “User’s Guide (Setup).”
 - Before turning off the power or ejecting a disk, make sure that the access LED is off.
 - When you have just turned off the power, wait at least 30 seconds before turning it on again.
 - Once you have turned on the server, do not turn it off until the “NEC” logo appears on the screen.
 - After plugging in the power cord, do not turn on the power of the equipment for 30 seconds.
 - For safe operation, it is recommended to reboot the OS after duplication is completed.
 - Before you move the equipment, turn off the power and unplug the cord.
 - This server shall not assure reproduction of copy-protect CDs using reproduction equipment if such disks do not comply with CD standards.
 - Clean the equipment regularly. (For procedures, see Chapter 6.) Regular cleaning is effective in preventing various types of trouble.
 - Lightning may cause voltage sag. As a preventive measure, it is recommended to use UPS (uninterruptible power supply).
- This equipment does not support the connection through an UPS serial port (RS-232C) or the control using PowerChute *Plus*.
- Check and adjust the system clock before operation in the following conditions:
 - After transporting the equipment
 - After storing the equipment
 - After the equipment halt under the conditions which is out of the guaranteed environment conditions (Temperature: 10 to 35°C, Humidity: 20 to 80%).
- Check the system clock once in a month. It is recommended to operate the system clock using a time server (NTP server) if it is installed on the system which requires high level of time accuracy. If the system clock goes out of alignment remarkably as time goes by, though the system clock adjustment is performed, contact your sales agent.

- When you store the equipment, keep it under storage environment conditions (Temperature: -10 to 55°C, Humidity: 20 to 80%, non-condensing).

- If NEC Express5800/ft series, the built-in optional devices, and the media set for the backup devices (tape cartridges) are moved from a cold place to a warm place in a short time, condensation will occur and cause malfunctions and breakdown when these are used in such state. In order to protect important stored data and assets, make sure to wait for a sufficient period of time to use the server or components in the operating environment.

Reference: Length of the time effective at avoiding condensation in winter (more than 10°C differences between room temperature and atmospheric temperature)

Disk devices: Approximately 2-3 hours

Tape media: Approximately 1 day

- Make sure that the optional devices are attachable and connectable to the equipment. There is a risk of malfunctions that could lead to a breakdown of the equipment even if you could attach and connect.
- Make sure that your options are compatible with the system. If you attach any incompatible option, there is a risk of malfunction that could lead to a breakdown.
- It is recommended to use NEC's genuine option products. Some competitors' products are compatible with this server. However, servicing for trouble or damage resulting from such a product will be charged even within the warranty period.

DISPOSAL OF EQUIPMENT AND CONSUMABLES

- When you dispose of the main unit, hard disk drives, floppy drives, floppy disks, DVDs, optional boards, etc., you need to observe your local disposal rules. Dispose the attached power cable along with the equipment to avoid being used with other equipment.

For details, ask your municipal office.

IMPORTANT:

For disposal (or replacement) of batteries on the motherboard, consult with your sales agent.

You are responsible for wiping out such data before disposal. Erase all data on the hard disk, backup data cartridges, floppy disks, or other writable media (such as CD-R and CD-RW); prevent your data from being restored and reused by a 3rd party. You need to exercise sufficient care to protect privacy and confidential information.


- Some of the system components have limited lifetime (e.g., cooling fans, built-in batteries, built-in optical disk drive, floppy disk drive and mouse). For stable operation, it is recommended to replace them regularly. For lifetime of individual components and replacing procedures, ask your sales agent.

⚠ WARNING



Do not detach a lithium battery yourself.

This equipment has a lithium battery. Do not detach it yourself. If the battery is exposed to fire or water, it could explode. **RISK OF EXPLOSION IF BATTERIES IS REPLACED WITH INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.** When the lithium battery is running down and the equipment doesn't work correctly, contact your sales agent. Do not disassemble, replace or recharge the battery yourself.



IF SYSTEM TROUBLE IS SUSPECTED

Before sending the equipment for repair, try the following:

1. Check if its power cord and connection cables are attached correctly.
2. See “Error Messages” in Chapter 7 to check if there is a relevant symptom. If yes, take measures as instructed.
3. Certain software programs are required for operation of NEC Express5800/ft series. Check if these programs are properly installed.
4. Use a commercially available anti-virus program to check the server.

If the problem isn't solved by the above actions, stop using the server and consult with your sales agent. In this case, check LED indications of the server and alarm indications on the display, which will serve as helpful information at the time of repair.

ABOUT REPAIR PARTS

The minimum duration of holding repair parts of this equipment may be different for each country, so contact the NEC sales representatives.

If the period is not specified, the repair parts are kept for 5 years after discontinuance of the product.

ABOUT OUR WEB SERVICE

Information on NEC Express5800/ft series including modification modules is also available on our web site, NEC Express5800 Web Site Asia Pacific, at <http://www.nec.co.jp/express/index.html>


Advice for Your Health

Prolonged use of a computer may affect your health. Keep in mind the following to reduce stresses on your body:

Sit in a good posture

Sit on your chair with your back straight. If the desk height is appropriate, you will slightly look down at the screen and your forearms will be parallel to the floor. This “good” work posture can minimize muscle tension caused by sedentary work.

If you sit in a “bad” posture—for example, sit round-shouldered or with your face too close to the display—you may easily suffer fatigue or have your eyesight affected.




Adjust the installation angle of Display

Most types of displays allow you to adjust the angle vertically and horizontally. This adjustment is very important to prevent the reflection of light as well as to make the screen more comfortable to see. Without this adjustment, it is difficult to maintain a “good” work posture and may get tired soon. Be sure to adjust the angle before using the display.



Adjust Brightness and Contrast

Displays allow you to adjust brightness and contrast. Optimum brightness and contrast vary depending on the individual, age, brightness of the room, etc; you need to make an adjustment accordingly. If the screen is too bright or too dark, it is bad for your eyes.



Adjust the installation angle of Keyboard

Some types of keyboards allow you to adjust the angle. If you adjust the angle to make the keyboard more comfortable to use, you can greatly reduce stresses on your shoulders, arms, and fingers.



Clean the Equipment

Cleanliness of the equipment is very important not only for reasons of appearance but also from the viewpoints of function and safety. Especially, you need to regularly clean the display, which gets unclear due to the accumulation of dirt.

Take a break when you get tired

If you feel tired, you are recommended to refresh yourself by taking a short break or doing a light exercise.



安全注意事項

本節講述安全使用本伺服器所需的注意事項。爲了您正確安全地使用本伺服器，請仔細閱讀該節內容。符號的相關說明請參考“安全標示（SAFETY INDICATIONS）”說明。

一般注意事項

 WARNING	
	<p>不要用於危及人命和需要高度可靠性的操作上。</p> <p>本產品不要安裝在醫療設備、原子能設備、航空宇宙機器、航空宇宙機器、運輸設備等會危及人命以及需要高度可靠性的設備和機器上，也不要使用本產品來控制這些機器。如果將本產品用於這類系統的設備及機器，造成人身事故及財產損失等後果，本公司概不負責。</p>
	<p>發生冒煙、異味、雜音時不要使用。</p>
	<p>發生冒煙、異味、雜音等時，請直接關閉電源POWER，並將電源插頭從插座上拔下。然後請與經銷商或維護服務公司聯繫。繼續使用會導致火災。</p>
	<p>不要插入鐵絲和金屬片。</p> <p>不要將金屬片和鐵絲等異物插入通氣孔或軟碟機、光碟機的縫隙。有觸電的危險。</p>
	<p>不要在未指定的場所使用本產品。</p> <p>不要在未指定的環境中安裝伺服器機架。</p> <p>否則，其他系統可能會受到影響，並且機架脫落可能導致火災或者人身傷害。有關安裝環境和防震技術的詳細事項請參閱附帶的用戶手冊或與經銷商或維護服務公司聯繫。</p>

 CAUTION	
 	<p>設備內不要進水和異物。</p> <p>設備內不要進入水、針、夾子等異物。有可能導致火災和觸電。一旦進入異物，請立即關閉電源，將電源插頭從插座上拔下來。不要自行拆卸，請與經銷商或維護服務公司聯繫。</p>

使用電源及電源線注意事項

⚠ WARNING	
	不要用濕手拿電源插頭。
不要用濕手插拔電源插頭。有觸電的危險。	
	不要把地線連接到煤氣管道上。
請勿將地線連接到煤氣管道上。有導致煤氣爆炸的危險。	

⚠ CAUTION	
不要插入未指定的插座。	
電源請使用指定電壓及電源的壁式插座。使用未指定的電源會造成火災和漏電。請避免使用延長線安裝設備。如果連接與本產品電源規格不相符的電線，會因過熱而導致火災。	
	不要在一個插座上插接多個電源線。
插座如果超過額定電流，會因過熱而導致火災的危險。	
	不要只插入一半。
請將電源插頭直插到底部。如果插入一半會因接觸不良而發熱，造成火災。另外，插入部如附著灰塵、水滴等，會因發熱導致火災。	
不要使用未指定的電源線。	
	請使用下列規格的AC電源線。
	此外，操作和連接電源線時請遵循以下注意事項。
<ul style="list-style-type: none">■ 不要拖拽電源線。■ 不要夾電源線。■ 不要彎折電源線。■ 不要使電源線靠近化學藥品。■ 不要扭曲電源線。■ 不要踩踏電源線。■ 不要在電源線上載入物品。■ 不要捆綁電源線。■ 不要對電源線進行改造、加工、修復。■ 不要用固定器等固定電源線。■ 不要使用損傷的電源線。（損傷的電源線要立即更換為相同規格的電源線。更換事宜請與經銷商或維護服務公司聯繫）	

安裝，移動，保管及連接注意事項

	<p style="text-align: center;">⚠ WARNING</p> <p> 在安裝或移動設備之前請拔下電源插頭。</p> <p>在安裝或移動設備之前要切斷設備電源，並拔下電源插頭。只有在拔下電源線後，設備的電壓才會消除。</p>
	<p style="text-align: center;">⚠ CAUTION</p> <p> 不要安裝或存放在未指定的場所。</p> <p>不要將本設備放置在如下場所和本書未指定的場所，有導致火災的危險。</p> <ul style="list-style-type: none">■ 灰塵較多的場所■ 熱水器旁等濕氣較高的場所■ 陽光直射的場所■ 不平穩的場所 <p> 請小心不要夾住或碰傷手指。</p> <p>將本機器安裝到機架上或者從機架上卸載的時候，請務必小心以免被滑軌劃傷手指。</p> <p> 不要在腐蝕性環境中使用或存放設備。</p> <p>不要在有腐蝕性氣體（如二氧化硫、氯化硫、氮、氫、氨或臭氧等）的環境中使用或存放本產品。</p> <p>不要將本產品安裝在灰塵較多或含有腐蝕性物質如氫化鈉或硫磺等的地方。</p> <p>不要將本產品安裝在空氣中含有過量金屬碎末或傳導粒子的地方。</p> <p>上述環境可能導致本產品腐蝕或短路，因而損壞產品，甚至引起火災。</p> <p>對產品安裝或存放環境有任何疑問，請與經銷商或維修服務公司聯繫。</p>

▲ CAUTION



不要在插入插頭的狀態下進行信號線的連接。

在安裝拆除可選配件或者拆裝信號線前先將電源線從插座拔下。即使電源已切斷，在電源線連接的狀態下，可能因接觸信號線和介面產生觸電、或因短路而引起火災。



不要使用未指定的信號線。

使用NEC指定的信號線，並在確認連接設備和介面後進行連接。使用未指定信號線或連接錯誤等會造成短路、導致火災。

信號線的操作和連接，須遵守以下注意事項：

- 不要使用任何損壞的信號線接頭。
- 不要踩踏信號線。
- 不要在信號線上載入物品。
- 信號線接鬆動時不要使用。
- 不要使用任何損壞的信號線。

整理及操作內部設備時的注意事項

 WARNING	
	<p>不要自行拆卸、修理或改造本伺服器。</p> <p>除本書記載的情況外，不要進行拆卸、修理、改造。否則，不但可能導致設備不能進行正常運行，還有發生觸電和火災的危險。</p>
	<p>不要看光碟機內部。</p> <p>光碟機使用了雷射，請不要在電源打開的狀態下觀看內部或插入鏡子等。雷射射入眼睛有導致失明的危險（雷射肉眼眼看不見）。</p>
	<p>不要擅自拆除鋰電池。</p> <p>本產品內部安裝有鋰電池。請不要拆下電池。鋰電池靠近火或浸水均有可能發生爆炸。</p> <p>由於電池使用期限而導致設備不能正常運行時，不要自行拆卸、更換、充電等，請與經銷商或維護服務公司聯繫。</p>
	<p>清潔伺服器前請拔下電源插座。</p> <p>整理或拆裝本設備內部的選購配置時，要切斷設備電源，並拔下電源插頭。即使已關閉電源，但連接著電源線，接觸到任何內部設備也有觸電的危險。</p> <p>另外，請經常拔下電源插頭，用乾布擦拭灰塵和附著物。有灰塵或水滴等附著時會發熱，有導致火災的危險。</p>
 CAUTION	
	<p>注意高溫</p> <p>本產品關閉電源後，內置硬碟等內部設備仍然處於高溫狀態。請在充分冷卻之後進行拆裝。</p>
	<p>確認安裝完畢。</p> <p>電源線和信號線、配件板要確實安裝妥當。</p> <p>安裝不牢有可能引起接觸不良，可能造成冒煙和著火。</p>

⚠ CAUTION
<p></p> <p>請用保護蓋保護好未使用的介面。</p> <p>請用保護蓋保護好未使用的電源線介面以防止短路或觸電。從內部設備上拔下電源插頭時，用保護蓋蓋好介面，否則有導致火災或觸電的危險。</p>

操作注意事項

⚠ CAUTION
<p> 不要在設備運行時拔出設備。</p> <p>不要拔出或拆除運行中的設備。有導致系統故障和損壞的危險。</p>
<p> 不要在打雷時觸摸機器。</p> <p>打雷時請拔下電源插頭。如來不及拔下電源插頭，請不要觸摸設備及線纜等，防止發生火災或觸電。</p>
<p> 不要讓寵物靠近。</p> <p>寵物的排泄物和毛髮進入設備可能導致火災和觸電。</p>
<p> 設備上不要放置物品。</p> <p>物品倒下可能引起傷亡，破壞硬體或導致火災。</p>
<p> 不要將光碟機托盤拉出放置。</p> <p>防止托盤中進入灰塵引起運轉錯誤。同時防止因碰撞等造成托盤損傷。</p>

機架式伺服器的注意事項

⚠ CAUTION

不要將設備安裝在未指定的機架上。

請將設備安裝在符合EIA標準的19英寸機架上。一定要將設備安裝在指定的機架上才能使用。否則設備可能無法正常使用，並有可能損壞機器零部件或導致人身傷害。關於合適的機架，請與您的經銷商聯繫。



請不要自行安裝本設備。

爲了避免人身傷害，請不要自行將本機器安裝到機架上。應該由受過專業訓練的維護人員來安裝。

**<僅供維護人員閱讀>**

安裝機器時不能將機器的所有重量由一個地方來承載。

爲了分散重量，應該加裝固定器或者同時安裝兩個或更多的機架，否則機架可能會傾倒導致人身傷害。



不要擅自組裝零部件。

將前門和托架安裝到機架上至少需要兩人共同完成，否則可能會因爲零部件跌落而導致損壞或者人身傷害。



不要從不牢固的機架中抽出設備。

在抽出設備之前請確認機架已經被穩固器或者通過抗震技術固定。



不要從機架抽出兩個或者兩個以上的設備。

同時抽出兩個或者兩個以上的設備可能導致機架傾倒。一次只能抽出一個設備。



不要裝配過多電線。

爲了避免火災和設備損壞，請務必確保不要超過線路的額定負載。有關電力設備的安裝和電線的更多資訊請聯繫電工或者當地的電力公司。

操作注意事項

為使伺服器正常運行，請遵守以下注意事項。如無視這些注意事項進行操作可能導致伺服器的運行錯誤和故障。

- 不要在設備附近使用行動電話或呼叫器。在本產品附近時請關閉行動電話及呼叫器電源，防止因電波影響導致運轉錯誤。
- 請將本產品安放在能正常運行的場所。具體請參考分冊“用戶指南(安裝)”。
- 關閉電源和取出軟碟前，請確認設備的訪問燈是否已滅。
- 電源切斷後，請間隔 30 秒以上再開啓電源。
- 一旦開啓了伺服器，在螢幕顯示“NEC”圖示之前請不要關閉伺服器。
- 將附帶的電纜插在電壓為 100V 的電源插座上。
- 插上電源線纜後，請等待 30 秒以後再打開設備電源。
- 移動本產品前請關閉電源，拔掉電源插頭。
- 本產品在使用不符合標準的 CD（複製保護式 CD）時，不保證 CD 驅動器能夠識別。
- 請定期清潔本產品（具體步驟請參考第六章）。定期清潔可使部分故障防患於未然。
- 為防止因雷擊等原因造成的瞬間電壓的下降，建議使用不間斷電源設備（UPS）。

該產品不支援通過不間斷電源序列埠(RS-232C)進行連接或者使用 PowerChutePlus 進行控制。

- 在下列情況下進行操作時，請檢查並調整系統時鐘：
 - 對本設備進行運輸後
 - 對本設備進行一段時間的儲存後
 - 當設備在超出正常環境條件下(溫度 10~35°C, 濕度：20~80%)停止時。

請每月檢查一次系統時鐘。如果系統對時間要求很高的精確度且安裝有時間伺服器(NTP)的話，建議您用時間伺服器來作業系統時鐘。如果即使進行了時鐘調整，但是隨著時間的流逝系統時鐘仍然顯著偏離正常水平的話，請向經銷商或維護服務公司諮詢。

- 如果要保存該設備，請將設備保存在以下環境溫度下(溫度:-10 to 55°C, 濕度: 20 to 80%, 無結露)。
- 在將 NEC Express800ft 系列、內部可選設備或備份媒體設備(盒式磁帶)突然從溫度很低的地方轉移到溫暖的地方時，會發生結露現象。如果在這種狀態下使用的話，會引起故障或系統崩潰。為了保證重要資料以及資產不至於受到損壞，請先等候充分時間後，再使用伺服器或其中的元件。

參考：冬季避免結露問題的有效時間長度（當室內與室外溫度差超過 10°C 時）

磁片設備：約 2-3 小時

磁帶媒體：約 1 天

- 請確認可選設備能安裝或連接在本設備上，否則即便安裝或連接上，不僅設備不能正常運行，還可能導致設備本身故障。

- 請確認可選設備與系統可以相容。如果使用了不可相容的可選設備，可能導致設備故障。

- 可選設備建議使用 NEC 原裝正品。其他公司生產的記憶體和硬碟等，雖然也可適用於本產品，但是由此產生的破損或故障，即便在保修期間內也要收取維修費用。

設備及消耗品的廢棄

- 伺服器主機及硬碟驅動器、軟碟、光碟及可選配件板卡等的廢棄方式，請遵守各地方廢棄規定。請將設備附帶的電源線纜一併廢棄以免用於其他設備。
詳情請諮詢各地方機構。

重要：


- 伺服器主板電池的廢棄（以及更換）請向經銷商或維護服務公司諮詢。
為防止設備的硬碟、備份光碟、軟碟及其他可寫媒體（CD-R/CD-RW 等）中存儲的資料，可能因被第三者複製或恢復後，被挪作他用，請客戶負責切實刪除這些資料。在廢棄設備時應充分考慮保護個人隱私及企業的機密資訊。
- 伺服器的某些部件到使用期限必須更換（風扇、內置電池、內置光碟機、軟盤機、滑鼠等）。為使設備穩定運行，建議定期更換這些部件。使用期限及更換相關事宜請與經銷商或維護服務公司聯繫。

⚠ WARNING



不要擅自拆開鋰電池。

本設備內裝有鋰電池。請不要拆下電池，防止鋰電池近火、浸水發生爆炸。用不同型號的電池更換有可能引起爆炸。請根據本書說明來處理舊電池。電池用完，設備無法正常工作時，不要自行拆卸、更換、充電等，請與維護服務公司聯繫。



懷疑系統出現故障時

當伺服器不能正常運行時，請在送修之前，先對照下述內容，找出問題所在並進行相應處理：

1. 請檢查電源線和連接線纜連接是否正確。
2. 請參照第七章的“錯誤消息”檢查是否出現相應症狀。如果有，請按提示採取相應的措施。
3. 請確認運行 NEC Express5800/ft 系列伺服器所需的軟體程式是否都已經正確安裝。
4. 請使用市場上銷售的抗病毒程式對伺服器進行檢查。

如果進行了相應的處理之後仍然不能正常運行，請停止使用本伺服器並與經銷商或維護服務公司聯繫。在這種情況下請檢查伺服器的指示燈顯示並記錄顯示器顯示的資訊，這些提示有助於機器的維護。

部件維修

部件保修期在各個國家不同，請諮詢NEC銷售代表。
如果沒有指定時期，部件維修將在停產後被保留5年。

網路服務


有關NEC Express5800/ft系列以及相關修正模組的資訊，可以參考NEC Express5800 亞太地區網站：
<http://www.nec.co.jp/express/index.html>

保護健康的建議

長時間連續使用電腦，有時身體各部位會出現異常反應。使用電腦時，請注意以下幾點，不要給身體造成負擔。


保持良好的坐姿

使用電腦時的基本姿勢是伸直腰背坐在椅子上，將鍵盤放置在與兩手和地板基本平行的高度，電腦螢幕比視線水平高度略低為宜。如果採用該基本姿勢，身體的任何部位都不用施加多餘的力，這是最能夠減小肌肉緊張的姿勢。不好的作業姿勢：如果彎腰曲背，臉離顯示器很近，這種狀態下工作會造成疲勞和視力下降。




調整顯示器的角度

顯示器角度大多可上下、左右調節。為防止耀眼強光射入畫面、保持顯示內容清晰，調節顯示器的角度非常重要。如果不調節角度，在不易觀看的角度下工作，則無法保持良好坐姿，很容易疲勞。因此，使用前，為便於觀看，請調整好顯示器的角度。



調整畫面亮度和對比度

顯示器具有調節亮度、對比度的功能。根據年齡和個人的差異，周圍的亮度不同，畫面的最佳亮度、對比度也有所不同，因此請根據具體情況將畫面調節到易於觀看的狀態。畫面過亮、過暗都會對眼睛產生不良影響。



調整鍵盤角度

有些鍵盤可以調節角度。調節鍵盤角度以便更易於輸入，對於減輕肩、腕和手指的負擔非常有效。



清潔機器

保持機器的整潔不論從美觀的角度，還是從功能和安全角度來看都是非常重要的。特別是顯示器的畫面上如果有灰塵等髒物，顯示內容就會看不清楚，所以定期清潔是很必要的。



疲勞時請注意放鬆

建議您疲勞時停下雙手休息一下，做做輕體操，轉換一下心情。



(This page is intentionally left blank.)

Chapter 2

General Description

This chapter describes what you need to know to use the NEC Express5800/ft series. Refer to this chapter when you want to know about certain components and how to operate them.

STANDARD FEATURES

The NEC Express5800/ft series is the server that has hardware for two servers.

High performance

- Quad-Core Intel® Xeon™ Processor (2.00GHz/3.00GHz)
- High-speed Ethernet interface (1000Mbps/100Mbps/10Mbps supported)
- High-speed disk access (SAS (Serial Attached SCSI))

Expandability

- Three slots
 - Low Profile (PCI-X bus, 133MHz) x 1
 - Full Size (PCI-X bus, 133MHz) x 1
 - Full Height (PCI-Express x 4 lane) x 1
- Large capacity memory (max: 24 GB)
- USB interface

High-reliability

- Memory monitoring feature (1-bit error correction/ 2-bit error detection)
- Bus parity error detection
- Error notification
- BIOS password feature

Management Utilities

- NEC ESMPRO

Ready-to-use

- Red Hat Enterprise Linux Advanced Platform 64bit
- Quick cableless connection: hard disk, CPU/IO module

Fault-tolerant Feature

- Redundant modules achieved within a system
- Higher hardware availability by isolation of failed module

Various Features

- Graphic accelerator “ ES1000” supported
- DVD Combo

Self-diagnosis

- Power On Self-Test (POST)
- Test and Diagnosis (T&D) Utility


Maintainability

- Off-line Maintenance Utility

Easy and Fine Setup

- NEC EXPRESSBUILDER (system setup utility)
- SETUP (BIOS setup utility)

Hardware modules work while synchronizing and comparing with each other. Even if one hardware module stops, the server can continue its operation as the service with the other hardware module.



Even if one hardware module stops, the server can continue operation with the other module. After the failed module is replaced, the new module will obtain information from the other and resume operation.

NEC Express5800/ft series is a highly fault-tolerant Linux server that achieves continuous computing operations, data storage mirror, and continuous network connection. It allows you to run Red Hat Enterprise Linux Advanced Platform 64bit-based applications.

NEC Express5800/ft series achieves continuous computing operations for the Linux server and server-based applications with its redundant CPU processing and redundant memory. It assures data redundancy through duplication of server data on an independent storage system. These features eliminate server downtime that is usually caused by network disconnection or trouble with the I/O controller, Ethernet adapter or disk drive, and support operation of the network and server applications continuously. While being transparent to application software, NEC Express5800/ft series achieves high fault-tolerance.

NEC Express5800/ft series detects status changes, errors and other events and notifies the Linux Syslog of these events. If you use an alarm notification tool, you can configure NEC Express5800/ft series to notify you when certain events occur.

NEC ESMPRO is installed on the system as a server management solution. NEC ESMPRO, a GUI-based management tool, allows you to monitor, view, and configure NEC Express5800/ft series. This tool also supports both local and remote management of NEC Express5800/ft series.

2-4 General Description

NEC Express5800/ft series mainly provides the following advantages:

- Highly fault-tolerant processing and I/O subsystems
NEC Express5800/ft series use redundant hardware and software to assure server operation even if one module suffers trouble with its processor, memory, I/O (including trouble related to the I/O controller), disk drive, or Ethernet adapter.
- Continuous network connection
NEC Express5800/ft series maintains continuous network connection by detecting any trouble with the network adapter, connection, etc. If trouble occurs, the standby network connection will take over all network traffic processing and thus securely maintain the network system connection of NEC Express5800/ft series without losing network traffic or client connection.
- Support of multiple network connections
Since NEC Express5800/ft series can support multiple Ethernet connections, you can add network redundant control or network traffic control.
- Industry standard hardware platform
NEC Express5800/ft series uses IA (Intel Architecture)-based system hardware.
- No need to modify applications
You can run Red Hat Enterprise Linux Advanced Platform 64bit-compliant applications on NEC Express5800/ft series. Thus, unlike other highly fault-tolerant products, special API or scripts are not necessary.
- Automatic mirroring
NEC Express5800/ft series automatically maintains data as the current data.
- Automatic detection and notification of faults
NEC Express5800/ft series detects and sorts out all events such as general status changes and faults, and notifies Linux Syslog of these events.
- Transparent migration
NEC Express5800/ft series constantly monitors events. If trouble occurs on NEC Express5800/ft series' server module, it will transparently use a redundant module of the failed module. This feature maintains data and user access without losing application service.
- Automatic reconfiguration
When the failed module restarts after the trouble is corrected, NEC Express5800/ft series will perform reconfiguration automatically, and if necessary, resynchronize the affected modules. Reconfiguration can include CPU processing (e.g., CPU memory), server's operating system (and related applications), and system data stored on the hard disks. In most cases, NEC Express5800/ft series automatically restores redundancy of the server modules after recovery.

- Local and remote management

NEC Express5800/ft series uses NEC ESMPRO as a server management tool. This tool uses a GUI that enables monitoring and setting of NEC Express5800/ft series. NEC ESMPRO can be used both locally and remotely on work station PCs or server PCs.

- Event notification function


When trouble or other events are detected on NEC Express5800/ft series, they will be notified to Linux Syslog and saved. Therefore, you can view the log items locally or remotely by a usual Linux procedure. Since an NEC Express5800/ft series events use unique IDs, they are easy to distinguish.

- In-service repairing

You can repair or replace a failed module even if NEC Express5800/ft series is operating.

- Partition structure

On this server model, the first logical drive will be the following state when the setup by NEC EXPRESSBUILDER is complete.



* The size varies depending on the specification at setup.

CHECK:


The partition for operating system is not mirrored at the time of NEC EXPRESSBUILDER setup completion. Mirror the partition separately.

- Linux OS and media

The Linux OS media used on NEC Express5800/ft series are not specifically processed for it. The standard operating methods of Linux are the same as general.


NAMES AND FUNCTIONS OF COMPONENTS

Names and functions of components are shown below:



- (1) **LEDs**
For more information see the description on the front view (page 2-8).
- (2) **Front bezel**
The cover to protect devices in the front.

Front View



(1) CPU/I/O module 0

This is a module with a set of CPU (processor), memory (DIMM), PCI board, cooling fan unit, and hard disk drive.

(2) POWER switch

This switch is used to power on/off the server. The in-built LED illuminates for the primary CPU/I/O module, showing that it is primary. (The secondary POWER LED (off) cannot be used. If the switch is pressed once, the server is powered on. If the switch is pressed again, the server is powered off. If the switch is pressed for more than 4 seconds, the server is forcibly shut down.

(3) DVD-ROM drive

This device is used to read data from DVDs and CD-ROMs.

(4) DISK ACCESS LED

This LED illuminates when the set optical disks are accessed.

(5) Tray eject button

This button ejects the tray.

(6) Forcible eject hole

This is the hole for forcibly eject by inserting a metal pin.

(7) Hard disk drive bay

This is the bay to mount the hard disk drive. The number after the parenthesized number indicates a slot number.

(8) CPU/IO module DISK ACCESS LED (green/amber)

This LED illuminates in green when the internal hard disk drives are accessed. If any internal hard disk drive is failing, the LED illuminates in amber.

(9) CPU/IO module 1

This is a module with a set of CPU (processor), memory (DIMM), PCI board, cooling fan unit, and hard disk drive.

(10)-1 CPU/IO module status LED 1 (amber)

This LED indicates the status of the CPU/IO module. When the module is successfully running, the LED is powered off. If a module has a problem, the LED illuminates in amber.

(10)-2 CPU/IO module status LED 2 (green)

This LED indicates the status of the CPU/IO module. When both of the CPU/IO modules are running, the LED illuminates in green. When one of the modules is running, the LED blinks in green or is powered off.


(11) CPU/IO module POWER LED (green)

When the power is turned on, the LED illuminates in green.

(12) EXPRESSSCOPE LEDs (amber)

This LED indicates the fault status of the designated modules. If a module has a problem, the LEDs illuminate in amber.

Rear View



2-10 General Description

(1) **CPU/IO module 0**

This is a module with a set of CPU (processor), memory (DIMM), PCI board, and cooling fan unit.

(2)-1, 2 **PCI slots 1, 2, 3**

(2)-1: A Low Profile type PCI board is mounted on this slot (64 bit 133MHz 3.3V PCI).

(2)-2: A Full Size and Full Height PCI-Express board is mounted on this slot (x8 socket x4 lane).

(2)-3: A Full Size and Full Height PCI board is mounted on this slot (64bit 100MHz 3.3V PCI-X).

(3)-0, 1, 2 **USB connector 0, 1, 2**

These connectors attach USB2.0-interface-supported devices.

(4) **Monitor connector**

This is used to attach a display device.

(5)-1, 2 **serial port 1, 2 connector**

This is used to attach a serial interface connector.

This is not supported with this server model.

(6)-1 **AC inlet A connector**

A power cord is connected to this socket (for the CPU/IO module 0). If you want make the CPU/IO module 0 primary, connect a power cord to this inlet first.

(6)-2 **AC inlet B connector**

A power cord is connected to this socket (for the CPU/IO module 1). If you want to make the CPU/IO module 1 primary, connect a power cord to this inlet first.

(7) **LAN connector (VTM)**

This is not used with this server model.

(8)-1 **LINK/ACT LED (VTM)**

This is not used with this server model.

(8)-2 **Speed LED (VTM)**

This LED indicates the transfer speed of LAN(VTM).

(9) **DUMP (NMI) switch**

This switch executes a memory dump.

Press the DUMP switch on the primary CPU/IO module, whose POWER LED has been blinking, for four to eight seconds.

(10)-1, 2 **PCI slot status LEDs (Slot 1, 2, 3)**

These LEDs display the status of the PCI slot. The status is shown by the display combination of the 2 LEDs (Refer to the chart on p 2-19).

(11)-1 CPU/IO module status LED 1 (amber)

This LED indicates the status of the CPU/IO module. When the module is successfully running, the LED is powered off. If a module has a problem, the LED illuminates in amber.

(11)-2 CPU/IO module status LED 2 (green)

This LED indicates the status of the CPU/IO module. When both modules are operating, the LED illuminates in green. When one module is operating, the LED blinks in green or is powered off.

(12) CPU/IO module POWER LED (green)

This LED illuminates in green when the system is powered on.

(13) CPU/IO module 1

This is a module with a set of CPU (processor), memory (DIMM), PCI board, and cooling fan unit.

(14)-1 LINK/ACT LED

This LED indicates the access status of the LAN connector.

(14)-2 Speed LED

This LED indicates the transfer speed of the LAN connector.


(15)-1, 2 LAN connector 1, 2

These connectors support 1000BASE-T/100BASE-TX/10BASE-T. These are connected to the network system on LAN.

(16)-F-MRC connector

A management device is connected to this connector.

Optical disk drive



(1) Status LED

The LED that illuminates while accessing the loaded DVD/CD-ROM


(2) Tray eject button

The button to eject the tray.

(3) Manual release hole


When the eject button does not work, insert a metal pin into this hole to forcefully eject the tray.

CPU/IO Module



CPU/IO module


Mother Board



CPU/IO module mother board

- (1) **Lithium battery**
- (2) **DIMM slot ((2)-1 from the bottom)**
 - (2)-1 DIMM CH0 Slot 0
 - (2)-2 DIMM CH0 Slot 1
 - (2)-3 DIMM CH0 Slot 2
 - (2)-4 DIMM CH1 Slot 0
 - (2)-5 DIMM CH1 Slot 1
 - (2)-6 DIMM CH1 Slot 2
- (3) **Processor 0 socket (CPU0)**
- (4) **Processor 1 socket (CPU1)**
- (5) **Jumper switch for clearing CMOS/password**
- (6) **Jumper switch for clearing BMC configuration**
- (7) **F-RMC card slot**
- (8) **LAN 2 connector**
- (9) **LAN 1 connector**

ft Remote Management Card



- (1) Attaching to servers.
This is a card edge part touching to the F-RMC slot inside of the server.

IMPORTANT:

Do not mount this card on other slots or devices in order to avoid a fault.

- (2) Management LAN port
This port can be connected to network system, and supports 100Mbps/10Mbps. The port can't be connected to phone line. The port is also used when managing the server with the management software NEC DianaScope attached on this device.

IMPORTANT:

You can not change the configuration manually because the communication mode of the Managed LAN port is only auto negotiation mode. Configure the link partner side (such as switch or hub) as auto negotiation mode.

- (3) MAC address
On the back side of the management card, a seal is labeled with MAC address printed. The MAC address can also be confirmed on the server's BIOS Setup screen.

LEDs

POWER LED

The POWER switch of the CPU/IO module has an in-built LED. If the AC power is supplied, the LED of the primary POWER switch illuminates (only the primary POWER switch functions). Also, the CPU/IO module has the POWER LED to show the status of the module power status.

CPU/IO Module POWER LED

LED indication	Description	Action
Not on	Power supply is off.	Check that the status LED 1 on both CPU/IO modules is powered off, and then press the POWER LED to power on the system.
On	Power supply is on.	

CPU/IO Module Status LED 1, 2

There are two kinds of LEDs that indicate the module status on the front and back sides of the CPU/IO module. The display combination of the two LEDs indicates the CPU/IO module status.

Status LED1	Status LED2	Description	Action
Not on	Not on	Power supply is off.	
	Blinking in green	When the system is starting, the initialization process is performed. If the OS is running, duplex configuration is not made for one of the components in the CPU/IO modules.	Wait for a while; the LED will illuminate in green. Check that the cable is firmly connected. If the LED does not illuminate in green after a while, record the status LED status, and contact a maintenance service company.
	Green	The device is duplexed and running normally.	
Amber	Not on	After the AC power is supplied, the device running in the standby power mode is being initialized.	Wait for a while. The status LED 1 will be powered off, and the POWER switch will be enabled.
		When the system is starting, the initialization process is performed. When the OS is running, the CPU/IO module has a problem.	Wait for a while; the status LED 1 is powered off. Check that the cable is firmly connected. If the LED does not illuminate in green after a while, record the status LED status, and contact a maintenance service company.

PCI Slot status LED 1, 2

There are two kinds of LEDs that indicate the PCI slot status on the back of the CPU/IO module. The PCI slot status is indicated by the display combination of the two LEDs.

Status LED1	Status LED2	Description	Action
Not on	Not on	Power supply is off.	<p>Wait for a while; the LED illuminates in white.</p> <p>Check that the cable is firmly connected. If the LED does not illuminate in white after a while, record the status LED status, and contact a maintenance service company.</p>
	Blinking in white	When the system is starting, the initialization process is performed. If the OS is running, and it is in the Simplex mode, the PCI slot of the other CPU/IO module is degenerated.	
	White	If the PCI slot status LED 2 of the other CPU/IO module is on, the device is successfully running in the Duplex mode.	
Amber	Not on	If the PCI slot status LED 2 of the other CPU/IO module is blinking, the cable may be disconnected, the option PCI board of the slot has a problem, or the CPU/IO module itself has a problem.	Check that the cable is connected securely. If the PCI slot status LED 2 of the other CPU/IO module does not illuminate white, record the status of the status LED, and call your maintenance service company.
		When the system is starting, the initialization process is performed. When the OS is running; 1) The optional PCI board of the slot has a problem. 2) The CPU/IO module has a problem.	Wait for a while; the status LED 1 is powered off. Check that the cable is firmly connected. If the LED does not illuminate in white after a while, record the status LED status, and contact a maintenance service company.

Hard Disk Drive LED

Hard Disk LED	Description	Action
Not on	The disk is in the idle state.	
Green	Accessing the disk	
Amber	Disk failure	Contact a maintenance service company.
Blinking in amber (illuminate in green when accessing the disk)	The mirror of the disk is disconnected.	Perform mirroring.
Blinking in green and amber in turn	The hard disk drive configuration (rebuild) is on going.	Wait for a while; the LED blinks in green after rebuild finishes. If the rebuild fails, the LED illuminates in amber.

Access LED on the optical disk drive

This LED illuminates when the installed DVD or CD-ROM is being accessed.

LAN Connector LED

- LINK/ACT LED

The LINK/ACT LED shows the status of a standard network port. It is green if power is supplied to the main unit and hub, and they are connected correctly (“LINK”). It blinks green while the network port sends or receives data (ACT).

When the LED does not illuminate during “LINK,” check the condition and connection of network cables. If there is nothing wrong with the cables, a defect is suspected in the network (LAN) controller. In this case, contact your sales agent.


- Speed LED

This LED indicates the network interface of the communication mode used by a network port.

1000BASE-T and 100BASE-TX are the supported LAN port types. When this LED illuminates in amber, the port is operating on 1000BASE-T; when in green, 100BASE-TX; and when not illuminate, 10BASE-T.

EXPRESSSCOPE

Corresponding EXPRESSSCOPE LEDs (amber) illuminate when modules have failures. The LEDs on the upper line correspond to the upper names, and the LEDs on the lower line correspond to the lower names.



CPU (CPU module error LED)

Amber LED illuminates when failure occurs on CPU of CPU/IO module.

I/O (I/O module error LED)

Amber LED illuminates when failure occurs on I/O of CPU/IO module.

VLT (Power error LED)

Amber LED illuminates when electric voltage failure occurs in CPU/IO module.

MEM0 (Memory slot 0 error LED)

Amber LED illuminates when failure occurs on the memory slot 0 of CPU/IO module.

MEM1 (Memory slot 1 error LED)

Amber LED illuminates when failure occurs on the memory slot 1 of CPU/IO module.

MEM2 (Memory slot 2 error LED)

Amber LED illuminates when failure occurs on the memory slot 2 of CPU/IO module.

PSU (Power supply unit error LED)

Amber LED illuminates when failure occurs on the power supply unit of CPU/IO module.

TMP (Abnormal temperature LED)

Amber LED illuminates when temperature in CPU/IO module becomes abnormal.

FAN0 (Fan 0 error LED)

Amber LED illuminates when failure occurs on the cooling fan for CPU0 of CPU/IO module.

FAN1 (Fan 1 error LED)

Amber LED illuminates when failure occurs on the cooling fan for CPU1 of CPU/IO module.

FAN2 (Fan 2 error LED)

Amber LED illuminates when failure occurs on the disk cooling fan of CPU/IO module.

FAN3 (Fan 3 error LED)

Amber LED illuminates when failure occurs on the power supply unit's fan of CPU/IO module.

BASIC OPERATION

This section describes basic operation procedures of NEC Express5800/ft series.


Installing/removing the front bezel

When you power on/off the server, handle the DVD-ROM drive, or remove/install a hard disk drive or CPU/IO module, remove the front bezel.


IMPORTANT:

The front bezel can only be removed by unlocking the lock with the security key attached.

- (1) Insert the product-accessory security key into the key slot and push lightly. Turn the key to the left to unlock.
- (2) Hold the right edge of the front bezel and pull it forward.
- (3) Slide the front bezel to take the tab off the frame and remove the front bezel.



When attaching the front bezel, hook the left tab into the server's frame first, then push forward on the right side.



Power ON

To power on NEC Express5800/ft series, press the POWER switch (the one whose in-built LED is illuminating).

Follow the steps below to turn on the power.

1. Power on the display unit and other peripheral devices connected to the server.


CHECK:

If the power cord is connected to a power controller like a UPS, make sure that it is powered on.

2. Remove the front bezel.
3. Press the power switch located on the front of the front panel.
After a while, the “NEC” logo will appear on the screen.

IMPORTANT:

Do not turn off the power before you see the “NEC” logo and a character below the logo.



While the “NEC” logo is displayed on the screen, NEC Express5800/ft series is performing a power-on self test (POST) to check itself. For details, see “POST Check” described later in this chapter. Upon the completion of POST, Linux will start.

CHECK:

If the server finds errors during POST, it will interrupt POST and display the error message. See Chapter 7.

Power OFF

Follow the steps below to turn off the power. If NEC Express5800/ft series is plugged to a UPS, see manuals included with the UPS or the application that controls the UPS.

1. Perform a normal shutdown from Linux.

The system will be powered off automatically. (Note: the POWER switch on the primary side will remain illuminating when AC power is supplied.)

2. Power off all peripheral devices.

POST Check

POST (power-on self test) is a self-test function stored on the motherboard of NEC Express5800/ft series.

When you power on the server, POST will start automatically to check the motherboard, ECC memory modules, CPU/IO modules, keyboard, mouse, etc. It also shows startup messages for various BIOS setup utilities.



According to the factory default settings, the “NEC” logo appears on the display while POST is being performed. (To view details of POST, press **Esc**.)

TIPS:

- You can view POST details from the beginning without the need to press **Esc** when the BIOS menu is displayed: select [System Configuration] - [Advanced], and set [Boot-time Diagnostic Screen] to “Enabled” (see Chapter 4).
- You can view the test items and details from a management PC where NEC ESMPRO Manager is installed.

You do not always need to check POST details. You will need to check messages when:

- You install a new NEC Express5800/ft series.
- A failure is suspected.
- You hear several beeps between the time of the power-on and OS start-up.
- The display unit shows an error message.

Flow of POST

This section walks you through how POST is performed.

1. When you power on the system, one selected CPU/IO module will start up. POST will be performed on this selected CPU/IO module.
2. Memory check starts.
A message appears at the upper left of the screen to show that the basic and expanded memories are being counted. The memory check may take a few minutes to complete depending on the server's memory size. Likewise, it may take about one minute for the screen to appear when the server is rebooted.
3. The server starts processor check, IO check, and initialization.
Several messages appear: they show the ID of the selected CPU/IO modules, information on the processor, detection of the keyboard and mouse, etc.
4. A message appears at the lower left of the screen, prompting for startup of the BIOS setup utility "SETUP."

Press <F2> to enter SETUP

- You will need to start it when you want to modify the configuration for using the server. Unless this message appears together with an error message, you do not need to start the utility to modify the configuration. (If you wait for a few seconds, POST will go on automatically.)
- To start the SETUP utility, press **F2** while the above message is displayed. For setting and parameter functions, see the section of BIOS setup.
- When SETUP is completed, the server will reboot itself automatically and perform POST.
5. A message appears prompting for startup of SAS BIOS setup utility.
When a built-in SAS controller is detected, a message will appear prompting for startup of SAS BIOS setup utility. (If you wait for a few seconds, POST will go on automatically.)
If you press **Ctrl + A**, the SAS BIOS setup utility will start. However, you usually do not need to use the setup utility. For setting and parameter functions, see "SAS BIOS" (page 4-33).
When SETUP is complete, the server will reboot automatically and perform POST from the start again.
 6. The screen shows the ID numbers of the connected disk drive.
 7. Upon completion of POST, the password entry screen appears prior to OS startup.
The password entry screen will appear after the normal termination of POST only if you have set a password in the BIOS setup utility "SETUP."

You can enter a password up to three times. If you enter an incorrect password three times, the startup will be unsuccessful. In this case, turn off the power and then turn it on again after waiting 30 seconds to boot the server.

IMPORTANT:

Do not set a password before installing the OS.

8. Upon completion of POST, the OS will start up.

Behavior at Occurrence of Error

If POST or OS startup does not finish normally, the server will reboot itself automatically.

At the time of reboot, it will select the other CPU/IO module and run POST or OS startup.

In this manner, the server retries POST or OS startup with different combinations of CPU/IO modules. If POST does not finish normally with any combinations, the server will stop with the state of DC OFF or Post end with an error message displayed.

While performing retries, the server displays or registers the error types.

For details of error messages, see Chapter 7 “Troubleshooting.”

POST Error Messages

When the server detects an error during POST, it will notify you of the occurrence in the following manners:

- Displays an error message on the display unit.

These notification methods are described in “POST Error Messages” (Page 7-4).

IMPORTANT:

Before you contact your sales agent, write down the error messages. They will serve as helpful information at the time of maintenance.

CPU/IO Module Status

The CPU/IO module (0 or 1) started first is managed as primary, and the module started later is managed as secondary. If one CPU/IO module is disconnected because of the failure and others, the other module becomes primary.

The CPU/IO module to be started first is selected depending on the primary/secondary status of modules when the server was shut down the last time.

The following devices are connected to the primary CPU/IO module by the hardware switch, although those can be connected to both CPU/IO modules 0 and 1. When one CPU/IO module is disconnected because of a failure, those are switched to the other module automatically and continue operating.

- VGA (display)
- USB device (keyboard, mouse, floppy disk drive)

TIPS:

As for DVD-ROM drive, the DVD-ROM drive of both CPU/IO modules 0 and 1 can be accessed. If one CPU/IO module is disconnected because of the failure, only the DVD-ROM of the other module can be accessed

Floppy Disk Drive (Option)

If you want to use a floppy disk drive with this server, connect N8160-74USB FDD UNIT, which are available optionally to a USB connector. This server supports 3.5-inch 2HD (1.44 MB) and 2DD (720KB) floppy disks.

IMPORTANT:

- When using a USB floppy disk drive, the access to the floppy disk is delayed on rare occasions if the display graphic load is high because a moving picture is being played. In such a case, retry the operation with the floppy disk inside the floppy disk drive.

Insert/Remove Floppy Disk

Before inserting a floppy disk into the drive, make sure that NEC Express5800/ft series is on (the POWER LED illuminates).

Insert a floppy disk into the drive firmly until it snaps in place. The eject button of the drive is then raised slightly.

CHECK:

- You cannot use 1.2 MB-formatted disks.
- If you insert an unformatted disk, you will see a message that the disk cannot be read or that needs formatting. To format a floppy disk, see your OS manual.
- If you power on or restart NEC Express5800/ft series with a floppy disk left in the drive, the server will access the floppy disk to start the system. Unless a system exits on the FD, the server will be unable to start.

To remove a floppy disk from the drive, press the eject button.

CHECK:


- Before removing a floppy disk, make sure that the floppy disk access LED is off. If you eject a floppy disk while the LED is on, the stored data could be damaged.
- When using a USB floppy disk drive, the access to the floppy disk is delayed on rare occasions if the display graphic load is high because a moving picture is being played. In such a case, retry the operation with the floppy disk inside the floppy disk drive.

Use of Floppy Disk

You may need to store important data on floppy disks. Since the floppy disk is a very delicate medium, you must handle it with extra care:

- Push the floppy disk gently into place.
- Attach the label on a proper position.
- Do not use a pencil or ballpoint pen to write on the floppy disk.

- Do not open the protective shutter.
- Do not use the floppy disk in a dusty place.
- Do not place anything on the floppy disk.
- Do not leave the floppy disk in a place that is subject to direct sunlight or high temperatures (e.g., near a heater).
- Keep away from cigarette smoke.
- Do not leave the floppy disk near water or chemicals.
- Keep away from magnetic objects.
- Do not clip disks. Be careful not to drop.
- Store floppy disks in a protective case where they are kept away from magnetic waves or dust.
- To prevent data from being erased accidentally, the floppy disk has a write-protect notch. When the disk is write-protected, you can read data, but you cannot write the data or format the disk. It is recommendable to write-protect floppy disks that contain important data except when you write data to the floppy disk. To write-protect a 3.5-inch floppy disk, slide the write-protect notch located on its back.
- The floppy disk is a very delicate storage medium. Dust or changes in temperature could cause data to be lost. Data loss could also be caused by faulty operation and computer trouble. To avoid such possible data loss, it is recommendable to back up important data regularly. (Be sure to make back-up copies of the floppy disks that are included with NEC Express5800/ft series.)



Optical disk drive

NEC Express5800/ft series has a DVD-ROM drive on the front panel. It is a device used to read data from an optical disk (compact disc read-only memory). Compared to a floppy disk, an optical disk allows for larger volume and fast data readout.

CAUTION





Observe the following instructions to use the server safely. There are risks of a burn, injury, or damage to physical assets. For details, see “PRECAUTIONS FOR SAFETY” in Chapter 1.

- Do not leave the DVD-ROM drive tray ejected.

Insert/Remove DVD-ROM


Follow the steps below to set an optical disk.

1. Before you insert an optical disk, make sure that the server is powered on. When the server is powered on, the LED illuminates in green.
2. Press the tray-eject button located in the front of the DVD-ROM drive. The tray is then ejected.
3. Hold the optical disk with its signaling side facing the tray.



4. As shown in the figure on the right, place the optical disk on the tray and press lightly on the center to lock.

5. Push the front side of the tray gently to the drive-closed position.




IMPORTANT:

If you hear noise while running the DVD-ROM drive, reset the optical disk.

To remove the optical disk, press the tray-eject button as you did in setting the optical disk.

When the access LED illuminates in green, it indicates the optical disk is being accessed. Make sure the access LED is not illuminating in green before you press the tray-eject button.




Press the locking part in the center of the tray and pick the optical disk gently. When you have removed the optical disk, push the tray to the drive-closed position.

When you cannot eject a DVD/CD-ROM

When you cannot eject the optical disk from the server even by pressing the eject button, follow the steps below to eject it:

1. Press the POWER switch to power off this server (i.e. the POWER LED is off).
2. Use a metal pin of about 1.2 mm in diameter and 100 mm long (alternatively, you can use a fairly large paper clip after straightening). Insert it gently into the manual release hole located at the low front side of the server until the tray is ejected.



IMPORTANT:

- Do not use a toothpick, plastic pin, or other breakable objects.
 - If you cannot eject the optical disk by following the steps above, contact your sales agent.
-

3. Hold the tray and pull it out.
4. Take out the optical disk.
5. Push the tray back.

Handling optical disks

Observe the following when you use an optical disk on NEC Express5800/ft series:

- As for a disk such as a noncompliant “copy-protected CD,” we shall not guarantee that you can use a CD player to play it with this server.
- Be careful not to drop the optical disk.
- Do not bend or place anything on the optical disk.
- Do not attach labels on the optical disk.
- Do not touch the signal side (blank side).
- Place the optical disk gently on the tray with the printed side up.
- Do not scratch, or use a pencil or ballpoint pen to write on the optical disk.
- Keep away from cigarette smoke.
- Do not leave the optical disk in a place that is subject to direct sunlight or high temperatures (e.g., due to a heater).
- If the optical disk becomes dirty with dust or fingerprints, wipe it gently from its center to edge with a dry soft cloth.
- When you clean the optical disk, use the cleaner expressly meant for it. Do not use a record cleaner (spray), benzine, or thinner.
- Store the optical disk in a protective case when not in use.

Chapter 3

Linux Setup and Operation

This chapter describes setup procedures to make NEC Express5800/ft series ready for use. CPU/IO module has a processor function part and IO function part. In utilities in this chapter, the processor function part is referred to as CPU module and IO function part PCI module.

DISK OPERATIONS

NEC Express5800/ft series duplicates disks to secure data integrity by Software-RAID. This section describes how to replace a disk.

IMPORTANT:

It is recommended to create only a system partition on the disks with OS.


When you create a partition other than a system partition on the disk with the OS, note the following:

If you reinstall the OS, the entire disk will be cleared. If there is any data partition other than the system partition, the data must be backed up before reinstalling the OS.

Operable disk configuration

RAID must be configured for all the internal disks in NEC Express5800/ft series.

As shown on the below chart, the hard drive redundancy is configured by software RAID with the hard disk drives of corresponding slots.



Corresponding slots

- PCI module 0 Slot 1 ⇔ PCI module 1 Slot 1
- PCI module 0 Slot 2 ⇔ PCI module 1 Slot 2
- PCI module 0 Slot 3 ⇔ PCI module 1 Slot 3

Note: In the above table, the PCI module names correspond to the following modules:

PCI module (for CPU/IO module 0): PCI module 0

PCI module (for CPU/IO module 1): PCI module 1

IMPORTANT:

When the status of each disk becomes RESYNC, RECOVERY, CHECK or REPAIR, do not add a disk, insert/remove HDD, power off or restart the system. Wait until the status turns to DUPLEX. Check the status of RAID using the `ftdiskadm` command, which is described later in this document. For more information, see the *User's Guide (Setup)*.

Do not use the hard disk drives specified by NEC. There is a risk of hard disk as well as the entire device breakdown when you install a third-party hard disk drive.

Purchase two, paired hard disk drive of the same model to configure the hard drive redundancy. For information on which HDD suits this device the best, ask your sales agent.

The operation such as mounting for a partition of an internal disk is done for the RAID device (`md`) that is configured by Software -RAID but not for partition.
For the `ftdiskadm` command described later in this document, slot numbers of internal disks are allocated as follows;

Disk slot number for H/W	Disk slot number for <code>ftdiskadm</code>
PCI module 0 Slot 1	Slot 1
PCI module 0 Slot 2	Slot 2
PCI module 0 Slot 3	Slot 3
PCI module 1 Slot 1	Slot 4
PCI module 1 Slot 2	Slot 5
PCI module 1 Slot 3	Slot 6

Replacing a hard disk drive

To replace a failing hard disk, follow the steps below. Replace a hard disk when the CPU/IO module 0 and 1 are powered on.

Determining a failing disk

This section provides information on how to determine a failing hard disk drive.

IMPORTANT:

This must be operated by root user.

1. In the `ftdiskadm` command, select and execute [List RAID Arrays], and the information on the device (`md`) for each RAID is displayed.
2. Check the failed disk form the displayed info.
In the Member column, if [F] is displayed, it means the partition of corresponding disk is having a failure. The number enclosed with brackets is a slot number telling you which partitions of the internal disk is having a problem.

The following is an example when a failure occurred on the internal disk stored in the slot 4 (PCI module 1 – Slot 1).

```
# ftdiskadm
Command action
 1 List RAID Arrays
 2 List Internal Disks
 3 Make Mirroring Arrays (RAID1)
 4 Repair Mirroring Arrays (RAID1)
 5 Delete Mirroring Arrays (RAID1)
 6 Remove Disk Partitions (RAID1)
 7 Make Striping Array (RAID1+0)
 8 Delete Striping Array (RAID1+0)
 c Configurations
 q Quit
Command: 1
[List RAID Arrays]
Name Partition (Label) Status Member
=====
<Mirroring Array (RAID1)>
md0 /boot ( - ) DUPLEX (1) sda1 (4) sdd1
md1 swap ( - ) DUPLEX (1) sda2 (4) sdd2
md2 / ( - ) SIMPLEX (1) sda3 F(4) sdd3
md3 /var/crash ( - ) DUPLEX (1) sda5 (4) sdd5
```

Restoring the redundant configuration manually

This section provides information on how to replace a failing internal disk and restore duplication.

IMPORTANT:

This must be operated by root user.

While the replaced disk is restoring to the RAID configuration, do not stop/restart the system when the reconfigured each RAID device is in RECOVERY. Wait until their status turns to DUPLEX. Note that the wait time is proportional to the disk volume.

1. In the command prompt of `ftdiskadm`, select [Remove Half Disk (RAID1)] to specify the slot number of the internal disk to replace, and isolate the disk from the RAID configuration.
2. Remove the disk from the system, and then, insert a new disk.
3. Wait approximately five minutes until the system automatically performs resynchronization.
4. If the system does not perform resynchronization automatically in step 3, recover RAID manually by selecting [Repair Mirroring Arrays (RAID1)] in `ftdiskadm`.

The following is an example of command prompt for the procedure from isolating the internal disk stored in the slot 4 (PCI module 1 - Slot 1) through restoring redundancy.

```
# ftdiskadm
Command action
 1 List RAID Arrays
 2 List Internal Disks
 3 Make Mirroring Arrays (RAID1)
 4 Repair Mirroring Arrays (RAID1)
 5 Delete Mirroring Arrays (RAID1)
 6 Remove Disk Partitions (RAID1)
 7 Make Striping Array (RAID1+0)
 8 Delete Striping Array (RAID1+0)
 c Configurations
 q Quit
Command: 6 (Isolate the disk specified with the slot number from
the RAID configuration.)
[Remove Disk Partitions (RAID1)]
* Which SCSI SLOT? [1-6] 4
mdadm: hot removed /dev/sdd5
mdadm: hot removed /dev/sdd3
mdadm: hot removed /dev/sdd2
mdadm: hot removed /dev/sdd1
Command action
 1 List RAID Arrays
 2 List Internal Disks (RAID1)
 3 Make Mirroring Arrays
```

3-6 Linux Setup and Operation

- 4 Repair Mirroring Arrays (RAID1)
- 5 Delete Mirroring Arrays (RAID1)
- 6 Remove Disk Partitions (RAID1)
- 7 Make Striping Array (RAID1+0)
- 8 Delete Striping Array (RAID1+0)
- c Configurations
- q Quit

Command: 1 (Check if the disk specified is isolated from the RAID configuration.)

```
[List RAID Arrays]
Name Partition (Label) Status Member
=====
< Mirroring Array (RAID1) >
md0 /boot ( - ) SIMPLEX (1) sda1
md1 swap ( - ) SIMPLEX (1) sda2
md2 / ( - ) SIMPLEX (1) sda3
md3 /var/crash ( - ) SIMPLEX (1) sda5
```

(After verifying the isolation of the specified disk from the RAID configuration (verifying no partition of the specified disk is in Member), replace the hard disk. Wait approximately five minute before the system starts to resynchronize. If there is no automatic synchronization, manually restore the disk with the below procedure.)

Command action

- 1 List RAID Arrays
- 2 List Internal Disks
- 3 Make Mirroring Arrays (RAID1)
- 4 Repair Mirroring Arrays (RAID1)
- 5 Delete Mirroring Arrays (RAID1)
- 6 Remove Disk Partitions (RAID1)
- 7 Make Striping Array (RAID1+0)
- 8 Delete Striping Array (RAID1+0)
- c Configurations
- q Quit

Command: 2 (Check if the replaced disk is recognized by the system.)

```
[List Internal Disks]
Slot Name [use] Information (Vendor/Model/Serial) path
=====
1 sda (sdg) [4] AAA/BBB/#CCC h5c0t12810
2 -
3 -
4 sdd (sdh) [4] AAA/BBB/#CCC h6c0t12810
5 -
6 -
```

Command action

- 1 List RAID Arrays
- 2 List Internal Disks
- 3 Make Mirroring Arrays (RAID1)
- 4 Repair Mirroring Arrays (RAID1)
- 5 Delete Mirroring Arrays (RAID1)

- 6 Remove Disk Partitions (RAID1)
- 7 Make Striping Array (RAID1+0)
- 8 Delete Striping Array (RAID1+0)
- c Configurations
- q Quit

Command: 4 (If the system does not synchronized the replaced disk automatically, execute the below command to restore to the RAID configuration manually.)

```
[Repair Mirroring Arrays (RAID1)]
* Which SCSI SLOT? [1-6] 4
```

Command action

- 1 List RAID Arrays
- 2 List Internal Disks
- 3 Make Mirroring Arrays (RAID1)
- 4 Repair Mirroring Arrays (RAID1)
- 5 Delete Mirroring Arrays (RAID1)
- 6 Remove Disk Partitions (RAID1)
- 7 Make Striping Array (RAID1+0)
- 8 Delete Striping Array (RAID1+0)
- c Configurations
- q Quit

Command: 1 (Check if the resynchronization process is started.)

```
[List of RAID Arrays]
```

Name	Partition	(Label)	Status	Member
=====				
< Mirroring Array (RAID1) >				
md0	/boot	(-)	RECOVERY (62%)	(1) sda1 R(4) sdd1
md1	swap	(-)	RESYNC	(1) sda2 R(4) sdd2
md2	/	(-)	RESYNC	(1) sda3 R(4) sdd3
md3	/var/crash	(-)	RESYNC	(1) sda5 R(4) sdd5

(Perform restoration (RECOVERY) to each RAID devices (md). After a while, check the Status with the below command. "RESYNC" shows it is waiting to be restored. "R" is displayed on the left side of the Member. This indicates the disk partition is either waiting to be restored or is in the process of restoring.)

Command action

- 1 List RAID Arrays
- 2 List Internal Disks
- 3 Make Mirroring Arrays (RAID1)
- 4 Repair Mirroring Arrays (RAID1)
- 5 Delete Mirroring Arrays (RAID1)
- 6 Remove Disk Partitions (RAID1)
- 7 Make Striping Array (RAID1+0)
- 8 Delete Striping Array (RAID1+0)
- c Configurations
- q Quit

Command: 1

Name	Partition	(Label)	Status	Member
=====				

3-8 Linux Setup and Operation

```
< Mirroring Array (RAID1) >
md0 /boot ( - ) DUPLEX (1) sda1 R (4) sdd1
md1 swap ( - ) DUPLEX (1) sda2 R (4) sdd2
md2 / ( - ) DUPLEX (1) sda3 R (4) sdd3
md3 /var/crash ( - ) DUPLEX (1) sda5 R (4) sdd5
```

(When the each RAID device Status is DUPLEX, the RAID configuration is restored normally. This ends the disk replacement procedure.)

DUAL LAN CONFIGURATION

NEC Express5800/ft series uses Bonding for duplex of 1000 BASE LAN cards controlled by the e1000 driver and builds them as bond*(#=0,1,2,...) device.

Functional overview

For duplicating a LAN, active backup for bonding is used. Active backup is a coupled-interface using multiple LAN controllers. When only active LAN controller fails, this function allows for continued operation by immediately switching to a backup controller.

Operable network configuration

For NEC Express5800/ft series, network interface names are based on the naming convention as described in the table below. Network duplication is achieved by pairing network interfaces of PCI slots in CPU/IO module 0 and network interfaces in the same PCI slots in CPU/IO module 1.

PCI slot and network interface name

PCI slot	Port	CPU/IO module 0	CPU/IO module 1
On Board	#1	eth100200 (1)	eth110200 (1)
	#2	eth100201 (2)	eth110201 (2)
PCI-X slot 1	#1	eth100600 (3)	eth110600 (3)
	(#2)	eth100601 (4)	eth110601 (4)
PCI-X slot 3	#1	eth100700 (5)	eth110700 (5)
	(#2)	eth100701 (6)	eth110701 (6)

*Port enclosed with brackets can be used when NIC is mounted on two ports.

*The number enclosed with brackets in the CPU/IO module column is slot numbers allocated by vndctl described later. The numbers from 1 to 8 are allocated to the interface names in alphabetical order.

Configuring duplication

The following shows information on how to configure duplication by using the settings shown below as an example.

```
<Configuration information>
Slot number: 3
SLAVE0 interface name: eth100600
SLAVE1 interface name: eth110600
IP address: 192.168.0.1
Subnet mask: 255.255.255.0
Default gateway: 192.168.0.1
```

IMPORTANT:

This must be operated by root user.

1. Execute the following command. Configure network interfaces eth100600 and eth110600 that are corresponding to slot 3 as a coupled interfaces.

```
# vndctl add 3
```

2. Execute the command below to configure the network settings (the parts with * are to be specified by a user) on the combined interface that has been constructed. When you enter default gateway, you can omit the process by pressing ENTER without specifying anything.

```
# vndctl config 3
*Boot Protocol? [none/dhcp/bootp] none
*IP address? 192.168.0.1
*Netmask? 255.255.255.0
*Default gateway (IP)? 192.168.0.1
*Are you sure to set it? [y/n] y
DEVICE=bond2
ONBOOT=yes
BOOTPROTO=none
IPADDR=192.168.0.1
NETMASK=255.255.255.0
GATEWAY=192.168.0.1
```

3. Execute the following command to activate the configured coupled-interfaces.

```
# vndctl up 3
```

4. Execute the following command to check the status of the configured coupled-interfaces.

```
# vndctl status
--Virtual Network Status--
BondingDevice Slot Status InetAddress RXErrors TXErrors Collisions
bond0 1 ONLINE - 0 0 0
bond1 2 ONLINE - 0 0 0
bond2 3 ONLINE 192.168.0.1 0 0 0
bond3 OFFLINE - 0 0 0
bond4 OFFLINE - 0 0 0

Slot RealDevice Status Interface LinkState LinkSpeed
1 top eth100200 DUPLEX UP LINK 1000Mb/s-FD
bottom eth110200 DUPLEX UP LINK 1000Mb/s-FD
2 top eth100201 DUPLEX UP LINK 1000Mb/s-FD
bottom eth110201 DUPLEX UP LINK 1000Mb/s-FD
3 top eth100600 DUPLEX UP LINK 1000Mb/s-FD
bottom eth110600 DUPLEX UP LINK 1000Mb/s-FD
4 top -
bottom -
```

5	top	-
	bottom	-
6	top	-
	bottom	-
7	top	-
	bottom	-
8	top	-
	bottom	-

When bond2 (bond 0 and bond 1 are configured by default.) is configured for the slot 3 and as shown above, and the status of each SLAVE interface (eth100600, eth110600) is DUPLEX, duplication is successfully completed.


CHECK THE DUPLICATING OPERATION OF MODULES

This section describes how to check if the system runs properly after system installation or reinstallation. CPU/IO module has a processor function part and IO function part. Each part is monitored and managed by the module. In this section, the processor function part is referred to as CPU module and IO function part PCI module.

Evaluate Startup and Stop of PCI Modules

This section describes how to confirm the continuous system operation by failover after stopping the primary PCI module.

1. Check which is the primary PCI module.
The PCI module with the POWER switch illuminated is the primary module.
2. Check whether the PCI modules are duplicated.
To check if the PCI modules are duplicated, see the CPU/IO modules' status LEDs.




[Indications of the status LEDs when PCI modules are duplicated]


LED	Primary	Secondary
1 CPU/IO module status LED1	-	-
2 CPU/IO module status LED2	Green	Green
3 DISK ACCESS LED	Green blinking	Green blinking

* The numbers in the table correspond to the numbers in the above figure.
The DISK ACCESS LED (3) lights when the hard disk drive is accessed.

3. Stop the operation of a PCI module using the ft server utility.
Move to the directory where the NEC ESMPRO Agent is installed.
cd /opt/nec/esmpro_sa/bin
Start the ft server utility.
./ESMftcutil
The screen of the ft server utility will appear.
Select [ftServer] - [PCI Module] - [PCI Module (to be removed)]. The screen of the PCI Module (to be removed) will appear.
Select [PCI Module Start/Stop] - [Stop] to the stop of the PCI Module.
* As for the primary PCI module (*), if the PCI module 0 is primary select [PCI Module(ID:10)]. If the PCI module 1 is primary, select [PCI Module (ID:11)].
When you stop the operation of the primary PCI module, a failover occurs and the secondary PCI module becomes the primary module.



ft server utility



PCI Module

4. Restart the PCI module.

From the ft server utility, click [Start] of [PCI Module Start/Stop] to the PCI module which was stopped in the step 3, and the PCI module will be started. Once the PCI module is started, PCI module diagnosis, mirror volume duplication and PCI module duplication are performed.

The PCI modules' status LEDs changes as shown below:

[Indications of the status LEDs]

Immediately after the PCI module startup until the completion of diagnosis

	LED	Secondary	Primary
1	CPU/IO module status LED1	-	-
2	CPU/IO module status LED2	-	Green blinking
3	DISK ACCESS LED	-	Amber or Green blinking (when the disk is accessed, this LED illuminates in green)



When duplication of disks is started after the completion of PCI module diagnosis

* The status of LEDs varies depending on the method of disk duplication.

	LED	Secondary	Primary
1	CPU/IO module status LED1	-	-
2	CPU/IO module status LED2	Green blinking	Green blinking
3	DISK ACCESS LED	Amber or Green blinking (when the disk is accessed, this LED illuminates in green)	Amber or Green blinking (when the disk is accessed, this LED illuminates in green)




After the completion of disk duplication and when the PCI modules are duplicated

	LED	Secondary	Primary
1	CPU/IO module status LED1	-	-
2	CPU/IO module status LED2	Green	Green
3	DISK ACCESS LED	Green blinking	Green blinking

Evaluate Start and Stop of CPU Modules

This section describes how to confirm the continuous system operation after stopping one of the CPU modules.

1. Confirm that the CPU modules are duplicated.
To check if the CPU modules are duplicated, see the status LEDs of the CPU modules.



[Indications of status LEDs when CPU modules are duplicated]

LED	CPU module 0 (Operating)	CPU module 1 (Operating)
1 CPU/IO module status LED1	-	-
2 CPU/IO module status LED2	Green	Green
3 DISK ACCESS LED	Green blinking	Green blinking


2. Use the ft server utility to stop the operation of a CPU module to remove.
Move to the directory where the ft server utility of NEC ESMPRO Agent is installed.

```
# cd/opt/nec/esmpro_sa/bin/
```

 Start the ft server utility.

```
# ./ESMftutil
```

 The screen of the ft server utility will appear.
 Select [ftServer] - [CPU Module] - [CPU Module (to be removed)]. The screen of the CPU Module(to be removed) will appear.
 Select [CPU Module Start/Stop] - [Stop] to the stop of the CPU .Module.
 * As for the CPU module to stop, select [CPU Module(ID:0)] to stop CPU module 0, select [CPU Module(ID:1)] to stop CPU module 1.



ft server utility

CPU Module

3. Restart the CPU module.

In the ft server utility, select the stopped CPU module and click [Start] of [CPU Module Start/Stop].

Once the CPU module is started, hardware diagnosis and then synchronization of memory (memory copy) are performed, and the duplication process is completed.

Note that the system is paused temporarily for copying memory during memory synchronization.

[Indications of status LEDs during diagnosis]

LED	CPU module 0 (Started)	CPU module 1 (Operating)
1 CPU/IO module status LED1	-	-
2 CPU/IO module status LED2	-	Green blinking
3 DISK ACCESS LED	Green blinking	Green blinking



[Indications of status LEDs after completion of duplication]

LED	CPU module 0 (Operating)	CPU module 1 (Operating)
1 CPU/IO module status LED1	-	-
2 CPU/IO module status LED2	Green	Green
3 DISK ACCESS LED	Green blinking	Green blinking

IMPORTANT:

After duplication is completed, the status of memory will be checked.

Wait until this process ends to perform the next step (evaluation of start and stop of PCI and CPU modules). When the process is complete, the following event log will be output:

Kernel: EVLOG: INFORMATION – Memory consistency check has completed memory scan.

ft Server service

NEC Express5800/ft series provides the services required for the system operation by the following service programs in addition to the dedicated drivers.

Service names:

- kdump
- ft-cclogger
- ft-firstboot
- ft-snmp
- snmpd
- portmap
- ESMntserver
- ESMamvmain
- ESMftreport
- ESMcmn
- ESMfilesys
- ESMlan
- ESMIS
- ESMps
- ntagent

The service programs above are required for operating NEC Express5800/ft series. Do not stop them.

Notes on access to USB FDD

When you attempt an access by directly specifying an sd device name as described below while a USB FDD is connected, the device name may be changed due to separation or integration of one of the PCI modules, which can destroy partition information etc. of other disks unintentionally.

[Example]

If you execute a command for the USB FDD after you integrate one of the PCI modules with the same sd device name that was specified before the system was separated, partition information etc. of the disk A is destroyed.

Transition of sd device names

	Disk A	USB FDD	Disk B
Before one of the PCI modules is separated	sda	sdb	sdc
After one of the PCI modules is separated	none	sda	sdc
After one of the PCI modules is integrated	sdb	sda	sdc

- 1) Before one of the PCI modules is separated
 # tar cf /dev/sdb files
 → Files are written in the USB FDD.
- 2) After one of the PCI modules is integrated
 # tar cf /dev/sdb files
 → Files are written in the disk A unintentionally → partitions are destroyed



Note:

It is a feature of NEC Express5800/ft series that the device names of the device files change due to integration or separation of one of the PCI modules.

Configuring the video mode

This section describes how to configure the video mode for this device.

1. Open `/etc/X11/xorg.conf` as a root user by using an editor.

IMPORTANT:

`xorg.conf` is a very important file for the X server system. It is recommended to create a backup because corrupting `xorg.conf` can result in failure to start up the X server in the worst case scenario. When you make a backup, use a different file name for the backup since the file name `/etc/X11/xorg.conf.backup` is used by the system.

2. Modify the following configuration in `xorg.conf`.

Enter the value you want to configure in (1)'s `Modeline` in the (2)'s `Modes` line.

Changing the numbers of colors

Change the value indicated by (3) to the number of colors you want (8bpp, 16bpp or 24bpp). If you have chosen 24bpp, delete # at the top of the line indicated by (4). (If you have chosen 8bpp or 16bpp, make sure the line starts with #. If there is no #, enter it.)

```
Section "Monitor"
Identifier      "Monitor0"
VendorName     "Monitor Vendor"
ModelName      "Unprobed Monitor"
HorizSync      30.0 - 95.0
VertRefresh    60.0 - 180.0
Modeline       "1024x768 @ 60Hz" 65.0 1024 1048 1184 1344 768 771 777 806 -hsync -vsync
Modeline       "1024x768 @ 70Hz" 75.0 1024 1048 1184 1328 768 771 777 806 -hsync -vsync
Modeline       "1024x768 @ 75Hz" 78.8 1024 1040 1136 1312 768 769 772 800 +hsync +vsync
Modeline       "640x480 @ 60Hz" 25.2 640 656 752 800 480 490 492 525 -hsync -vsync
Modeline       "800x600 @ 60Hz" 40.0 800 840 968 1056 600 601 605 628 +hsync +vsync
Modeline       "800x600 @ 72Hz" 50.0 800 856 976 1040 600 637 643 666 +hsync +vsync
Modeline       "800x600 @ 75Hz" 49.5 800 816 896 1056 600 601 604 625 +hsync +vsync
Modeline       "800x600 @ 85Hz" 56.3 800 832 896 1048 600 601 604 631 +hsync +vsync
Option         "dms"
EndSection

Section "Device"
#
Driver         "ati"
Identifier     "Videocard0"
Driver         "fbdev"
VendorName     "Videocard vendor"
BoardName      "ATI Radeon RV100 framebuffer mode"
Option         "UseFBDev"
EndSection

Section "Screen"
# Uncomment next line if DefaultDepth 24 only
DefaultFbBpp  24
Identifier     "Screen0"
Device         "Videocard0"
Monitor        "Monitor"
SubSection    "Display"
    Viewport   0 0
    Depth      16
    Modes      "800x600 @ 75Hz"
EndSubSection
SubSection    "Display"
    Viewport   0 0
    Depth      24
    Modes      "1024x768 @ 75Hz" "1024x768 @ 70Hz" "1024x768 @ 60Hz" "800x600 @ 85Hz" "800x600 @ 75Hz" "800x600 @ 72Hz" "800x600 @ 60Hz"
EndSection
```

3. If the X server is started, shut down the server by entering `'init 3'` in a command line.
4. The mode is switched to the console mode (CUI), and then, start up the X server by entering `'init 5'` in a command line.

**Note:**

- You cannot use `xrandr` to modify the resolution because the `xrandr` function is not supported.
- If you use the X server on the console, operate the system at the run level 5 and perform graphical login. If X is not started when the system is started (i.e run level 3), log in as root and enter `"init 5"` from a command line on the text console to start the X server.
- You cannot change the resolution and the number of colors from application menu due to hardware specification.

If you cannot restore the system since you have changed the resolution from application menu, follow the steps below.

- (1) Switch to the console mode. (Enter `"init 3"` in the command line. If the window cannot be displayed, press `[Ctrl] + [Alt]` + any one of the keys from F1 through F6 to switch to the console mode, and then log in as a root user and type `"init 3"`.)
- (2) Open `/etc/X11/xorg.conf` by an editor.
- (3) The value of Modes in (1) is as shown in the figure below. Select the value you want to configure in (1)'s `Modeline` and enter it in the (2)'s `Modes` line.
- (4) Enter `"init 5"` in the command line to start the X server.

```

Section "Monitor"
  Identifier      "Monitor0"
  VendorName     "Monitor_Vendor"
  ModelName      "Unprobed Monitor"
  HorizSync      30.0 - 95.0
  VertRefresh    50.0 - 180.0
  Modeline       "1024x768 @ 60Hz" 65.0 1024 1048 1184 1344 768 771 777 806 -hsync -vsync
  Modeline       "1024x768 @ 70Hz" 75.0 1024 1048 1184 1328 768 771 777 806 -hsync -vsync
  Modeline       "1024x768 @ 75Hz" 78.8 1024 1040 1136 1312 768 769 772 800 +hsync +vsync
  Modeline       "640x480 @ 60Hz" 25.2 640 656 752 800 480 490 492 525 -hsync -vsync
  Modeline       "800x600 @ 60Hz" 40.0 800 840 968 1056 600 601 605 628 +hsync +vsync
  Modeline       "800x600 @ 72Hz" 50.0 800 856 976 1040 600 637 643 666 +hsync +vsync
  Modeline       "800x600 @ 75Hz" 49.5 800 816 896 1056 600 601 604 625 +hsync +vsync
  Modeline       "800x600 @ 85Hz" 56.3 800 832 896 1048 600 601 604 631 +hsync +vsync
EndSection

Option          "dpms"

Section "Device"

#   Driver      "ati"
#   Identifier  "Videocard0"
#   Driver      "fbdev"
#   VendorName  "Videocard vendor"
#   BoardName   "ATI Radeon RV100 framebuffer mode"
#   Option      "UseFBDev"

EndSection

Section "Screen"

# Uncomment next line if DefaultDepth 24 only
#   DefaultFBpp      24
#   Identifier       "Screen0"
#   Device           "Videocard0"
#   Monitor          "Monitor0"
#   DefaultDepth     16
#   SubSection "Display"
#     Viewport      0 0
#     Depth         16
#     Modes         "1024x768" "800x600" "640x480"
#   EndSubSection
#   SubSection "Display"
#     Viewport      0 0
#     Depth         24
#     Modes         "1024x768 @ 75Hz" "1024x768 @ 70Hz" "1024x768 @ 60Hz" "800x600 @ 85Hz" "800x600 @ 75Hz" "800x600 @ 72Hz" "800x600 @ 60Hz"
(1)

```

(This page is intentionally left blank.)

Chapter 4

System Configuration

This chapter describes Basic Input Output System (BIOS) configuration.

When you install the NEC Express5800/ft series for the first time or install/remove optional devices, thoroughly read this chapter for better understanding and correct setups.

SYSTEM BIOS –SETUP–

The SETUP utility is provided to make basic hardware configuration for the server. This utility is pre-installed in the flash memory of the server and ready to run.

The server is configured with the correct parameters using the SETUP utility and shipped in the best conditions. Thus, you do not need to use the SETUP utility in most cases. However, you might wish to use the SETUP utility in the cases described below.

IMPORTANT:

- The SETUP utility is intended for system Administrator or for root user only.
 - The SETUP utility allows you to set a password. The server is provided with two levels of password: Supervisor and User. With the Supervisor password, you can view and change all system parameters of the SETUP utility. With the User password, system parameters available for viewing and changing are limited.
 - Do not set any password before installing the OS.
 - The server contains the latest version of the SETUP utility. Dialog boxes appearing on your SETUP utility, thus, may differ from descriptions in this User's Guide. If you find anything unclear, see the online help or ask your sales agent.
-

Starting SETUP Utility

Powering on the server starts POST (Power On Self-Test) and displays its check results. If the NEC logo is displayed, press **Esc**.

After a few seconds, either of the following messages appears at bottom left on the screen depending on your system configuration.

Press <F2> to enter SETUP

Press <F2> to enter SETUP or Press <F12> to boot from Network

You may see either of the following messages at bottom left on the screen when POST terminates.

Press <F1> to resume, <F2> to SETUP

Press **F2** to start the SETUP utility and display its Main menu.

If you have previously set a password with the SETUP utility, the password entry screen appears. Enter the password.

Enter password:|

Up to three password entries will be accepted. If you fail to enter the password correctly for three consecutive times, the server halts. (You can no longer proceed.) Power off the server.

TIPS:

The server is provided with two levels of password: Supervisor and User. With the Supervisor password, you can view and change all system configurations. With the User password, the system configurations you can view or change are limited.

Description of On-Screen Items and Key Usage

Use the following keyboard keys to work with the SETUP utility. (Key functions are also listed at the bottom of the screen.)

The screenshot shows the 'ftServer Setup' utility with the following menu structure:

- Main
 - Advanced (highlighted)
 - Security
 - Server
 - Boot
 - Exit
- Advanced Processor Configuration (highlighted)
 - I/O Device Configuration
 - Option ROM Configuration
 - Boot-time Diagnostic Screen: [Disabled]
 - HPET [Disabled]
- Item Specific Help
 - Advanced Processor settings

At the bottom of the screen, the following key functions are listed:

- F1 Help
- Esc Exit
- ↑ Select Item
- ↓ Change Values
- ← Select Menu
- Enter Select
- Sub Menu
- F9 Setup Defaults
- F10 Save and Exit

Annotations in the image:

- 'Shows the current menu.' points to the 'Advanced' menu item.
- 'Options to be configured' points to the 'Advanced Processor Configuration' option.
- 'Denotes there are submenus' points to the 'I/O Device Configuration' and 'Option ROM Configuration' options.
- 'Online help window' points to the 'Item Specific Help' section.
- 'Parameters (selected parameters are highlighted)' points to the '[Disabled]' text.
- 'Explanation of keys' points to the key function list at the bottom.

Cursor (↑, ↓):

Selects an item on the screen. The highlighted item is currently selected.

Cursor (←, →):

Selects the Main, Advanced, Security, System Hardware, Boot, or Exit menu.

- Changes the value (parameter) of the selected item to the previous value.

+ Changes the value (parameter) of the selected item to next value.

Enter Displays a submenu or chooses the selected parameter.

Esc Displays the previous screen.

F1: Press **F1** when you need help on SETUP operations. The help screen for SETUP operations appears. Press **Esc** to return to the

F9: previous screen.
Shows the following:

Setup Confirmation
Load default configuration now?
[Yes] [No]

If you select "Yes" and then press the **Enter** key, all items in the setup are set to default values. If you select "No" and then press either the **Enter** or **Esc** key, the status before pressing the **F9** key is restored.

F10: Shows the following:

Setup Confirmation
Save Configuration changes and exit now?
[Yes] [No]

If you select "Yes" and then press the **Enter** key, the setup will complete with all changes you have made saved. If you select "No" and then press either the **Enter** or **Esc** key, the status before pressing the **F10** key is restored.

Configuration Examples

The following describes examples of configuration required to use software-link features or for system operations.

UPS

To link power supply with the UPS

- To power on the server when power is supplied from the UPS
Select [Server] - [AC-LINK] - [Power On].
- To keep the server off-powered even when power is supplied from the UPS if the POWER switch was used to power off
Select [Server] - [AC-LINK] - [Last State].
- To keep the server off-powered even when power is supplied from the UPS
Select [Server] - [AC-LINK] - [StayOff].

Keyboard

To set Num Lock

Select [Advanced] - [I/O Device Configuration] - [NumLock]

Security

To set passwords on the BIOS level

Select [Security] - [Set Supervisor Password] and enter a password.

Select [Security] - [Set User Password] and enter a password.

Set Supervisor password first, then User password.

Optional PCI-related devices

To enable Option ROM of the PCI card (option) installed on the server

Select [Advanced] - [Option ROM Configuration] - [PCI Slot n (...)] - [Enabled].

n: Slot number to install the board

Boot

To change the boot order of devices connected to the server

Select [Boot] and specify the boot order.

To display POST check results

Select [Advanced] - [Boot-time Diagnostic Screen] - [Enabled].

You can also press **Esc** while the NEC log is on the screen to display POST check results.

To control from the HW console

- Remote operation via Serial
Select [Server] - [Console Redirection], and make necessary settings.

Remote Wakeup

To enable remote wake on LAN

Select from LAN: [Advanced] - [Advanced Chipset Control] - [Wake on LAN] - [Enabled].

Memory

To check the installed memory (DIMM) status:

Select [Advanced] - [System Memory] and [Extended Memory] and check the status indications.

Saving the Configuration Data

To save the BIOS configuration data

Select [Exit] - [Exit Saving Changes]

To discard changes to the BIOS configuration data

Select [Exit] - [Exit Discarding Changes]

To restore the default BIOS configuration data (the data may differ from the factory preset)

Select [Exit] - [Load Setup Defaults].

Menu and Parameter Descriptions

The SETUP utility has the following six major menus:


- Main
- Advanced
- Security
- Server
- Boot
- Exit

To configure detailed settings of functions, select a submenu from the above menus. Below describes configurable functions and parameters and the factory settings displayed in the screen for each menu.

Main

Start the SETUP utility to display the Main menu.

When you select a menu with the “▶” mark and press the **Enter** key, its submenu appears.
<Example>



Available options in the Main and descriptions are listed below.

Option	Parameter	Description
System Time	HH:MM:SS	Specify the system time.
System Date	MM/DD/YYYY	Specify the system date.
CPU Speed	XXXX MHz	Displays the processor clock frequency.
Physical CPUs	X	Displays the number of processor installed.
System Memory	XXXX KB	Displays the size of system memory.
Extended Memory	XXXX MB	Displays the size of extended memory.
Cache Ram	XXXX KB	Displays the capacity of LS cache.
SATA AHCI Enable	[Disabled] Enabled	Specify whether or not to enable AHCI mode.

[] factory default

IMPORTANT:

Check and adjust the system clock before operation in the following conditions.

- After transporting the equipment
- After storing the equipment
- After the equipment halt under the conditions which is out of the guaranteed environment conditions (Temperature: 10 to 35°C, Humidity: 20 to 80%).


Check the system clock once in a month. It is recommended to operate the system clock using a time server (NTP server) if it is installed on the system which requires high level of time accuracy. If the system clock goes out of alignment remarkably as time goes by, though the system clock adjustment is performed, contact your sales agent.

Do not change "SATA AHCI" as "Enabled." The BIOS version may become unable to display on the ft Server Utility.

Advanced

Move the cursor onto “Advanced” to display the Advanced menu.

There is no configurable item on the Advanced menu screen below. Display each sub menu and make settings on the sub menu screen. Select an option with the “▶” mark and press **Enter** to display its submenu.




See the table below for setup options on the screen.

Option	Parameter	Description
Boot-time Diagnostic Screen	[Disabled] Enabled	Specify whether to display the Power On Self-Test (POST) screen at start-up. If “Disabled” is selected, the NEC logo appears while POST is in progress. (To display POST check results, press Esc .)

[]: factory default

Advanced Processor Configuration

When you select “Advanced Processor Configuration” in the Advanced menu, the following screen appears.



Refer to the table below for information on options.

Option	Parameter	Description
Execute Disable Bit	[Enabled] Disabled	Specify whether or not to enable Execute Disable Bit feature.
Intel(R) Virtualization Tech	[Enabled] Disabled	Specify whether or not to enable Intel Virtualization Technology feature.
PECI Interface	[Enabled] Disabled	Specify whether or not to enable Platform Environment Control Interface feature.

[]: factory default

I/O Device Configuration

When you select “I/O Device Configuration” in the Advanced menu, the following screen appears. If you select a menu with the “▶” mark and press **Enter**, its submenu appears.

ftServer Setup			
Main	Advanced	Security	Server Boot Exit
I/O Device Configuration		Item Specific Help	
Serial Port1: Base I/O address: Serial Port 1 Connection: Serial Port2: Base I/O address:	[Enabled] [3F8/IRQ 4] [Serial Connector] [Enabled] [2F8/IRQ 3]	Configure Serial Port 1 using options: [Disabled] No configuration [Enabled] User configuration [Auto] BIOS or OS chooses configuration	
Serial Port2 Sharing	[Disabled]		
Keyboard Features:			
NumLock:	[Off]	NOTE: Serial Port 1 may not be routed to the Modem if a VTM is present.	
F1 Help	↑ ↓ Select Item	-/+ Change Values	F9 Setup Defaults
Esc Exit	← → Select Menu	Enter Select ▶ Sub Menu	F10 Save and Exit

Refer to the table below for information on options.


Option	Parameter	Description
Serial Port 1	Enabled [Disabled] Auto	Specify whether or not to enable Serial Port 1.
Base I/O address	[3F8/IRQ4] 2F8/IRQ3 3E8/IRQ4 2E8/IRQ3	Specify the I/O address and IRQ of Serial Port 1.
Serial Port 1 Connection	[Serial Connector] Internal Modem	Specify Serial Connector or Internal Modem for Serial Port 1 connection.
Serial Port 2	Enabled [Disabled] Auto	Specify whether or not to enable Serial Port 2.
Base I/O address	3F8/IRQ4 [2F8/IRQ3] 3E8/IRQ4 2E8/IRQ3	Specify the I/O address and IRQ of Serial Port 2.
Serial Port 2 Sharing	Enabled [Disabled]	Specify whether or not to use Serial Port 2 in BMC.

Keyboard Features		Display only.
NumLock	AUTO On [Off]	Specify whether or not to enable NumLock at system startup.

[]: factory default

Option ROM Configuration

When you select “Option ROM Configuration” in the Advanced menu, the following screen appears.



Refer to the table below for information on options.


Option	Parameter	Description
PCI Slot 1 (onboard) Option ROM	Enabled [Disabled]	If “Enabled” is selected, the extended ROM of the PCI card installed on PCI Slot 1 is initialized. Note: this option is displayed only when a PCI card is installed.
PCI Slot 2 (lower) Option ROM	Enabled [Disabled]	If “Enabled” is selected, the extended ROM of the PCI card installed on PCI Slot 2 is initialized. Note: this option is displayed only when a PCI card is installed.
PCI Slot 3 (upper) Option ROM	Enabled [Disabled]	If “Enabled” is selected, the extended ROM of the PCI card installed on PCI Slot 3 is initialized. Note: this option is displayed only when a PCI card is installed.
Embedded SAS Option ROM	[Enabled] Disabled	If “Enabled” is selected, SAS extended ROM embedded in the motherboard is initialized.

Option	Parameter	Description
Embedded PXE#1 Option ROM	[Enabled] Disabled	If “Enabled” is selected, the extended ROM of LAN #1 embedded in the motherboard is initialized.
Embedded PXE#2 Option ROM	[Enabled] Disabled	If “Enabled” is selected, the extended ROM of LAN #2 embedded in the motherboard is initialized.

[]: factory default

Advanced Chipset Control

When you select “Advanced Chipset Control” in the Advanced menu, the following screen appears.



Refer to the table below for information on options.

Option	Parameter	Description
HPET	[Enabled] Disabled	Specify whether or not to enable High Precision Timer feature.
Intel(R) I/OAT	[Enabled] Disabled	Specify whether or not to enable Intel(R) I/OAcceleration Technology feature.
Wake On LAN	[Enabled] Disabled	Specify whether or not to enable network remote power-on feature.

[]: factory default


IMPORTANT:

Under Wake On LAN environment

When you disconnect either or both of the AC cables on the server and the Alternate Current supply is stopped, the Wake On LAN function becomes unavailable on the next system launch after the electricity supply starts. You need to connect the cables to both equipments to supply the electricity, and press the power switch to start the system.

Security


Move the cursor onto “Security” to display the Security menu.



4-18 System Configuration

Select “Set Supervisor Password” or “Set User Password” and press **Enter** to display the following pop-up screen. The screen below shows when “Set Supervisor Password” is selected.

Set a password on this pop-up screen. Enter a password of up to seven alphanumeric characters and symbols from the keyboard.



IMPORTANT:

- “User password” setup is not available before “Supervisor password” setup.
- Do not set any password before installing the OS.
- If you forget your password, contact your sales agent.

See the table below for setup options on the screen.

Option	Parameter	Description
Supervisor Password Is	Unset Set	Indicates Supervisor password setup status (view only).
User Password Is	Unset Set	Indicates User password setup status (view only).
Set Supervisor Password	[Enter]	Press Enter to display the supervisor password entry screen. This option is available only when you log into the SETUP utility with the supervisor password.
Set User Password	[Enter]	Press Enter to display the user password entry screen. With a user password, accessing the SETUP menus is restricted.

Option	Parameter	Description
Password on boot	[Disabled] Enabled	Specify whether to request a password entry at boot-up. User password setup is required beforehand.

[]: factory default

IMPORTANT:

If you have logged in SETUP by using the Supervisor Password, you can check and change all settings. If you have logged in SETUP by using User Password, you can see the settings but cannot make changes on the settings except System Time, System Date and User Password of Main.

Server

Move the cursor onto [Server] to display the Server menu.

The following describes options you can configure in the Server menu and their functions. Select an option with the “▶” mark and press **Enter** to display its submenu.

Refer to the table below for information on options.

ftServer Setup			
Main	Advanced	Security	Server Boot Exit
▶ System Management ▲ Console Redirection ▲ Event Log Configuration ▲ Monitoring Configuration Post Error Pause: [Enabled] AC-LINK: [Last State] Power On Delay Time: [180]		Item Specific Help Additional setup menu to view server management features.	
F1 Help	↑ ↓ Select Item	-/+ Change Values	F9 Setup Defaults
Esc Exit	← → Select Menu	Enter Select ▶ Sub Menu	F10 Save and Exit

Option	Parameter	Description
Post Error Pause	Disabled [Enabled]	Set whether or not to pause POST at the end of POST if an error has occurred during POST execution.
AC LINK	Stay Off [Last State] Power On	Specify the AC LINK feature by selecting the status of the power supply unit of the server when the AC power supply restarts. (See the following table for details.)
Power ON Delay Time	[180]-255(s)	Configure the DC ON delay time if AC LINK is set to “Power On” or “Last State” (unit: second).

[j: factory default

The table below lists how selections for “AC LINK” determine the power status of the server when the power supply to the server restarts.

State before powered off	Parameter		
	Stay Off	Last State	Power On
In service	Off	On	On
Out of service (DC power: Off)	Off	Off	On
Forced shutdown *	Off	Off	On

* Pressing the POWER switch for over four seconds shuts down the power to the server.

System Management

Select “System Management” on the Server menu and press **Enter** to display the following screen.
(Example)

ftServer Setup

Main	Advanced	Security	Server	Boot	Exit
System Management					
BIOS Version: 2.1:44 Board Part #: 243-632791 Board Serial #: 113108030768 System Part #: N8800-124 System Serial #: 9072543618 Chassis Part #: 243-535509 Chassis Serial #: 01 BMC Device ID: 26 BMC Device Rev: 01 BMC Firmware Rev: 0E.25 SDR Rev: SDR Version 00.10 PIA Rev: 01.10 ASIC Rev: 2023 SMM Rev: 00.25			Item Specific Help All items on this menu cannot be modified in user mode. If any items require changes, please consult your system Supervisor.		
F1 Help ↑ ↓ Select Item -/+ Change Values F9 Setup Defaults Esc Exit ← → Select Menu Enter Select ▶ Sub Menu F10 Save and Exit					

See the table below for setup options on the screen.

Option	Parameter	Description
BIOS Version	—	Displays the BIOS version.
Board Part Number	—	Displays the board information.
Board Serial Number	—	Displays the board information.
System Part Number	—	Displays the system information.
System Serial Number	—	Displays the system information.
Chassis Part Number	—	Displays the chassis information.

4-22 System Configuration

Option	Parameter	Description
Chassis Serial Number	—	Displays the chassis information.
BMC Device ID	—	Displays the BMC information.
BMC Device Revision	—	Displays the BMC information.
BMC Firmware Revision	—	Displays the BMC information.
SDR Revision	—	Displays the revision of SDR (sensor device information).
PIA Revision	—	Displays the PIA (plat form information) revision.
ASIC Rev	—	Displays the firmware information of the fault-tolerant chipset.
SMM Rev	—	Displays the firmware information of System Management.
CPU0 BMC MAC Address	—	Displays MAC Address of the CPU/IO Module0-mounted BMC if the ft management card is implemented.
CRU1 BMC MAC Address	—	Displays MAC Address of the CPU/IO Module1-mounted BMC if the ft management card is implemented.\

[]: factory default

Console Redirection

Select “Console Redirection” on the Server menu and press **Enter** to display the following screen.


ftServer Setup					
Main	Advanced	Security	Server	Boot	Exit
Console Redirection		Item Specific Help			
Com Port Address	[Disabled]				
Baud Rate	[19.2K]				
Console Type	[PC-ANSI]				
Flow Control	[CTS/RTS]				
Console connection:	[Direct]				
Continue C.R. after POST:	[Off]				
F1 Help	↑ ↓ Select Item	-/+	Change Values	F9 Setup Defaults	
Esc Exit	← → Select Menu	Enter	Select ► Sub Menu	F10 Save and Exit	

See the table below for setup options on the screen.

Option	Parameter	Description
Com Port Address	[Disabled] Serial Port1 Serial Port2	Select a serial port.
Baud Rate*	9600 [19.2K] 38.4K 57.6K 115.2K	Select a port rate used for the interface with a hardware console to be connected.
Console Type*	VT100 VT100, 8bit PC-ANSI, 7bit [PC-ANSI] VT100+ VT-UTF8	Select a console type.
Flow Control*	None XON/XOFF [CTS/RTS]	Select a flow control method.
Console Connection	[Direct] Via modem	Select a connector.
Continue C.R. after POST	[Off] On	Specify whether or not to continue Console Redirection after OS is loaded. []: factory default

Event Log Configuration

Select “Event log Configuration” on the Server menu and press **Enter** to display the following screen.



See the table below for setup options on the screen.

Option	Parameter	Description
Clear Online Event Logs	[Press Enter]	To clear event logs of the working module, press the Enter key and select “Yes.”
Clear Offline Event Logs	[Press Enter]	To clear event logs of the stand-by module, press the Enter key and select “Yes.”

Monitoring Configuration

Select “Monitoring Configuration” on the Server menu and press **Enter** to display the following screen.

ftServer Setup	
Main	Advanced Security Server Boot Exit
Monitoring Configuration	
FRB-2 Timer	[Enabled]
PCI Enumeration Monitoring:	[Enabled]
PCI Enumeration Monitoring Timeout:	[180]
Option ROM Scan Monitoring:	[Enabled]
Option ROM Scan Monitoring Timeout:	[300]
OS Boot Monitoring:	[Enabled]
OS Boot Monitoring Timeout:	[600]
POST Pause Monitoring:	[Enabled]
POST Pause Monitoring Time-out	[180]
F1 Help	↑ ↓ Select Item -/+ Change Values F9 Setup Defaults
Esc Exit	← → Select Menu Enter Select ► Sub Menu F10 Save and Exit
	Item Specific Help
	Disables/enables the FRB-2 Timer.

Option	Parameter	Description
FRB-2 timer	Disabled [Enabled]	Select whether or not to enable the FRB-2 timer.
PCI Enumeration Monitoring	Disabled [Enabled]	Select whether or not to enable the function to monitor PCI Device scan.
PCI Enumeration Monitoring Timeout	60-[180]-1200	Set the timeout for PCI Device scan. (unit: second)
Option ROM Scan Monitoring	Disabled [Enabled]	Select whether or not to enable the function to monitor the extended ROM scan.
Option ROM Monitoring Timeout	60-[300]-1200	Set the timeout of the extended ROM scan. (unit: second)
OS Boot Monitoring	Disabled [Enabled]	Select whether or not to enable the function to monitor OS boot-up. If you are starting up from an OS with no NEC ESMPRO Agent installed, disable this option. If you use Disaster Recovery Option for ARCServe, select [Disabled].
OS Boot Monitoring Timeout	60-[600]-1200	Set the timeout at OS boot-up. (unit: second)
POST Pause Monitoring	Disabled [Enabled]	Select whether or not to enable the POST monitoring function during boot pause. (unit: second)

4-26 System Configuration


Option	Parameter	Description
POST Pause Monitoring Time-out	60-[180]-1200	Set the time for POST monitoring during boot pause. (unit: second)

[]: factory default

Boot

Move the cursor onto “Boot” to display the Boot menu.

The server searches for the boot device according to the order specified in this menu and use the software to boot the system if found.




You can change the boot device order using ↑ or ↓ and + or -. Move the cursor to select the device by ↑ or ↓, and then change the priority using + or -.

IMPORTANT:

Move to set “CD-ROM Drive” above “Hard Drive” when you boot the NEC EXPRESSBUILDER.

Exit

Move the cursor onto “Exit” to display the Exit menu.




The following describes each option on the Exit menu:

Exit Saving Changes


Select this option to save the current configuration data into the CMOS (non-volatile memory) and exit the SETUP utility.

Select “Exit Saving Changes” to display the screen below. Select “Yes” to save the current configuration data into the CMOS (non-volatile memory) and exit the SETUP utility. The server will automatically restart the system.




Exit Discarding Changes

Select this option to exit the SETUP utility without saving the current configuration data into the CMOS (non-volatile memory). If you select “Yes” here, the “SETUP Warning” dialogue box appears. If you select “No” in the “SETUP Warning” dialogue box, you can exit SETUP without saving the changes you have made. If you select “Yes” in the dialogue box, you can exit SETUP with the changes you have made saved in CMOS. The server reboots automatically.




Load Setup Defaults

Select this option if you want to reset all values in SETUP to default (factory-set values). When you select Load Setup Defaults, the dialogue box as shown below appears. If you select “Yes” in the dialogue box, default values are restored. If you select “No”, you will see the Exit menu screen.



Discard Changes

Select this option if you want to restore previous values before saving values in CMOS. When you select “Discard Changes”, you will see the dialogue box as shown below. If you select “Yes” in the dialogue box, changes you have made are discarded and previous settings are restored.




IMPORTANT:

The default value and the factory default value differ partially. If you want to bring the value back to the default, verify all the value you want to make changes.

Save Changes

Select this option if you want to save changes you have made in CMOS (non-volatile memory) without exiting SETUP. When you select the Save Changes, you will see the dialogue box as shown below.

If you select “Yes” in the dialogue box, changes you have made are saved in CMOS (non-volatile memory).



SAS BIOS –Adaptec SAS/SATA Configuration Utility–

Adaptec SAS/SATA Configuration utility makes settings of the built-in SAS controller on a motherboard. You can start it up by simple key operation during POST execution without using any special startup disk.

IMPORTANT:

- Because the server is installed with the latest version of the SCSISelect utility, your screen display may be different from the one described in this guide. For information on options different from those described in this guide, refer to the online help or ask your service agent.
- When you start this utility, select [Server], [Monitoring Configuration], [Option ROM Scan Monitoring], and [Disabled]. If [Enabled] is selected, system may reboot while you are making settings. However, set [Option ROM Scan Monitoring] to [Enabled] after making settings.

Starting and Quitting the Adaptec SAS/SATA Configuration utility

The following section describes the procedures from starting the Adaptec SAS/SATA Configuration utility to quitting the utility.


1. Power on the server.

The following message appears on the screen during POST execution.

Adaptec Serial Attached SCSI (SAS) BIOS Vx.x-x
(C) 1998–2006 Adaptec, Inc. All Rights Reserved.
◀◀◀ Press <CTRL><A> for Adaptec SAS/SATA Configuration Utility! ▶▶▶


2. Press and hold down the **Ctrl** key and press the **A** key.

The Adaptec SAS/SATA Configuration utility starts up with the “Main” menu displayed.



3. Select a menu in the “Options”, and then press the **Enter** key.
If you want to make settings of the adapter, select “SerialSelect Utility.”
If you want to format or verify the hard disk drive connected to the adapter, select “Disk Utility.”
For more information, see the explanation below.

4. To quit, press the **Esc** key until you see the closing message. (If any changes have been made, the message asking you whether or not to save the changes is displayed. Select Yes (save the changes) or No (discard the changes)).



Parameter and Description


Adaptec SAS/SATA Configuration utility has two types of menu.

- SerialSelect Utility
- Disk Utilities

You can set features that are more detailed by selecting a submenu from these menus. The following describes the features and parameters that can be set in each menu and factory settings displayed on the screen.

SerialSelect Utility

The following screen is displayed when you select “SerialSelect Utility” in the “Options” menu.



Select an item using the UP and DOWN ARROW keys and press **Enter**. The following describes the menu and parameters.

Tips:

You do not need to specify the parameters. The following is described for reference.

Controller Properties

The following screen is displayed when “Controller Properties” is selected in the menu.

Adaptec SAS/SATA Controller#0

Controller Information

```


PCI Slot:Bus:Device:Function..... 0:A:0:0
Interrupt (IRQ) Channel..... 7
I/O Port Address..... 8000
Device ID..... 041E
Controller Serial number.....
Controller WWN..... 50030130F0B13700
    
```

See the following table for each item.

Item	Parameter	Description
PCI Slot Bus: Device:Function	—	Displays the storage device bus on the SAS controller.
Interrupt(IRQ) Channel	—	Displays the interrupt.
I/O Port Address	—	Displays the I/O port device.
Device ID	—	Displays the device ID.
Controller Serial Number	—	Displays the controller serial number.
Controller WWN	—	Displays the controller WWN. [] : factory default

Controller Configuration

The following screen is displayed when “Controller Configuration” is selected in the menu.



See the following table for each item.

Item	Parameter	Description
Runtime BIOS	[Enabled] Disabled Disabled:Scan bus	Controls the BIOS status at the POST. If [Enabled] is selected, the controller can be operated as a boot device by SAS controller BIOS. If [Disabled] is selected, other appropriate SAS controllers operate as boot devices.
BBS Support	[Device] Controller	If the setting of BBS support is set to [Device], the boot device connected to SAS controllers is registered to the boot menu of system BIOS. If BBS support is set to [Controller], only SAS controllers are registered to the BIOS boot menu.
POST Banner Display	[Enabled] Disabled	If [Enabled] is selected, Adaptec banner, the version, and copyright are displayed. If [Disabled] is selected, Adaptec banner, the version, and copyright are not displayed.
CTRL-A Message Display	[Enabled] Disabled	If [Enabled] is selected, the message "Press <CTRL><A> for Adaptec SAS/SATA Configuration Utility" is displayed in SAS controller BIOS during the POST. Even if this option is set to [Disabled], the utility can be started by pressing CTRL+A after the BIOS title of SAS controllers is displayed.
Physical Display Post	[Enabled] Disabled	If [Enabled] is selected, connected physical devices are displayed during the system POST. However, depending on the device display, the time that it takes to complete entire POST can become a few seconds longer.
RAID Support	Enabled [Disabled]	Do not set to [Enabled] since RAID is not supported.

[] : factory default

1. Press **F6** to return to the initial value.
2. To quit, press **Esc** until you see the closing message (If any changes have been made, the message asking you whether or not to save the changes is displayed.).
3. When the closing message is displayed, select [Yes] to quit SerialSelect Utility and restart the system by pressing any key. The changes made in SerialSelect Utility are enabled after the system is restarted.

PHY Configuration

The following screen is displayed when ‘PHY Configuration’ is selected in the menu.

SAS Device Configuration

SAS Port ID	#0	#1	#2	#3	#4	#5	#6	#7
<hr/>								
PHY Rate (Gb/s)	Auto							
SAS Address ...50030130F0B13700	0	0	0	0	0	0	0	0

<F6> – Reset to Defaults

See the following table for each item

Item	Parameter	Description
PHY Rate	[Auto] 1.5 3.0	Data transfer rate between SAS controller and devices. The initial value is set to [Auto]. SAS card adjusts the rate if necessary.
SAS Address	0-F	Specifies the last digit of a 64-bit SAS address of the SAS controller, device, and each port using a globally unique worldwide name (WWN) identifier.

[]: factory default

1. Press **F6** to return to the initial value.
2. To quit, press **Esc** until you see the closing message (If any changes have been made, the message asking you whether or not to save the changes is displayed.).
3. When the closing message is displayed, select [Yes] to quit SerialSelect Utility and restart the system by pressing any key. The changes made in SerialSelect Utility are enabled after the system is restarted.

Disk Utilities

The following screen is displayed when “Disk Utilities” is selected in the menu.

Scanning for drives...

The following screen is displayed after a while.

Adaptec SAS/SATA Controller#0

Select SAS/SATA Disk and press <Enter>

Device	Box	Slot	Model	FW Rev
#0	FF	FF	HITACHI	A340
#1	00	FF	No device	
#2	00	FF	No device	
#3	00	FF	No device	
#4	00	FF	No device	
#5	00	FF	No device	
#6	00	FF	No device	
#7	00	FF	No device	
#8	00	FF	No device	
#9	00	FF	No device	
#10	00	FF	No device	
#11	00	FF	No device	
#12	00	FF	No device	
#13	00	FF	No device	
#14	00	FF	No device	
#15	00	FF	No device	

Drive with + sign is Bootable
Use Page Up or Page Down keys to move to next page

Select an item using the UP and DOWN ARROW keys and press **Enter**. The following menu will appear.

Adaptec SAS/SATA Controller#0

Select SAS/SATA Disk and press <Enter>

Device	Box	Slot	Model	FW Rev
#0	FF	FF	HITACHI HUS151436VLS300	A340
#1	00	FF	No device	
#2	00	FF	No device	
#3	00	FF	No device	
#4	00	FF	No device	
#5	00	FF	No device	

Format Disk
 Verify Disk Media
 Indicate LED
 Write Cache Setting
 Connection Rate
 Set Bootable

FF	No device
FF	No device

Drive with + sign is Bootable
 Use Page Up or Page Down keys to move to next page

See the following table for each item.

Item	Parameter	Description
Format Disk	—	Low-level format is simulated by writing entire disk to zero. TIPS: Low-level format is performed to the disk drive at factory. You do not need to perform low-level format again.
Verify Disk Media	—	IMPORTANT: All the data on the disk is deleted. Back up your data before performing this operation.
Indicate LED	—	Check for errors by scanning the disk drive media Flash the LED on the selected disk drive.
Write Cache Setting	Enabled [Disabled]	Enable/Disable Write Cache.
Connection Rate	[Auto] 1.5Gb/s 3.0Gb/s	The data transfer rate of disk drive. The initial value is set to [Auto]. You do not need to change it.
Set Bootable	Enabled [Disabled]	Set the disk drive to the bootable disk drive. You do not need to change it.

[]: factory default


FORCED SHUTDOWN AND CLEAR

Read this section if your server does not operate as expected, or if you want to return all setup values to those made at shipment.

Forced Shutdown

Use this function when an OS command does not shut down the server, the POWER switch does not turn off the server, or resetting does not work.

Press and hold the POWER switch on the primary server for over 4 seconds. The power is forcibly turned off. To turn on the power back again, wait approximately 30 seconds after the forced shutdown.



Press it for over 4 seconds.

CLEAR CMOS/PASSWORD

With the pre-installed SETUP utility, you can set desired passwords to protect data stored on the server from unauthorized user access. If you forget the password, you can clear them by following the procedure described in this section.

You can also use the same procedure to clear the CMOS data in the server.


IMPORTANT:

- Clearing the CMOS data restores the factory settings.
- To clear the password or CMOS data, power off the server.

To clear the password or the CMOS data, use configuration jumper pins (jumper switches) located inside of the server. The jumper switches are found on the motherboard in a CPU/IO module. See the figure below.

IMPORTANT:

Do not change any other jumper switch settings. Any improper change may cause the server to fail or malfunction.



- Pins for protecting/clearing the password
Short-circuiting the two pins: Clears the password
Opening the two pins: Protects the password (factory preset)
- Pins for protecting/clearing the CMOS data
Short-circuiting the two pins: Clears the CMS data
Opening two pins: Protects the CMOS data (factory preset)
- Pins for protecting/clearing the BMC configuration
Short-circuiting the two pins: Clears the BMC configuration
Opening two pins: Protects the BMC configuration (factory preset)

The following describe the clearing procedure.

	WARNING
	<p>Observe the following instructions to use the server safely. There are risks of death or serious personal injury. See “PRECAUTIONS FOR SAFETY” in Chapter 1.</p> <ul style="list-style-type: none">■ Do not disassemble, repair, or alter the server.

How to Clear CMOS

1. Power off the NEC Express5800/ft series and unplug the both power cords.
2. Remove the both CPU/IO modules (0 and 1) from the NEC Express5800/ft series (see “Removing CPU/IO Module” on page 8-11).
3. Make setting of jumper switch for clearing CMOS of CPU/IO module 0.
Remove the clips from the jumper pins (J57) 2-3 and place them on the jumper pins (J20) 9-10 on the CPU/IO Module 0.
4. Connect only the power cord of the CPU/IO module 0 and press the POWER switch to power on.
5. When POST is completed after the startup, press the POWER switch to power off, and then disconnect the power cord from the outlet.

- 6.** By referring to “Removing CPU/IO Module” on page 8-11, remove the CPU/IO module 0 from the server.
- 7.** Restore the previous CMOS clear jumper switch settings. Remove the jumper pins (J20) 9-10 of the CPU/IO module 0 and install them on the jumper pins (J57) 2-3.
- 8.** By referring to “Installing CPU/IO Module” on page 8-14, install the CPU/IO module 0 on the server.
- 9.** Reconnect only the power cord of the CPU/IO module 0 and press the POWER switch to power on.
- 10.** After the startup, press the **F2** key during POST to start BIOS SETUP.
- 11.** Make settings in SETUP as you desire and then save the settings by selecting “Exit”→ “Exit Saving Changes.” Switch the power off and disconnect the power cord from the outlet.
- 12.** Clear CMOS for the CPU/IO module 1 by following the steps 3 to 12.
- 13.** By referring to “Installing CPU/IO Module” on page 8-14, connect both CPU/IO modules to the device.
- 14.** Connect both power cords.

How to Clear Passwords

1. Power off NEC Express5800/ft series and unplug the both power cords.
2. Remove the both CPU/IO modules (0 and 1) from the NEC Express5800/ft series (see “Removing CPU/IO Module” on page 8-11).
3. Make setting of jumper switch for clearing the password of CPU/IO module 0.
Remove the clips from the jumper pins (J57) 2-3 on CPU/IO module 0 and place them on the jumper pins (J20) 7-8 on the CPU/IO module 0.
4. Mount the CPU/IO module 0 to NEC Express5800/ft series (see “Installing CPU/IO Module” on page 8-14).
5. Connect the power cord of CPU/IO module 0 only, and then press the POWER switch to power on.
6. When POST is completed after the startup, press the POWER switch to power off, and then disconnect the power cord from the outlet.
7. By referring to “Removing CPU/IO Module” on page 8-11, remove the CPU/IO module 0 from the server.
8. Reset the jumper switch setting.
Remove the clips from the jumper pins (J20) 7-8 and place them on the jumper pins (J57) 2-3 on the CPU/IO module 0.
9. Clear password for the CPU/IO module 1 by following the steps 3 to 8.
10. By referring to “Installing CPU/IO Module” on page 8-14, install both CPU/IO modules on the server.
11. Connect both power cords.

How to Clear THE BMC configuration

1. Power off NEC Express5800/ft series and unplug the both power cords.
2. Remove the both CPU/IO modules (0 and 1) from the NEC Express5800/ft series (see “Removing CPU/IO Module” on page 8-11).
3. Make setting of jumper switch for clearing the BMC configuration of module 0.
Remove the clips from the jumper pins (J57) 2-3 on CPU/IO module 0 and place them on the jumper pins (J20) 7-8 on the CPU/IO module 0.
4. Mount the CPU/IO module 0 to NEC Express5800/ft series (see “Installing CPU/IO Module” on page 8-14).
5. Connect the power cord of CPU/IO module 0 only, and then press the POWER switch to power on.
6. When POST is completed after the startup, press the POWER switch to power off, and then disconnect the power cord from the outlet.
7. By referring to “Removing CPU/IO Module” on page 8-11, remove the CPU/IO module 0 from the server.
8. Reset the jumper switch setting.
Remove the clips from the jumper pins (J20) 7-8 and place them on the jumper pins (J57) 2-3 on the CPU/IO module 0.
9. Clear password for the CPU/IO module 1 by following the steps 3 to 8.
10. By referring to “Installing CPU/IO Module” on page 8-14, install both CPU/IO modules on the server.
11. Connect both power cords.

REMOTE MANAGEMENT FUNCTION

320Fd-LR and 320Fd-MR models are equipped with the optional card, N8815-006A ft Remote Management Card on the server. By connecting to a network via their management LAN port, BMC (Baseboard Management Controller), an LSI for system management, installed on the server allows remote monitoring and controlling of the server such as keyboard, video and mouse (KVM) control over management network.

Network Default Values

The following are default values to connect the server to a network.

IP Address	: 192.168.1.1
User Name	: administrator
Password	: (None)
Host Name	: ARMCXXXXXXXXXXXXXX

- The host name above is the host name used for auto registering with a DNS server using DHCP functions. XXXXXXXXXXXXX is the MAC address assigned to each management card. The MAC address can be found on the label attached to the rear of the card or [Server] – [System Management] – [CRU0 BMC MAC Address]/[CRU1 BMC MAC Address] on the BIOS Set UP screen.

IMPORTANT:

- The communication mode on the management LAN board is fixed as auto negotiation mode; it cannot be changed manually. At the same time, set the communication on the link partner side as auto negotiation mode.
 - The default IP address of the management LAN is 192.168.1.1 for both CPU/IO module #0 and CPU/IO module #1. Therefore, the servers are unable to connect network simultaneously without changing this IP address. In order to enable the network connections simultaneously, specify different IP address for each CPU/IO module.
 - To ensure security, change values for host name, password and IP address according to your network environment.
-

Settings on the Server

The following describes the setting procedure.

CHECK:

The resolution and refresh rate of the screen that can be displayed on a remote KVM console are 1024x768, 75Hz and smaller respectively. If values larger than these are set, the remote screen does not display any data. If a great value is set for the number of colors on the screen for the server, the remote may not show colors accurately. Connecting this card to a network where broadcast occurs frequently may affect remote control performance.

Initial Settings on the Server

1. If information specific to the server has not been written in, the following message informing you that the server-specific information is not written is displayed while the NEC logo is displayed, and the startup processing of the server is paused.

If this message is not displayed, the remote management function does not need to be initialized. If it is displayed, the remote management function needs to be initialized in order to monitor devices into details.

H/W Configuration of BMC is corrupted.

- !! Update BMC H/W Configuration by configuration tool !!
- !! Refer to BMC configuration manual !!

The message above may appear in a different screen during POST with the NEC logo shown and paused. In that case, press the **Esc** key to display the diagnosis screen to check whether or not the above message is shown. If a different error message is shown, refer to Chapter 7 “Troubleshooting.”

2. How to make initial settings

Either wait for a while after the above message is shown or press the **F1** key to precede POST. Start up the “NEC EXPRESSBUILDER”DVD and select “initialize RNEStc Management Card” from the Tool menu. By doing so, information specific to each server will be written in.

When writing the information is completed, the following message appears. Press any key to reboot the server for use.

Programming complete, reboot server for normal operation.

Strike a key when ready...

TIPS:

Running the initialize Remote Management Card resets the AC LINK setting (Server-AC LINK) of the BIOS setup to the initial value “Last State.” If you have changed the value, you will need to set it again.

Setting a Management PC

The following provides management PC considerations to connect the server and a management PC.

Setting Your Browser

Configure the following.

- Enable SSL.

Supported browsers

The following browsers are supported.

- Microsoft Internet Explorer 6.0, 7.0
- Netscape 7.0
- Mozilla 1.6

Java2 Runtime Environment

Java2 Runtime Environment, Standard Edition 1.4.2_16 and later, or Java Runtime Environment (JRE) 5.0 Update 15 and later are required.

Install by downloading the installer from the following site:

<http://java.sun.com/j2se>

- When the OS of the management PC is Windows:
Execute the downloaded installer and follow the steps displayed.
- When the OS of the management PC is Linux:
Execute the downloaded installer and install the following step.

Install .by logging in as the root user or obtain the root authority with the su command.

- (1) Copy the JRE installer to any directory. Below is an example of copying the installer from the NEC EXPRESSBUILDER to /user/local/bin:

```
cp /mnt/cdrom/dianascope/jre_xj2re-1_4_2_09-linux-i586.rpm.bin/usr/  
local/bin
```

- (2) Go to the directory where you copied the JRE installer. Below is an example that the installer was copied to /user/local/bin:

```
cd /user/local/bin
```

- (3) Extract the JRE installer.

```
./j2re-1_4_2_09-linux-i586.rpm.bin
```

- (4) Install JRE. JRE will be installed in the directory of each JRE version under /usr/java.
rpm -ivh ./j2re-1_4_2_09-linux-i586.rpm

- (5) Add an environment variable "JAVA_HOME." Enter the directory name that you

4-52 System Configuration

installed JRE.

For bash:

```
export JAVA_HOME=/usr/java/j2re1.4.2_09
```

For tesh:

```
setenv JAVA_HOME=/usr/java/j2re1.4.2_09
```

(6) Set the path to JRE.

For bash:

```
export PATH=$JAVA_HOME/bin:$PATH
```

For tesh:

```
setenv PATH $JAVA_HOME/bin:$PATH
```

IMPORTANT:

For the Mozilla browser, create a symbolic link to the Java Plug-in in the Mozilla plugins directory.

* If you want to install the latest Java Runtime, download it from the following site. If you use NEC DianaScope on the same management PC, use Java2 Runtime Environment, which you can find in the “NEC EXPRESSBUILDER” DVD.

<http://java.sun.com/j2se/>

If you access the logon page without installing Java2 Runtime Environment, the following message may appear. Check the message and perform installation.



Using Remote Management

Overview

You can control power of this server and use the remote KVM console from a web browser by using web server functions of BMC.

IMPORTANT:

Remote KVM console is available only on the LAN port of the primary CPU/IO module (the operating side's CPU/IO module). This is not available on the LAN port of the secondary CPU/IO module (the waiting side's CPU/IO module).

This function is achieved by Java Applet.

How to get connected

From a Web browser on the management PC, access the following URL.
URL: http://BMC_HostPort/index.htm

TIPS:

“BMC_HostPort” is a BMC IP address or host name followed by a colon and http port number. If the http port number is 80 (the default value), you can omit the port number.

When connecting to network which supports DHCP protocol:

The default host name of BMC is ARMC characters followed by the MAC address if you use DHCP functions and automatically register it with your DNS server.

IP Address	: 192.168.1.1
User Name	: administrator
Password	: (None)
Host Name	: ARMCXXXXXXXXXXXX

Default host


When connecting to network which does not support DHCP protocol:

- (1) The default IP address of the LAN of the managed server is “192.168.1.1” for both CPU/IP module #0 and #1. If you want to access the network that does not support DHCP protocol, access the network that the default IP address can use, and then set the IP address according to your network environment from the managing PC (see “BMC Configuration”).

- If you cannot use the default IP “192.168.1.1”, start up the “NEC EXPRESSBUILDER” DVD on the server and select [Tool menu] → [English] → [System Management] → [Set System Management Parameters] → [Configuration]. Select [New] to register new settings, or [Change] to change the settings. Then, set IP addresses of the managed LAN ports on the [BMC Configuration] menu.

LAN1: CPU/IO Module#0 management LAN port


LAN2: CPU/IO Module#1 management LAN port



The following is a configuration screen for LAN1 (CPU/IO module #0). Specify an IP address to use. Make settings for LAN2 (CPU/IO module #1) in the same manner.

For the settings to take effect, you need to execute [OK] on the previous menu, “BMC Configuration” window.

Specify different IP addresses to LAN1 (CPU/IO module #0) and LAN2 (CPU/IO module #1).




TIPS:

To disable the remote management console function, make the following settings from the NEC EXPRESSBUILDER DVD. Load the NEC EXPRESSBUILDER DVD on the server, and from the main menu, select [Tool menu] - [English] - [System Management] - [Set FT Remote Management Card].- [Set FT Remote Management Card (LAN1/LAN2)]. Select [Disable] on [Remote Management Console] and register the setting. “Obtain an IP address automatically (DHCP)” “HostName” “DomainName” and “IP Address” are display only. The image below shows the setting screen for LAN1 (CPU/IO module #0).



If you use remote management for the first time, the “Warning - Security” dialog box as shown below may be displayed. Check the message, and then click [Yes], or [Always]. Then you will see the logon page. If you are not sure, click [No].



TIPS:

If you use SSL for access, the “Warning - Security” dialogue box(es) for server certification may be displayed for SSL in addition to the dialogue box shown above.

Login and logout

Login

When the login page appears, enter the user name and password, and then click [Login].

When you login for the first time, use the following default user name and password.

Default user name: administrator

Default password: None (enter no data)


IMPORTANT:

By default, no password is set. Set your password immediately after logging on.

For security, it is recommended to change the default user name as well.

For information on settings and modification, see “BMC Configuration” described later.

When the password is authenticated, the following end user license agreement is displayed.



Read the agreement carefully.

If you can agree, click [Yes], and you can start using remote management functions.

If you cannot agree, click [No]. You cannot use remote management functions.


TIPS:

If you click [Yes], you do not see this message again because the data will be stored on the management PC.

Logout

Click the File menu and select Exit to logout. When you log out, the main window closes and you will return to the login page on the browser.

Main Window




- (1) Click this to show the File menu.
Click "Exit" to quit this applet.
- (2) Click this to show the Window menu.
From the Window menu, you can open windows including the KVM console window.
- (3) Main frame
A window is shown here.
- (4) Click this to show the Help menu.
Click "Help" to see the version information of this applet.

Control panel

The control panel allows you to see the server status and to control the power supply.

The control panel also allows you to activate windows.

Control panel functions



- (1) Displays the BMC host name or IP address
- (2) Displays the LCD of the server.
- (3) The power lamp of the server telling you of the power status
- (4) The same as pressing the POWER switch of the server. Note that the forced power off, pressing the power button for 4 seconds and more, is not supported.
- (5) Performs memory dump on the server (the same as pressing the DUMP switch of the server).
- (6) Makes the Unit ID lamp of the server blink
- (7) Starts up the remote KVM console.
- (8) Starts up the BMC configuration.
- (9) Starts up the firmware update.
- (10) A user name is displayed here.
- (11) Displays the connectivity with BMC.
- (12) Displays communication security status
- (13) Displays network access status
- (14) Opens the window showing system event logs (SEL).
- (15) Opens the window showing the sensor device information (SDR).
- (16) Opens the window showing the information on parts to be replaced for maintenance (FRU).
- (17) Displays the slot position information (module #0 or module #1)
- (18) Displays the slot status (primary or secondary).
- (19) Hides the control panel

Remote KVM Console

Remote KVM console functions of the BMC allow you to transfer a local console to the browser on the management PC over a network.

You can make full access to the server from the management PC using video, keyboard and mouse.

CHECK:

- The remote KVM console supports the following five resolutions:
 - 1024 x 768
 - 800 x 600
 - 640 x 480
 - 720 x 400
 - 720 x 350
 - Set the resolution of the device to one of these values. If any value other than these values, nothing will be shown on the remote KVM console.
 - The mouse cannot be used on the remote KVM console on the operation window of NEC EXPRESSBUILDER.
-

TIPS:

KVM is an acronym for keyboard, video and mouse.

The remote KVM control is different from those using a serial console remotely in that it allows you using graphics directly and remotely.

CHECK:

You cannot use the remote KVM remote control for connection via proxy.

When you use the remote KVM console logon with the settings where no proxy is used.

Starting up the remote KVM console window

Click the startup icon [] on the remote KVM console on the control panel to display the KVM console window.




IMPORTANT:

NEVER open the remote KVM console when you log on to the BMC from a local console. If you do so, data entry from the keyboard or mouse becomes disabled.

CHECK:

You cannot use the KVM console on the secondary side. Use it on the primary side.

Items on the remote KVM console window



- (1), (2) and (3) are special icons. Use them when you want to operate special keys.
- (4) Virtual keyboard icon: use this icon when you want to enter a special key other than those mentioned above.
- (5) Screen refresh icon: use this icon to refresh the window.

- (6) KVM properties icon.
- (7) Enlarge icon: use this icon to enlarge the view.
- (8) Shrink icon: use this icon to reduce the view.
- (9) Equal size icon: use this icon to display images in the same magnification.
- (10) Window size icon: use this icon to adjust the window size to the screen size.
- (11) KVM indicator showing information including resolution.
- (12) Remote KVM console screen, on which the server screen is shown.

IMPORTANT:

When you operate **Shift + Caps Lock** or **Num Lock** on the remote KVM console window, such action may not be reflected in the **Shift + Caps Lock** or **Num Lock** status of the management PC LED. Likewise, on the server, the Caps Lock or Num Lock status may become different from LED status after the remote KVM console is used. If this happens, press the key(s) on the device in issue so that LED status and actual operation match.

Operating special keys

Operation of special keys from the keyboard of the management PC is not reflected in the server. Click the following special key icons for operation on the host server.



(raised)



(pressed): the status change every time you click the icon.



(raised)



(pressed): the status change every time you click the icon.

IMPORTANT:

For example, if you want to enter “**Ctrl + Alt + Del**,” click the [Ctrl] and [Alt] icons and then press the **Del** key on the keyboard. By doing so “**Ctrl + Alt + Del**” is sent to the server. After the operation, click the [Ctrl] and [Alt] icons to cancel the special key operation.



(Windows key icon)

Virtual keyboard

When you click the virtual keyboard icon [], the virtual keyboard appears.



You can select either 104 or 109 keyboard from the tab. By clicking buttons corresponding to each key, you can make entry to the host server.

Zoom-in and zoom-out of the view

Click the [] icon to zoom in the view.

Click the [] icon to zoom out the view.

Click the [] icon to display the screen in the same size as the device.

Click the window resize icon [] to adjust the remote KVM console window size to the remote screen size.

Refreshing the screen

Click the screen refresh icon [] to refresh the remote KVM console screen. If the screen is distorted, refresh the screen.

Modifying properties

When you click the KVM properties icon [], the KVM properties window appears, in which you can specify an interval between screen refreshes.

IMPORTANT:

A shorter interval will reduce garbage remaining on the screen. However, note that a shorter interval can slow down the terminal response speed or impact network traffic.

IPMI information


System event logs (SEL), sensor data record (SDR), or field replacement unit (FRU) can be displayed. Such information is referred to as the IPMI information. The information is used to examine errors and events on the server and identify which part should be replaced.

System Event Log (SEL)



When you click the icon to start up system event logs [] on the control panel, SEL information is collected from the BMC and shown on the system event log (SEL) window as shown below.

The upper pane shows a list of system event logs while the lower pane shows details of the entry selected in the list.



By clicking the reloading icon [], you can reload the SEL information from the BMC and display the latest information.

Clearing the SEL information

Do not use this function, as the system executes the automatic SEL clear.

Sensor Data Record (SDR)



When you click the icon to start up sensor device information (SDR) [] on the control panel, the SDR information is collected from the BMC and shown on the sensor device information (SDR) window as shown below.

The SDR window displays a table of sensor records and a detailed dump for the selected record (1h).

Record ID	Sensor Type	Owner
1h	Voltage(Processor 1 VCCP)	Basbrd Mgmt Ctr
2h	Voltage(Processor 2 VCCP)	Basbrd Mgmt Ctr
3h	Voltage(Baseboard 3.3V)	Basbrd Mgmt Ctr
4h	Voltage(Baseboard 3.3VSB)	Basbrd Mgmt Ctr
5h	Voltage(Baseboard 5V)	Basbrd Mgmt Ctr
6h	Voltage(Baseboard 5VSB)	Basbrd Mgmt Ctr
7h	Voltage(Baseboard 12V)	Basbrd Mgmt Ctr
8h	Voltage(Baseboard VBAT)	Basbrd Mgmt Ctr

```

[Record ID ] 1h
[Sensor Type ] Voltage(Processor 1 VCCP)
[Entity ] Processor1
[Owner ] Basbrd Mgmt Ctr
[Upper non-recoverable Threshold ] ---
[Upper critical Threshold ] 1.64Volts (Hysteresis: 1.63Volts)
[Upper non-critical Threshold ] 1.56Volts (Hysteresis: 1.55Volts)
[Lower non-critical Threshold ] 1.15Volts (Hysteresis: 1.16Volts)
[Lower critical Threshold ] 1.06Volts (Hysteresis: 1.07Volts)
[Lower non-recoverable Threshold ] ---
[Dump ]
01 00 51 01 38 20 00 10 03 01 7F E9 02 01 85 32
85 32 1B 1B 00 04 00 00 EB 42 07 01 00 B4 07 82
B0 5B FF 00 00 BF 80 00 49 5B 02 02 00 00 00 D0
50 72 6F 63 65 73 73 6F 72 20 31 20 56 43 43 50
  
```

The upper pane shows a list while the lower pane shows details of the entry selected in the list.

TIPS:


SDR information is definition data on device sensors.

The BMC monitors sensors according to this information.

Field Replaceable Unit (FRU)



When you click the icon to start up information on parts to be replaced for maintenance (FRU) [] on the control panel, FRU information is collected from the BMC and shown on the window for parts to be replaced for maintenance (FRU) as shown below.



The upper pane shows a list while the lower pane shows details of the entry selected in the list.


BMC Configuration

You can configure the BMC settings.

Starting up the BMC Configuration window



When you click the icon in the BMC configuration [] on Control Panel, the BMC configuration window appears as shown below.



- (1) Reads the BMC configuration file
- (2) Saves the BMC configuration file
- (3) Edits the BMC configuration
- (4) Reloads the BMC configuration
- (5) Sets the data loaded from the file to the BMC in a batch
- (6) Lets you select what to be configured
- (7) Shows the overall information on the current values

TIPS:


When you load configuration from the file, choose to make settings of the BMC in a batch.

User Settings

Here you can make user account settings.

When you click [User] on the left pane of the BMC configuration window, total of 20 accounts appear in the right pane.

When you select the account you want to modify or add and click the icon for editing [], the following window for editing a user account appears.



The image shows a 'User Settings' dialog box with a title bar containing a close button and the text 'User Settings'. The dialog has a tab labeled 'User'. It contains the following fields and controls:

- A 'No.' field with the value '1'.
- A 'User_name:' text input field, indicated by a line and the number '1'.
- A 'P_assword:' text input field, indicated by a line and the number '2'.
- A 'P_assword(Confirm):' text input field, indicated by a line and the number '3'.
- A 'KVM Privilege' section containing a checked checkbox labeled 'Remote KVM Console Enable'.
- 'OK' and 'Cancel' buttons at the bottom right.

- (1) Enter the user name.
- (2) Enter the password.
- (3) You can specify whether or not to enable the remote KVM console. Select the check box if you want to enable it.

When you click [OK], all the information you have edited will be written into the BMC.
When you click [Cancel], the window closes without saving what you have edited.

Network Settings

Here you can make network settings of BMC such as IP address configuration.


IMPORTANT:

- The following ports are used for the remote management functions. If your network environment has any firewall, you also need to have configuration for the firewall.

Module name	Port number	Protocol	Direction	Module name	Port number
Remote KVM client	Not determined	UDP	← →	BMC	623
Mail server	25(*1)	TCP	← →	BMC	Not determined
WEB client	Not determined	TCP	← →	BMC	80(*2)
WEB client (SSL)	Not determined	TCP	← →	BMC	443(*3)


- *1: Can be modified by selecting [BMC Settings] - [Alert Mail] - [E-Mail Alert Settings] - [SMTP] - [SMTP Port Number].
- *2: Can be modified by selecting [BMC Settings] - [WEB Server] - [WEB Server Settings] - [HTTP Port Number].
- *3: Can be modified by selecting [BMC Settings] - [WEB Server] - [WEB Server Settings] - [SSL Port Number].

When you click [Network] on the left pane of the BMC configuration window, the right pane shows the overall information of the network settings as shown below.



When you click the icon for editing [], the following window for editing appears. The window for network settings has three tabs.

LAN




- (1) The MAC address of the BMC
- (2) Allows you to choose whether or not to acquire an IP address automatically by DHCP.
- (3) Allows you make the IP address settings if the address is not acquired automatically by DHCP. If the address is acquired automatically by DHCP, the data acquired is shown here.

IMPORTANT:


- Specify different IP addresses to CPU/IO module #0 and CPU/IO module #1.
- If you change the IP address, the current connection will be disconnected when the BMC settings are completed by clicking OK. Close the window once, and then log on again by entering the newly set IP address (or host name) in the browser.
- The logon page remaining on the browser is the page you accessed by using the old address. You cannot use it to log on.
- When you configure “default gateway,” the gateway, the server, the management PC should be in a state where communication over network is available.
- If you make the settings in a state where communication is not available, you need to switch on/off the AC of the server in a state where the gateway, the server and the management PC can be communicated over the network.
- After you changed the DHCP setting, you should turn off the AC power of the system and turn on it after 5 seconds or more.
- After you changed the DHCP setting using NEC EXPRESSBUILDER and NEC DianaScope Agent, you should turn off the AC power of the system and turn on it after 5 seconds or more..

DNS



- (1) Allows you to select whether or not to automatically acquire the IP address of the DNS server by DHCP.
- (2) If you have selected not to automatically acquire the IP address by DHCP, make settings here. If the address is acquired automatically by DHCP, the acquired address appears here.

Host name



- (1) The default host name to be used when no host name is set when DHCP is used
- (2) Set the BMC host name. If this option is not configured, the default host name mentioned in 1) will be used.
- (3) Set the domain name of the network to which the BMC belongs.
- (4) Choose whether or not to register the host name with the DNS server.

TIPS:

It is recommended to set the BMC host name to be easily guessed from the server's host name on the OS.

For example, you may set the BMC host name as “sapphire_bmc” if the server's host name on the OS is “sapphire.”

IMPORTANT:


Specify different host names to CPU/IO module #0 and CPU/IO module #1.

When you click [OK], all of what you have set in the three tabs will be written into the BMC. When you click [Cancel], the editing window closes without saving what you have edited.

WEB server settings

Here you can make web server settings such as HTTP port settings for the BMC.


When you click [Web Server] on the left pane of the BMC configuration window, the right pane shows the overall information of the web server settings.



IMPORTANT:

- When you change the HTTP port number, settings of SSL (enable/disable), or SSL port number, the current connection will be temporarily disconnected. Close the window and exit, and then log on again by entering the newly set port number in the browser.
- The logon page remaining on the browser is the page you accessed by using old web server settings. You cannot use it to log on.

When you click the icon for editing [], the window for editing appears as shown below.



- (1) Specify the HTTP port number.
- (2) Specify whether or not to enable SSL communication. If you select the check box for enabling, connection by HTTPS (SSL enabled) is enabled. Clear the check box if you want to disable SSL.

TIPS:

It is recommended to use connection by the encrypted HTTPS protocol unless you have any specific reason such as SSL cannot be used. This option is disabled by default.

- (3) Specify the SSL port number.
- (4) Specify the logon trial period during which you can try logging on again if you have failed to log on.
- (5) Specify the number of logon retries. If the number of retries exceeds the number specified here during the period specified in (4), logon retries will be rejected for the time period specified in (6).
- (6) Specify the time period during which logon is rejected.

TIPS:

Although the three entries mentioned above are effective in blocking automatic and unauthorized logins, they do not completely block such logins.

If you click [Default], the default values for HTTP port number, SSL port number, logon trial period, number of logon retries and the account lock period are displayed. The SSL check box configuration remains the same.


When you click [OK], all of what you have set will be written into the BMC.

When you click [Cancel], the editing window closes without saving what you have edited.


Alert Mail Configuration

This allows you to make alert mail settings for BMC.

When you click [Alert Mail] on the left pane of the BMC configuration window, the right pane shows the summary of the alert mail settings.



When you click the icon for editing [], the window for editing appears as shown in the next page. The window for editing has four tabs: basic, message, SMTP and option. The following describes each tab in detail.

Basic

- (1) Specify whether or not to enable the alert mail functions by the check box. When you select the check box, you can make mail-related settings.
- (2) Select a notice level from six levels. Levels are categorized according to severity of factor events.
- (3) Allows you to send a test mail.

IMPORTANT:

Perform the mail test after you have completely configured “E-Mail Alert Settings” described in the following pages.

Making entries in the editing window does not complete settings. You need to click [OK] after entering all the required information to complete the BMC settings.

TIPS:


The X-Priority: field in the mail header changes according to the severity of factoring event.

Non-recoverable/Critical X-Priority: 1

Non-critical X-Priority: 3

OK/Information/Monitoring X-Priority: 5

Message



- (1) Specify mail address of receivers to whom alert mail is sent. You can specify up to four addresses.
- (2) Specify the sender's address used in alert mail.
- (3) Enter the subject to be given to alert mail.
- (4) Select whether or not to enable the body messages for all alert mail, which is configured in the next step.
- (5) Enter the body message to be used in all alert mail. If you do not need such a body message, clear the check box of (4). If you click [Get Default Message], the recommended message appears.

TIPS:

The subject and message you configure here will be used in all alert mails.

SMTP




- (1) Specify the address of the SMTP server. You can enter the IP address or host name.
- (2) Specify the port number of the SMTP server.
- (3) Specify the number of send retry if sending a mail has failed.
- (4) Specify the time in seconds before the next mail send retry.

If you click [Default], the default values for SMTP port number, number of retries, and retry interval appears. It is recommended to use the default values unless you have specific reasons.

IMPORTANT:

This card does not support SMTP authentication (SMTP-AUTH).

Option

- (1) Specify information to add to the body of alert mail.

The information you specify here will be contained in the body of alert mail with the message you specified in the message box in the message tab.

Product Information	Product name, code, number of the server
IP Address	IP address of the BMC
Event Time	Time that the event occurred
SEL Dump Data	Data representing system event logs (SEL) in the hexadecimal format
BMC URL	URL of the ARMC logon page
BMC FQDN	Full domain name of the BMC
LCD Message	LDC message on the server at the time of event occurrence
BMC FW Rev.	Revision information of the BMC firmware/SDR/PIA

- (2) Used in the date filed of the mail header of alert mail.


Firmware Update

You can update applets, KVM firmware, BMC firmware, sensor device information (SDR), and platform information (PIA).

Starting up the firmware update window



When you click the icon to start up firmware update [] on the control panel, each piece of revision information is loaded from the BMC to display the following firmware update window.




If you click [Cancel], the firmware update window closes without making any changes.

The following pages provide step-by-step instructions for update.

Loading update data files

When you click the icon for adding update files [], the window to select a file appears.



Specify an update data file.

When you click [Open] after specifying the file, loading of the file begins.

Wait for file loading to complete.

TIPS:

You can update in a batch.

If there are more than one update targets, all the information of the update targets must be loaded. You can select more than one file to be loaded at the same time.

Confirming revision

When loading data files completes, information on current revisions, loaded revisions and file data (file names and time stamps) appears on the window.

Check the information carefully.


Target	Current Revision	New Revision	Update Status	File name	Timestamp
BMC firmware	00.08	0f.21	<input type="checkbox"/>	ABMCFW.bhx	Jul 9, 2004 2:55:33 PM
Platform Information (PIA)	01.10	01.01	<input type="checkbox"/>	PIA0101.hex	Jul 9, 2004 2:55:35 PM
Sensor Data Record (SDR)	00.10	----	<input type="checkbox"/>	----	----
Applet	00.11	00.06	<input type="checkbox"/>	gng0006.bin	Jul 9, 2004 2:55:37 PM
KVM firmware	05.2a	03.29	<input type="checkbox"/>	ABMC.RBF	Jul 9, 2004 2:55:31 PM

CHECK:

Check each revision carefully because downgrading is possible as well. If you click the icon for clearing update data [], all loaded data will be discarded. When you click [Cancel], the update window will be closed without saving any loaded data.

Selecting what to be upgraded

Select check boxes of update targets.

**CHECK:**

Only those selected here will be written in.


Items with no check box selected will not be written in even if files have been loaded.

IMPORTANT:

If you update both SDR and PIA, make sure to write in simultaneously. If writing is done twice, the first writing will not take effect.

Writing update data into the BMC

When you click the icon for writing update [], the writing the update data into the BMC begins.




As shown below, the window showing writing process appears for each update target.



If any error is detected during the writing process, an error message is displayed and the process terminates.

End of writing

When writing is completed, the "Status" column displays the result for each target.



CHECK:

- To apply updates for targets other than applet, reboot the server or power off and then on the server.
- When you rebooted or power on the server to apply an update for BMC software, SDR, or PIA, the connection with BMC will be disconnected. Because of this, you need to log in again.
- To apply updates for applets, log out once, close all browsers, and then logon again. You do not need to reboot the server.

Troubleshooting

Error Messages

When using the remote management, an error dialog box may appear on the management PC if some problem occurs. Messages and actions for the errors are described below.

Fatal errors

No.	Error message	Action
1	Fatal error. JavaVM quits.	Try logging in again. If the same message continues to appear, contact your service representative.
2	A fatal software error has occurred.	Try logging in again. If the same message continues to appear, contact your service representative.

Logon error

No.	Error message	Action
1	Authentication error	Check the user name and password, and then enter them again.

Access privilege error

No.	Error message	Action
1	Unauthorized operation. You have no privilege to perform the operation.	Try performing the operation with administrator's privileges. Consult your administrator.

Network errors

No.	Error message	Action
1	The HTTP communication failed.	Check the network environment and try again. Contact your service representative if the error persists. .
2	Could not resolve the IP address.	Check the network environment. You cannot use Remote KVM Console for connections via proxy.
3	Unable to reach the target host.	Check the network environment. You cannot use Remote KVM Console for connections via proxy.
4	The HTTP communication failed.	Check the network environment and try again. Contact your service representative if the error persists. .
5	Failed to download applet.	Check the network environment and try again. Contact your service representative if the error persists.
6	The RMCP+ session is closed.	Check the network environment. If there is no network problem, contact your service

No.	Error message	Action
7	Failed to establish the RMCP+ session.	representative. Check the network environment. If there is no network problem, contact your service representative.
8	The RMCP+ transmission failed.	Check the network environment. If there is no network problem, contact your service representative.
9	The specified RMCP+ protocol cannot be used.	Check the network environment. If there is no network problem, contact your service representative.
10	BMC resources to establish a new RMCP+ session are insufficient.	Try again after a connection from other client is finished.
11	The RMCP+ session time-out occurred.	Check the network environment and server. If you do not find any problem, contact your service representative.

BMC-related error

No.	Error message	Action
1	The IPMI request was aborted.	The network may be busy. Try again. If the error persists, contact your service representative because a failure may have occurred in BMC.
2	Received bad response from BMC.	Check the server. A failure may have occurred in BMC. If you do not find any problem, contact your service representative.
3	BMC does not support IPMI 2.0 functions.	Contact your service representative.
4	Failed to run the IPMI command.	Check the server. A failure may have occurred in BMC. If you do not find any problem, contact your service representative.
5	Failed to send the IPMI message.	Check the network environment. If the network has no problem, contact your service representative.
6	Illegal IPMI message was requested.	Contact your service representative.
7	Specified target is not present.	Check the server. A failure may have occurred in BMC. If you do not find any problem, contact your service representative.

Errors on the Remote KVM Console

No.	Error message	Action
1	Failed to disable Remote KVM Console.	Check the network environment and try again. Contact your service representative if the error persists.
2	Failed to enable Remote KVM Console.	Check the network environment and try again. Contact your service representative if the error persists.
3	KVM packet transmission failed.	Check the network environment and server.

No.	Error message	Action
		If you do not find any problem, contact your service representative.
4	The KVM request was aborted.	This is no problem. Click [OK] and close the message box.
5	UDP packet transmission failed.	Check the network environment and server. If you do not find any problem, contact your service representative.
6	Remote KVM console can not activate because it is disabled	Refer to page 4-68 and enable remote KVM console.
7	Remote KVM Console is used by other client.	Try again after the client using Remote KVM Console finishes using.
8	Failed to shut down Remote KVM Console.	Use Remote KVM Console after waiting 3 or more minutes.
9	Failed to make settings.	Check the network environment and try again. Contact your service representative if the error persists. .
10	The UDP connection is closed.	Check the network environment and server. If you do not find any problem, contact your service representative.

System event log (SEL) display errors

No.	Error message	Action
1	Failed to clear session event logs of BMC.	The network may be busy. Try again. If the error persists, contact your service representative because a failure may have occurred in BMC.
2	Failed to acquire system event logs.	The network may be busy. Try again. If the error persists, contact your service representative because a failure may have occurred in BMC.

Sensor data records (SDR) display error

No.	Error message	Action
1	Failed to acquire sensor data records.	The network may be busy. Try again. If the error persists, contact your service representative because a failure may have occurred in BMC.

Field replaceable (FRU) information display error

No.	Error message	Action
1	Failed to acquire field replaceable units information.	The network may be busy. Try again. If the error persists, contact your service representative because a failure may have occurred in BMC.

BMC configuration errors

No.	Error message	Action
1	Failed to make settings:	Check the network environment and try again. Contact your service representative if the error persists.
2	Failed to acquire BMC Configuration:	Check the network environment and try again. Contact your service representative if the error persists.
3	Used by other software program. Try again after a while.	Try again after a while.
4	Invalid BMC configuration file.	The BMC configuration file may be corrupted. Check the file.
5	The required XML tag is not found.	The BMC configuration file may be corrupted. Check the file.
6	Failed to write the file.	The BMC configuration file is not saved successfully. Change the location to save the file and try again.
7	Invalid user name	You can use only alphanumeric characters, minus sign (-), and underscore (_) for a user name. A user name should be 31 characters or less.
8	The user name is too long	A user name should be 31 characters or less.
9	The password is too long.	Use 16 or less characters.
10	Passwords are not matched.	Enter passwords again.
11	Invalid HTTP port number	You can only use numeric values.
12	Invalid SSL port number	You can only use numeric values.
13	HTTP/SSL should not be the same.	The same port number cannot be specified for HTTP and SSL. Specify different value.
14	Invalid login attempt period	You can only use numeric values.
15	Invalid failed login attempts	You can only use numeric values.
16	Invalid account lock period	You can only use numeric values.
17	Invalid IP address	Use numbers and periods to specify an IP address.
18	Invalid subnet mask	Use numbers and periods to specify a subnet mask.
19	Invalid default gateway	Use numbers and periods to specify a default gateway.
20	Invalid DNS server IP address	Use numbers and periods to specify the IP address of DNS server.

No.	Error message	Action
21	Invalid host name	You can use only alphanumeric characters, minus sign (-), and underscore (_) for a host name. A host name should be 64 characters or less.
22	Invalid domain name	You can use only alphanumeric characters, minus sign (-), underscore (_) and period (.) for a domain name. A domain name should be 128 characters or below.
23	The SMTP server address is too long.	Specify the value within 128 characters.
24	Invalid SMTP port number.	You can only use numeric values.
25	Invalid retry count	You can only use numeric values.
26	Invalid retry interval	You can only use numeric values.
27	"To" is too long.	Specify the value within 128 characters.
28	"From" is too long.	Specify the value within 128 characters.
29	"Subject" is too long.	Specify the value within 256 characters.
30	The message is too long.	The message should be up to 1024 characters.
31	Failed to open the file:	The specified file may not exist. Check the file name.
32	Failed to close the file:	The specified file may be corrupted.
33	Can't open the file:	The specified file may not exist. Check the file name.
34	Timeout has occurred.	Try again. If the error persists, contact your service representative because a failure have occurred in BMC.

Firmware update errors

No.	Error message	Action
1	There are uncompleted update images on BMC as follows:	Reboot the server to complete the update.
2	Failed to acquire status of the update area.	The network may be busy. Try again. If the error persists, contact your service representative because a failure may have occurred in BMC.
3	Update data is too large:	Some update files may be corrupted. Obtain update files again.
4	Failed to prepare update	The network may be busy. Try again. If the error persists, contact your service representative because a failure may have occurred in BMC.
5	Invalid file size:	The update file may be corrupted. Obtain the update file again.
6	Could not find the revision	Some update files may be corrupted. Obtain update

No.	Error message	Action
	information:	files again.
7	Failed to create rollback image.	Try again. If the error persists, contact your service representative because a failure may have occurred in BMC.
8	Failed to erase.	Try again. If the error persists, contact your service representative because a failure may have occurred in BMC.
9	Unsupported format version:	Some update files may be corrupted. Obtain update files again.
10	Failed to load the update image file.	Some update files may be corrupted. Obtain update files again.
11	Update has failed.	Try again. If the error persists, contact your service representative because a failure may have occurred in BMC.
12	Could not switch to the update mode.	Try again. If the error persists, contact your service representative because a failure may have occurred in BMC.
13	Could not find the update targets:	Some update files may be corrupted. Obtain update files again.
14	Invalid address:	Some update files may be corrupted. Obtain update files again.
15	Writing has failed.	Try again. If the error persists, contact your service representative because a failure may have occurred in BMC.
16	Unsupported token is detected:	Some update files may be corrupted. Obtain update files again.
17	Invalid segment information:	Some update files may be corrupted. Obtain update files again.
18	Invalid data length:	Some update files may be corrupted. Obtain update files again.
19	Failed to open the file:	The specified file may not exist. Check the file name.
20	Failed to close the file:	The specified file may be corrupted.
21	Invalid file checksum:	Some update files may be corrupted. Obtain update files again.
22	Failed to parse files.	Some update files may be corrupted. Obtain update files again.
23	Failed to parse files:	Some update files may be corrupted. Obtain update files again.
24	Failed to load files:	Some update files may be corrupted. Obtain update files again.
25	Could not find files:	Some update files may be corrupted. Obtain update files again.
26	Failed to verify	Try again. If the error persists, contact your service representative because a failure may have occurred in BMC.
27	Update will be stopped because interruption has occurred.	Check clients. A software program other than you are using may have interrupted.
28	Online update is now being used.	Try again as necessary after online update performed by other tool is completed.
29	Failed to acquire the current revision.	The network may be busy. Try again. If the error persists, contact your service representative because a failure may have occurred in BMC.

4-90 System Configuration

No.	Error message	Action
30	Failed to acquire lines:	Some update files may be corrupted. Obtain update files again.
31	Invalid line length:	Some update files may be corrupted. Obtain update files again.
32	Unexpected EOF is detected:	Some update files may be corrupted. Obtain update files again.
33	Unexpected token is detected:	Some update files may be corrupted. Obtain update files again.
34	PIA does not suit this server	It is not Platform Information (PIA) of this server. Obtain update files again.

Chapter 5

Installing and Using Utilities


This section describes how to use the NEC EXPRESSBUILDER DVD that comes with your server and to install the utilities stored on the NEC EXPRESSBUILDER. CPU/IO module has a processor function part and IO function part. In utilities in this chapter, the processor function part is referred to as CPU module and IO function part PCI module.

NEC EXPRESSBUILDER

The NEC EXPRESSBUILDER, integrated setup software, can automatically detect the hardware connected to an NEC Express800/ft series machine to advance the processing. The hardware subject to setup with the NEC EXPRESSBUILDER should have the same configuration as that for operation.

Start Menu


When you insert the EXPRESSBUILDER disk into the optical disk drive and reboot the system, the following menu appears.



1. Os installation

IMPORTANT:

Do not choose this option. If you choose this option, the following topmenu of the EXPRESSBUILDER window appears. When this appears, close the window.



2. Tool menu

If you select this item after choosing the display language, the Tool menu appears.



You can use the below functions for maintenance.

- a) Maintenance Utility
Starts up the Offline Maintenance Utility.
- b) BIOS/FW Updating
Updates the system BIOS.
- c) ROM-DOS Startup FD
Creates Startup FD is used for starting the ROM-DOS system.
- d) Test and Diagnostics
Starts up the system test and diagnostics.
- e) System Management
Starts up the system management function.

Autorun Menu

The Master Control Menu automatically appears when the “NEC EXPRESSBUILDER” DVD is loaded on a computer running Windows (Windows XP, Vista or Windows Server 2003 or later).



IMPORTANT:

This function is not available on the server.

NEC ESMPRO Agent and Manager

NEC Express5800/ft series system management applications “NEC ESMPRO Manager” and “NEC ESMPRO Agent” are bundled to the accessory “NEC EXPRESSBUILDER DVD.”

This section describes the functions and features provided by NEC ESMPRO Manager and NEC ESMPRO Agent and the notes on their operations.

These applications are necessary for continuous operation of NEC Express5800/ft series.

Overview

NEC ESMPRO Manager and NEC ESMPRO Agent are the server management software provided for the stable operation of a server system and effective system operations. They can manage the configuration information and operating status of server resources to prevent server faults from occurring. If a server fault occurs, they detect the fault to notify the system Administrator of the occurrence. This enables the system Administrator to take appropriate action against faults.

- Importance of server management
 - “Constantly stable operation” and “less management workload” are keywords in server management.
 - Stable operation of server
 - Shutdown of a server immediately leads the customer to lose business opportunities and profits. This requires servers to always operate in their perfect state. If a fault occurs in a server, it is necessary to detect the occurrence as soon as possible, make clear the cause, and take appropriate action. The shorter the time taken from the occurrence of a fault to the recovery from the fault is, the smaller the loss of profits (and/or costs) is.
 - Load reduction of server management
 - The server management requires many jobs. In particular, if the system becomes large or remote servers are used, required jobs increase further. The reduction of the load of the server management brings the decrease in costs (and thus customer's benefit).
- What are NEC ESMPRO Manager and NEC ESMPRO Agent?
 - NEC ESMPRO Manager and NEC ESMPRO Agent are server management software used to manage and monitor NEC Express5800 series systems on the network. The installation of NEC ESMPRO Manager and NEC ESMPRO Agent enables the server configuration, performance, and fault information to be acquired, managed, and monitored in real time and also the occurrence of a fault to be detected immediately by the alert report function.

- Effects of using NEC ESMPRO Manager and NEC ESMPRO Agent
NEC ESMPRO Manager and NEC ESMPRO Agent have sufficient effects on a variety of needs in versatile and complicated system environments.
 - Detection of server fault
NEC ESMPRO Agent collects a variety of fault information on NEC Express5800 series systems to identify the states of the systems. If a server detects a fault, the server provides NEC ESMPRO Manager with the proper alert report.
 - Prevention of server fault
NEC ESMPRO Agent includes the preventive maintenance function predicting the occurrence of a fault in advance as countermeasures for preventing faults from occurring. It can previously detect the increase in the chassis temperature and the empty capacity in a file system.
 - Management of server operation status
NEC ESMPRO Agent can acquire the detailed hardware configuration and performance information on NEC Express5800 series systems. The acquired information can be viewed at any point through NEC ESMPRO Manager.
 - Collective management of distributed servers
NEC ESMPRO Manager provides the GUI interface that allows servers distributed on the network to be managed efficiently.

Detection of Server Fault

NEC ESMPRO Manager and NEC ESMPRO Agent detect errors causing faults to occur at an early stage and notify Administrators of fault information real-time.

- Early detection of error
If a fault occurs, NEC ESMPRO Agent detects the fault and reports the occurrence of the fault to NEC ESMPRO Manager (alert report). NEC ESMPRO Manager displays the received alert in the AlertViewer and also changes the status colors of the server and server component in which the fault occurs. This allows you to identify the fault at a glance. Further, checking the content of the fault and the countermeasures, you can take appropriate action for the fault as soon as possible.

- Types of reported faults

The table below lists the typical faults reported by NEC ESMPRO Agent.

Component	Reported information
CPU	<ul style="list-style-type: none"> • CPU load is over the threshold • CPU degrading, etc.
Voltage	Voltage lowering
Power supply	<ul style="list-style-type: none"> • Voltage lowering • Power failure, etc.
Temperature	Temperature increase in chassis, etc.
Fan	Fan failure (decrease in the number of revolutions), etc.
Storage	File system usage rate, etc.
LAN	<ul style="list-style-type: none"> • Line fault threshold over • Send retry or send abort threshold over, etc.

Prevention of Server Fault

NEC ESMPRO Agent includes the preventive maintenance function forecasting the occurrence of a fault as countermeasures for preventing faults from occurring.

NEC ESMPRO Manager and NEC ESMPRO Agent can set the threshold for the CPU usage rate and the empty capacity in a file system, etc. in the server. If the value of a source exceeds the threshold, NEC ESMPRO Agent reports the alert to NEC ESMPRO Manager.

The preventive maintenance function can be set for a variety of monitoring items including the CPU usage rate.

Management of Server Operation Status

NEC ESMPRO Agent manages and monitors a variety of components installed in the server. You can view the information managed and monitored by NEC ESMPRO Agent on the Data Viewer of NEC ESMPRO Manager.

NEC ESMPRO Agent also manages and monitors components and conditions required to keep the server reliability at a high level such as hard disks, CPU, fans, power supply, and temperature.

Functional availability on the DataViewer:

Function name	Availability	Function outline
Hardware	Available	This function shows the hardware's physical information.
	Available	This function shows the memory's physical information.
	Available	This function shows the device's unique information.
	Available	This function shows CPU's physical information.
System	Available	This function shows CPU's logical information and monitors CPU utilization. This function shows memory's logical information and monitors the status.
	Available	This function shows information about I/O devices (such as Floppy disk, serial port, parallel port, keyboard, mouse, video). # USB Floppy disk drive does not appear on the dataviewer.
System environment	Available	This function monitors temperature, fan, voltage, power supply and door.
	Available	This function monitors temperature inside of chassis.
	Available	This function monitors fan.
	Available	This function monitors voltage inside of chassis.
	Unavailable	This function monitors power supply unit.
Software	Unavailable	This function monitors chassis intrusion(open/close of cover/door of chassis).
	Available	This function shows information about service, driver and OS.
	Available	This function shows network (LAN) information and monitors packet.
	Available	This function shows information about expansion bus device.
	Available	This function shows BIOS information.
	Available	This function monitors values of MIB that agent takes at random.
	Available	This function monitors controllers and strage devices such as HDD.
File system	Available	This function shows file system structure and monitors utilization.
	Unavailable	This function monitors LSD disk array controller (N8103-73A/80/81) and Promise disk array controller.
Disk array	Unavailable	
	Unavailable	This function monitors OS stall by using Watch Dog Timer.
Others	Unavailable	

Monitoring (Management) of NEC Express5800/ft series

NEC Express5800/ft series is a fault tolerant system. It can continue the operation even if a major component fails. NEC Express5800/ft series improves the system availability with the hardware, NEC ESMPRO, and system software functions.

If a major component fails, the NEC ESMPRO fault report function can notify the system Administrator of the occurrence of the fault. In addition, the Data Viewer of NEC ESMPRO Manager can monitor the system status and also identify the failed component.

NEC ESMPRO provides several maintenance functions such as the update of F/W and BIOS in the NEC Express5800/ft series in the online state (in which the system continues the operation but the components used to update F/W or BIOS is suspended) and the suspension of a specific component.

The table below lists the NEC Express5800/ft series management tasks using NEC ESMPRO and system functions.


NEC Express5800/ft series management task	NEC ESMPRO function or tool (on managed NEC Express5800/ft series)*	NEC ESMPRO function or tool (on management manager)
Monitoring of major component states	–	NEC ESMPRO Manager DataViewer
Diagnosis and start/stop of major components and F/W update	NEC ESMPRO Agent ft server utility	NEC ESMPRO Manager DataViewer
Verification of alert or verification of fault occurrence event information	Event Viewer	NEC ESMPRO Manager AlertViewer

* When the administration manager is also the managed NEC Express5800/ft series (or NEC ESMPRO Manager is installed on the managed NEC Express5800/ft series), all functions of the administration manager can be used on the managed NEC Express5800/ft series.

5-10 Installing and Using Utilities

The report of a fault occurrence in the NEC Express5800/ft series (alert) is immediately sent to the NEC ESMPro Manager. When the NEC ESMPro Manager receives the alert, a popup message appears.

The alert contains the detailed information of the fault and the proper countermeasures. You can take the appropriate action for the alert.




Collective Management of Distributed Servers

The excellent GUI provided by NEC ESPRO Manager allows servers on a network to be managed collectively. The management screen is designed in the Explorer format to indicate the components in a server hierarchically for effective server management.

NEC ESPRO Manager manages servers by using the following three types of GUIs.


- Operation Window

The operation window is used to create the map of servers connected to network to manage them. The map can be multi-layered depending on the installation areas, organizations, and objects.



- DataView


The DataView indicates the server source configuration information in the Explorer format. In addition, it changes the status color of the failed server component. This enables you to identify the failed portion.



- AlertViewer

The AlertViewer manages fault reports sent from servers together. A fault occurred in a server is immediately reported to the AlertViewer.

The Administrator can recognize all faults on the network instantly.



NEC ESMPRO Agent

NEC ESMPRO Agent is a utility which acts as an agent (proxy) between NEC Express5800/ft series and NEC ESMPRO Manager (management PC). For details on the operating environment, the setting required before the setup, and the installation procedure, see the separate volume “User’s Guide (Setup).”

Device ID in Alert Report

Some NEC Express5800/ft series reports use unique device IDs which correspond to the devices listed in the table below as the device identification information.

Device name	Device ID
CPU module 0	0
DIMM CH0/CH1 SLOT 0 on CPU module 0	0/0
DIMM CH0/CH1 SLOT 1 on CPU module 0	0/1
DIMM CH0/CH1 SLOT 2 on CPU module 0	0/2
DIMM CH0/CH1 SLOT 3 on CPU module 0	0/3
DIMM CH0/CH1 SLOT 4 on CPU module 0	0/4
DIMM CH0/CH1 SLOT 5 on CPU module 0	0/5
CPU0 on CPU module 0	0/20
CPU1 on CPU module 0	0/23
CPU module 1	1
DIMM CH0/CH1 SLOT 0 on CPU module 1	1/0
DIMM CH0/CH1 SLOT 1 on CPU module 1	1/1
DIMM CH0/CH1 SLOT 2 on CPU module 1	1/2
DIMM CH0/CH1 SLOT 3 on CPU module 1	1/3
DIMM CH0/CH1 SLOT 4 on CPU module 1	1/4
DIMM CH0/CH1 SLOT 5 on CPU module 1	1/5
CPU0 on CPU module 1	1/20
CPU1 on CPU module 1	1/23
PCI module 0	10
PCI slot 1 on PCI module 0	10/6
PCI slot 2 on PCI module 0	10/8
PCI slot 3 on PCI module 0	10/7
SCSI adapter 1 on PCI module 0	10/0
SCSI adapter 2 on PCI module 0	10/1
Ethernet board 1 on PCI module 0	10/2
PCI module 1	11
PCI slot 1 on PCI module 1	11/6
PCI slot 2 on PCI module 1	11/8
PCI slot 3 on PCI module 1	11/7

Device name	Device ID
SCSI adapter 1 on PCI module 1	11/0
SCSI adapter 2 on PCI module 1	11/1
Ethernet board 1 on PCI module 1	11/2

Supplement

Note the followings when using NEC ESMPRO Agent.

Notice on running NEC ESMPRO Agent

NEC ESMPRO Agent sometimes cannot send alert report after recovering from hardware failure.

[Workaround]

Execute the following procedure after recovering from hardware failure.

After replacing the hardware, confirm both of the CPU/IO module status lamp 2s turn green (duplex), login as a root user, and then run the following command.

```
# /opt/nec/esmpro_sa/bin/ESMRestart
```


For status lamp positions, refer to “Names and Functions of Components” in Chapter 2 “General Description” in User’s Guide.

Restarting NEC ESMPRO Agent after the OS boot

10 minutes after the OS boot, NEC ESMPRO Agent reboots its related services in order to show the status after changing from Simplex to Duplex appropriately.

Displaying ft Server utility

When you start ft server utility starts by using GNOME terminals from X Windows or konsole command, the right part of the initial screen goes beyond the screen by defaults. There is no problem on using the utility as it is. The screen refreshes and back to normal when you press [Ctrl]+[L].



Display

For vertical resolution, horizontal resolution and pixel on [/O device]-[Display adapter name] of the dataviewer, 0 is displayed when the user does not locally login (on the user name entering screen).

Portmap

ESMPRO/ServerAgent uses the function of portmap.

If portmap stops or reactives while operating ESMPRO/ServerAgent, ESMPRO/ServerAgent cannot be normally operated. Please execute the following commands, and reactivate ESMPRO/ServerAgent.

```
# /opt/nec/esmpro_sa/bin/ESMRrestart.
```

Maintenance-related Functions

When you want to use maintenance-related functions of the NEC Express5800/ft series, contact your maintenance personnel.

CPU Information

If you select [CPU Module] – [CPU] in the [ft] tree of the Data Viewer, unknown or incorrect information appears in some information items.

The CPU information can be viewed by selecting [System] – [CPU] in the [ESMPRO] tree.

Change of Installation States of CPU and PCI Modules

If you dynamically change the configuration of the CPU or PCI module in the relevant system during review of the server information by using the Data Viewer, the information in the Data Viewer may be different from the current system information because the change of the system configuration is not reflected on the Data Viewer. Please execute the following commands, and reactivate ESMPRO/ServerAgent.

```
# /opt/nec/esmpro_sa/bin/ESMRrestart
```

Mouse on the Data Viewer

A mouse is undisplayed on the NEC ESMPRO Manager's Data Viewer, as there is no /etc/sysconfig/mouse file for NEC ESMPRO Agent to refer to on the Red Hat Enterprise Linux Advanced Platform 5.2.

Impact When Module Status Changes

PCI modules, SCSI adapters, SCSI buses, and modules under the SCSI enclosure have impact on each other. For example, when the “Status” item of a module changes to “fault,” it may be caused by another module’s error. Therefore, you need to check the status of the other modules based on alert information.

LAN Monitoring Report

The LAN monitoring function defines the line status depending on the number of transmission packets and the number of packet errors within a certain period. Thus, the LAN monitoring function may report a line fault or high line load only in a temporary high line impedance state. If a normal state recovery is reported immediately, temporal high line impedance may have occurred thus there is not any problem.

Setting of Data viewer at update intervals

Set the update interval of Data Viewer 60 seconds(default) or more. Otherwise, a report might be delayed or not be sent.

Set Memory usage of ntagent

The memory usage of ntagent will increase by about 10KB in an hour when the Data Viewer is displayed. Please do not display the Dataviewer, and display it only when you occur the trouble.

LAN Monitoring Threshold

Because the NEC Express5800/ft series detects hardware faults on the network in the driver level, NEC ESMPRO Agent does not monitor line faults. Thus, the value set for “Line fault occurrence rate” of a [LAN] tab of [NEC ESMPRO Agent properties] in the control panel is not used.

Hardware Monitoring by ESMPRO

On NEC Express5800/320Fd-MR, the power supply is not monitored. Moreover, the tree of [power supply] is not displayed under [System Environment] of the data viewer of ESMPRO/ServerManager.

System Environment Monitoring

On NEC Express5800/320Fd-MR, monitoring of temperature, fan and voltage under [System Environment] of [ESMPRO] tree in the Data Viewer is set to enable and cannot be changed to disabled by default.

Change of SNMP Community

If the security setting of the SNMP Service of a system, where the NEC ESMPRO Agent is installed, is changed from the default “public” to a community name, change the community settings of the NEC ESMPRO Agent, too.

- 1.** Login as a root user.
- 2.** Go to the folder where NEC ESMPRO Agent control panel is installed.
cd /opt/nec/esmpro_sa/bin
- 3.** Start the control panel.
./ESMagentconf
The control panel is displayed.
- 4.** Select [General].
The [General property] is displayed.
- 5.** Select a desired community name from the [SNMP Community] list box in [SNMP Setting] of the [General] sheet.
- 6.** Click [OK] to terminate the operation.

Connection with Hard Disk Drive

The preventive hard disk drive maintenance function may not work properly when a hard disk drive which was used in a system where NEC ESMPRO Agent is installed is connected to other systems. Make sure not to connect such hard disk drives.

Change Settings of File System Monitoring Function

New settings in thresholds of monitoring interval and free space monitoring are not reflected immediately after they are changed. They are reflected at the next monitoring interval of monitoring service.

CPU Load Ratio of SNMP Service

While monitoring the server from NEC ESMPRO Manager, the CPU load ratio of SNMP Service on the NEC ESMPRO Agent side may increase at every monitoring interval (default: 1 minute).

NEC ESMPRO Manager and NEC ESMPRO Agent exchange information through SNMP Service. If the server status monitoring by NEC ESMPRO Manager is on (default: ON), NEC ESMPRO Manager regularly issues a request to NEC ESMPRO Agent to get the current status of the server. In response, NEC ESMPRO Agent checks the status of the server. As a result, the CPU load ratio of SNMP Service increases temporarily.

If you have trouble of terminating a movie player application, turn off the server status monitoring by NEC ESMPRO Manager or extend the monitoring interval.

Hang of SNMP Service

SNMP Service has a module called “SNMP Extended Agent.” This module may be registered when you install some software that uses SNMP Service.

If you start SNMP Service, SNMP Extended Agent is also loaded at the initialization. However, if the initialization is not completed within a specified period, SNMP Service will hang.

It may take time to complete the initialization due to temporary high load on the system. In this case, wait for the system load become low enough before restarting SNMP Service.

When [ft] Tree Appears on Date Viewer in an Incorrect Manner

If you open a DataViewer immediately after the system starts up, the tree or the state of a DataViewer may not be displayed correctly due to high load of the system. Please restart a DataViewe again in about 5 minutes.

Ethernet Adapters You Do Not Use

When the cables are not connected to the Ethernet adapter ports, NEC ESMPRO Agent determines that the ports are faulty (does not have any media), and the status color of [ft] – [PCI module] – [Ethernet Board] of the Data Viewer turns red (abnormal). The server status color of Operation Window also turns red (abnormal).

As to the ports of the unused Ethernet adapter, connect the unused port of PCI module 0 and that of PCI module 1 with a cross cable.

DataViewer display when only one of the PCI modules (IO modules) is operating

When only one of the PCI modules (IO modules) is operating (non-dual configuration), the SCSI enclosure or mirror disk status cannot be displayed normally.

To check if the dual configuration is changed to the simplex operation mode, check the event log, AlertViewer log, or the status color of PCI module of Data Viewer.

Display of Ethernet Board of ftServer Utility

ftServer Utility displays the information of Network Controller.

Express5800/320Fd-LR/MR has four in-built Network Ports. Two trees of the Ethernet Board are displayed since a module has two Network Controllers.

NEC ESMPRO Manager

To monitor and manage a computer, on which NEC ESMPRO Agent is installed, with a management PC online, use NEC ESMPRO Manager that is bundled with the product.

For detailed procedures of installation and setting, see online documents or NEC ESMPRO Online Help.

TIPS:

- Online documents provide cautions and information for using NEC ESMPRO Manager. See *NEC ESMPRO Manager User's Guide* in the NEC EXPRESSBUILDER DVD.
 - The sample screen shown in this subsection may differ from that of your server software; however, it offers the same function.
-

Monitoring by Use of DataViewer

To monitor the state of the NEC Express5800/ft series on a management computer with installation of NEC ESMPRO Manager, the DataViewer is used. If you click each of the modules and items to be checked sequentially on the tree view in the Windows Explorer format, the DataViewer indicates their states on the right side of the screen.

You can manage the status on a Web browser using Web component functions of NEC ESMPRO Manager. For details, see Help on Web Component.

This section describes the tree structure and displayed screens in the DataViewer.


To make the DataViewer indicate the state of each module and those of the components on it, select the server to be monitored from NEC ESMPRO Manager to start the DataViewer (in the following description, the start procedure of the DataViewer is omitted).

Monitoring CPU Module

To monitor the CPU modules and the components on the CPU module, see the [CPU Module] tree. To see the information on the [CPU Module] tree, select the target CPU module from [CPU Module] in the [ft] tree.


You can see the following information on the modules and the components on the CPU modules in the [CPU Module] tree.

- **General**
Allows the configuration and other information on the CPU modules to be viewed.




- **Maintenance**

Allows the start/stop, MTBF information clear, dump acquisition, and diagnosis of the CPU modules to be provided. See “Maintenance of NEC Express5800/ft series” described later for the start/stop and MTBF information clear of the CPU modules.




- **Update**
Allows the device identification information of the CPU modules to be viewed and BIOS of the CPU modules to be updated. See “Maintenance of NEC Express5800/ft series” described later for the update of BIOS of the CPU modules. The detailed device identification information can be checked by selecting [ESMPRO] tree→[Hardware] tree→[Field Replaceable Unit] tree.



- **CPU**
Allows the information of the CPU on the CPU modules to be viewed.



- DIMM
Allows the information of DIMM on the CPU modules to be viewed.



Monitoring PCI Module

To monitor the PCI modules and the components on the PCI modules, refer to the [PCI Module] tree. To see the information on the [PCI Module] tree, select the target PCI module from [PCI Module] in the [ft] tree.

You can see the following information on the PCI modules and the components on the PCI modules of the [PCI Module] tree.


(This section describes the general information screens of the PCI modules. The components on the PCI modules are described later.)

- **General**
Allows the configuration and other information of the PCI modules to be viewed.




- Maintenance

Allows the start/stop, MTBF information clear, and diagnosis of the PCI modules to be provided. See “Maintenance of NEC Express5800/ft series” described later for the start/stop and MTBF information clear of the CPU modules.



- Update

Allows the device identification information of the PCI modules to be viewed. The detailed device identification information can be checked by selecting [ESMPRO] tree→[Hardware] tree→[Field Replaceable Unit] tree.



Monitoring PCI Slots and Devices on PCI Module

To monitor the PCI slots and devices on the PCI modules, see the [PCI slot] tree. To see the information on the [PCI slot] tree, select [PCI Module]→[PCI module (containing PCI slot to be seen)]→[PCI slot] of the [ft] tree.

You can see the following information on the PCI slot and the devices on the PCI slot in the [PCI slot] tree.

- **General**
Allows the PCI slot configuration information to be viewed.



- **Maintenance**
Allows a device on the PCI slot to be started. This function is not supported in the current version.



- **PCI Device – General**
Allows the information of devices on the PCI slot to be viewed.
This function is not supported in the current version.
- **PCI Device – Detail**
Allows the detailed information of a device on the PCI slot to be viewed.
This function is not supported in the current version.
- **PCI Bridge – General**
Allows the information of bridges on the PCI bus to be viewed.
This function is not supported in the current version.
- **PCI Bridge – Bus**
Allows the bus information of a bridge on the PCI bus to be viewed.
This function is not supported in the current version.
- **PCI Bridge – Detail**
Allows the detailed information of a bridge on the PCI bus to be viewed.
This function is not supported in the current version.

Monitoring SCSI adapter on PCI module

To monitor the SCSI adapters on the PCI modules, see the [SCSI adapter] tree. To see the information on the [SCSI adapter] tree, select [PCI Module]→[PCI module (connected to SCSI adapter to be seen)]→[SCSI adapter] of the [ft] tree.

You can see the following information on the SCSI adapters in the [SCSI adapter] tree.

- **General**
This allows the SCSI configuration information to be viewed.
- **Maintenance**
This allows the MTBF information of SCSI adapters to be viewed and cleared.
- **Update**
This function is not supported in the current version.
- **SCSI bus**
This function is not supported in the current version.

Monitoring Ethernet adapter on PCI module

To monitor the Ethernet adapters on the PCI modules, see the [Ethernet adapter] tree. To see the information on the [Ethernet adapter] tree, select [PCI Module]→[PCI module (connected to the Ethernet adapter to be seen)]→[Ethernet adapter] of the [ft] tree. You can see the following information on the Ethernet adapters in the [Ethernet adapter] tree.

IMPORTANT:

When there is unused Ethernet adapter, ESMPRO Agent determines that the port is faulty (does not have any media), and the status color of [ft] - [PCI module] - [Ethernet Board] of the Data Viewer turns red (abnormal). The server status color of the integrated viewer also turns red (abnormal).

You need to connect the PCI module 0 and the PCI module 1 with the cross LAN cable when these Ethernet ports are not in use.


- General

This allows the ethernet configuration information to be viewed.




- Detail

This allows the communication data of the ethernet adaptor to be viewed.



- Maintenance

This allows to refer/clear the MTBF information of the ethernet adaptor. See “Maintenance of NEC Express5800/ft series” described later for the MTBF information clear of the ethernet adaptor.



Monitoring SCSI Enclosure

To monitor the SCSI enclosure, see the [SCSI enclosure] tree. To see the information on the [SCSI enclosure] tree, select [SCSI enclosure] of the [ft] tree.

You can see the following information of the SCSI enclosure from the [SCSI enclosure] tree.

- General
This function is not supported in the current version.
- Maintenance
This function is not supported in the current version.
- Update
This function is not supported in the current version.
- Electronics – General
This function is not supported in the current version.
- Electronics – Maintenance
This function is not supported in the current version.
- SCSI Slot – General
This function is not supported in the current version.
- SCSI Slot – Maintenance
This function is not supported in the current version.

Monitoring Mirror Disk

To monitor the mirror disk components, see the [Mirror Disk] tree. To view information on [Mirror Disk] tree, select [Mirror Disk] under [ft] tree.

You can see the redundancy status of the mirrors and the device IDs of the SCSI slots into which these hard disk components are connected.

However, this function is not supported in the current version.

Maintenance of NEC Express5800/ft series

NEC Express5800/ft series maintenance can be done in two ways; one is to use NEC ESMPRO Manager for remote maintenance and the other is to use the NEC ESMPRO Agent ft server utility on the NEC Express5800/ft series for local maintenance.

TIPS: To start the NEC ESMPRO Agent ft server utility installed in the NEC Express5800/ft series, select the items as follows:

```
# /opt/nec/esmpro_sa/bin/ESMftcutil
```

The maintenance functions that can be executed from NEC ESMPRO include three types, those common to all components, those specific to particular components, and general system settings.

The maintenance functions common to all components are operated in the same way basically (the operation procedure and typical examples of screen images are described below).

The table below lists the availability of maintenance functions common to all components.

Component	Start		Stop		MTBF clear		Diagnosis		F/W update	
	R	L	R	L	R	L	R	L	R	L
CPU module	√	√	√	√	√	√	√	√	√	√
PCI module	√	√	√	√	√	√	√	√	–	–
PCI slot	–	–	–	–	–	–	–	–	–	–
Ethernet adapter	–	–	–	–	√	√	–	–	–	–
SCSI adapter	–	–	–	–	√	√	–	–	–	–
SCSI enclosure	–	–	–	–	–	–	–	–	–	–
SCSI electronics	–	–	–	–	–	–	–	–	–	–
SCSI slot	–	–	–	–	–	–	–	–	–	–

R: Remote. Executable from remote management PC by using NEC ESMPRO Manager

L: Local. Executable on local server by using ft server utility

√: Supported

–: Not supported

Note: The MTBF clear of SCSI adapter and Ethernet cannot be performed to built-in devices.

The table below shows the component-specific maintenance functions executable from NEC ESMPRO.

Component	Dump harvest		Dump harvest during system operation		Board switch	
	R	L	R	L	R	L
CPU module	-	√	√	√	√	√

- R: Remote. Executable from remote management PC by using NEC ESMPRO Manager
- L: Local. Executable on local server by using ft server utility
- √: Supported
- : Not supported

Component	Bus reset		Change of primary SCSI bus	
	R	L	R	L
SCSI bus	-	√	-	-

- R: Remote. Executable from remote management PC by using NEC ESMPRO Manager
- L: Local. Executable on local server by using ft server utility
- √: Supported
- : Not supported

The table below shows the support of the whole system setup functions.

Component	Quick dump		Auto firmware update		Auto module start	
	R	L	R	L	R	L
Whole system	-	√	-	√	-	√

- R: Remote. Executable from remote management PC by using NEC ESMPRO Manager
- L: Local. Executable on local server by using ft server utility
- √: Supported
- : Not supported

The table below shows the support of the preventive disk maintenance (S.M.A.R.T.) setup function.

Component	Preventive disk maintenance (S.M.A.R.T.) setup	
	R	L
SCSI disk	-	-

- R: Remote. Executable from remote management PC by using NEC ESMPRO Manager
- L: Local. Executable on local server by using ft server utility
- √: Supported
- : Not supported

Start and Stop of Components

To start or stop a component with NEC ESMPRO Manager, use the [Maintenance] tree of the component in the [ft] tree of the DataViewer. Open the tree of the component to be started or stopped and select the [Maintenance] tree.

To start or stop a component with the ft server utility, use the utility screen of the component.

The table below shows the common cases in which a component is to be started or stopped.

Component	Start		Stop	
	Remote	Local	Remote	Local
CPU Module	When the cause of down is reviewed and the system is restarted in module down state. Executable in any of the following module states (this can be viewed on manager screen): <ul style="list-style-type: none"> • Removed • Broken • Shot • Firmware Update Complete • Diagnostics Passed 	When the cause of down is reviewed and the system is restarted in module down state. Executable in the following module state: <ul style="list-style-type: none"> • When the status LED 1 is amber and the status LED 2 is off Only the status LED illuminates amber when the module is in one of the following states: <ul style="list-style-type: none"> • Removed • Broken • Shot • Firmware Update Complete • Diagnostics Passed 	When system is stopped forcibly due to replacement or malfunction of module. Executable in the following module state: <ul style="list-style-type: none"> • Only the green LED is on and in redundant configuration state The both green LEDs are on when the module is in the following state: <ul style="list-style-type: none"> • Duplex 	When system is stopped forcibly due to replacement or malfunction of module. Executable in the following module state: <ul style="list-style-type: none"> • Only the green LED is on and in redundant configuration state The both green LEDs are on when the module is in the following state: <ul style="list-style-type: none"> • Duplex
PCI Module	Same as above	Same as above	Same as above	Same as above
SCSI Slot	—	—	—	—

Remote: Executable from remote management PC by using NEC ESMPRO Manager

Local: Executable on local server by using ft server utility

—: Not supported

IMPORTANT: PCI modules, SCSI adapters, SCSI buses, and modules under the SCSI enclosure have impact on each other. You need to be aware of this, for example, when you replace a PCI module. For details, see “Impact When Module Status Changes” described earlier in this chapter.

Procedure in NEC ESMPRO Manager

Start

1. Select the target component in the [ft] tree.
2. Check the current state with the “Status” display on the target component screen.
3. Click the [Bring Up] button in the [Maintenance] screen for the target component.
A certain time is required for the start.

The start result can be verified by “State” on the target component screen. The result of the start operation is reported by the NEC Express5800/ft series as an alert.


Stop

Perform the procedure below before replacing a component.

1. Select the target component in the [ft] tree.
2. Check the current state with the “State” display on the target component screen.
3. Click the [Bring Down] button in the [Maintenance] screen for the target component.
A certain time is required for the stop.


The stop result can be verified by “State” on the target component screen. The result of the stop operation is reported by the NEC Express5800/ft series as an alert.

Sample screen of NEC ESMPRO Manager 1



[Maintenance] screen of PCI module
[CPU Module] – [CPU Module] - [Maintenance]

Sample screen of NEC ESMPRO Manager 2



[Maintenance] screen of PCI module
[PCI Module] - [Maintenance]

Procedure in the ft server utility

Start

1. Select the target component by using the ft server utility.
2. Check the current state of the target component with the LEDs.
3. Click the [Up] button of the target component.

A certain time is required for the start.

The start result can be verified by the LEDs on the target component. The result of the start operation is registered in the event log.



Stop

1. Stop before replacing components.
2. Select the target component by using the ft server utility.
3. Check the current state of the target component with the LEDs.
4. Click the [Down] button of the target component.

A certain time is required for the start.

The start result can be verified by the LEDs on the target component. The result of the start operation is registered in the event log.

Sample screen of ft server utility



Check and Clear of MTBF Information

The MTBF information of a component can be viewed or cleared (initialized).

NEC Express5800/ft series manages the MTBF (mean time between failure) of each component. If a fault occurs in a component, the NEC Express5800/ft series calculates the MTBF of the component again. If the calculated value is lower than the pre-defined threshold, the NEC Express5800/ft series disables the component to be used.

Contact your maintenance personnel if such a symptom as above occurs.

IMPORTANT: A disabled component with the MTBF lower than the threshold can be forcibly enabled by clearing the MTBF. However, contact your maintenance personnel for the forced use of such a component.

To clear the MTBF information of a component with NEC ESMPRO Manager, use the [Maintenance] tree of the component of the [ft] tree of the DataViewer. Open the tree of the component whose MTBF information is to be cleared and select the [Maintenance] tree.

To clear the MTBF information of a component with the ft server utility, use the utility screen of the component. The table below shows the potential cases in which the MTBF information of a component is to be cleared. Contact your maintenance personnel for clearing MTBF information.

Component	MTBF clear	
	Remote	Local
CPU Module	To start the module forcibly after replacing a module or if MTBF became lower than the threshold due to malfunction and disabled the module. Executable in the following module state (this can be viewed on manager screen): <ul style="list-style-type: none"> • Broken • MTBF is lower than the threshold. Same as above	To start the module forcibly after replacing a module or if MTBF became lower than the threshold due to malfunction and disabled the module. Executable in the following module state: <ul style="list-style-type: none"> • The amber LED is on. • The event indicating that MTBF is lower than the threshold is registered in the event log. Same as above
PCI Module Ethernet Adapter	Same as above To start the module/component forcibly after replacing a module or if MTBF became lower than the threshold due to malfunction and disabled the module/component. Executable in the following module state (this can be viewed on manager screen): Broken MTBF is lower than the threshold.	Same as above To start the module/component forcibly after replacing a module or if MTBF became lower than the threshold due to malfunction and disabled the module/component. Executable in the following module state (this can be viewed on manager screen): <ul style="list-style-type: none"> • The amber LED is on. • The event indicating that MTBF is lower than the threshold is registered in the event log. Same as above
SCSI Adapter	Same as above	Same as above

IMPORTANT: You can also clear MTBF information for the PCI module, Ethernet Adapter and SCSI Adapter by unplugging and plugging the live wire of the PCI module.

Component	MTBF clear	
	Remote	Local
SCSI Enclosure	—	—
SCSI Electronics	—	—
SCSI Slot	—	—

Remote: Executable from remote management PC by using NEC ESMPRO Manager

Local: Executable on local server by using ft server utility


—: Not support

Procedure in NEC ESMPRO Manager

Perform the procedure below before replacement of a component.

1. Select the target component in the [ft] tree.
2. Check the current state with the “State” display on the target component screen.
3. Click the [MTBF Clear] button in the [Maintenance] screen for the target component.
You can verify the MTBF clearing result by confirming whether the reset is done when the number of fault becomes 0 on the MTBF information of the target component screen.
4. Start the component.

Sample screen of NEC ESMPRO Manager





[Maintenance] screen of SCSI enclosure
[PCI module] – [Maintenance]

Procedure in the ft server utility

Perform the procedure below before replacement of a component.

1. Select the target component by using the ft server utility.
2. Check the current state of the target component with the LEDs and event log.
3. Click the [Clear] button in [MTBF Clear] of the target component.
The MTBF clearing result can be verified by the LEDs on the target component. The result of the MTBF clearing operation is registered in the event log.
4. Start the component.

Sample screen of ft server utility



[PCI Module]

Diagnostics

The NEC Express5800/ft series provides the self-check diagnosis function for some components. If a fault occurs in a component, the NEC Express5800/ft series can diagnose the component to detect the fault.

To diagnose a component with the NEC ESMPRO Manager, use the [Maintenance] tree of the component in the Data Viewer. Open the tree of the component to be diagnosed and select the [Maintenance] tree.


To diagnose of a component with the ft server utility, use the utility screen of the component.

However, the current version does not support this function.

Procedure in NEC ESMPRO Manager

1. Select the target component in the [ft] tree.
 2. Check the current state with the “State” display on the target component screen. If the component is operating, stop the component.
 3. Click the [Diagnostics] button in the [Maintenance] screen for the target component.
- The diagnosis result can be verified by “Result” of the diagnosis on the target component screen. The result of the diagnosis is reported by the NEC Express5800/ft series as an alert.
- The result of diagnosis executed last is displayed in the [Diagnosis Information] column. In addition, if a fault is detected by the result of the diagnosis, the state of the [General] tree of the component is changed.

Sample screen of NEC ESMPRO Manager





[Maintenance] screen of PCI module
[PCI Module] – [Maintenance]

Procedure in the ft server utility

1. Select the target component by using the ft server utility.
2. Check the current state of the target component with the LEDs. If the component is operating, stop the component.
3. Click the [Diagnostics] button in the [Diagnosis Information] on the target component.
The diagnosis result can be verified by the LEDs on the target component. The result of the diagnosis is registered in the event log.
4. Start the component.

Sample screen of ft server utility



[PCI Module]

Firmware Update

NEC Express5800/ft series can update firmware (including BIOS) if some hardware components operate in the online state (in which the system continues the operation but the component trying to update firmware or BIOS is stopped).

To update firmware with NEC ESMPRO Manager, use the [Update] tree of the component in the Data Viewer. Open the tree of the component for which firmware is updated and select the [Update] tree.

To update the firmware of a component with the ft server utility, use the utility screen of the component.

To update the firmware of a component, the firmware image file of the firmware for update must previously be stored in the managed server. On the firmware update screen, specify the path to the firmware image file for update.

The table below shows the potential cases in which the firmware of a component is to be updated.

Component	Firmware update	
	Remote	Local
CPU Module	<p>When BIOS must be updated to new one. Executable in any of the following module states (this can be viewed on manager screen):</p> <ul style="list-style-type: none"> • Removed • Broken or forced stop • No fault found by diagnosis <p>To update the module under operation, bring down the module before the update.</p>	<p>When BIOS must be updated to new one. Executable in the following module state:</p> <ul style="list-style-type: none"> • When the status LED 1 is amber and the status LED 2 is off <p>Only the status LED 1 illuminates amber when the module is in one of the following states:</p> <ul style="list-style-type: none"> • Removed • Broken or forced stop • No fault found by diagnosis (Firmware Update Complete) <p>To update the module under operation, bring down the module before the update.</p>

Remote: Executable from remote management PC by using NEC ESMPRO Manager


Local: Executable on local server by using ft server utility

–: Not support

Procedure in NEC ESMPRO Manager

1. Save the image data of the update firmware in an arbitrary directory of the NEC Express5800/ft series.
Save the image data in any way. Write down the path to the directory in which the image data is saved.
2. Select the target component in the [ft] tree.
3. Check the current state with the “State” display on the target component screen. If the component is operating, stop the component.
4. Click the [Firmware Update] button in the [Update] screen for the target component.


Sample screen of NEC ESMPRO Manager




[Update] screen of CPU module
[CPU Module] – [Update]

5. Select [Specify the file path to update], enter the directory in which the updated firmware specified in the input box in step 1 is saved, and click the [Execute] button.
Perform the firmware update.

The update result can be verified by the state on the target component screen (indication of “Firmware update completed”). The result of the update processing is reported by the NEC Express5800/ft series as an alert.



6. After the BIOS for a single CPU module is completed, click the [Jump Switch] button. The module completely updated is started and the active module is stopped.
7. Start the other module stopped.
Starting the module causes the firmware to be updated automatically. However, if the [Enable automatic firmware update] property is invalid, update the module in the procedure as follows:
 - (1) Check the current state with the “State” display on the target component screen. If the component is operating, stop the component.
 - (2) Click the [Firmware Update] button in the [Update] screen for the target component.
 - (3) Select the update method in the [Firmware Update] dialog box and click the [Execute] button.
 - (4) Start the module.



Even if you do not have the image data of firmware for update, the firmware can be copied from the other module.



By starting the module, the firmware will be updated automatically. However, when the [Enable automatic firmware update] property is disabled, follow the steps below to update the firmware:

- 1.** Start the system using the module of the firmware copy source.
See the current status by the “Status” indication on the target component screen of the copy destination and verify that it is stopped.
- 2.** On the [Update] screen of the target component, click [Firmware update].
- 3.** When a firmware updating dialog appears, check [Copy online BIOS image to Offline] and execute it.
Firmware is updated by copying the firmware on the online side to the offline side.
- 4.** Start the stopped module.

Procedure in ft server utility


1. Save the image data of the update firmware in a desired directory of the NEC Express5800/ft series.
Save the image data in some manner. Write down the path to the directory in which the image data is saved.
2. Select the target component with the ft server utility.
3. Check the current state of the target component with the LEDs. If the component is operating, stop the component.
4. Click the [Firmware...] button for the target component.

Sample screen of ft server utility



[CPU Module]

5. Select [Specify new firmware for update], enter the directory in which the updated firmware specified in the input box in step 1 is saved, and click the [Execute] button. Perform the firmware update.




6. Check the update result with the event log.

7. After the BIOS for a single CPU module is completed, click the [Jump Switch] button. The module completely updated is started and the module under operation is stopped. [Jump Switch] function is not supported in the current version.
8. Start the other inactive module.

Starting the module causes the firmware to be updated automatically. However, if the [Enable automatic firmware update] property is disabled, update the module in the procedure as follows:

 - (1) Check the current state with the “State” display on the target component screen. If the component is operating, stop the component.
 - (2) Click the [Firmware...] button for the target component.
 - (3) Select the update method in the [Firmware Update] dialog box and click the [Execute] button.
 - (4) Start the module.



Even if you do not have the image data of firmware for update, the firmware can be copied from the other module.

By starting the module, the firmware will be updated automatically. However, when the [Enable automatic firmware update] property is disabled, follow the steps below to update the firmware:

1. Start the system using the module of the firmware copy source.

See the current status by the “Status” indication on the target component screen of the copy destination and verify that it is stopped.
2. Click the [Firmware...] button for the target component.
3. When a firmware updating dialog appears, check [Copy firmware from Online module to Offline one] and execute it.

Firmware is updated by copying the firmware on the online side to the offline side.
4. Start the stopped module.

Dump Collection

To collect the dump file with NEC ESMPRO Manager, use [CPU Module] → [Maintenance] tree in the DataViewer.

To collect the dump with the ft server utility, use the utility screen of the component.

IMPORTANT: Acquire the dump only for the examination of a fault.

The dump can be collected in two ways. In each way, the dump file is stored under the directory of /var/crash/ on the server.

- Collecting dump of inactive module
The dump is acquired from the inactive CPU module (due to the occurrence of a fault or forced stop).
- Collecting dump under system operation
Either of the CPU modules is entered into the offline state and the dump is collected during system operation. After the acquisition, the CPU module is returned to the online state again. This can be done only in the duplex system.

However, this function is not supported in the current version.


Procedure in NEC ESMPRO Manager

The [Dump] button of NEC ESMPRO Manager performs the function of “saving dump during system operation.”

However, this function is not supported in the current version.

1. Select [CPU Module] in the [ft] tree.
 2. Check the current state with the “State” display on the target component screen.
 3. Click the [Dump] button in the [Maintenance] screen for the target component.
A certain time is required for the dump saving.
The dump is stored under the directory of /var/crash/ on the managed server.
- The result of the dump saving is reported by the NEC Express5800/ft series as an alert.

Sample screen of NEC ESMPRO Manager



[Maintenance] screen of CPU module
[CPU Module] – [Maintenance]

Procedure in ft server utility

This function is not supported in the current version.



4. Select the target CPU module by using the ft server utility.
5. Check the current state of the target CPU module with the LEDs.
6. Select the dump acquisition method with [Dump] of the target CPU module and click the [Harvest] button.

A certain time is required for the dump acquisition.

The dump is stored under /var/crash/ directory on the server.

The result of the dump acquisition can be viewed in the syslog.

Sample screen of ft server utility



[CPU Module]


Refresh of View based on State Change Alert Setting

A new function is supported so that NEC ESMPRO Manager window will be updated on a system state change basis (in other words, whenever necessary). This function is OFF by default. See the [Setting] below about how to turn it ON.

NEC ESMPRO Manager window is updated by one minute-interval polling by default. Therefore, there is some time-lag for NEC ESMPRO Manager to recognize changes in NEC Agent. By using this function, the time-lag can be reduced. However, it may consume a little bit more network band width since each state change will be notified to NEC ESMPRO Manager as some kind of alert.


[Setting]

7. Select [Program] - [NEC ESMPRO Manager] from the Start menu and click [Manager Settings].



[Manager Settings] dialog box

8. Check [Enable the State Change Alert Setting].
9. Click the [Agent Setting...] button.



[State Change Alert Setting] dialog box

10. Check the name of servers sending the state change alert to the Manager when the Agent recognizes changes in the state.
Click the [Execute] button for the setting change to take effect.

Chapter 6

Maintenance

This chapter describes the daily maintenance of NEC Express5800/ft series and precautions when relocating or storing the server.

DAILY MAINTENANCE


To use your NEC Express5800/ft series in best condition, check and maintain regularly as described below. If an error is found on your NEC Express5800/ft series, consult your sales agent.

Checking Alert


Monitor the failure occurrence by NEC ESMPRO during the system operation.

Always check whether any alert is reported to NEC ESMPRO Manager on the management PC. Check whether any alert is reported on the Operation Window, Data Viewer, or Alert Viewer of NEC ESMPRO Manager.

Viewers of NEC ESMPRO



Operation Window



Severity	IC.B.I.	Type	Message	Component	Address	Breaked
OK	2048	Security	mg_1994C7	1994C7	140.0.0.27	021412000
OK	2048	Security	mg_1994C7	1994C7	140.0.0.27	021412000
Warning		Server Reov...	mg_1994C7	1994C7	140.0.0.27	021412000
Warning		Power Line Rebo...	mg_1994C7	1994C7	140.0.0.27	020912000
Warning		Power Supply Err...	mg_1994C7	1994C7	140.0.0.27	020912000
Warning		Power Supply Error	mg_1994C7	1994C7	140.0.0.27	020912000

Alert Viewer



Data Viewer

Checking STATUS LEDs

Check the LED indication on the front of the NEC Express5800/ft series, on hard disks installed in 3.5-inch hard disk drive bay, or on LCD display when the server is powered on or powered off by the shut down operation. The functions and indications of LEDs are described in Chapter 2. If any indication that shows an error, contact your sales agent.

Making Backup Copies

NEC recommends you make backup copies of your valuable data stored in hard disks of the server on a regular basis. For backup storage devices suitable for the server and backup tools, consult with your sales agent.

When you have changed the hardware configuration or BIOS configuration, select "System Information Management" and then "Save" of the Off-line Maintenance Utility to make a backup copy of the system information.

Cleaning

Clean the server on a regular basis to keep the server in a good shape.

 WARNING
<p>Observe the following instructions to use the server safely. There are risks of death or serious personal injury. See "PRECAUTIONS FOR SAFETY" in Chapter 1.</p> <ul style="list-style-type: none">• Do not disassemble, repair, or alter the server.• Do not look into the DVD-ROM drive.• Disconnect the power plug before cleaning the server.

Cleaning the NEC Express5800/ft series

For daily cleaning, wipe the external surfaces of the server with a dry soft cloth. Follow the procedure below if stains remain on the surfaces:

IMPORTANT:

- To avoid altering the material and color of the server, do not use volatile solvents such as thinner or benzene to clean the server.
 - The power receptacle, the cables, the connectors on the rear panel of server, and the inside of the server must be kept dry. Do not moisten them with water.
-
1. Make sure that the server is powered off.
 2. Unplug the power cord of the server from a power outlet.
 3. Wipe off dust from the power cord plug with a dry cloth.
 4. Soak a soft cloth in neutral detergent that is diluted with cold or warm water, and squeeze it firmly.
 5. Rub off stains on the server with the cloth prepared in Step 4.
 6. Soak a soft cloth in water, squeeze it firmly and wipe the server with it once again.

7. Wipe the server with a dry cloth.
8. Wipe off dust from the fan exhaust opening on the rear of the server with a dry cloth.

Cleaning the Keyboard and Mouse


IMPORTANT:

A keyboard and a mouse use USB interface. Therefore it is not necessary to power off the server when connecting or disconnecting them.

Disconnect the keyboard from the server while the devices in the system (the server and the peripheral devices) remain turned on. Wipe the keyboard surface with a dry cloth. Then connect the keyboard to the server.

The mouse operation depends on the degree of smoothness of the internal ball rotation. To keep the mouse ball clean, use the mouse in a place with little dust. Follow the steps below to clean the mouse regularly:

1. Disconnect the mouse from the USB port of the keyboard while the server remains powered on.
2. Turn the mouse upside down, and rotate the mouse ball cover counterclockwise to remove it. Take out the ball from the mouse.
3. Wipe the mouse ball with a dry soft cloth. If stains remain, use a soft cloth to wipe them off. Soak the soft cloth in neutral detergent that is diluted with water or warm water, and squeeze it firmly.
4. Wipe three small rollers inside the mouse with cotton swab. Use the cotton swab soaked with alcohol if stains remain.
5. Put the mouse ball back into the mouse. If the mouse or rollers are wet in steps 3 and 4, put it back after fully dried.
6. Place the mouse ball cover, and rotate it clockwise until it is locked.
7. Connect the mouse to the server .



Cleaning the Floppy Disk Drive

A read/write error may occur due to stains on the read/write head of the floppy disk drive.

Use the cleaner dedicated for floppy disk drive to clean the read/write head. It is recommended to clean the head on regular basis.

Cleaning DVD/CD-ROM

A dusty DVD/CD-ROM or dust-accumulated tray causes the device to fail to read data correctly.

Follow the procedure below to clean the tray and DVD/CD-ROM regularly:

1. Make sure that the server is powered on.
2. Press the Eject button on the front of the DVD-ROM drive. The tray comes out.
3. Hold the DVD/CD-ROM lightly and take it out from the tray.


IMPORTANT: Do not touch the signal side of the DVD/CD-ROM with your hand.

4. Wipe the tray with a dry soft cloth.

IMPORTANT: Do not wipe the lens of the DVD-ROM drive. Doing so may damage the lens and may cause a malfunction of the drive.

5. Gently push on the tray front to close the tray.
6. Wipe the signal side of the CD/DVD-ROM with a dry soft cloth.

IMPORTANT: Wipe DVD/CD-ROMs from the center to the outside. Use only CD-ROM cleaner if necessary. Cleaning a DVD/CD-ROM with record spray/cleaner, benzene, or thinner causes damage to the DVD/CD-ROM contents. At worst, inserting the DVD/CD-ROM into the server may cause failure.



Cleaning Tape Drive

Dirt on the tape head may be a cause of unsuccessful backup and damage to tape cartridge. Clean the tape head regularly using a cleaning tape. For procedure and interval of cleaning as well as lifetime of a tape cartridge to use, see instructions included with the tape drive.

SYSTEM DIAGNOSTICS

The System Diagnostics runs several tests on the server.

Select [Tool menu] - [Test and Diagnostics] in the NEC EXPRESSBUILDER to diagnose the system.

Test Items

The following items are tested in system diagnostics.

- Memory
- CPU cache memory
- Hard disk drive used as a system

IMPORTANT: When executing the system diagnostics, make sure to remove the LAN cable. Executing the system diagnostics with the LAN cable connected, the network may be influenced.


TIPS: On checking the hard disk drive, no data is written into the disk.

Startup and Exit of System Diagnostics

Follow the steps below to start the system diagnostics. (If the server is running, shut it down, and execute Step 1 through Step 12.)

1. Shutdown the OS, and power off the server. Then, unplug the power cord.
2. Disconnect all the LAN cables from the server.
3. Plug the power cord and power on the server.
4. Use the NEC EXPRESSBUILDER DVD to start the system.
5. Select [Tool menu].

6. Select [Test and diagnostics].
Select [End-User Mode] and the system diagnostics starts. The diagnostics will be completed in approximately three minutes.
When the diagnostics is completed, the screen of the display changes as shown below:



Diagnosics tool title

Shows the name and version of the diagnostic tool.

Test window title

Shows the progress of the diagnostics. “Test End” is displayed when the diagnostics completes.

Test result

Shows the start, end, and elapsed time and completion status of the diagnostics.

Guideline

Shows the details of the keys to operate window.


Test summary window

Shows the results of each test that executed the diagnostics. Move the cursor and press the **Enter** key on the cursor line to display the details of the test.

When an error is detected by the system diagnostics, the relevant test result in the test summary window is highlighted in red, and “Abnormal End” is displayed in the result on the right side.

Move the cursor to the test that detected the error, and press the **Enter** key. Record the error message that has been output to the Detail Information screen and contact your sales agent.

7. Follow the guideline shown at the bottom of the screen, and press the **Esc** key.
The [Enduser Menu] below is displayed.



<Test Result>

Shows the diagnostics completion screen of the above diagnostics.

<Device List>

Shows a list of connected devices.

<Log Info>

Shows the log information of the diagnostics. It can be saved on a floppy disk. To save it on a floppy disk, insert a formatted floppy disk to the floppy disk drive, and select <Save(F)>.

<Option>

Optional features can be used from this menu.

<Reboot>

Reboots the system.

8. Select <Reboot> in the [Enduser Menu] above.
The server restarts and the system is started from the NEC EXPRESSBUILDER.
9. Exit the NEC EXPRESSBUILDER, and remove the DVD from the DVD-ROM drive.
10. Power off the server and unplug the power cord from the receptacle.
11. Reconnect all the LAN cables that have been disconnected in Step 2 to the server.
12. Plug the power cord.

This completes the system diagnostics.

MAINTENANCE TOOLS

The Maintenance Tools is a tool of this product for preventive maintenance, as well as for trouble analysis and its settings. Follow the below procedure to start the Maintenance Tool.


Starting the Off-line Maintenance Utility

The Off-line Maintenance Utility may be started in the following ways.

1. Boot peripheral devices at first, then power on the Express server.
2. Load the [EXPRESSBUILDER] DVD into the optical disc drive of the Express server.
3. After loading the DVD, reset (by pressing <Ctl> + <Alt> + <Delete> keys) or power off and on to reboot the Express server.
Following menu appears on the DVD.

Tool Menu:


Select this to launch the Off-line Maintenance Utility.



IMPORTANT:

Default selection is [OS installation] on the menu. When there is no operation for ten seconds after the Boot selection menu appears, [OS installation] starts automatically.


4. Select [Tool Menu].
Following Language selection menu appears.



IMPORTANT:

Default menu selection is [Japanese]. When there is no key operation for five seconds after Language menu appears, [Japanese] starts automatically.

5. Select [English]
When [English] is selected, following tool menu appears.



6. Select one of the tool and start.

Function of Maintenance Tools

The following functions are available in the Maintenance Tools.

■ **Maintenance Utility**

The Off-line Maintenance Utility is started in “Maintenance Utility.” The Off-line Maintenance Utility is an OS-independent maintenance program. When you are unable to start the OS-dependent NEC ESMPRO to troubleshoot a problem, the Off-line Maintenance Utility can be used.

IMPORTANT:

- The Off-line Maintenance Utility is intended for use of your service representative. The NEC EXPRESSBUILDER DVD contains a file that describes the operation of the utility, but do not attempt to use the utility by yourself. Contact your service representative and follow their instructions.
 - See the on-line help for details for the Off-line Maintenance Utility. For further information, ask your service representative.
-

The Off-line Maintenance Utility provides the following features.

- IPMI Information Viewer
 - Provides the functions to view the system event log (SEL), sensor data record (SDR), and field replaceable unit (FRU) and to make a backup copy of them.
 - Using this feature, you can find system errors and events to determine a maintenance part.
- BIOS Setup Viewer
 - Provides the functions to export the current configuration data defined with the SETUP utility to a text file.
- System Information Viewer
 - Provides the functions to view and information on the processor (CPU) and on the BIOS. You can export the information to a text file.
- System Information Management
 - Provides the function to make a back-up copy of your data.

Without the backup data, the system-specific information and/or configuration may not be restored.

Only the authorized service maintenance staff is allowed to restore the backup data.

– System Management

The parameters of BMC (Baseboard management Controller) are set for remote control and alert.

- BIOS/FW Updating
Update BIOS and firmware by using the distributed update module for BIOS/FW.

You can find the procedure to update BIOS and firmware in README.TXT included in the distributed update module for BIOS/FW. Update BIOS and firmware as described in the procedure.

IMPORTANT:

Do not turn off the server while the update program is running. If the update processing is discontinued, the system becomes unable to start.

- ROM-DOS startup FD
Create a support disk for starting the ROM-DOS system.

- Test and diagnostics

Execute various tests on the server system to check if the server functions are normal and if the connection between the server and additional board is normal.

After the Test and diagnostics is executed, a system check program assigned to each model starts.

- System Management


The parameters of BMC (Baseboard Management Controller) are set for remote control and alert.

This menu's function is the same as the "System Management" of the "Maintenance Utility."

RELOCATING/STORING THE NEC EXPRESS5800/FT SERIES

Follow the procedure below to relocate or store the server.

CAUTION



Observe the following instructions to use the server safely. There are risks of fire, personal injury, or property damage. See “PRECAUTIONS FOR SAFETY” in Chapter 1 for details.

- Never attempt to lift the server only by yourself.
- Do not install the server in any place other than specified.
- Do not connect/disconnect any interface cable with the power cord of the server plugged to a power source.

IMPORTANT:

- If the server needs to be relocated/stored due to a change in the floor layout to a great extent, contact the sales agent.
- Make sure to make a backup copy of your valuable data in the hard disk, if any.
- When moving the server with hard disks, make sure not to give a shock to the hard disks.
- When storing the server, keep it under storing environment conditions (temperature: -10 to 55°C, humidity: 20 to 80%, non-condensing).

1. Take a floppy disk and a DVD out of the server, if any.
2. Power off the server.
3. Unplug the power cord of the server from a power outlet.
4. Remove all the cables from the server.
5. Remove all the mounted CPU/IO modules.
6. Remove the 4U chassis and the rails from the rack cabinet.
7. Carry 4U chassis and CPU/IO modules separately.
8. Protect the server with the shock-absorbing materials, and pack it securely.

IMPORTANT:

Check and adjust the system clock before operating the server again after relocating or storing it.

If the server and the built-in optional devices are moved from a cold place to a warm place in a short time, condensation will occur and cause malfunctions and breakdown when these are used in such state. When you start operating these equipments again after the transportation or the storage, make sure to wait for a sufficient period of time to use them in the operating environment.

If the system clock goes out of alignment remarkably as time goes by, though the system clock adjustment is performed, contact your sales agent.

(This page is intentionally left blank.)

Chapter 7

Troubleshooting


If the product does not work properly, see this chapter before deciding that it is a breakdown.

TO LOCATE THE ERRORS

Use NEC ESMPRO to monitor the occurrence of fault during the system operation.

Especially take note on whether any alert is reported to NEC ESMPRO Manager on the management PC. Check whether any alert is reported on the Operation Window, Data Viewer, or AlertViewer of NEC ESMPRO Manager.

[Example]



ERROR MESSAGES

If the NEC Express5800/ft series enters the abnormal state, the error is posted by various means. This section explains the types of error messages.


Error Messages by LED Indication

The LEDs on the front and rear panels of the NEC Express5800/ft series and near the handles of hard disks inform the user of the various server statuses by the colors and the patterns of going on, going off, and flashing. If trouble seems to have occurred, check the LED indication. For the LED indication and meanings, see page 2–15 “LEDs.”

This User’s Guide describes actions to be taken for watch error message. However, if replacement of modules is necessary, contact your sales agent.

POST Error Messages

Powering on the server automatically starts the self-diagnostic program, POST (Power On Self-Test). When POST detects any error, it displays an error message and its measure on the display unit. Follow the table below to troubleshoot such errors.



Message indicating a floppy disk drive error

TIPS:

For error messages on optional PCI boards, refer to the manual provided with those options.

On-screen error message	Cause	Action
0200 Failure Fixed Disk	<ul style="list-style-type: none"> Hard disk is faulty CPU/IO module is faulty. 	<ul style="list-style-type: none"> Replace the hard disk. Replace the CPU/IO module.
0210 Stuck Key	Keyboard connection error	<ul style="list-style-type: none"> Disconnect the keyboard and connect it back again. Replace the keyboard.
0211 Keyboard error	Keyboard is faulty.	<ul style="list-style-type: none"> Disconnect the keyboard and connect it back again. Replace the keyboard. If restarting does not help, replace the CPU/IO module.
0212 Keyboard Controller Failed	Keyboard controller is faulty.	If restarting the server does not help, replace the CPU/IO module.
0213 Keyboard locked - Unlock key switch	Keyboard is locked.	Unlock the key switch.
0230 System RAM Failed at offset	DIMM is faulty.	<ul style="list-style-type: none"> Replace DIMM. Replace the CPU/IO module.
0231 Shadow RAM Failed at offset	Shadow RAM is faulty.	<ul style="list-style-type: none"> Replace DIMM. Replace the CPU/IO module.
0232 Extended RAM Failed at address line	Extended RAM is faulty.	<ul style="list-style-type: none"> Replace DIMM. Replace CPU/IO module.
0233 Memory type mixing detected	Memory of the different types is installed.	Memory of the different types is installed. Replace DIMM with appropriate one. <ul style="list-style-type: none"> Replace system battery. Replace CPU/IO module.
0250 System battery is dead -Replace and run SETUP	System battery is dead.	<ul style="list-style-type: none"> Replace system battery. Replace CPU/IO module.

On-screen error message	Cause	Action
0251 System CMOS checksum bad-Default configuration used	System CMOS configuration is changed.	<ul style="list-style-type: none"> Reconfigure the system CMOS by using BIOS setup. Clear system CMOS using hardware jumper.
0252 Password checksum bad -Password cleared	Password is cleared.	<ul style="list-style-type: none"> Reconfigure by using BIOS setup. Clear system CMOS using hardware jumper.
0260 System Timer error	System Timer is faulty.	Reconfigure by using BIOS setup. If the error cannot be solved after this, replace the CPU/IO module.
0270 Real time clock error	RTC is faulty.	
0271 Check date and time setting	Date and time are incorrectly set.	
02D0 System cache error - Cache disabled	CPU cache is faulty.	If replacing the CPU does not help, replace the CPU/IO module.
02D1 System Memory exceeds the CPU's caching limit	CPU cache is faulty.	If restarting does not help after resetting the setting to default by using BIOS setup, replace the CPU/IO module.
0613 COM A configuration change	COM A configuration is faulty.	
0614 COM A config, error - device disable	Device constructing COM A is faulty.	
0615 COM B configuration change	COM B configuration is faulty.	Check the supported CPU and replace it. If this does not help, replace the CPU/IO module.
0616 COM B config, error - device disable	Device constructing COM A is faulty.	
0B28 Unsupported Processor detected on Processor 1	Unsupported CPU is mounted.	Replace the CPU/IO module.
0B29 Unsupported Processor detected on Processor 2	Unsupported CPU is mounted.	
0B80 BMC Memory Test Failed	RMC device is faulty.	Replace the CPU/IO module.
0B81 BMC Firmware Code Area CRC check failed		
0B82 BMC core Hardware failure		
0B83 BMC IBF or OBF check failed	RMC device is faulty.	Replace the CPU/IO module.
0B8B BMC progress check timeout	BMC check is suspended.	Replace the CPU/IO module.
0B8C BMC command access failed	BMC command access failed.	Replace the CPU/IO module.
0B90 BMC Platform Information Area corrupted	BMC device is faulty.	Replace the CPU/IO module.
0B91 BMC update firmware corrupted		
0B92 Internal Use Area of BMC FRU corrupted	Data within SROM is faulty.	Replace the system backboard.
0B93 BMC SDR Repository empty	SDR data is faulty.	If updating SDR does not help, replace the CPU/IO module.

7-6 Troubleshooting

On-screen error message	Cause	Action
0B94 IPMB signal lines do not respond	SMC is faulty.	Replace the CPU/IO module or a system backboard after determining where IPMB error has occurred based on OS information.
0B95 BMC FRU device failure	NVRAM within BMC is faulty.	Replace the CPU/IO module.
0B96 BMC SDR Repository failure	SDR repository within BMC is faulty.	
0B97 BMC SEL device failure	SEL repository within BMC is faulty.	
0B98 BMC RAM test error	BMC RAM is faulty.	
0B99 BMC Fatal hardware error	BMC FPGA is faulty.	If updating FPGA does not help, replace the CPU/IO module or ft Remote Management Card (option).
0B9A BMC not responding	BMC device is faulty.	Replace the CPU/IO module.
0B9B Private I2C bus not responding	I2C bus is faulty.	If turning AC power off and on does not help, replace the CPU/IO module or the system backboard.
0B9C BMC internal exception	BMC device is faulty.	Replace the CPU/IO module.
0B9D BMC A/D timeout error		
0B9E SDR repository corrupt	SDR data is faulty.	If updating SDR does not help, replace the CPU/IO module or ft Remote Management Card (option).
0B9F SEL corrupt	SEL repository within BMC is faulty.	Replace the CPU/IO module.
0BA0 SDR/PIA mismatched. SDR, PIA must be updated.	SDR and PIA data do not match.	If updating SDR/PIA does not help, replace CPU/IO module.
0BB0 SMBIOS - SROM data read error	<ul style="list-style-type: none"> • I2C bus is faulty. • SROM is faulty. • BMC is faulty. 	If turning AC power off and on does not help, replace the system backboard.
0BB1 SMBIOS - SROM data checksum bad	Data within SROM is faulty.	
0BC0 POST detected startup failure of 1st Processor	CPU is faulty.	Replace the CPU.
0BC1 POST detected startup failure of 2nd Processor	CPU is faulty.	
8100 Memory Error detected in DIMM group #1	DIMM is faulty.	Replace the DIMM Slot0 (2 DIMMs).
8101 Memory Error detected in DIMM group #2	DIMM is faulty.	Replace the DIMM Slot1 (2 DIMMs).
8102 Memory Error detected in DIMM group #3	DIMM is faulty.	Replace the DIMM Slot2 (2 DIMMs).
8120 Unsupported DIMM detected in DIMM group #1	Unsupported DIMM is mounted.	Check supported DIMMs and replace them. If replacing the DIMMs does not help, replace the CPU/IO module.
8121 Unsupported DIMM detected in DIMM group #2		

On-screen error message	Cause	Action	
8122 Unsupported DIMM detected in DIMM group #3	Unsupported DIMM is mounted.	Check supported DIMMs and Replace them. If replacing the DIMMs does not help, replace the CPU/IO module.	
8130 Mismatch DIMM detected in DIMM group#1	DIMM group do not match.		
8131 Mismatch DIMM detected in DIMM group#2			
8132 Mismatch DIMM detected in DIMM group#3			
8150 NVRAM Cleared By Jumper	CMOS clear jumper is mounted.	Turn off the DC power and change back the jumper setting.	
8151 Password Cleared By Jumper	Password clear jumper is mounted.		
8160 Mismatch Processor Speed detected on Processor 1	CPU frequency does not match.	Check supported CPUs and replace them. If replacing the CPU does not help, replace CPU/IO module.	
8161 Mismatch Processor Speed detected on Processor 2			
9064 Mixed CPU Steppings detected	Different CPU steppings are found.	Check supported CPUs and replace them. If replacing the CPU does not help, replace CPU/IO module.	
9002 Memory not installed.	DIMM is not implemented. DIMM is faulty.	Mount or replace the DIMM.	
9003 Memory implementation error detected	Error is detected on memory implementation.	Check supported DIMMs and replace the DIMM. If replacing the DIMM does not help, replace the CPU/IO module.	
9006 HW Memory Test failed.	Memory is faulty.	Replace the DIMM. If replacing it does not help, replace the CPU/IO module.	
9000	A serious error occurred during a POST.	There are some error messages in addition to this error code. Check the other error message.	
9090-9097	A memory error has occurred, or memory is faulty.	(a) Verify that the memory is mounted properly. (b) Replace the memory. If this does not help, replace the module.	

Server Management Application Error Message

If the server management tool such as NEC ESMPRO Agent or NEC ESMPRO Manager has been installed in the NEC Express5800/ft series or management PC, you can obtain the error information from the display unit of the server or management PC.

See Chapter 5 or online documentation for details of such application programs.



TROUBLESHOOTING

When the server fails to operate as expected, see the following to find out your problem and follow the given instruction before asking for repair.

If the server still fails to operate successfully after solving your problem, take a note on the on-screen message and contact your sales agent.

Problems with NEC Express5800/ft series

Fail to power on the server:

- Is the server properly supplied with power?
 - Check if the power cord is connected to a power outlet (or UPS) that meets the power specifications for the server.
 - Check if the two pieces of the provided power cord are connected to the main unit properly.
 - Make sure to use the power cord provided with the server. Check the power cord for broken shield or bent plugs.
 - Make sure the power breaker for the connected power outlet is on.
 - If the power cord is plugged to a UPS, make sure the UPS is powered and it supplies power. See the manual that comes with the UPS for details.
- Power supply to the server may be linked with the connected UPS using the BIOS setup utility of the server.
 - <Menu to check: [Server] - [AC-LINK] - [Power On]>
 - Make sure the POWER switch on the power unit is on.
- Did you press the POWER switch?
 - Press the POWER switch on the front of the NEC Express5800/ft series to turn on the power (the POWER LED lights).
- Did you install the CPU/IO module properly?
 - Check if the CPU/IO module is properly installed in the server. Secure the CPU/IO module with screw located on the module removable handle.

POST fails to complete:

- Is the DIMM installed?
 - At least one DIMM is required for operation.
- Is the memory size large?
 - The memory check may take a time if the memory size is large. Wait for a while.
- Did you perform any keyboard or mouse operation immediately after you started the server?
 - If you perform any keyboard or mouse operation immediately after start-up, POST may accidentally detect a keyboard controller error and stops proceeding. In such a case, restart the server once again. Do not perform any keyboard or mouse operation until the BIOS start-up message appears when you restart the server.
- Does the server have appropriate memory boards or PCI card?
 - Operation of the server with unauthorized devices is not guaranteed.

Server reboots while running the Adaptec SAS/SATA Configuration utility:

- Have you modified the Setup settings?
 - From [Server] - [Monitoring Configuration] - [Option ROM Scan Monitoring] of Setup, select “Disabled.” If [Option ROM Scan Monitoring] is enabled, the system may reboot while using the utility. Change back the setting after you finish using the utility.

Fail to access to external devices:

- Are cables properly connected?
 - Make sure that the interface cables and power cord are properly connected. Also make sure that the cables are connected in the correct order.
- Is that device compliant with NEC Express5800/ft series?
 - Operation of the server with unauthorized devices is not guaranteed.
- Is the power-on order correct?
 - When the server has any external devices connected, power on the external devices first, then the server.
- Did you install drivers for connected optional devices?
 - Some optional devices require specific device drivers. Refer to the manual that comes with the device to install its driver.
- Is SCSI controller (including options) configuration correct?
 - If the server has an optional SCSI controller board and SCSI devices are hooked up to the server, make correct settings by the SCSI controller board's SCSI BIOS utility. For details, see manuals included with the SCSI controller board.

CPUs not in Duplex mode:

- Check if the memory configuration is correct.
- Check if third-party CPUs or memory (DIMM) are used.

Disks not in Duplex mode:

- Unless you perform mirroring (including reconfiguration after failed disks are replaced) in correct order, the mirror may not be (re)configured. Check if the steps were correct.

RAID configuration is not automatically resynchronized even though the failed hard disk is replaced:

- Generally, when you replace a failed hard disk, RAID configuration is automatically resynchronized.
 If RAID configuration is not resynchronized automatically, you can resynchronize it manually.
 (See Chapter 3 “Replacing a hard disk drive” for details.)
 Occasionally, the replaced disk may not be recognized.
 If this happens, follow the steps below.

- 1) Remove the disk, wait for approximately 15 seconds and then insert the disk again.
- 2) If the disk is not recognized even after the operation above, stop the PCI module in which the unrecognized disk is installed by using ft server utility, then restart.

See Chapter 3 “Evaluate Startup and Stop of PCI Modules” for information on starting/stopping PCI module.

The keyboard or mouse fails to operate:

- Is the cable properly connected?
 - Make sure that the cable is connected to the correct connector on the rear of the server.
- Are the keyboard and mouse are compliant with NEC Express5800/ft series?
 - Operation of the server with unauthorized devices is not guaranteed.
- Does the server have drivers installed?
 - Refer to the manual that comes with your OS to check that the keyboard and mouse drivers are installed. (These drivers are installed along with the OS.) Some OS's allow you to change the keyboard and mouse settings. Refer to manual that comes with your OS to check that the keyboard and mouse settings are correct.

Screen freezes, keyboard and mouse don't work:

- If the amount of memory is large, it takes time to copy the memory in dual mode and the system stops working temporarily during the copying, but it is not system trouble.

Fail to access (read or write) to the floppy disk:

- Does the floppy disk drive contain a floppy disk?
 - Insert a floppy disk into the floppy disk drive until it clicks.
- Is the floppy disk write-protected?
 - Place the write-protect switch on the floppy disk to the "Write-enabled" position.
- Is the floppy disk formatted?
 - Use a formatted floppy disk or format the floppy disk in the floppy disk drive. Refer to the manual that comes with the OS for formatting a floppy disk.
- Is the medium mounted?
 - If a failover takes place with a medium mounted, the medium is forcefully unmounted, in which case remounting of the medium is necessary.

(An error such as Buffer I/O error may be reported in installing a CPU/IO module or at a fail over. The error is a feature of the device and will not affect the operation.) The device name of the floppy disk drive may change (for example, from sdc to sdb), which is again a feature of the device and will not affect the operation. If the device name has changed, use the new name for mounting.

Fail to access to the optical disk:

- Is the CD-ROM properly set in the DVD-ROM drive tray?
 - The tray is provided with a holder to secure the optical disk. Make sure that the optical disk is placed properly in the holder.
- Isn't the CPU/IO module isolated (i.e. off-line status)?
 - The DVD-ROM drive of an isolate PCI module cannot be used. If you try to mount the DVD-ROM drive of an separated module, the OS displays the following error message.
 mount : special device /dev/scd1 does not exist
- Is the optical disk applicable to the server?
 - The optical disk for Macintosh is not available for use.

Fail to access the hard disk:

- Is the hard disk applicable to the server?
 - Operation of any device that is not authorized by NEC is not guaranteed.
- Is the hard disk properly installed?
 - Make sure to lock the hard disk with the lever on its handle. The hard disk is not connected to the internal connector when it is not completely installed (see Chapter 8). When the hard disk is properly installed, the drive power LED for the hard disk is lit while the server is powered.

Fail to start the OS:

- Is a floppy disk in the floppy disk drive?
 - Take out the floppy disk and restart the server.
- Is the NEC EXPRESSBUILDER DVD-ROM (or the other bootable media) in the DVD-ROM drive?
 - Take out the CD-ROM and restart the server.
- Is the OS damaged?
 - Use the recovery process of the OS to attempt to recover the damaged OS.

OS behavior is unstable:

- Aren't you making access to directory or file in /dev, /proc or /sys?
- The NEC Express5800/ft series frequently saves and updates information related to system operation and management in the following directories. Because accessing any of these directories by a command or other means may impact fault tolerant functions and make behavior of the system unstable, do not access them.
/dev/mem
/proc/kcore
/proc/bus
/proc/ft
/proc/ide
/sys

The system does not operate according to the configured settings of "Automatic Restart" at the occurrence of error.

- The system may or may not restart automatically even if the "Automatic Restart" settings are made at occurrence of an error is set. If the system does not restart automatically, restart it in manual mode.

The server is not found on the network:

- Is the LAN cable connected?
- Make sure to connect the LAN cable to the network port on the rear of the server. Also make sure to use the LAN cable that conforms to the network interface standard.
- Have the protocol and service already configured?
- Install the distinctive network driver for the server. Make sure that the protocol, such as TCP/IP, and services are properly specified.
- Is the transfer speed correct?
- The built-in LAN controller mounted as standard on this server can be used in network with the transfer speed of 1000Mbps, 100Mbps or 10Mbps. You can change the transfer speed or configure the setting from OS. However, do not use the "Auto Detect" function. Fix the setting of the transfer rate to the same with that of the connected hub. Also, check if the duplex mode is the same with that of the connected hub.
The transfer speed can be configured by editing /etc/modprobe.d/ft-network.conf.
The configuration is effective internal network adapters N8804-002 and N8804-005.
When you configure eth100200, for example, add the following description to /etc/modprobe.d/ft-network.conf.
option eth100200 Speed=1000 Duplex=2

Select one of the following three for the speed value.
1000 = 1000Mbps

- 100 = 100Mbps
- 10 = 10Mbps

Select one of the following two for the duplex value.

- 1 = Half duplex
- 2 = Full duplex

Machine repeats rebooting at startup:

- Isn't reset working by the OS boot monitoring function?
 - When you are using the NEC Express5800/ft series, the OS boot monitoring function must be disabled in the following cases. For information on disabling the OS boot monitoring, see "Disable OS Boot Monitoring Function" in page 4-7 of User's Guide (Setup).
 - * The following message is shown on the screen.
 - Give root password for maintenance (or type Control-D to continue):
 - * For the device configuration with large memory or disk volume, it is recommended to set an appropriate value for the BIOS setup from the default 10 minutes.

When the mode changes to the maintenance mode during the boot:

- * The following message is shown on the screen.

Give root password for maintenance (or type Control-D to continue):

- * For the device configuration with large memory or disk volume, it is recommended to set an appropriate value for the BIOS setup from the default 10 minutes.

Disk access LEDs on the disks are off:

- The LEDs may seem to be off when an excessive amount of access causes the frequent blinking. Check if the LEDs are blinking green when the access is reduced.

Memory dump (debug information) cannot be collected when a failure occurs:

- Make sure that the partition (e.g. /var/crash) to which memory dump (debug information) is stored has free disk space that is more than 1.2 times larger than the device-mounted memory size.

Warning message appears in POST after implementing ft Remote Management Card:

- Did you set "Initialize Remote Management Card"?
 - H/W Configuration of BMC is corrupted.
 - !! Update BMC H/W Configuration by configuration tool!!
 - !! Refer to BMC Configuration manual !!

If the message above appears, press **F1** key or wait for a while. Then POST proceeds. Insert NEC EXPRESSBUILDER CD-ROM attached to the server to the DVD-ROM drive to start NEC EXPRESSBUILDER. Select [Tools] - [Initialize Remote Management Card] from its main menu to write the sensor information specific to the server to the card.

A CPU/IO module and/or a disk cannot be integrated:

→ When reinstallation is done due to a failure in a component, the reinstallation may stop with the following message recorded in a log file. If this occurs, MTBF of the component does not reach the threshold and the reinstallation cannot be performed as it is determined that repair is needed. Typically, device replacement is required. Contact your maintenance service engineer. Should any reason requires, you can forcefully reinstall the currently used device through consultation with the maintenance service engineer.

```
- x is now STATE_BROKEN / REASON_BELOW_MTBF  
(x is a device number)
```

Screen under changing (distorted display) can be seen when screen resolution is changed.

→ If screen resolution is changed while the entire system is under high load, screen under changing (distorted display) may be seen. This is because screen update is taking time to complete due to high load in the system. This is not because an error is occurring. The screen will return to normal if you wait awhile.

A white-colored character is displayed on the system console while booting the OS.

→ While booting the system and loading the Logical Volume Manager, one or more block-shaped and white-colored character(s) may appear on the system console. These characters show no sign of a system trouble; but they scroll and disappear as the boot message continues.

Error message appears when booting the OS.

→ The following message appears everytime the OS boot, but this does not indicate the system has a problem.

ACPI Error (evxfevnt-0189): Could not enable RealTimeClock event [20060707]

Problems with NEC EXPRESSBUILDER

When the server is not booted from the NEC EXPRESSBUILDER DVD-ROM, check the following:

- Did you set the NEC EXPRESSBUILDER DVD-ROM during POST and restart the server?
 - If you do not set the NEC EXPRESSBUILDER DVD-ROM during POST and restart the server, an error message will appear or the OS will boot.
- Is BIOS configuration correct?
 - The boot device order may be specified with the BIOS setup utility of the server. Use the BIOS setup utility to change the boot device order to boot the system from the DVD-ROM drive first.
<Menu to check: [Boot]>

When an error occurs while the NEC EXPRESSBUILDER is in progress, the following message appears. After this message appears, check the error and take the appropriate corrective action according to the error codes listed in the table below.

Message	Cause and Remedy
This machine is not supported.	This EXPRESSBUILDER version cannot be used for this server. Execute the NEC EXPRESSBUILDER on the compliant server.
NvRAM access error	Cannot access to the nonvolatile memory (NvRAM).
Hard disk access error	The hard disk is not connected or it is faulty. Check whether the hard disk is correctly connected.
The system-specific information does not exist on the baseboard. Please restore the backup data or write the data by using [System Information Management] of the Off-line Maintenance Utility. Only the authorized personnel are allowed to do this operation.	This message is displayed when NEC EXPRESSBUILDER cannot find device specific information due to the replacement of a motherboard, etc. Maintenance personnel write information using offline maintenance utility.

Problems with Master Control Menu

Failed to read online documentation:

- Is Adobe Acrobat Reader installed properly?
 - A part of online documentation is supplied in PDF file format. Install the Adobe Acrobat Reader (Version 4.05 or later) in your operating system. You can also install the Adobe Acrobat Reader using the NEC EXPRESSBUILDER CD-ROM. Launch the Master Control Menu and select [Setup] - [Adobe Acrobat Reader]. (After installation, launch Adobe Acrobat Reader and agree on license agreement before you use it).

Image of online documentation is not clear:

- Is your display unit set to display 256 colors or more?
 - Set the display unit to display 256 colors or more.

The master control menu fails to appear:

- Is your system Windows NT 4.0 or later, or Windows 95 or later?
 - The CD-ROM Autorun feature is supported by Windows NT 4.0 and Windows 95. The older versions do not automatically start from the CD-ROM.
- Is **Shift** pressed?
 - Setting the CD-ROM with **Shift** pressed down cancels the Autorun feature.
- Is the system in the proper state?
 - The menu may not appear depending on the system registry setting or the timing to set the CD-ROM. In such a case, start the Internet Explorer and run \MC\1ST.EXE in the CD-ROM.

Menu items are grayed out:

- Is your computer environment proper?
 - Some software requires the administrative authority for operation or needs to operate on the server. Use that software in the appropriate computer environment.

Problems with NEC ESMPRO

NEC ESMPRO Manager

→ See Chapter 5. See also online document in NEC EXPRESSBUILDER CD-ROM for troubleshooting and other supplementary information.

NEC ESMPRO Agent

→ See Chapter 5.

COLLECTION OF TROUBLE LOGS

If a failure occurs, you can collect information at the time of failure occurrence by the following ways.

IMPORTANT:

- Collect failure information that is described later only when you are asked to do so by a maintenance service engineer of the maintenance service company.
 - You may see a message telling you the virtual memory is not sufficient in a reboot following a failure. Continue to start up the system. If you perform reset and attempt to restart again, collecting failure information fails.
-

Collection of System Information

IMPORTANT:

If you collect a system information with the below command, verify that the collect-target's disk partition has enough free space. This must be operated as a root user.

When you collect system information in the NEC Express5800/ft series, execute the below command:

```
#!/opt/ft/sbin/buggrabber.pl
```

The collected data will be stored in the following created directory.

```
/home/BugPool/
```

TIPS:

If you change the collect target, add the below option to the above command and execute.

```
--dir=<relative/absolute path to the targeted directory>
```

Collection of the Memory Dump

If a failure occurs, the memory data should be dumped to acquire the required information.

IMPORTANT:

- Collect memory dump through consultation with a maintenance service engineer of your maintenance service company. Collecting memory dump while the system is running successfully can result in a problem in system operation.
- You may see a message telling you the virtual memory is not sufficient in a reboot following a failure. Continue to start up the system. If you perform reset and attempt to restart again, dumping data may fail.
- Press the DUMP switch on the primary CPU/IO module with POWER LED blinking, for four to eight seconds. .
- Use the memory dump collection setting that is automatically configured at the installation of the ft Server Control Software. If you change this setting, proper memory dump collection will not be guaranteed.

Preparing for Memory Dump

Memory dumping with the DUMP switch may disable the server to restart. In such a case, it is required to force the server to shut down.


Saving Dump Files

Press the DUMP (NMI) switch on the primary CPU/IO module to save the dump file when an error occurs. Insert something sharp-pointed like a pen into the switch hole to press the DUMP switch.

Pressing the DUMP switch restarts the system automatically. Wait until the system restores to the duplicated status.

Memory dump is saved to the `/var/crash/` directory. (Memory dumping may not be available when the CPU stalls.)

IMPORTANT: Do not use a toothpick or plastic stick that is easy to break.



(This page is intentionally left blank.)

Chapter 8

System Upgrade

This chapter describes procedures to add options and replace failed components.

IMPORTANT:

- Optional devices described in this chapter should not be installed or removed by the user. NEC does not assume any liability for damage to optional devices or the server or malfunctions of the server resulted from installation by the user.
 - Be sure to use only optional devices and cables designated by NEC. Repair of the server due to malfunctions, failures, or damage resulted from installing undesignated devices or cables will be charged.
-

SAFETY PRECAUTIONS

Observe the following notes to install or remove optional devices safely and properly.

 WARNING
<p>Observe the following instructions to use the server safely. There are risks of death or serious personal injury. See “PRECAUTIONS FOR SAFETY” in Chapter 1 for details.</p> <ul style="list-style-type: none">• Do not disassemble, repair, or alter the server.• Do not look into the DVD-ROM drive.• Do not remove the lithium battery.• Disconnect the power plug before working with the server.

 CAUTION
<p>Observe the following instructions to use the server safely. There are risks of fire, personal injury, or property damage. See “PRECAUTIONS FOR SAFETY” in Chapter 1 for details.</p> <ul style="list-style-type: none">• Do not install or remove components by a single person.• Do not install the server leaving the cover removed.• Make sure to complete component installation.• Do not pinch your finger(s).• High temperature

ANTI-STATIC MEASURES

The server contains electronic components sensitive to static electricity. Avoid failures caused by static electricity when installing or removing any optional devices.

- Wear wrist straps (arm belts or anti-static gloves).

Wear wrist straps on your wrists. If no wrist strap is available, touch an unpainted metal part of the cabinet before touching a component to discharge static electricity from your body.

Touch the metal part regularly when working with components to discharge static electricity.

- Select a suitable workspace.
 - Work with the server on the anti-static or concrete floor.
 - When you work with the server on a carpet where static electricity is likely to be generated, make sure take anti-static measures beforehand.

- Use a worktable.

Place the server on an anti-static mat to work with it.

- Clothes

- Do not wear a wool or synthetic cloth to work with the server.
- Wear anti-static shoes to work with the server.
- Take off any metal accessories you wear (ring, bracelet, or wristwatch) before working with the server.

- Handling of components

- Keep any component in an anti-static bag until you actually install it to the server.
- Hold a component by its edge to avoid touching any terminals or parts.
- To store or carry any component, place it in an anti-static bag.

PRE-UPGRADE VERIFICATION

If you add on optional devices onto this equipment, some devices require specific ft server software version (s).

If the optional asks for specific version number (s), refer to the following procedure before adding on the devices.

- 1.** Confirm the required ft server control software's version, Refer to the sever-accessory User's Guide, check the NEC website, or contact your sales representative.
- 2.** Verify the version of the ft control software on your system.
- 3.** After confirming it as the available version, add the device onto the server.

For more information on how to verify the working ft server utility's, refer to the separate User's Guide (setup) "Confirming the ft Server Control Software Version" (page 5-13).

PREPARING YOUR SYSTEM FOR UPGRADE

Note the following, when installing or replacing devices, to improve the performance of NEC Express5800/ft series.

- With the NEC Express5800/ft series, devices can be replaced during the continuous operation. Take extreme care for electric shock and damage to the component due to short-circuit.
- Optional devices cannot be installed or removed during continuous operation. When you shutdown Linux, check that the server is powered off, disconnect all power cords and interface cables from the server before installing or removing the optional devices.
- To remove the CPU/IO module during the continuous operation, disable the intended module (place the module off-line) by using the ftServer Utility of the NEC ESMPRO Agent or the NEC ESMPRO Manager from the management PC on the network. After a new module is installed to the server, enable the module using the ftServer Utility or the NEC ESMPRO Manager.

TIPS:

The system is defaulted to automatically boot the module, once installed. For more information, see Chapter 5.

- Make sure to provide the same hardware configuration on both CPU/IO modules (except SCSI board).
- Use the same slots and sockets on both groups.
- Do not install those devices having different specifications, performance, or features.
- Before removing the set screws from the CPU/IO modules, place the desired module off-line using the ftServer Utility or the NEC ESMPRO Manager.

3.5-INCH HARD DISK DRIVE


The 3.5-inch hard disk drive bay in front of the server contains six slots in which hard disks with the SAS interface are installed.

IMPORTANT:

Do not use any hard disks that are not authorized by NEC. Installing a third-party hard disk may cause a failure of the server as well as the hard disk. Purchase hard disks of the same model in pair. Contact your sales agent for hard disk drives optimum for your server.

You can install 25.4mm (1-inch) high hard disk drives to six 3.5-inch hard disk drive bays on the server.

The hard disk drives installed on the slot 1, 2, and 3 of the CPU/IO module 0 and 1 are mirrored respectively. (The OS is installed on the mirror volumes that consist of the hard disks in the slot 1.)



Empty slots in the 3.5-inch hard disk drive bay contain dummy trays. The dummy trays are inserted to improve the cooling effect within the device. Always insert the dummy trays in the slots in which hard disks are not installed.

Installing 3.5-inch Hard Disk Drive

Follow the procedure below to install the hard disk. A hard disk may be installed in another slot in the same procedure.

IMPORTANT:


- Refer to “ANTI-STATIC MEASURES” and “PREPARING YOUR SYSTEM FOR UPGRADE” before starting installing or removing options.
 - You must mount two HDDs that form dual disk configuration before starting Linux.
-

1. Shut down Linux. The system turns off automatically.
2. Remove the front bezel.

3. Identify the slot to which you want to install the hard disk drive.

Install a hard disk in an empty slot in the group, starting from the lower slot. (In the order of slot 1, slot 2, and slot 3 in CPU/IO module 0 and 1)

4. Pull the lever toward you while pushing the green lock of the dummy tray to the left.



5. Hold the handle of the dummy tray to remove the tray.


IMPORTANT:

Keep and store the dummy tray with care.


TIPS:

The lever on the slot 3 may be hard to pull toward you. This does not become a problem for proper operation.

6. Unlock the hard disk to be added.




you.



7. Firmly hold the handle of the hard disk to install and insert the hard disk into the slot.

TIPS:

- Insert the disk until the lever hook touches the server frame.
- Check the orientation of lever. Insert the hard disk with the lever unlocked.



8. Slowly close the lever.


When the lever is locked, you will hear a click sound.

IMPORTANT:

Be careful not to pinch your finger(s) between the lever and handle.

TIPS:

Check the hook of the lever is engaged with the frame.



9. Press the POWER switch to power on.
10. Install the front bezel.
11. Set the dual disk configuration (see “Step 8: Set Dual Disk Configuration” in Chapter 4 in the User’s Guide (Setup)).


Removing 3.5-inch Hard Disk Drive

Follow the procedure below to remove the hard disk.

IMPORTANT:


Make sure to read “ANTI-STATIC MEASURES” and “PREPARING YOUR SYSTEM FOR UPGRADE” before you take the following procedures.

1. Shut down Linux.
The system turns off automatically.
2. Remove the front bezel.
3. Push the lever of the hard disk to unlock the handle.



4. Hold the handle and hard disk to pull them off.
5. Install the dummy tray in an empty tray according to procedures described in "Installation".

Make sure to install the dummy slot in the empty slot to improve the cooling effect within the device.



TIPS:

It may not be easy to pull the lever of slot 3 toward you, but it will not cause a problem for operation.

Replacing 3.5-inch Hard Disk Drive

Follow the procedure below to remove the failed hard disk. If the hard disk fails, it should be replaced with new device with the server powered-on.

IMPORTANT:

Make sure to read “ANTI-STATIC MEASURES” and “PREPARING YOUR SYSTEM FOR UPGRADE.” You can replace disks during continuous operation.

Replacing the Hard Disk Drive

1. Locate the failed hard disk.

When a hard disk fails, the DISK ACCESS LED on the hard disk drive’s handle illuminates amber.

2. Remove the failed hard disk referring to “Replacing Failed Hard Disk Drives” on page 3-21 and “Removing 3.5-inch Hard Disk Drive” on page 8-9.

No need to shut down Linux.

3. Refer to the steps in “Installing 3.5-inch Hard Disk Drive” to install a new hard disk.

CHECK:

- The hard disk to be installed for replacement must have the same specifications as its mirroring hard disk.
 - After disk physical format, refer to “Disk Operation” in Chapter 3 and restore the dual configuration. For physical format, see “SAS BIOS Adaptec SAS/SATA Configuration Utility” in Chapter 4, “System Configuration,” and format disks with Disk Utilities. To format disks, select “Server,” “Monitoring Configuration” and set “Option ROM Scan Monitoring” to Disabled.” For how to configure the setting, see “System BIOS SETUP ” in Chapter 4, “System Configuration.”
-
4. Restore the redundant configuration (see Chapter 3).

CPU/IO MODULE

To replace a CPU (processor, DIMM (memory), PCI card, you need to remove the CPU/IO module.

IMPORTANT:

- Ask your sales agent to replace the CPU/IO module and components of the CPU/IO module.
 - Make sure to read “ANTI-STATIC MEASURES” and “PREPARING YOUR SYSTEM FOR UPGRADE.”
 - To install or remove CPU or DIMM, first power off the server before removing the CPU/IO module.
 - Removing the module being operating may cause unexpected trouble. Use the management software (e.g., ftServer Utility or NEC ESMPRO Manager) to identify the module to be removed so that the module is removed when it is stopped, without fail. Then remove the relevant module after verifying the Status LED on the CPU/IO module. See Chapter 2 “LEDs” for details of the Status LED.
-

Precautions

When replacing both CPU/IO modules, replace one module and wait until dual configuration is established to replace the other module. If you replace the both modules simultaneously, establishing dual CPU/IO module configuration can result in interruption of the whole system.


Removing CPU/IO Module

Follow the procedure below to remove the CPU/IO module.

1. Stop the CPU/IO module you want to remove.


To this end, use the ftServer Utility of the NEC ESMPRO Agent installed to your server or the Data Viewer of the NEC ESMPRO Manager.

For the detailed procedure, see “NEC ESMPRO Agent and Manager” – “Maintenance of NEC Express5800/ft series” in Chapter 5.



NEC ESMPRO Manager

Select [ft] - [CPU Module] - [CPU Module (to be removed)] - [Maintenance] - [Bring Up/Bring Down] - [Bring Down].



Select [FTServer] - [CPU Module] - [CPU Module (to be removed)] - [CPU Module Start/Stop] - [Down].

Repeat the operation mentioned above for the IO module (PCI module) and confirm that the status of the CPU/IO module and the IO module (PCI module) are “offline”

TIPS:


When removing CPU/IO modules 0, select [Bring Down] for CPU module (ID:0) and PCI module (ID:10)

2. Remove the front bezel

3. Hold the stopper, and disconnect the power cable of the module to be removed. The stopper will return to the vertical position when you release it.

CHECK:

Leave your hands and make sure that the stopper returned to the vertical position. If you disconnect the cable and the stopper does not go back to this position, you cannot pull out the CPU/IO module in the next step.




4. Loosen the screws securing the CPU/IO module handle to press down the handle.

IMPORTANT:

Before you pull out a CPU/IO module, check the rear of the server to make sure cables for connection with peripheral equipment or network are disconnected. If any cables are connected, keep a record of where the cables are connected and disconnect all cables connected to the module you are to pull out.

TIPS:


If you cannot disconnect the LAN cable easily, disconnect while pressing the latch with a slotted screwdriver.




5. Hold the black levers of the CPU/IO module and pull it off. Pull it off until it is locked and stopped.

IMPORTANT:

- Do not hold part other than the handle to pull the module.
- Handle the CPU/IO module carefully. Do not drop the module or bump it against parts in the device when you remove it.



6. The CPU/IO module is locked on the way and cannot be pulled out. Lower the lock on the side of CPU/IO module and unlock it, and then pull it out.



7. Pull out the CPU/IO module gently and carefully place it on a flat and sturdy table. Avoid the dusty or humid place.

This allows you to access the devices in the CPU/IO module. For more information on how to handle these devices, see the associated sections.

Installing CPU/IO Module

Follow the procedure below to install the CPU/IO module:


IMPORTANT:

Make sure to read “ANTI-STATIC MEASURES” and “PREPARING YOUR SYSTEM FOR UPGRADE.”


Insert the black lever slowly and fasten the screws tightly. Be careful not to cause a shock to the device at this time.

1. Firmly hold the CPU/IO module with both hands and insert it into the rack.

Hold the CPU/IO module in such a way that its back panel connector faces the back of the rack and engage the guides of the module and chassis, and insert it slowly.



2. Push up the black levers placed on the left and right sides of the front of the CPU/IO module, and fasten them with screws.



IMPORTANT:

- Secure the handle with the screws. If it is not secured by the screws, the operation of the CPU/IO module will be unstable.
 - In some system statuses or settings, auto start up or integration does not take place when the module is connected. In such a case, check the status by using the ftServer Utility or NEC ESMPRO Manager data viewer, and then start up the CPU/IO modules.
-
3. Connect the cables for connecting the peripheral devices and network.
 4. Hold the stopper with your hand and insert the cable of the installed module.
 5. The installed CPU/IO module will be automatically started.

DIMM

The DIMM (dual inline memory module) is installed to the DIMM socket in the CPU/IO module on the NEC Express5800/ft series.

The CPU/IO module board is equipped with six sockets.


DIMMs should be installed in a set of 2 DIMMs, starting from the lowest socket number.

TIPS:

- You can add memory up to 24 GB (4GB x 6). In the error messages and logs in POST NEC ESMPRO, or Off-line Maintenance Utility, the DIMM connector may be described as “group.” The number next to “group” corresponds to the slot number shown in the figure on the next page.

IMPORTANT:

- The DIMM is extremely sensitive to static electricity. Make sure to touch the metal frame of the server to discharge static electricity from your body before handling the DIMM. Do not touch the DIMM terminals or onboard parts with a bare hand or place the DIMM directly on the desk. For more information on static electricity, see “ANTI-STATIC MEASURES.”
- Make sure to use the DIMM authorized by NEC. Installing a third-party DIMM may cause a failure of the DIMM as well as the server. Repair of the server due to failures or damage resulted from installing such a board will be charged.
- Before adding or removing DIMMs, power off the server and detach the CPU/IO module.
- Make sure to read “ANTI-STATIC MEASURES” and “PREPARING YOUR SYSTEM FOR UPGRADE” before installing/removing DIMM.



Motherboard of the CPU/IO module

Precautions


Note the following to install or replace DIMM.

- The DIMMs with the same slot number are linked between the CH1 and CH0.. When a DIMM is added to one CH, another identical DIMM should be installed to the slot with the same number in another CH. This rule is applied to the case of removal.
- The linked DIMMs between CHs should be of the same product with the same performance.
- DIMMs should be installed in sockets from the lowest slot number to the highest slot number.
- To install DIMM, install the product with the same serial number to the same CHs and slots of the CPU/IO modules 0 and 1.


Installing DIMM

Follow the procedure below to install the DIMM.

1. Shut down OS.
The sever turns off automatically.
2. Disconnect the power cords from the outlets.
3. Remove the CPU/IO module referring to page 8-12.
4. Remove the screw, and remove the top cover of the CPU/IO module.



5. Remove the memory duct.



6. Check to be sure in which socket you are mounting the DIMM

7. Remove the DIMM connector cover from the socket in which the DIMM is installed.

A DIMM connector cover is installed to the open socket. When the levers on both ends of the connector are opened, the DIMM connector cover is unlocked and you can remove the cover.

IMPORTANT:

Keep the removed DIMM connector cover.



8. Insert a DIMM into the DIMM socket vertically.

TIPS:

Pay attention to the orientation of the DIMM. The terminal of the DIMM has a cutout to prevent wrong insertion.

After the DIMM is completely inserted into the socket, the levers are automatically closed.

9. Attach the memory duct
10. Place the top cover of the CPU/IO module and secure it with the screws.



11. Refer to page 8-15 and install the CPU/IO module.
12. Connect the power cords.
13. Press the POWER switch to power on the server.
14. Verify that POST displays no error message.

If POST displays an error message, write it down and see the POST error message list on page 7-4.

15. After starting the OS, set the paging file size to at least the recommended value (1.5 times the installed memory size). (See “Size of the Partition to be Created” in Chapter 4 of the User’s Guide (Setup).)


Removing DIMM

Follow the procedure below to remove the DIMM.


IMPORTANT:

This server works only when there are at least two DIMMs installed.


- 1.** Shutdown OS.
The system turns off automatically.
- 2.** Disconnect the power cords from the outlets.
- 3.** Remove the CPU/IO module referring to page 8-12.
- 4.** Remove the screws and the top cover of the CPU/IO module.




- 5.** Remove the memory duct.



6. Open the levers attached on both sides of the socket of the DIMM to be removed. It will be unlocked and the DIMM can be removed.




7. Attach the memory duct.
8. Attach the top cover of the CPU/IO module and secure it with screws.



9. Refer to page 8-15 and install the CPU/IO module.
10. Connect the power cords.
11. Press the POWER switch to power on the server.
12. Verify that POST displays no error message.
If POST displays an error message, write it down and see the POST error message list on page 7-4.

Replacing DIMM

Follow the procedure below to replace a failed DIMM.




1. Identify the failed DIMM using the Data Viewer of NEC ESMPRO Manager.
2. Remove the CPU/IO module referring to page 8-12.
3. Replace the DIMM.
4. Install the CPU/IO module referring to page 8-15.
5. Start up the CPU/IO module using the Data Viewer of NEC ESMPRO Manager or ftServer Utility.

PROCESSOR (CPU)

In addition to the standard CPU (Quad-Core Intel® Xeon™ Processor), you can operate the system by adding one CPU.

IMPORTANT:


- The CPU is extremely sensitive to static electricity. Make sure to touch the metal frame of the server to discharge static electricity from your body before handling the CPU. Do not touch the CPU terminals or onboard parts with a bare hand or place the CPU directly on the desk. For more information on static electricity, see “ANTI-STATIC MEASURES.”
- Do not use the system before checking to see it works correctly.
- Make sure to use the CPU specified by NEC. Installing a third-party CPU may cause a failure of the CPU as well as the server. Repairing the server due to failures or damage resulting from these products will be charged even if it is under guarantee.
- Before adding or removing a CPU, power off the server and then remove the CPU/IO module.



Installing CPU

Follow the steps below to install a CPU (model with air-cooling kit).


1. Shut down the OS.
The server is automatically powered off.
2. Unplug the power cords.
3. Remove the CPU/IO module referring to page 8-12.
4. Remove the cable connected to the CPU duct cover.




IMPORTANT:

Remove the cable without adding pressure to the bases of the fan cable.

5. Remove the CPU duct cover.




6. Check to be sure of the location of the CPU socket.



7. Detach the socket cover on the CPU socket.


IMPORTANT: Keep the socket cover.

8. Lift the socket lever.



IMPORTANT: Open the lever fully. It can be opened 120° or more.


9. Lift the CPU socket holder.




10. Place the CPU on the socket carefully.

TIPS:


Pay attention to the orientation of the CPU. The CPU and socket have pin marks to prevent wrong insertion. Check the pin marks of the CPU and the socket and insert the CPU correctly.




11. After pressing the CPU softly against the socket, place the CPU socket holder back to its original place.



12. Return the socket lever back to its original place.




13. Place the heat sink on the CPU and secure it with 4 screws. Loosely fasten the screws in the cross-coupling way, and then fasten them tightly.



IMPORTANT:

Place the heat sink so that its corners will not bump against the parts on the motherboard.



14. Check that the heat sink is attached to the motherboard horizontally.

IMPORTANT:

- If the heat sink is tilted, remove the heat sink and then attach it again.
If the heat sink is not attached horizontally, it may be caused by the following.
 - The CPU is not attached correctly.
 - Screws are not secured tightly enough.
- Do not move around the heat sink fastened.

15. Connect the duct cover.
16. Fasten the cable to the duct cover.
17. Refer to page 8-15 and attach install the CPU/IO module.
18. Connect the power cord.
19. Turn on the power by pressing the POWER switch.
20. Verify that POST displays no error message. If an error message is displayed, write it down and check it in the error message list on page 7-4.

Removing CPU

Removal of a heat sink and CPU is the reverse procedure of installation.

PCI BOARD

Up to three PCI boards can be installed to the CPU/IO module.


IMPORTANT:

- The PCI board is extremely sensitive to static electricity. Make sure to touch the metal frame of the server to discharge static electricity from your body before handling the PCI board. Do not touch the PCI board terminals or onboard parts by a bare hand or place the PCI board directly on the desk. For more information on static electricity, see "ANTI-STATIC MEASURES" on page 8-3.
 - Make sure to read "ANTI-STATIC MEASURES" and "PREPARING YOUR SYSTEM FOR UPGRADE."
-

Note the following to install or replace PCI board.

- To make a dual PCI board configuration, install the same type of board (i.e., having the same specifications and performance) to the same slot for each group.

When a PCI board is installed to one group, another identical PCI board should be installed to the same slot in another group. This rule is applied to the case of removal.



8-30 System Upgrade

List of option PCI boards and installable slots:

N-code	Product name	PCI-1		PCI-2		PCI-3		Remarks
		PCI-X	PCI-X	PCI Express	PCI Express	PCI-X	PCI-X	
		133MHz/64bit	133MHz/64bit	X4 lane	X4 lane	133MHz/64bit	133MHz/64bit	
		Low Profile	Low Profile	Full Height	Full Height			
PCI board type	3.3V	x8 socket	x8 socket	3.3V	3.3V			
Mountable board size	MD2	Full Size	Full Size					
N8804-002	1000BASE-T 1ch board set	○						Mount exactly the same board into the same slot on each CPU/IO module 0, 1.
N8804-003	1000BASE-SX 1ch board set	○						Up to 1 board when N8804-005 or N8803-035 is already mounted..
N8804-005	1000BASE-T 2ch board set					○		Up to 1 board. Mount exactly the same board into the same slot on each CPU/IO module 0, 1. Up to 2 boards can be mounted when combined with other boards. But this board must not be mixed with N8804-005 or N8803-035.
N8803-032	SCSI board	○				○		Up to 1 board.
N8803-035	Fibre Channel board set			○				Mount exactly the same board into the same slot on each CPU/IO module 0, 1. Up to 2 boards can be mounted when combined with other boards. But this board must not be mixed with N8804-005 or N8803-035.

Installing PCI Board

Follow the procedure below to install the board to be connected to the PCI board slot.

TIPS:


To install the PCI board, make sure the shape of the board connector matches with the shape of the PCI board slot connector.

1. Remove the CPU/IO module referring to the page 8-12.


The following steps explain how to install a PCI board on the PCI board slot (PCI-X slot 2, PCI-X slot 3) of the riser card.

Go to step 10 to install a PCI board on the PCI board slot (PCI-X slot 1).


2. Disconnect the cable from the connector of the riser card.




3. Loosen a fixed screw on the PCI stopper on the rear side of the device, and remove the PCI stopper.




4. Loosen the 3 fixed screws on the PCI bracket on the rear side of the device, and remove the PCI bracket.



5. Remove the riser card from the motherboard.




6. Insert an optional PCI board into the PCI slot of the riser card.




7. Remove the bracket cover from the PCI bracket.

IMPORTANT:


Carefully keep the removed PCI bracket.




8. Install the riser card on which the PCI board is installed on the motherboard.



9. Fix screws on the PCI stopper on the rear side of the device, and slide to attach the PCI stopper.




10. Secure the PCI brackets with 3 screws.




11. Connect the disconnected cable to the connector of the riser card.

IMPORTANT:


Connect the cable to the connector on the lower part.



- 12.** Loosen the fixed screw on the bracket cover that corresponds to another PCI slot that is hidden behind the riser card, and remove the bracket cover.



- 13.** Install the optional PCI board to another PCI slot hidden behind the riser card.



- 14.** Secure the PCI board with a fixed screw.

Removing PCI Board

To remove PCI board card, follow the reverse procedure of the installation and install the expansion slot cover.

Replacing PCI Board

Follow the procedure below to replace the failed PCI board.

- 1.** Check the failed board from the event log.
- 2.** Remove the CPU/IO module referring to the page 8-12.
- 3.** Remove the PCI bracket, then remove the PCI board.
- 4.** Replace the board and fasten it.
- 5.** Install the CPU/IO module referring to the page 8-15.
- 6.** Connect the network cable and cables for PCI boards.
- 7.** The installed CPU/IO module will start automatically.
- 8.** Confirm that the PCI board is correctly recognized by POST and OS.

Setup of Optional PCI Board

IMPORTANT:

- To enable the fault-tolerant feature of the optional device, the identical PCI boards must be installed to the slots with the same number in CPU/IO module 0 and CPU/IO module 1.
- The BIOS settings need to be modified when mounting some optional PCI boards. To change the BIOS settings, start the BIOS setup utility to change the [OS Boot Monitoring] configuration in [Server] – [Monitoring Configuration]. See page 4-24 for more details.
- For the supported connecting devices, contact your sales agent.

N8804-002 1000BASE-T 1ch board set

N8804-003 1000BASE-SX 1ch board set

N8804-005 1000BASE-T 2ch board set

IMPORTANT:

For LAN cable's connector, use a RJ-45 connector which is compliant with IEC8877 standard. If any other connector is used, it may not be removed easily.

- List of slots to install optional PCI boards
 - Refer to “List of option PCI boards and installable slots” on page 8-30.
 - Driver installation procedure
- You do not need to install drivers for N8804-002, N8804-003 and N8804-005 boards because they are included in the OS. After installing the boards, refer to 3-9 “Dual LAN Configuration” to set the dual LAN.

N8803-032 SCSI Board

- The lists of slots to install optional PCI boards

Refer to the table “List of option PCI boards and installable slots” on page 8-30.

- Driver installation procedure

You do not need the driver for N8803-032 because it is included in the OS. After installing the board, confirm the following directory exists by using the ls command.

```
/proc/scsi/aic79xx
```

If the directory above is not created, the board is recognized inappropriately.
(This directory exists only when the board is installed.)

N8803-035 Fibre Channel Board Set

- List of slots to install optional PCI boards

“List of option PCI boards and installable slots:” on page 8-30.

- Driver installation procedure

You do not need to install the driver for N8803-035 because it is included in the OS. However, you may need to add the following contents into /etc/modprobe.conf depending in your environment.

```
<N8190-119>
```

```
options lpfc lpfc_topology=0
```

```
<Other cases>
```

```
options lpfc lpfc_topology=6
```

After configuring above, use the following command to reboot the system.

```
(1) #sync
```

```
(2) #reboot
```

- Configure redundant path

IMPORTANT:

This must be operated by root user.

1. Execute the following command to create the multi-path device.
multipath

This command creates the dm device of md-N and the dm-mp device (symbol click of the dm device) of the mapper/mpathN, mapper/mpathNpM(N and M are value other than 1). This procedure virtualizes the sd device of the FibreChannel into dm-mp device on each path. Since the dm device is not apart from the whole devices, the dm-mp device is used. The mpathN indicates this is the Nth LUN, and the mpathNpM indicates the Mth partition of mpathN.

2. Execute the following command to start the path monitoring daemon (multipathd).
chkconfig multipathd on
/etc/init.d/multipathd start

3. Execute the following command to confirm the path status.
multipath -l

You can confirm the path status of each dm-mp device.

- Environment change during operation

- Partition change

Execute fdisk for the virtualized /dev/mapper/mpathN(N is value other than 1).

You need to reboot the OS to apply the changes on the system.

- Add/change/delete LUN

Reboot the OS to apply the changes on the system.

N8815-005/006 ft Remote Management Card


Each CPU/IO module can mount one ft Remote Management Card.

IMPORTANT:


- The ft Remote Management Card is extremely sensitive to static electricity. Make sure to touch the metal frame of the server to discharge static electricity from your body before handling the card. Do not touch the card terminals or onboard parts with a bare hand or place the card directly on the desk. For more information on static electricity, see “ANTI-STATIC MEASURES.”
- Make sure to read “ANTI-STATIC MEASURES” and “PREPARING YOUR SYSTEM FOR UPGRADE” before mounting the ft Remote Management Card.

Mounting the ft Remote Management Card


1. Refer to 8-12 and remove the CPU/IO module.
2. Hitch the bracket to a hole on the back of the 2U chassis and fix with a flat head screw.




3. Mount the ft Remote Management Card.



4. Fix the card and the bracket with a screw.




5. Remove the blank cover by removing the screw.




6. Put a LAN cable through a hole from outside the server and plug the LAN connector (the bigger connector) to the back of the chassis.


Make sure you see two hooks on the both sides of the LAN connector and hear the snap sound as you fix the LAN connector.



7. Attach the smaller connector to the LAN connector on the fit Remote Management card.



8. Attach the below label above the LAN connector on the outside of the chassis.



(This page is intentionally left blank.)

Appendix A

Specifications

Item	NEC Express5800/320Fd-LR N8800-124F	NEC Express5800/320Fd-MR N8800-125F
Factory-set model	Install model	
CPU	Type	Quad-Core Intel® Xeon® Processor 2.00GHz
	Clock/second cache	1333MHz/4MB x 2
	Number of processors	1 processor (the number of processors installed per module)
	Standard	Up to 1 processors (the number of processors installed per module)
Maximum	Up to 2 processors (the number of processors installed per module)	
Chipset	Intel Blackford + ESB2M	
Memory	Standard	2GB (1GB x 2*)
	Maximum	* the number of memory per module
	Expansion unit	24GB (The standard DIMM must be replaced.)
	Memory module	2 DIMMs
Error check	DDR II SDRAM DIMM (Fully Buffered)	
Graphics (VRAM)	ECC	
Auxiliary input device	ATI ES1000	
File bay (3.5 inch)	Floppy disk (option)	3.5 inch drive x 1 (USB)
	DVD-ROM (standard)	DVD Combo (Load type: tray. Speed: x6)
	Hard disk (standard)	None
	Hard disk (maximum)	1.8TB* (300GB x 6)
Additional slot	* The user area is reduced to a half of the physical capacity due to software mirroring.	
LAN interface	6 slots	
External interface	1 slot (Low profile : PCI-X 133MHz, 64 bit), 1 slot (Full height, full length : PCI-X 100MHz, 64 bit), 1 slot (PCI-Express x4 lane x8)	
Cabinet design	USB	1000BASE-T/100BASE-TX/10BASE-T (2 ports)
	Network	4-pin connector (3 ports) Keyboard occupies one port.
External dimensions	Display	RJ-45 (2 ports)
	Weight	MINI D-sub 5-pin (1 port)
Power supply	Rack-mount type	
Power consumption	483 (w) x 178 (h) x 762 (d) mm	
Environmental requirements	In operation	47.5 kg (Max. 53.5kg)
	In storage	100-127 / 200-240 VAC ±10%, 50/60 Hz ±1 Hz
Supported OS	1202VA / 1200W	
	Temperature 10 to 35°C/Humidity 20 to 80% RH (non-condensing)	
	Temperature -10 to 55°C/Humidity 20 to 80% RH (non-condensing)	
	Red Hat Enterprise Linux Advanced Platform 64bit	

Appendix B

I/O Port Addresses

The factory-set I/O port addresses for the server are assigned as follows:

Address	Chip in Use
0x00000000-0x000000CF7	Direct memory access controller
0x00000010-0x0000001F	Motherboard resources
0x00000020-0x00000021	Programmable interrupt controller
0x00000024-0x00000025	Motherboard resources
0x00000028-0x00000029	Motherboard resources
0x0000002C-0x0000002D	Motherboard resources
0x0000002E-0x0000002F	Motherboard resources
0x00000030-0x00000037	Motherboard resources
0x00000038-0x00000039	Motherboard resources
0x0000003C-0x0000003D	Motherboard resources
0x00000040-0x00000043	System timer
0x00000050-0x00000053	Motherboard resources
0x00000060-0x00000060	Motherboard resources
0x00000061-0x00000061	System speaker
0x00000062-0x00000063	Motherboard resources
0x00000064-0x00000064	Motherboard resources
0x00000066-0x00000067	Motherboard resources
0x00000070-0x00000073	System CMOS/real time clock
0x00000074-0x00000077	Motherboard resources
0x00000080-0x00000080	Motherboard resources
0x00000081-0x0000008F	Direct memory access controller
0x00000090-0x0000009F	Motherboard resources
0x000000A0-0x000000A1	Programmable interrupt controller
0x000000A4-0x000000A5	Motherboard resources
0x000000A8-0x000000A9	Motherboard resources
0x000000AC-0x000000AD	Motherboard resources
0x000000B0-0x000000B5	Motherboard resources
0x000000B8-0x000000B9	Motherboard resources
0x000000BC-0x000000BD	Motherboard resources
0x000000C0-0x000000DF	Direct memory access controller
0x000000E0-0x000000E3	Motherboard resources
0x000000E4-0x000000E6	Stratus BMC Device
0x000000E7-0x000000EF	Motherboard resources
0x00000120-0x00000120	Stratus Virtual ATI Video
0x00000274-0x00000277	ISAPNP Read Data Port
0x00000279-0x00000279	ISAPNP Read Data Port
0x000002F8-0x000002FF	Communications Port (COM2)
0x000003B0-0x000003BB	PCI standard PCI-to-PCI bridge
0x000003B0-0x000003BB	Stratus Fault Tolerant North PCI to PCI Bridge
0x000003B0-0x000003BB	Stratus Fault Tolerant East/West PCI to PCI Bridge
0x000003B0-0x000003BB	Stratus Fault Tolerant Core

B-2 I/O Port Addresses

Address	Chip in Use
0x000003B0-0x000003BB	Intel(R) 82801 PCI Bridge - 244E
0x000003B0-0x000003BB	Stratus Virtual ATI Video
0x000003C0-0x000003DF	PCI standard PCI-to-PCI bridge
0x000003C0-0x000003DF	Stratus Fault Tolerant North PCI to PCI Bridge
0x000003C0-0x000003DF	Stratus Fault Tolerant East/West PCI to PCI Bridge
0x000003C0-0x000003DF	Stratus Fault Tolerant Core
0x000003C0-0x000003DF	Intel(R) 82801 PCI Bridge - 244E
0x000003C0-0x000003DF	Stratus Virtual ATI Video
0x0000040B-0x0000040B	Direct memory access controller
0x000004D0-0x000004D1	Programmable interrupt controller
0x000004D6-0x000004D6	Direct memory access controller
0x00000500-0x0000057F	Motherboard resources
0x00000580-0x0000059F	Motherboard resources
0x000005A0-0x000005BF	Motherboard resources
0x00000A79-0x00000A79	ISAPNP Read Data Port
0x00000C00-0x00000C01	Programmable interrupt controller
0x00000CA2-0x00000CA2	Stratus BMC Device
0x00000CA3-0x00000CA3	Stratus BMC Device
0x00000CA4-0x00000CA7	Stratus BMC Device

N8800-124F, EXP320J
NEC Express5800/320Fd-LR
N8800-125F, EXP320K
NEC Express5800/320Fd-MR
User's Guide

2nd Edition
10-2008
856-127506-121-B