

Microsoft® Windows Server® 2008 Standard/ Microsoft® Windows Server® 2008 Enterprise

Installation Guide

for NEC Express5800/110Ge, i120Ra-e1, 140Rf-4

PROPRIETARY NOTICE AND LIABILITY DISCLAIMER

The information disclosed in this document, including all designs and related materials, is the valuable property of NEC Corporation (NEC) and /or its licensors. NEC and/or its licensors, as appropriate, reserve all patent, copyright and other proprietary rights to this document, including all design, manufacturing, reproduction, use, and sales rights thereto, except to the extent said rights are expressly granted to others.

The NEC product(s) discussed in this document are warranted in accordance with the terms of the Warranty Statement accompanying each product. However, actual performance of each such product is dependent upon factors such as system configuration, customer data, and operator control. Since implementation by customers of each product may vary, the suitability of specific product configurations and applications must be determined by the customer and is not warranted by NEC.

To allow for design and specification improvements, the information in this document is subject to change at any time, without notice. Reproduction of this document or portions thereof without prior written approval of NEC is prohibited.

Microsoft, Windows, Windows Server, Active Directory, and Hyper-V are registered trademarks or trademarks of Microsoft Corporation in the United States and other countries. All other product, brand, or trade names used in this publication are the trademarks or registered trademarks of their respective trademark owners.

Copyright 2008
NEC Corporation
7-1 Shiba 5-Chome, Minato-Ku
Tokyo 108-8001, Japan
All Rights Reserved
Printed in Japan

Contents

1. Overview.....	1
2. Before You Start.....	2
Prerequisites for Installing Windows Server 2008	2
Downloading a Driver Set	2
3. Important Instructions.....	3
Windows Activation	3
Supported Optional Boards.....	3
NEC Express5800/140Rf-4	3
NEC Express5800/i120Ra-e1	4
NEC Express5800/110Ge	4
Updating Your System.....	5
Installing on the Mirrored Volume.....	5
MO Drive.....	5
Tape Media	5
Peripheral Devices such as RDX.....	5
BIOS Update.....	5
RAID Configuration	6
About the System Partition Size	7
Windows Server 2008 64-bit (x64) Edition.....	7
Windows Server 2008 32-bit (x86) Edition.....	8
BitLocker	9
NEC ESM PRO	9
4. Installing Windows Server 2008	10
5. Updating the System	20
6. Installing Drivers and Configuring Driver Settings	22
LAN Driver and PROSet.....	22
Using N8104-125 Adapter after System Update	22
Optional Network Boards	23
Adapter Fault Tolerance (AFT)/ Adaptive Load Balancing (ALB).....	24
<Creating a Team>	24
<Removing a Team>.....	25
Network Driver.....	25
Changing a link speed.....	25
SCSI Controller N8103-75/95/107	26
When Using Disk Array Controller (N8103-90)	26
Fibre Channel Controller N8190-127/131	26
Graphics Accelerator	26
7. Setting for Solving Problems	27
Memory Dump (Debug Information)	27
How to Create a User-mode Process Dump File	33
Network Monitor Setup	34
Network Trace Capture.....	34

8. Activating Windows.....	35
For a Server Running a Full Installation.....	35
For a Server Running a Server Core Installation	38
9. Troubleshooting.....	40
10. Upgrading to Windows Server 2008	43
Overview	43
Before You Upgrade	44
Important Instructions.....	44
Graphic Accelerator Driv3r.....	45
PROSet	45
Upgrading Windows	46
Installing Drivers after Upgrade	51

Introduction

This document provides step-by-step guidance for installing Microsoft® Windows Server® 2008 Standard Edition and Microsoft® Windows Server® 2008 Enterprise Edition ("Windows Server 2008") on the NEC Express5800/110Ge, i120Ra-e1, 140Rf-4 servers.

Before you install Windows Server 2008, read this document carefully.

<Windows Server 2008 >

- Microsoft® Windows Server® 2008 Standard 64-bit (x64) Edition
- Microsoft® Windows Server® 2008 Enterprise 64-bit (x64) Edition
- Microsoft® Windows Server® 2008 Standard 32-bit (x86) Edition
- Microsoft® Windows Server® 2008 Enterprise 32-bit (x86) Edition
- Microsoft® Windows Server® 2008 Standard without Hyper-V™ 64-bit (x64) Edition
- Microsoft® Windows Server® 2008 Enterprise without Hyper-V™ 64-bit (x64) Edition
- Microsoft® Windows Server® 2008 Standard without Hyper-V™ 32-bit (x86) Edition
- Microsoft® Windows Server® 2008 Enterprise without Hyper-V™ 32-bit (x86) Edition

IMPORTANT: For the beta version of Windows Server 2008 Hyper-V, no support service is available.

Optical Disk Drives

Throughout this manual, optical disk drives mean:

1. CD-R/RW with DVD-ROM drive
2. DVD-ROM drive
3. DVD Super MULTI drive
4. DVD-Combo drive
5. DVD-RAM drive


Text Conventions

The following conventions are used throughout this manual.

- | | |
|-------------------|--|
| IMPORTANT: | Denotes important instructions that require your attention |
| NOTE: | Denotes helpful information |

1. Overview

The Windows Server 2008 installation flow is provided below. Be sure to select "clean installation" when you install Windows Server 2008 on your system.



If you need to install application programs including NEC ESM PRO Manager or Agent, install them according to the relevant Installation Guide after completion of OS installation.

2. Before You Start

Before installing Windows Server 2008, make sure of your hardware configuration including RAID configuration according to the User's Guide or other manuals of the server stored in NEC EXPRESSBUILDER DVD.

Prerequisites for Installing Windows Server 2008

- The Windows Server 2008 Driver Set ("Driver Set") for the NEC Express5800/110Ge, i120Ra-e1, 140Rf-4 [WS2008.10-002.01]
*To download, see the section below on this page.
- A removable medium (e.g., a CD-R disk) to save the Driver Set
- Microsoft® Windows Server® 2008 Standard /Microsoft® Windows Server® 2008 Enterprise Installation Guide for NEC Express5800/110Ge, i120Ra-e1, 140Rf-4 (this manual)
- The Windows Server 2008 installation media ("Windows Server 2008 DVD-ROM")
- Accessories provided with your NEC Express5800 series server
 - The NEC EXPRESSBUILDER DVD
 - The User's Guide
(Start the NEC EXPRESSBUILDER DVD, and open → **Read Document** on the menu.)

Downloading a Driver Set

Follow the steps below to download the Driver Set appropriate for your system.

1. Download the Driver Set at: <http://www.nec.com/express/>.
2. Unzip the downloaded Driver Set to a temporary folder (e.g., C:\TEMP) in your disk drive.

NOTE: The name of the folder to save the Driver Set may not include a blank space.

3. Copy the entire winnt folder created in step 2 to your storage media. Copy it to a folder under the root directory.

NOTE: Use the writing software provided as the OS standard feature or other software conforming to Orange Book standards so that Windows can access the folder.


4. After the winnt folder has been copied to your media, delete the temporary folder and all the unzipped files in it.

3. Important Instructions

Before you install Windows Server 2008, read this chapter carefully.

Windows Activation

To activate Windows Server 2008, enter the product key (Physical Product key) on your Certificate of Authenticity (COA) label.



For more details, see "Activating Windows" (page 35).

IMPORTANT:

- Activate Windows Server 2008 within 30 days after installation, or the system may be locked after the initial 30 days.
 - Use the Virtual Product Key to activate Windows Server 2008 in a virtual operating system environment. You cannot use it to install Windows Server 2008 on a physical server.
-

Supported Optional Boards

The Driver Set contains the drivers for the following optional boards:

NEC Express5800/140Rf-4

- LSI MegaRAID™ SAS PCI EXPRESS™ ROMB (embedded on the mother board)
- N8103-90 Disk array controller (External SAS HDD)
- N8190-127 Fibre Channel controller
- N8190-131 Fibre Channel controller (2ch)
- N8104-121 1000 BASE-T connection board (2ch)
- N8104-125 1000 BASE-T connection board (4ch)

NEC Express5800/i120Ra-e1

- N8103-116 RAID controller (128 MB, RAID0/1)
- N8103-117 RAID controller (128 MB, RAID0/1/5/6)
- N8103-118 RAID controller (256 MB, RAID0/1/5/6)
- N8103-75 SCSI controller
- N8103-95 SCSI controller
- N8103-107 SCSI controller
- N8190-127 Fibre Channel controller
- N8190-131 Fibre Channel controller (2ch)
- N8104-112 1000 BASE-SX connection board
- N8104-119 1000 BASE-T connection board
- N8104-120 1000 BASE-T connection board (2ch)
- N8104-121 1000 BASE-T connection board (2ch)
- N8104-122 1000 BASE-T connection board (2ch)

NEC Express5800/110Ge

- N8103-116 RAID controller (128 MB, RAID0/1)
- N8103-117 RAID controller (128 MB, RAID0/1/5/6)
- N8103-75 SCSI controller
- N8103-95 SCSI controller
- N8103-107 SCSI controller
- N8104-112 1000 BASE-SX connection board
- N8104-119 1000 BASE-T connection board
- N8104-120 1000 BASE-T connection board (2ch)
- N8104-121 1000 BASE-T connection board (2ch)
- N8104-125 1000 BASE-T connection board (4ch)

Updating Your System

After Windows Server 2008 has been installed, you need to update your system using the Driver Set. To update your system, see Chapter 5, "Updating the System".

Installing on the Mirrored Volume

When re-installing the OS to a hard disk drive which has been upgraded to Dynamic Disk, only the simple dynamic volume is available for installation.

If you want to install the OS on a volume that is mirrored using **Disk Management**, invalidate the mirroring and reset to the basic disk before the installation, and validate the mirroring again after the installation.

You can create, invalidate, or delete the mirror volume by using **Disk Management** in **Computer Management**.

MO Drive

If you try to set the current file system to NTFS on your system with MO drives connected, you may fail to format the file system.

To format correctly, disconnect the MO drives from your system and repeat the installation procedure.

Tape Media

Remove all tapes from the tape drives before you install.

Peripheral Devices such as RDX

Depending on your hardware configuration, some peripheral devices need to be removed or disabled before starting setup. Refer to the instruction manual which came with the peripheral device for pertinent information, and proceed accordingly.

BIOS Update

To install Windows Server 2008, you may need to update your BIOS.

To check if your system needs a BIOS update, go to: <http://www.nec.com/express/>.

For the update procedure, see Readme.txt, also available on the above website.

RAID Configuration

To use the hard disk drives in RAID configuration, you must configure the RAID system before installing Windows Server 2008.

To use the RAID controller (LSI MegaRAID™ SAS PCI EXPRESS™ ROMB) embedded on the mother board, refer to "RAID System Configuration" in the User's Guide of the server.

To use the optional RAID controller, refer to the manual which came with the controller.

About the System Partition Size

Use the following formula to calculate the total partition size required for Windows Server 2008:

Windows Server 2008 64-bit (x64) Edition

Required partition size = size required to install OS + paging file size + dump file size + application size

Size required to install OS	= 11,600MB (Full Installation) or = 4,100MB (Server Core Installation)
Paging file size (recommended)	= Installed memory size x 1.5
Dump file size	= Installed memory size + 300MB
Application size	= Required size

IMPORTANT:

- The above-mentioned paging file size is recommended for collecting debug information (memory dump). A paging file with initial size large enough to store the dump file in the boot drive is required.
Correct debug information might not be able to be collected due to virtual memory shortage when the paging file is insufficient, so be sure to set a paging file of sufficient size.
 - Regardless of the size of the mounted memory, or the Write debugging information (type of memory dump), the maximum size of the dump file is 'The size of the mounted memory + 300MB'.
 - If you install any application program or the like, add necessary space to the partition to install these programs.
-

Example:

The partition size required for a system with an installed memory size of 512 MB and a full installation of the operating system:

$$11,600\text{MB} + (512\text{MB} \times 1.5) + (512\text{MB} + 300\text{MB}) + \text{application size} \\ = 13,180\text{MB} + \text{application size}.$$

If the provided partition size is smaller than that required to install the OS and paging file, expand the partition size or utilize a larger disk. If your system does not have a sufficient dump file size, divide the required file space into multiple disks by performing the steps below:

1. Set the system partition size to a size sufficient to install the OS and paging file.
2. See Chapter 7 "Setting for Solving Problems" to write the debug information of the dump file onto another disk.

If there is not enough disk space to write the debug information, add another disk for the dump file.

Windows Server 2008 32-bit (x86) Edition

Required partition size = size required to install OS + paging file size + dump file size + application size

Size required to install OS	= 6,300MB (Full Installation) or = 2,200MB (Server Core Installation)
Paging file size (recommended)	= Installed memory size x 1.5
Dump file size	= Installed memory size + 300MB
Application size	= Required size

IMPORTANT:

- The above-mentioned paging file size is recommended for collecting debug information (memory dump). A paging file with initial size large enough to store the dump file in the boot drive is required.
Correct debug information might not be able to be collected due to virtual memory shortage when the paging file is insufficient, so be sure to set a paging file of sufficient size.
 - The maximum paging file size which can be set on one partition is 4095MB. If the above paging file size exceeds 4095MB, specify 4095MB for the paging file size.
 - The maximum dump file size for the system with more than 2GB memory mounted is '2048MB + 300MB'.
 - If you install any application program or the like, add necessary space to the partition to install these programs.
-

Example:

The partition size required for a system with an installed memory size of 512 MB and a full installation of the operating system:

$$6,300\text{MB} + (512\text{MB} \times 1.5) + 512\text{MB} + 300\text{MB} + \text{application size} \\ = 7,880\text{MB} + \text{application size}.$$

If the partition where the operating system is installed is smaller than that required to install the OS and paging file, expand the partition size or utilize a larger disk. If your system does not have a sufficient dump file size, divide the required file space into multiple disks by performing the steps below:

1. Set the partition size to a size sufficient to install the OS and paging file.
2. See Chapter 7 "Setting for Solving Problems" to write the debug information of the dump file onto another disk.

If there is not enough disk space to write the debug information, add another disk for the dump file.

BitLocker

If you use BitLocker, note the following:

- Before you install Windows Server 2008, create two partitions:.
 - System partition for a loader
 - Boot partition for the operating system

NOTE: For more information, see the following documentation in Microsoft TechNet.

"Windows BitLocker Drive Encryption Step-by-Step Guide"

- Be sure to keep the recovery password secure. Do not keep it around a server running BitLocker.

IMPORTANT: Without the recovery password, you cannot start the operating system and see the partition content encrypted by BitLocker.

The recovery password may be needed when you start the operating system after performing the following tasks:

- Replacing the motherboard
 - Initializing the TPM
 - Changing the BIOS setting
-

- Windows Server 2008 is not installed in the partition encrypted by BitLocker.

NEC ESMPRO

When Windows Server 2003 is upgraded to Windows Server 2008, the WDT (watch dog timer) and shutdown monitor settings will be changed back to the default. See the current settings in the NEC ESMPRO Agent control panel and change the settings, if necessary.

To use NEC ESMPRO Agent on a server running Windows Server 2008, see the NEC ESMPRO support information.

4. Installing Windows Server 2008

This chapter provides the steps to install Windows Server 2008.

1. Turn on your system.

IMPORTANT: To install Windows Server 2008, you may need to update BIOS. To check if your system needs a BIOS update, go to: <http://www.nec.com/express/>.

2. Insert the Windows Server 2008 DVD-ROM into your DVD-ROM drive.
3. Restart the system.

To restart the system, press **Ctrl + Alt + Del** or turn off the system once, and then turn it on again.

IMPORTANT: When prompted to **press any key to boot from CD or DVD**, press **Enter** while the message is displayed. If the Windows installation screen (shown in step 4) does not appear, turn off the system, and then turn it on again.

The DVD-ROM starts.

A message "Windows is loading files ..." appears.

4. Select a language and other options from the drop-down lists, and then click **Next**.




5. Click the **Install now** button. ➡

The installation starts.




6. Enter your product key, and then click **Next**.



7. Select the edition of the Windows operating system that you purchased.


Select **I have selected the edition of Windows that I purchased**, and then click **Next**.

You will see only possible editions that have been determined by Windows based on the key you entered in step 6.




NOTE: The Windows versions listed on the screen vary depending on the Windows Server 2008 DVD-ROM you are using.

8. Read the license terms carefully. If you agree, select **I accept the license terms**, and then click **Next**.



9. Select the type of installation you want.


Custom (advanced) is selected below.



10. You will be asked, **"Where do you want to install Windows?"** If you are using any of the following devices, go to step 11. If not, go to step 12.

- ☐ LSI MegaRAID™ SAS PCI EXPRESS™ ROMB (embedded on the mother board)
- ☐ N8103-116
- ☐ N8103-117
- ☐ N8103-118

11. Select **Load Driver**, and then click **Browse**.



The folder reference dialog box appears. Select a path to the folder in your removable media (CD-R and USB memory stick) containing the Driver Set, and then click **OK**.

- ☐ Windows Server 2008 64-bit(x64) Editions: <drive letter>:\winnt\oemfd\ws2008x64\fd1
- ☐ Windows Server 2008 32-bit(x86) Editions : <drive letter>:\winnt\oemfd\ws2008\fd1

NOTE: For example, if the driver kit is stored in "temp" folder in drive D, select **Start - RUN**, enter the following command, and click **OK**.

- Windows Server 2008 64-bit(x64) Edition:
D: \temp\winnt\oemfd\ws2008x64\fd1\xxx
- Windows Server 2008 32-bit(x86) Edition:
D: \temp\winnt\oemfd\ws2008\fd1\xxx


After you select the path, a list of drivers is displayed. Select the following driver, and then click **OK**. Then, go to Step 12.

- When LSI MegaRAID™ SAS PCI EXPRESS™ ROMB (embedded on the mother board) is used:
[LSI Logic MegaRAID SAS PCI Express ROMB]
- When N8103-116/117/118 is used:
[LSI Logic MegaRAID SAS 8708EM2 RAID Controller]

- 12.** Select the disk where a partition will be created, and then click **Drive Option**.

IMPORTANT: If the partition has already been created, go to step 15.

- 13.** Click **New**, enter a partition size, and then click **Apply**.
- 14.** Select the partition created in step 13, and then click **Format**.
- 15.** Select the partition created, and then click **Next**.




When the following message appears, the installation starts automatically.

Installing Windows ...
That's all information we need right now. Your computer
will restart several times during installation.

- ✓ Copying files
- Expanding files
- Installing features
- Installing updates
- Completing installation□

NOTE: If the disk drive has a media containing the driver kit, you will be prompted to replace a media with that for OS installation. Insert the install media according to the on-screen message.





16. Log on to the system. The steps vary depending on the edition you selected in step 7.

If you have selected a full installation

1. After a full installation of Windows Server 2008 is completed, the following dialog box will prompt you to set or change the password before you log on. Click **OK**.



2. Change the password, and then click the **Next** button. 




NOTE: The Windows Server 2008 password must combine uppercase letters, lowercase letters, and numbers.

3. When the following message appears, click **OK** to log on.



4. In the **Initial Configuration Tasks** window, enter user information.



If you have selected a Server Core installation


1. After a Server Core installation of Windows Server 2008 is complete, press **Ctrl + Alt + Del**.




2. Select **Other User**.




3. Log on to the system as an administrator.


You need not enter your password in this dialog box. Click the  button.



4. Before you log on, you will be prompted to change the password. Click **OK**.



5. Change the password, and then click the **Next** button .




NOTE: The Windows Server 2008 password must combine uppercase letters, lowercase letters, and numbers.

6. When the following message appears, click **OK**.



7. At the command prompt, enter user information.



NOTE: For more detailed procedure, see the "Microsoft Windows Server 2008 Step-By-Step Guide".

17. See Chapter 5, "Updating the System".
18. See Chapter 6, "Installing Drivers and Configuring Driver Settings".
19. See Chapter 7, "Setting for Solving Problems".

The installation is complete.

5. Updating the System

After installing Windows Server 2008, you must update your system by following the steps in this chapter.

If you have not yet downloaded the Driver Set, see *Downloading a Driver Set* in Chapter 2, "Before You Start" (page 2).

IMPORTANT: You should update your system if you have:

- Changed the system configuration
(Added or removed optional built-in devices: If you are prompted to restart the system after the system configuration has been changed, click **No**, and update the system.)
 - Recovered the system by using a recovery process
 - Restored the system by using a backup tool
-

1. Log on to the system using an administrator account.


Insert your removable media containing the Driver Set into your drive.

2. Run `<drive letter>:\winnt\bin\oschk\oschk.bat`.

NOTE: For example, if the driver kit is stored in "temp" folder in drive D, do the following:

- Full installation
 - (1) Enter "`D:\temp\winnt\bin\oschk\oschk.bat`", and click **OK**.
 - Server Core installation
 - (1) Enter the following command from the command prompt:
`cd /d D:\temp\winnt\bin\oschk\`
 - (2) Enter the following command and click **Enter**:
`oschk.bat`
-


The following box appears.




3. Read the message, and then click **OK**.

The update starts.

NOTE: The following box appears during the update if you have deployed a full installation of Windows Server 2008. Wait until the update is completed.



4. When the following message appears, click **OK** to restart the system.



The system has been updated.

6. Installing Drivers and Configuring Driver Settings

This chapter provides the procedures for installing the drivers for the optional boards supported by the NEC Express5800 servers.

For other options that are not described in this chapter, see the User's Guide for the relevant driver.

LAN Driver and PROSet

The LAN driver and PROSet were installed automatically while your system was being updated in the previous section.

NOTE: To change the LAN driver and PROSet settings, log on to the system from a local console using an administrator account. Remotely changing the settings by using the operating system's remote desktop feature is not supported.

Using N8104-125 Adapter after System Update

To use the N8104-125 Adapter after updating your system, you must first uninstall the LAN driver and PROSet, and then update your system with the N8104-125 Adapter connected.

For a server running a full installation

1. Remove the team of network adapters.

Before you remove, note the current settings (e.g., IP addresses) of the standard and optional adapters teamed for network redundancy. Configure the settings after reinstalling the LAN driver and PROSet.

To remove the team, see "Adapter Fault Tolerance (AFT)/ Adaptive Load Balancing (ALB)" on page 24.

2. On **Control Panel**, click **Uninstall Program**.

3. Double-click **Intel(R) Network Connections 12.4.38.0**.

Intel(R) Network Connections (Remove Options) appears.

4. On **Remove Options**, click **Remove**.

Intel(R) Network Connections - Remove Software appears.

5. Select **Yes**.

The uninstallation starts automatically.

6. When **InstallShield Wizard Completed** appears, click **Finish**.

Restart the system.

For a server running a Server Core installation

1. Note the current settings (e.g., IP addresses) of the standard and optional adapters teamed for network redundancy before uninstalling LAN driver. Configure the settings after reinstalling the LAN driver.
2. At the command prompt, run DxSetup.EXE in your removable medium containing the Driver Set.
 - ❑ Windows Server 2008 64-bit (x64) Editions:
`<drive latter>:\winnt\ws2008x64\dl5\APPS\PROSETDX\Vistax64\DxSetup.EXE`
 - ❑ Windows Server 2008 32-bit (x86) Editions:
`<drive latter>:\winnt\ws2008\dl5\APPS\PROSETDX\Vista32\DxSetup.EXE`
3. In **Intel(R) Network Connections - InstallShield Wizard**, click **Next**.
4. Select **Remove**, and click **Next**.
5. Click **Remove**.
Uninstallation starts automatically.
6. When **InstallShield Wizard Completed** appears, click **Finish**.
Restart the system.

Optional Network Boards

The following optional network boards are available for the NEC Express5800/110Ge, i120Ra-e1, 140Rf-4.

To use the N8104-125 Adapter, see "Using N8104-125 Adapter after System Update" on the previous page.

The drivers for other network boards are automatically installed by Windows Plug-and-Play. You do not need to install them manually.

- For NEC Express5800/110Ge:
[N8104-112/119/120/121/125]
- For NEC Express5800/i120Ra-e1:
[N8104-112/119/120/121/122]
- For NEC Express5800/140Rf-4:
[N8104-121/125]

Adapter Fault Tolerance (AFT)/ Adaptive Load Balancing (ALB)

Adapter Fault Tolerance (AFT) provides network adapter redundancy by creating a team of adapters. If any adapter fails, another in the team automatically takes over.

Adaptive Load Balancing (ALB) improves the overall network throughput by equally balancing data traffic among a team of adapters.

You can configure AFT and ALB using the standard and optional network adapters.

IMPORTANT:

- Adapter Fault Tolerance (AFT) and Adaptive Load Balancing (ALB) are not available when Server Core is in use.
 - Be sure to configure AFT and ALB after you boot the system following the driver installation.
-

<Creating a Team>

1. Open **Control Panel**. Under **System and Maintenance**, click **Open Device Manager** to start **Device Manager**.
2. Open **Network adapters**, and then double-click **Intel(R)~**.
3. Select the **Teaming** tab, select **Team with other adapters**, and then click **New Team...**
4. Type a team name, and click **Next**.
5. Confirm the adapters to include in the team, and then click **Next**.
6. Select **Adapter Fault Tolerance or Adaptive Load Balancing** as a team mode, and then click **Next**.
7. Click **Finish**.
8. In **Device Manager**, double-click a teamed adapter to see its property. Select the **Settings** tab, and then click **Modify Team...**
9. To set an adapter to primary, select the adapter, and then click **Set Primary**.

To set an adapter to secondary, select the adapter, and then click **Set Secondary**.

After both the primary and the secondary adapters are selected, click **OK** to close the screen.

To confirm the team settings:

Open the team property, and select the **Settings** tab. The setting for each adapter is shown in **Adapters in team**.

10. In the **Settings** tab, click **Test Switch...** When the switch test screen appears, click **Run Test**.

When **No problems ~** appears, the test is complete.

Restart the system.

<Removing a Team>

1. Open **Control Panel**. Under **System and Maintenance**, click **Open Device Manager** to start **Device Manager**.
2. Open **Network adapters**, and then double-click a teamed adapter.
3. Select the **Settings** tab, and then click **Remove Team**.
4. When the **Team Settings** pop-up box appears, click **Yes**.
5. Under **Device Manager**, go to **Network adapters**. Make sure that no adapter is teamed.

Restart the system.

IMPORTANT:

- To use AFT, it is recommended that the network adapters be connected to the same L2 switching hub. You may use different switching hubs, but cascade them over the same network.
 - To configure ALB, connect the network adapters only to the L2 switching hub.
 - To replace a motherboard or an optional network card, you must first remove the team and create it again after the replacement.
-

Network Driver

Changing a link speed

Follow the steps below to set a link speed and duplex mode. To set an IP address, make sure that the Internet Protocol Version (TCP/IP) box is checked.

1. Open **Control Panel**. Under **System and Maintenance**, click **Open Device Manager** to start **Device Manager**.
2. Open **Network adapters**, and then double-click **Intel(R)~**.
3. Click **Link Speed**, and then set the same values for **Speed and Duplex** as those for the switching hubs.
4. In the **Property** dialog box, click **OK**.

IMPORTANT: To use Onboard LAN: Intel(R) PRO/1000 PL Network Connection on the NEC Express5800/i120Ra-e1, follow the steps below:

1. Open **Control Panel**, and click **Open Device Manager** under **System and Maintenance** to start **Device Manager**.
 2. Open **Network adapters**, and open the property of **Intel(R) PRO/1000 PL Network Connection**.
 3. Select **Advanced**, change **Receive Side Scaling** to "Disabled", and click **OK**.
 4. Restart the system.
-

SCSI Controller N8103-75/95/107

If you use the SCSI Controller N8103-75/-95/-107, you do not need to install the driver manually. It is automatically installed by Windows Plug-and-Play feature.

When Using Disk Array Controller (N8103-90)

If you use the disk array controller (N8103-90), you do not need to install the driver manually. It is automatically installed by Windows Plug-and-Play feature.

Fibre Channel Controller N8190-127/131

If you use the Fibre Channel Controller N8190-127/-131, you do not need to install the driver manually. It is automatically installed by Windows Plug-and-Play feature.

Graphics Accelerator

The driver for the standard graphics accelerator was installed automatically while your system was being updated from the Driver Set.

NOTE: The graphics accelerator driver is supported only on a server running a full installation. Use VGA on a server running a Server Core installation.

To reinstall the driver alone, perform the steps below:

1. Go to **Start**, select **Programs**, select **Accessories**, and click **Windows Explorer**.

Insert your removable media into your drive.

2. Run **SETUP.EXE** in the following directory.

- To install on NEC Express5800/140Rf-4 or i120Ra-e1:

<Drive Letter>:\winnt\ws2008\video\matrox

- * Windows Server 2008 64-bit (x64) Edition:

<Drive Letter>:\winnt\ws2008x64\video\matrox

- To install on NEC Express5800/110Ge:

<Drive Letter>:\winnt\ws2008\video\xgi

- * Windows Server 2008 64-bit (x64) Edition:

<Drive Letter >:\winnt\ws2008x64\video\xgi

3. Follow the messages to proceed with the reinstallation.

If the message "**Digital Signature could not be found**". appears, click **OK** to continue the installation.

4. The installation is complete.

Restart the system.

7. Setting for Solving Problems

Set up your system as follows so that your computer can recover quickly and surely in the event of a problem.

Memory Dump (Debug Information)

This section describes the procedures for collecting memory dump (debug information) in the server.

IMPORTANT: Cautions for the Memory Dump


- The maintenance service representative is in charge of collecting memory dump. Customers need only to specify the memory dump.
 - If any problem occurs after specifying the memory dump according to the process below, a message informing you that the system is short of virtual memory may appear. In this case, do not restart the system. If you restart the system, the memory dump may not be stored correctly.
-

Follow the procedure below to specify the memory dump.

1. Select **Control Panel** and click **System**.


The **System** dialog box appears.

2. Click **Advanced system settings**.




The **System Properties** dialog box appears.

3. Select the **Advanced** tab.
Click **Settings** on the **Startup and Recovery** group box.



4. Modify "Dump file" in the "Write debugging information" group box.
E.g., Write the debug information in drive D with the file name "MEMORY.DMP".
D: \MEMORY.DMP



IMPORTANT:

Windows Server 2008 64-bit (x64) Edition


- It is recommended that you specify "Complete Memory Dump" to write the debug information. If the mounted memory size is larger than 2GB, "Complete Memory Dump" cannot be specified; in this case, specify "Kernel Memory Dump" instead.
- Specify the drive where there is a free area more than the size of "the memory capacity mounted on Express server + 300MB".
- In case the mounted memory size exceeds 2GB due to the added memory, change the write debugging information to [Kernel Memory Dump] before adding memory. The size of debugging information (memory dump) also changes with the addition of memory. Verify the size of the free area in the destination drive to write the debugging information (memory dump).

Windows Server 2008 32-bit (x86) Edition


- It is recommended that you specify "Complete Memory Dump" to write the debug information. If the mounted memory size is larger than 2GB, "Complete Memory Dump" cannot be specified; in this case, specify "Kernel Memory Dump" instead.
 - Specify the drive where there is a free area more than the size of "the memory capacity mounted on Express server + 300MB" (In case the memory capacity is more than 2GB, a free area of "2048+300MB" or more).
 - In case the mounted memory size exceeds 2GB due to the added memory, change the write debugging information to [Kernel Memory Dump] before adding memory. The size of debugging information (memory dump) also changes with the addition of memory. Verify the size of the free area in the destination drive to write the debugging information (memory dump).
-

5. Click **Settings** on the **Performance** group box.


The **Performance Options** window appears.




6. Click the **Advanced** tab on the **Performance Options** window.



7. Click **Change** in the **Virtual memory** group box.




8. Uncheck the **Automatically manage paging file size for all drives** box, and check **Custom size**.



9. In the **Paging file size for each drive** box, specify as follows:

- A value larger than the recommended size shown in **Total paging file size for all drives** for **Initial size**
- A value larger than the **Initial size** for **Maximum size**

Then click **Set**.



IMPORTANT:

- The above-mentioned paging file size is recommended for collecting debug information (memory dump). A paging file with an initial size large enough to store the dump file in the boot drive is required.
Correct debug information might not be able to be collected due to virtual memory shortage when the paging file is insufficient, so be sure to set a paging file of sufficient size.
 - For more information on "Recommended" value, see "About the System Partition Size", described earlier.
 - In case the memory is expanded, re-specify the paging file to suit the actual memory size.
-

10. Click **OK**.

A message to restart the system may appear according to the modified specification.
In this case, follow the message to restart the system.

How to Create a User-mode Process Dump File

"User-mode Process Dump" is the file that records information when any application error occurs.

When an application error occurs, do not close the pop-up window that notifies you of the error, but collect a dump using the following process.

1. Right-click a blank part of the taskbar and click **Task Manager**, or press **Ctrl + Shift + Esc** to start **Task Manager**.
2. Click the **Processes** tab.
3. Right-click on the name of the process from which you want to collect a dump, and then click **Create Dump File**.
4. The dump file is stored in the following directory.

C:\Users\<User Name>\AppData\Local\Temp

NOTE: The folder may be treated as hidden folder. If the folder does not appear, run Explorer and select **Tools - Folder Options... - View**, and check to **Show hidden files and folders**.

When the User-mode Process Dump is created, pick up the file from the directory described in Step 4.

Refer to the Knowledge Base of Microsoft web-site for more information about the User-mode Process Dump file collection.

"How to create a user-mode process dump file in Windows Server 2008"

<http://support.microsoft.com/kb/949180/en-us>

NOTE: For Windows Server 2008, Dr. Watson is replaced with [Problem Reports and Solutions]; therefore, you can not collect the Crash Dump file using Dr. Watson. The procedure detailed above provides you with the information equivalent to that in the Crash Dump file.

Network Monitor Setup

Microsoft Network Monitor allows you to examine and troubleshoot network problems.

NOTE: Windows Server 2008 does not provide Network Monitor. To use Network Monitor on Windows Server 2008, install Network Monitor by following the steps below.

1. Download Microsoft Network Monitor from the following web site:
<http://support.microsoft.com/kb/933741/en-us>
2. Run the downloaded file to start the installer.

Follow the on-screen instructions to install Network Monitor.

NOTE: If a Security Alert appears, click **Run**. Select **Complete** for a setup format.

3. Network Monitor is installed.

NOTE: To remove Network Monitor, go to **Programs and Features**.

Network Trace Capture

1. On the **Start** menu, start **Microsoft Network Monitor**.
2. On **Start Page**, select **Create a new capture tab...** or select **New** in the **File** menu, and click **Capture...**

A new tab for capturing a network trace is created.

3. On the **Select Networks** window, select a network you want to capture a trace.
4. On the **Capture** menu, click **Start** to start capturing a network trace.
5. On the **Capture** menu, click **Stop** to stop capturing a network trace.
6. On the **File** menu, select **Save As...**

The **Save As** window appears. Select **All captured frames** from **Frame selection**, and enter the names of a folder and a file.

NOTE: The default folder name is:
C:\Users\<User name>\Documents\Network Monitor 3\Captures


7. Click **Save** to create the file in the folder selected in step 6.

8. Activating Windows


To continue using the Windows features, you must activate Windows on your system. Make sure that you have already activated Windows. If not, follow the procedure below.

For a Server Running a Full Installation


1. Go to the **Start** menu, and in the **Run** dialog box, type **slui**, and press **Enter**.




IMPORTANT: If the following message appears, Windows has already been activated on your system. Click **Close** to exit.




2. On the following screen, click **Type a different product key**.



3. Type the product key shown on your COA label, and click **Next**.




4. Activate Windows.



The Windows activation is complete.

For a Server Running a Server Core Installation


1. At the command prompt, type **slmgr -dli**, and press **Enter**.




```


Administrator: C:\Windows\system32\cmd.exe
Microsoft Windows [Version 6.0.6001]
Copyright (c) 2006 Microsoft Corporation.

C:\Users\Administrator>slmgr -dli
    
```

IMPORTANT: If the following message appears, Windows has already been activated on your system. Click  to exit.



2. Type **slmgr -ipk <PID>**, and press **Enter**.
 * PID is your product key on the COA label.




```

Administrator: C:\Windows\system32\cmd.exe
Microsoft Windows [Version 6.0.6001]
Copyright (c) 2006 Microsoft Corporation. All rights reserved.

C:\Users\Administrator>slmgr -ipk XXXXX-XXXXX-XXXXX-XXXXX-XXXXX_
    
```

3. Type **slmgr -dti** to obtain an installation ID for Windows activation, and press **Enter**.




```

Administrator: C:\Windows\system32\cmd.exe
Microsoft Windows [Version 6.0.6001]
Copyright (c) 2006 Microsoft Corporation. All rights reserved.

C:\Users\Administrator>slmgr -dti_
    
```

4. See `%systemroot%\system32\slui\phone.inf` for the phone number of the Microsoft customer service.
5. Call the above number, inform the representative of the installation ID which you obtained in step 3, and receive a confirmation ID.
6. At the command prompt, type `slmgr -atp <CID>`, and press **Enter**.
* CID is the confirmation ID that you received from the call center.



```
Administrator: C:\Windows\system32\cmd.exe
Microsoft Windows [Version 6.0.6001]
Copyright (c) 2006 Microsoft Corporation. All rights reserved.

C:\Users\Administrator>slmgr -atp xxxxx-xxxxx-xxxxx-xxxxx-xxxxx_
```

The Windows activation is complete.

9. Troubleshooting

This chapter provides instructions to troubleshoot system problems that you might encounter when using Windows Server 2008. If you are experiencing the same problem as listed in this chapter, perform the resolution first before you contact your sales agent. If your system still does not operate normally, provide your sales agent with the error messages on the screen.

This chapter only lists the events that might occur in Windows Server 2008. For other events, see your User's Guide.

The following system events are logged when Windows Server 2008 is installed.

- | | |
|--------------|---|
| Event ID: | 134 |
| Source: | Microsoft-Windows-Time-Service |
| Level: | Warning |
| Description: | NtpClient was unable to set a manual peer to use as a time source because of a DNS resolution error on 'time.windows.com,0x9'. NtpClient will try again in 15 minutes and double the reattempt interval thereafter.
The error was: No such host is known. (0x80072AF9) |
| | |
| Event ID: | 263 |
| Source: | PlugPlayManager |
| Level: | Warning |
| Description: | The service 'ShellHWDetection' may not have unregistered for device event notifications before it was stopped. |
| | |
| Event ID: | 7000 |
| Source: | Service Control Manager |
| Level: | Error |
| Description: | The Parallel port driver service failed to start due to the following error:
The service cannot be started, either because it is disabled or because it has no enabled devices associated with it. |
| | |
| Event ID: | 15016 |
| Source: | Microsoft-Windows-Http |
| Level: | Error |
| Description: | Unable to initialize the security package Kerberos for server side authentication. The data field contains the error number. |
| Resolution: | These events do not affect system operation. Ignore these messages. |

The following application events are logged when Windows Server 2008 is installed.

Event ID: 63

Source: Microsoft-Windows-WMI

Level: Warning

Description: A provider, Ncs2, has been registered in the Windows Management Instrumentation namespace Root\cimv2 to use the LocalSystem account. This account is privileged and the provider may cause a security violation if it does not correctly impersonate user requests.

A provider, IntelEthernetDiag, has been registered in the Windows Management Instrumentation namespace Root\CIMv2 to use the LocalSystem account. This account is privileged and the provider may cause a security violation if it does not correctly impersonate user requests.

A provider, WmiPerfClass, has been registered in the Windows Management Instrumentation namespace root\cimv2 to use the LocalSystem account. This account is privileged and the provider may cause a security violation if it does not correctly impersonate user requests.

Resolution: These events do not affect system operation. Ignore these messages.

The following errors or warnings are logged when I start the system.

Event ID: 11

Source: IANSMiniport

Level: Warning

Description: Adapter link down: Intel(R) ~

Event ID: 13

Source: IANSMiniport

Level: Warning

Description: Intel(R) ~ has been deactivated from the team.

Event ID: 16

Source: IANSMiniport

Level: Warning

Description: [Team Name]: The last adapter has lost link. Team network connection has been lost.

Resolution: If you have created a team of network adapters, the above events may be logged when you start the system. These events do not affect the LAN driver operation. Ignore these messages.

The following system event is logged when Windows Server 2008 is installed.

Event ID: 10

Source: VDS Dynamic Provider

Description: The provider failed while storing notifications from the driver.
The Virtual Disk Service should be restarted. hr=80042505

Resolution: Go to the Microsoft website:

<http://support.microsoft.com/kb/948275/en-us/>

The memory mirroring or online spare memory feature is enabled in NEC Express5800/140Rf-4, and the available memory capacity has been changed. However, the memory information shown in [System] and [System Information] on Windows Server 2008 do not change.

→ The **Memory (RAM)** shows the total capacity of mounted memory when you select **Start - Control Panel - System**.

Similarly, the **Installed Physical Memory (RAM)** shows the total capacity of mounted memory when you select **Start - All Program - Accessories - System Tools - System Information**.


To know the physical memory currently available on the system, select **Windows Task Manager - Performance - Physical Memory(MB) - Total**.

10. Upgrading to Windows Server 2008

This chapter describes guidelines for upgrading Windows Server 2003 to Windows Server 2008.

Overview

The Windows Server 2008 upgrade flow is shown below. Be sure to remove the installed graphics accelerator driver and PROSet before you upgrade.



Before You Upgrade

Important Instructions

- Windows Server 2003 requires Service Pack 1 or later.
- Upgrading from Windows Server 2003 to Windows Server 2008 is not recommended.
Windows Server 2008 supports the following upgrade paths:
For Windows Server 2003 Standard x64 Edition:
 - Windows Server 2008 Standard 64-bit (x64) Edition
 - Windows Server 2008 Standard without Hyper-V 64-bit (x64) Edition
 - Windows Server 2008 Enterprise 64-bit (x64) Edition
 - Windows Server 2008 Enterprise without Hyper-V 64-bit (x64) EditionFor Windows Server 2003 Enterprise x64 Edition:
 - Windows Server 2008 Enterprise 64-bit(x64) Edition
 - Windows Server 2008 Enterprise without Hyper-V 64-bit(x64) EditionFor Windows Server 2003 Standard Edition:
 - Windows Server 2008 Standard 32-bit(x86) Edition
 - Windows Server 2008 Standard without Hyper-V 32-bit (x86) Edition
 - Windows Server 2008 Enterprise 32-bit (x86) Edition
 - Windows Server 2008 Enterprise without Hyper-V 32-bit (x86) EditionFor Windows Server 2003 Enterprise Edition:
 - Windows Server 2008 Enterprise 32-bit (x86) Edition
 - Windows Server 2008 Enterprise without Hyper-V 32-bit (x86) Edition
- To use Windows Server 2008, you must first perform a backup of necessary user information by following the instructions in Chapter 4, "Installing Windows Server 2008".
- Upgrading between different architectures i.e. upgrading from Windows Server 2008 32-bit (x86) Edition to Windows Server 2008 64-bit (x64) Edition and vice versa is not supported.
- Upgrading from Windows Server 2008 without Hyper-V to Windows Server 2008 and vice versa is not supported.
- Upgrading from a full installation of Windows Server 2008 to a Server Core installation is not supported.
- To upgrade the system, the system partition must have sufficient capacity available to install the system. See "About the System Partition Size" described earlier.

Graphic Accelerator Driver

To upgrade from Windows Server 2003 to Windows Server 2008 on a server in use, you must first uninstall the graphics accelerator driver.

To uninstall the driver:

1. Navigate to **Control Panel**, and click **Add or Remove Programs**.
2. Select **Matrox Graphics Software (remove only)** from the program list, and click **Change/Remove**.
 - To uninstall Express5800/140Rf-4 or i120Ra-e1:
[Matrox Graphics Software (remove only)]
 - To uninstall Express5800/110Ge, 110Ge-S:
[XGI Volari Z7/Z9/Z9s/Z11 Display Driver]
3. Follow the messages on the screen to uninstall the driver.
After the uninstallation, restart the system.

PROSet

To upgrade from Windows Server 2003 to Windows Server 2008 on a server with PROSet installed, you must first uninstall PROSet.


To uninstall PROSet:

1. Remove the team of network adapters.
Before you remove them, note the current settings (e.g., IP addresses) of the standard and optional adapters teamed for network redundancy. You can configure the team settings after upgrading
To remove the team, see "Adapter Fault Tolerance (AFT)/ Adaptive Load Balancing (ALB)" on page 24.
2. Navigate to **Control Panel**, and click **Add or Remove Programs**.
3. Select **Intel (R) PRO Network Connections xx.xx.xx.xx** from the program list, and click **Change/Remove**.
*xx.xx.xx.xx is a version of PROSet and varies depending on the server.
4. Follow the messages on the screen to uninstall PROSet.
After the uninstallation, restart the system.

Upgrading Windows


This section provides the procedure for upgrading from Windows Server 2003 32-bit (x86) to Windows Server 2008 32-bit (x86) Edition.

IMPORTANT: Before you upgrade, you must first uninstall the graphics accelerator driver and PROSet.


1. When Windows Server 2003 is running, insert the Windows Server 2008 DVD-ROM into the optical disk drive.
2. On the following screen, click **Install now** .




3. On the following screen, select one of the options for capturing the update program.



4. Enter your product key, and click **Next**.




5. Select the Windows edition you want to install, and click **Next**.




IMPORTANT: Select the same edition of Windows Server 2008. For more details, see "Before You Upgrade" on page 44.


6. Read the license terms carefully. If you agree, check **I accept the license terms**, and click **Next**.




7. Select **Upgrade**.





8. Read the content, and click **Next**.




9. The following screen appears.



10. After the setup, log on to the system.
11. If you have set a password in Windows Server 2003, enter the same password, and click .
12. After login, on the **Server Manager** screen, confirm your user settings.



NOTE: The following message may appear several times when you upgrade the system. Click **Cancel** to proceed.



-
13. Update your system. See Chapter 5, "Updating the System".
 14. Install the drivers. See Chapter 6, "Installing Drivers and Configuring Driver Settings".
 15. If you have upgraded to Windows Server 2008, follow the instructions in "Installing Drivers after Upgrade" on page 51.
 16. Follow the instructions in Chapter 7, "Setting for Solving Problems".

The upgrade is complete.

Installing Drivers after Upgrade

This section provides the procedures for installing the driver(s) for optional controller(s) after the upgrade.

IMPORTANT: You may need to install multiple drivers, depending on your environment.

When Using RAID Controller (N8103-116/117/118)

When Using LSI MegaRAID™ SAS PCI EXPRESS™ ROMB (embedded on the mother board)

If you are using the RAID controller (N8103-116/117/118) or using LSI MegaRAID™ SAS PCI EXPRESS™ ROMB on NEC Express5800/140Rf-4, proceed as follows to install the driver.

IMPORTANT: The installation procedure depends on your server model. Follow steps below appropriate to your server.

NEC Express5800/140Rf-4

1. Start **Server Manager**.
2. Go to **Diagnostics - Device Manager**. Under **Storage Controllers**, right-click **LSI Logic MegaRAID SAS PCI Express ROMB**, and select **Update Driver Software**.
3. On the **Update Driver Software** screen, select **Browse my computer for driver software**.
4. On the **Browse for driver software on your computer** screen, select **Let me pick from a list of device drivers on my computer**, and click **Next**.
5. When prompted to **select the device driver you want to install for this hardware**", click **Have Disk**.
6. On the **Install From Disk** screen, select one of the following paths, i.e., a path to the folder storing the driver (e.g., your storage media storing the Driver Set) from the **Copy manufacture's files from:** area, and click **OK**.
 - For Windows Server 2008 64-bit (x64) Edition:
`<drive latter>:\winnt\oemfd\ws2008x64\fd1`
 - For Windows Server 2008 32-bit (x86) Edition:
`<drive latter>:\winnt\oemfd\ws2008\fd1`
7. When prompted to **select the device driver you want to install for this hardware**, click **Next**.
The driver installation starts.
8. After the driver installation is complete, the message "**Windows has successfully updated your driver software**" is displayed. Click **Close**.
9. When the message "**Do you want to restart your computer now?**" appears, select **Yes**.
The system restarts.

The driver update is complete.

NEC Express5800/110Ge, i120Ra-e1

1. Start **Server Manager**.
2. Go to **Diagnostics - Device Manager**. Under **Storage Controllers**, right-click **LSI Logic MegaRAID SAS 8708EM2 RAID Controller**, and select **Update Driver Software**.
3. On the **Update Driver Software** screen, select **Browse my computer for driver software**.
4. On the **Browse for driver software on your computer** screen, select **Let me pick from a list of device drivers on my computer**, and click **Next**.
5. When prompted to **select the device driver you want to install for this hardware**, click **Have Disk**.
6. On the **Install From Disk** screen, select one of the following paths, i.e., a path to the folder storing the driver (e.g., your storage media storing the Driver Set) from the **Copy manufacture's files from:** area, and click **OK**.
 - For Windows Server 2008 64-bit (x64) Edition:
`<drive letter>:\winnt\oemfd\ws2008x64\fd1`
 - For Windows Server 2008 32-bit (x86) Edition:
`<drive letter>:\winnt\oemfd\ws2008\fd1`
7. When prompted to **select the device driver you want to install for this hardware**, click **Next**.
The driver installation starts.
8. After the driver installation is complete, the message "**Windows has successfully updated your driver software**" is displayed. Click **Close**.
9. When the message "**Do you want to restart your computer now?**" appears, select **Yes**.
The system restarts.

The driver update is complete.

Installing a driver for the ATA/ATAPI Controller

An ATA/ATAPI controller driver must be installed on all NEC Express5800 series servers, except for the 140Rf-4.

IMPORTANT: The installation procedures vary by server model.

For the NEC Express5800/110Ge, i120Ra-e1:

1. Start **Server Manager**.
2. Go to **Diagnostics - Device Manager**. Under IDE ATA/ATAPI Controllers, right-click **Intel(R) ICH9 SATA AHCI Controller**, and select **Update Driver Software**.
3. On the **Update Driver Software** screen, select **Browse my computer for driver software**.
4. On the **Browse for driver software on your computer** screen, select **Let me pick from a list of device drivers on my computer**, and click **Next**.
5. When prompted to **select the device driver you want to install for this hardware**, select **Standard AHCI 1.0 Serial ATA Controller**, and click **Next**.

The driver installation starts.

6. After the driver installation is complete, the message "**Windows has successfully updated your driver software**" is displayed. Click **Close**
7. When the message "**Do you want to restart your computer now?**" appears, select **Yes**.

The system restarts

NOTE: Restart your system when prompted by a pop-up window.

The driver update is complete.

Installing a Driver for the SCSI Controller [N8103-107]

If you are using or adding the SCSI controller N8103-107, perform the steps below to install the driver:

1. Start Server Manager.
2. Go to **Diagnostics - Device Manager**. Under **Storage Controllers**, right-click **Adaptec SCSI Card 29320LPE - Ultra320 SCSI**, and select **Update Driver Software**.
3. On the **Update Driver Software** screen, select **Browse my computer for driver software**.
4. On the **Browse for driver software on your computer** screen, select **Let me pick from a list of device drivers on my computer**, and click **Next**.
5. When prompted to **select the device driver you want to install for this hardware**", select **Adaptec SCSI Card 29320LPE - Ultra320 SCSI**, and click **Next**.

The driver installation starts.

6. After the driver installation is complete, the message "**Windows has successfully updated your driver software**" is displayed. Click **Close**.
7. When the message "**Do you want to restart your computer now?**" appears, select **Yes**.

The system restarts.

NOTE: Restart your system when prompted by a pop-up window.

The driver update is complete.

Installing a Driver for the SCSI Controller [N8103-75]

If you are using or adding the SCSI controller N8103-75, perform the steps below to install the driver:

1. Start **Server Manager**.
2. Go to **Diagnostics - Device Manager**. Under **Storage Controllers**, right-click **Adaptec SCSI Card 29320LPE - Ultra320 SCSI**, and select **Update Driver Software**.
3. On the **Update Driver Software** screen, select **Browse my computer for driver software**.
4. On the **Browse for driver software on your computer** screen, select **Let me pick from a list of device drivers on my computer**, and click **Next**.
5. When prompted to **select the device driver you want to install for this hardware**, select:

For Windows Server 2008 64-bit (x64) Edition:

Adaptec SCSI Card 29320ALP - Ultra320 SCSI Version: 7.2.0.0 [01/25/2007]

For Windows Server 2008 32-bit (x86) Edition:

Adaptec SCSI Card 29320ALP - Ultra320 SCSI Version: 7.2.0.0 [01/25/2007]

Then click **Next**.

The driver installation starts.

6. After the driver installation is complete, the message "**Windows has successfully updated your driver software**" is displayed. Click **Close**.
7. When the message "**Do you want to restart your computer now?**" appears, select **Yes**.

The system restarts.

NOTE: Restart your system when prompted by a pop-up window.

The driver update is complete.

Using a SCSI Controller N8103-95

When you use the SCSI Controller [N8103-95], the driver is automatically installed. You do not need to install it manually.

Adding Fibre Channel Controller N8190-127/131

When you use the Fibre Channel Controller [N8190-127/-131], the driver is automatically installed. You do not need to install it manually.