NEC

ESMPRO

Server Management Guide

Rev. 8

June, 2009

NEC Corporation

- ESMPRO is the registered trademark of NEC Corporation.
- Microsoft, Windows, Windows Vista, Windows Server, and MS-DOS are registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.
- The official name of Windows is Microsoft Windows Operating System.
- Intel is the registered trademark of Intel Corporation in the United States.
- ARCserve is the registered trademark of Computer.Associates, Inc. in the United States.
- All other names of company and product used in this guidebook are the trademarks and the registered trademarks of each company.

- Windows Server 2008 stands for Microsoft® Windows Server® 2008 Standard operating system and Microsoft® Windows Server® 2008 Enterprise operating system.
- Windows Vista stands for Microsoft® Windows Vista® Business operating system.
- Windows Server 2003 x64 Editions stands for Microsoft® Windows Server® 2003 R2, Standard x64 Edition Operating system and Microsoft® Windows Server® 2003 R2, Enterprise x64 Edition operating system, or Microsoft® Windows Server® 2003, Standard x64 Edition operating system and Microsoft® Windows Server® 2003, Enterprise x64 Edition operating system.
- Windows Server 2003 stands for Microsoft® Windows Server® 2003 R2, Standard Edition operating system and Microsoft® Windows Server® 2003 R2, Enterprise Edition operating system, or Microsoft® Windows Server® 2003, Standard Edition operating system and Microsoft® Windows Server® 2003, Enterprise Edition operating system.
- Windows XP x64 Edition stands for Microsoft® Windows® XP Professional x64 Edition operating system.
- Windows XP stands for Microsoft® Windows® XP Home Edition operating system and Microsoft® Windows® XP Professional operating system.
- Windows 2000 stands for Microsoft® Windows® 2000 Server operating system and Microsoft® Windows® 2000 Advanced Server operating system, and Microsoft® Windows® 2000 Professional operating system.

How to use this guide

This guidebook describes how to set up the features of product, introduction/operation procedure, each function of "Server Management Software of Express5800 Series" and "NEC ESMPRO Manager, and NEC ESMPRO Agent"
By using this guidebook, NEC would like our customers to realize stable system management of their system, by deepening their understanding of the product bundled to Express Server as standard.

Please note that this guidebook is for NEC ESMPRO Manager Ver. 4.3/4.4 and NEC ESMPRO Agent Ver. 4.3/4.4 and the succeeding versions.

Chap. 1 NEC ESMPRO Manager and Agent Product Outline

Outline of Functions provided by NEC ESMPRO Manager and Agent, Purpose and Effect

describes the outline of functions provided by NEC ESMPRO Manager and Agent. NEC believes that you can understand the features of the product, merit you can enjoy by introducing it or necessity of server management.
This guidebook can be used for materials with which salespersons/SE propose server management to our customers by utilizing this product, and also it can be used for our customers who want to know the outlined functions of this product for their reference.

Chap. 2 Server Management Using NEC ESMPRO

Procedure of Setting up and Operation of Management Machine using NEC ESMPRO Manager and Agent

describes each server management function, its operation and setup of NEC ESMPRO Manager and Agent in detail. This chapter describes technique to realize server management more efficiently, having our customers understood the functions of NEC ESMPRO managing several servers on network at the same time.

Chap. 3 Management Items and Operation Procedure of NEC ESMPRO

Separate Resource Management Method and Operation Procedure of NEC ESMPRO Manager and Agent

describes what of Express server NEC ESMPRO Manager and Agent can manage and supervise in each resource NEC ESMPRO can rapidly make trouble shooting of server as well as realize safe and sure server management functions, in close collaboration with high reliability function provided by hardware of Express server.

Chap. 4 Server Management by Web Browser (Web Component)

Management Procedure of Management Machine using Web Component

describes the operation method of main functions of NEC ESMPRO Manager utilizing from Web browser via Web server, operating environment to utilize Web Component and how to use each tool.

Chap. 5 Cooperation between NEC ESMPRO Manager and HP OpenView Network Node Manager (HP OpenView Integration)

Management Procedure of Management Machnine Using HP OpenView Integration

describes the start-up of the main functions of NEC ESMPRO Manager, how to monitor NEC ESMPRO Agent from HP OpenView Network Node Manager.

Chap. 6 Introduction of NEC ESMPRO Manager and Agent

Installation and basic setup of NEC ESMPRO Manager and Agent

describes introduction procedure of NEC ESMPRO Manager and Agent.
NEC ESMPRO Manager and Agent can be installed by using EXPRESSBUILDER attached to Express server, and be set up server management environment by easy operation.

Table of Contents

Chap.1 Product Outline of NEC ESMPRO Manager and Agent 7
1.1 Detection and Rapid Handling of Server Failure 11
1.2 Prevention of Server Failure 13
1.3 Assured Report of Server Failure 14
1.4 Management of Server Operation Status 15
1.5 Collective Management of Distributed Servers 16

Chap.2 Server Management Utiliizing NEC ESMPRO 18
2.1 Start-up of Server Management Functions 19
2.2 Easy Registration of Server to be Managed(Operation Window) 21
2.3 Configuration Information of Server and Management of Operating Status (DataViewer) 30
2.4 Check of Long-Term Operating Status of Server (Automatic Data Collection) 32
2.5 Quick Detection of Server Failure (AlertViewer) 37
2.6 Addition of Monitoring Items of Server (Local Polling) 45
2.7 Remote Start-up of Server (Remote Wake Up) 48
2.8 Remote Shutdown of Server (Remote Shutdown) 51
2.9 Easy Management of Large-Scale Network (Inter-Manager Communication) 55
2.10 Identify Function 59
2.11 Suppression of Blade Chassis Sensor Report 60
2.12 Redirect SNMP Trap to Other Vendor's Console (SNMP Trap Redirection) 62
2.13 Server Management by Script (Script Component) 66
2.14 Extension of Report Method 68

Chap.3 Management Items and Operation Procedures of ESMPRO 76
3.1 Monitoring of CPU 77
3.2 Monitoring of Memory 82
3.3 Monitoring of Temperature 87
3.4 Monitoring of Fan 91
3.5 Monitoring of Chassis Power Voltage 94
3.6 Monitoring of Power Unit 98
3.7 Monitoring of Cooling Unit 100
3.8 Monitoring of Chassis Cover 102
3.9 Monitoring of File System 104
3.10 Monitoring of SCSI/IDE Device 110
3.11 Monitoring of Display 115
3.12 Monitoring of Network LAN) 127
3.13 Reference of System Information 130
3.14 Reference of Error information detected by Hardware Level 133
3.15 Monitoring of Event 135
3.16 Monitoring of Stall 140
3.17 Detection of System Error (Panic) 143
3.18 Monitoring of Shutdown 144
3.19 Monitoring of PCI Hot Plug 146
3.20 Monitoring of Dump Setting 147
3.21 Chassis Identification Function 149

Chap.4 Web Server Management by Browser (Web Component) 151
4.1 About Web Component 152
4.2 Display a list of Management Server (Operation Window) 154
4.3 Display of Configuration Information of Server in table form (DataViewer) 161
4.4 Reference of Server Failure Information (AlertViewer) 164
4.5 Remote Setup of Server Monitoring (Agent Control Panel) 166
4.6 Remote Start-up of Server (Remote Wake Up) 179
4.7 Remote Shutdown of Server (Remote Shutdown) 181

Chap.5 Cooperation Between NEC ESMPRO Manager and HP OpenView Network Node Manager (HP OpenView Integration) 183
5.1 About HP OpenView Integration 184
5.2 Registration of NEC ESMPRO Agent 186
5.3 Monitoring of NEC ESMPRO Agent 189
5.4 Display of SNMP Trap of NEC ESMPRO Agent 191
5.5 Start-up of Operation Window and AlertViewer 192

Chap.6 Introduction of NEC ESMPRO Manager and Agent 193
6.1 Preparation of Installation 195
6.2 Installation 202
6.3 Remote Installation Utilizing ESMPRO/DeploymentManager 203
6.4 Setup of Post-Installation 204
6.5 Confirmation of Post-Installation 207
6.6 Uninstallation 208
6.7 In case Trouble Happens 209
6.8 Port used by NEC ESMPRO Manager and Agent 211