Alert list of NEC ESMPRO ServerAgentService (Syslog Monitor)

It is the list of alerts that Syslog Monitoring. When the combination of KeyWord1 and KeyWord2 accords, It report an applicable event.
Detected by Monitor Service, the message that syslog output is detected and Express Report is sent.

Source Name<SRC:>
It is displayed on "SOURCE" of the AlertViewer of NEC ESMPRO Manager.
Event ID(Hex digit)
The Event ID is a hexadecima number to identified for every report.
Error Type
The classification of the alert notified is expressed. There are three kinds, it is "Information", " Warning" and "Error".
Event ID
It is displayed on "Event ID" of the AlertViewer of NEC ESMPRO Manager.
Type
It is displayed on "Type" of the AlertViewer of NEC ESMPRO Manager.
Trap Name
It is displayed on "trapname" of the AlertViewer of NEC ESMPRO Manager.
KeyWord
When the special word is appeared in syslog, and it's message will be send
Message
"%1" - "%7" in the message means an implantation letter.
It is displayed on "Report Message" of the AlertViewer of NEC ESMPRO Manager.
Deal Meathod
It is displayed on "Deal Meathod" of the AlertViewer of NEC ESMPRO Manager.
Recover Action
It is processing to carry out after NEC ESMPRO ServerAgentService worked to report it.
It is a default and can change it by report setting.
Manager Report
In the case of "ON", reporting is possibly to send NEC ESMPRO Manager as SNMP Trap. In the case of "OFF", no action.
It is a default and can change it by report setting.
Manager Report(CIM-Indication)
If after 2.1.3-0, in the case of "ON", reporting is possibly to send NEC ESMPRO Manager as CIM Indication. In the case of "OFF", no action. It is a default and can change it by report setting.
If before 2.1.2-0, refer to alert list (Monitoring service).
Express Report(Level)
When Express Report is "ON" and Level are 0-3, or 8, and the Express Report, In the case of "OFF", no action.
It is a default. Because you cannot change Level, you cannot switch to an event to report the event that you do not report to.
Version
Version of target NEC ESMPRO ServerAgentService. In the case of "○", it support the event. In the case of "×", it not support the event.

<notice>
Manager Report(CIM-Indication) is supported after 2.1.3-0.

Syslog Event list of hardware monitoring

When Esmpro-Omsrv package is installed, this event registers an event.

Source Name<SRC:>: ESMCOMMONSERVICE (BMC support model)

This event detect in information of System Management BIOS(SMBIOS), it is a message to register. Default of "Manager Report(SNMP)" is "OFF". iLO support model is not supported.

Event ID (Hex digit)	Error Type	Event ID	Type	Trap Name	KeyWord1	KeyWord2	Message	Deal Meathod	Recover Action	Manager Report	Manager Report(CIM-)	Express Report (Level)	SNMP Trap OID (Enterprise ID.Specific ID)	Version																				
														2.2.7-0	2.2.5-0~2.2.6-0	2.2.4-0	esmsasup (2022-03-15)	2.2.3-0	2.2.2-0	2.2.0-0	2.1.3-0	2.1.2-0~2.1.1-0	2.1.0-0	2.0.9-0	2.0.8-0	2.0.7-0	2.0.6-0	2.0.5-0	2.0.3-0~2.0.4-0	2.0.1-0~2.0.2-1	2.0.0-0	1.3.0-0~1.3.1-0	1.1.3-0	1.1.0-0~1.1.2-0	1.0.0-0
800002BF	Warning	703	CPU	CPU Reduce	ESMCommonService	800002BF	Physical CPU%1 was degraded and is in no use.	Warning: A part of Processor has stopped. Please report to the maintenance member and exchange Processor.	NONE	OFF	ON	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
800002C6	Warning	710	Memory	Memory Reduce	ESMCommonService	800002C6	A memory is a degenerate state. Bank ID: %1 Memory ID: %2	Warning: A part of memory is a degenerate state. Please report to the maintenance member and exchange memory.	NONE	OFF	ON	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

Source Name<SRC:>: ESM STORAGE SERVICE (BMC support model)

When a HDD(SSD) of non-RAID changed, it is a message to register. Default of "Manager Report(SNMP)" is "OFF". iLO support model is not supported.

Event ID (Hex digit)	Error Type	Event ID	Type	Trap Name	KeyWord1	KeyWord2	Message	Deal Meathod	Recover Action	Manager Report	Manager Report(CIM-)	Express Report (Level)	SNMP Trap OID (Enterprise ID.Specific ID)	Version																				
														2.2.7-0	2.2.5-0~2.2.6-0	2.2.4-0	esmsasup (2022-03-15)	2.2.3-0	2.2.2-0	2.2.0-0	2.1.3-0	2.1.2-0~2.1.1-0	2.1.0-0	2.0.9-0	2.0.8-0	2.0.7-0	2.0.6-0	2.0.5-0	2.0.3-0~2.0.4-0	2.0.1-0~2.0.2-1	2.0.0-0	1.3.0-0~1.3.1-0	1.1.3-0	1.1.0-0~1.1.2-0	1.0.0-0
800403E9	Warning	1001	Storage HD Unit	Hard Disk Failure Prediction:S.M.A.R.T. Error	ESM Storage Service	800403E9	S.M.A.R.T. predicts that your hard disk is going to fail. %1 %2	Warning: S.M.A.R.T. predicts that your hard disk is going to fail. Contact your hardware vendor for a replacement.	NONE	OFF	ON	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
4004044C	Information	1100	Storage HD Unit	HDD(SSD) Endurance Remaining Information	ESM Storage Service	4004044C	HDD(SSD) Endurance Remaining is Safe(100-51%). %1 %2		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×
4004044D	Information	1101	Storage HD Unit	HDD(SSD) Endurance Remaining Information	ESM Storage Service	4004044D	HDD(SSD) Endurance Remaining is Reducing(50-21%). %1 %2		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×
8004044E	Warning	1102	Storage HD Unit	HDD(SSD) Endurance Remaining Warning	ESM Storage Service	8004044E	HDD(SSD) Endurance Remaining is Running out.(20-11%). %1 %2		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×
8004044F	Warning	1103	Storage HD Unit	HDD(SSD) Endurance Remaining Warning	ESM Storage Service	8004044F	HDD(SSD) Endurance Remaining is Need to replace(10 percent or less). %1 %2	Warning: Please replace the HDD(SSD).	NONE	OFF	ON	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×
C0040450	Error	1104	Storage HD Unit	HDD(SSD) Endurance Remaining Error	ESM Storage Service	C0040450	HDD(SSD) Endurance Remaining is End of Life. %1 %2	Fatal: Please replace the HDD(SSD).	NONE	OFF	ON	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×
400407D0	Information	2000	Storage HD Unit	Storage device configuration change	ESM Storage Service	400407D0	Configuration of the storage device has changed.		NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

Source Name<SRC:>: ESMCOMMONSERVICE (BMC support model)

This event detect in information of System Event Log(SEL), it is a message to register. Therefore there is the event that is not detected by a server of the use. Manager Report(CIM-Indication) is not support. Default of "Manager Report(SNMP)" is "OFF".

Event ID (Hex digit)	Error Type	Event ID	Type	Trap Name	KeyWord1	KeyWord2	Message	Deal Meathod	Recover Action	Manager Report	Manager Report(CIM-)	Express Report (Level)	SNMP Trap OID (Enterprise ID.Specific ID)	Version																				
														2.2.7-0	2.2.5-0~2.2.6-0	2.2.4-0	esmsasup (2022-03-15)	2.2.3-0	2.2.2-0	2.2.0-0	2.1.3-0	2.1.2-0~2.1.1-0	2.1.0-0	2.0.9-0	2.0.8-0	2.0.7-0	2.0.6-0	2.0.5-0	2.0.3-0~2.0.4-0	2.0.1-0~2.0.2-1	2.0.0-0	1.3.0-0~1.3.1-0	1.1.3-0	1.1.0-0~1.1.2-0	1.0.0-0
C0000064	Error	100	Temperature	Temp Upper Error	ESMCommonService	C0000064	The temperature has exceeded the upper threshold (Error). Sensor Number: %2 Location: %3 Temperature: %1 Threshold: %4	Fatal: The system cannot be operated with the current temperature. It may shutdown. Please check if the vent is not closed and the air conditioner is normally operating. Then please report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(1)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000065	Warning	101	Temperature	Temp Upper Warning	ESMCommonService	80000065	The temperature has exceeded the upper threshold (Warning). Sensor Number: %2 Location: %3 Temperature: %1 Threshold: %4	Warning: If the temperature rises any higher, it will affect the proper operation of the system. Check that the air inlet is not clogged and the air conditioner is running.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000066	Error	102	Temperature	Temp Lower Error	ESMCommonService	C0000066	The temperature has fallen below the lower threshold (Error). Sensor Number: %2 Location: %3 Temperature: %1 Threshold: %4	Fatal: The system cannot be operated with the current temperature. It may shutdown. Please check if the air conditioner is normally operating and report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(1)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000067	Warning	103	Temperature	Temp Lower Warning	ESMCommonService	80000067	The temperature has fallen below the lower threshold (Warning). Sensor Number: %2 Location: %3 Temperature: %1 Threshold: %4	Warning: It will malfunction if continue operating below the current temperature. Please check if the air conditioner is normally operating.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000068	Information	104	Temperature	Temp Upper Recovered	ESMCommonService	40000068	The temperature has recovered from its upper warning state. Sensor Number: %2 Location: %3 Temperature: %1 Threshold: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000069	Information	105	Temperature	Temp Lower Recovered	ESMCommonService	40000069	The temperature has recovered from its lower warning state. Sensor Number: %2 Location: %3 Temperature: %1 Threshold: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
8000006A	Warning	106	Temperature	Temp Upper Error Recovered	ESMCommonService	8000006A	The temperature has recovered from a high temperature fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Temperature: %1 Threshold: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
8000006B	Warning	107	Temperature	Temp Lower Error Recovered	ESMCommonService	8000006B	The temperature has recovered from a lower temperature fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Temperature: %1 Threshold: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000070	Error	112	Temperature	Temp Lower Limit Error	ESMCommonService	C0000070	%5 has fallen below the lower threshold (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Fatal: The system cannot be operated with the current temperature. It may shutdown. Please check if the air conditioner is normally operating and report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(1)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000071	Error	113	Temperature	Temp Lower Limit Error Recovered	ESMCommonService	C0000071	%5 has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000072	Error	114	Temperature	Temp Upper Limit Error	ESMCommonService	C0000072	%5 has exceeded the upper threshold (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Fatal: The system cannot be operated with the current temperature. It may shutdown. Please check if the vent is not closed and the air conditioner is normally operating. Then please report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(1)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

C0000073	Error	115	Temperature	Temp Upper Limit Error Recovered	ESMCommonService	C0000073	%S has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C00000C8	Error	200	Fan	Fan Unit Error	ESMCommonService	C00000C8	Fan Unit is malfunctioning. Location: %3 Sensor Number: %2 Date: %1	Fatal: The system cannot be operated with the current status. It may shutdown. Please report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(1)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
400000CD	Information	205	Fan	Fan Unit Error Recovered	ESMCommonService	400000CD	%S has recovered from the failure. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
800000CE	Warning	206	Fan	Fan Lower Limit Warning	ESMCommonService	800000CE	%S has fallen below the lower limit (Warning). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Warning: It will malfunction if continue operating with current status. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
400000CF	Information	207	Fan	Fan Lower Limit Warning Recovered	ESMCommonService	400000CF	%S has recovered from its lower warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C00000D0	Error	208	Fan	Fan Lower Limit Error	ESMCommonService	C00000D0	%S has fallen below the lower limit (Error). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Fatal: The system cannot be operated with the current status. It may shutdown. Please report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(1)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
800000D1	Warning	209	Fan	Fan Lower Limit Error Recovered	ESMCommonService	800000D1	%S has recovered from a fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C00000D2	Error	210	Fan	Fan Lower Limit Error	ESMCommonService	C00000D2	%S has fallen below the lower limit (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Fatal: The system cannot be operated with the current status. It may shutdown. Please report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(1)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C00000D3	Error	211	Fan	Fan Lower Limit Error Recovered	ESMCommonService	C00000D3	%S has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
800000D4	Warning	212	Fan	Fan Upper Limit Warning	ESMCommonService	800000D4	%S has exceeded the upper limit (Warning). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Warning: It will malfunction if continue operating with current status. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
400000D5	Information	213	Fan	Fan Upper Limit Warning Recovered	ESMCommonService	400000D5	%S has recovered from its upper warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C00000D6	Error	214	Fan	Fan Upper Limit Error	ESMCommonService	C00000D6	%S has exceeded the upper limit (Error). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1	Fatal: The system cannot be operated with the current status. It may shutdown. Please report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(1)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
800000D7	Warning	215	Fan	Fan Upper Limit Error Recovered	ESMCommonService	800000D7	%S has recovered from a fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C00000D8	Error	216	Fan	Fan Upper Limit Error	ESMCommonService	C00000D8	%S has exceeded the upper limit (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Fatal: The system cannot be operated with the current status. It may shutdown. Please report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(1)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C00000D9	Error	217	Fan	Fan Upper Limit Error Recovered	ESMCommonService	C00000D9	%S has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
4000012E	Information	302	RPS	Power Supply Recovered	ESMCommonService	4000012E	Power Supply has recovered from its warning status. Sensor Number: %2 Date: %1		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000132	Warning	306	RPS	Power Supply Error	ESMCommonService	80000132	Power Supply has lost the AC supply. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: Check the power supply's connectivity. If there are no connectivity problems, it might be a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000132	Error	306	RPS	Power Supply Error	ESMCommonService	C0000132	Power Supply has lost the AC supply. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Check the power supply's connectivity. If there are no connectivity problems, it might be a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000135	Error	309	RPS	Power Unit Error	ESMCommonService	C0000135	Power supply to the system has been stopped because Power Unit error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Check the power supply's connectivity. If there are no connectivity problems, it might be a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000136	Error	310	RPS	Power Unit Error	ESMCommonService	C0000136	The system has been forced to be power down, because the side cover was opened. Sensor Number: %2 Location: %3 Date: %1	Fatal: Please check the side cover has been closed. If there are no problems, it might be a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000137	Warning	311	RPS	Power Unit Error	ESMCommonService	80000137	Power Unit has lost the AC supply. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: Check the power supply's connectivity. If there are no connectivity problems, it might be a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000139	Warning	313	RPS	Power Unit Error	ESMCommonService	80000139	Power Unit error has been found. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: Check the power supply's connectivity. If there are no connectivity problems, it might be a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
8000013A	Warning	314	RPS	Power Supply Error	ESMCommonService	8000013A	Power Supply is in fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: Check the power supply's connectivity. If there are no connectivity problems, it might be a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

C000013A	Error	314	RPS	Power Supply Error	ESMCommonService	C000013A	Power Supply is in fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a power supply malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
8000013B	Warning	315	RPS	Power Supply Warning	ESMCommonService	8000013B	Power Supply is in warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: Check the power supply's connectivity. If there are no connectivity problems, it might be a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
800001FB	Warning	507	Voltage	Voltage Lower Limit Warning	ESMCommonService	800001FB	%5 has fallen below the lower limit (Warning). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Warning: It will malfunction if continue operating with current status. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
400001FC	Information	508	Voltage	Voltage Lower Limit Warning Recovered	ESMCommonService	400001FC	%5 has recovered from its lower warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C00001FD	Error	509	Voltage	Voltage Lower Limit Error	ESMCommonService	C00001FD	%5 has fallen below the lower limit (Error). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Fatal: The system cannot be operated with the current voltage. It may shutdown. Please report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
800001FE	Warning	510	Voltage	Voltage Lower Limit Error Recovered	ESMCommonService	800001FE	%5 has recovered from a fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C00001FF	Error	511	Voltage	Voltage Lower Limit Error	ESMCommonService	C00001FF	%5 has fallen below the lower limit (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Fatal: The system cannot be operated with the current voltage. It may shutdown. Please report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000200	Error	512	Voltage	Voltage Lower Limit Error Recovered	ESMCommonService	C0000200	%5 has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000201	Warning	513	Voltage	Voltage Upper Limit Warning	ESMCommonService	80000201	%5 has exceeded the upper limit (Warning). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Warning: It will malfunction if continue operating with current voltage. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000202	Information	514	Voltage	Voltage Upper Limit Warning Recovered	ESMCommonService	40000202	%5 has recovered from its upper warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000203	Error	515	Voltage	Voltage Upper Limit Error	ESMCommonService	C0000203	%5 has exceeded the upper limit (Error). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Fatal: The system cannot be operated with the current voltage. It may shutdown. Please report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000204	Warning	516	Voltage	Voltage Upper Limit Error Recovered	ESMCommonService	80000204	%5 has recovered from a fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000205	Error	517	Voltage	Voltage Upper Limit Error	ESMCommonService	C0000205	%5 has exceeded the upper limit (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Fatal: The system cannot be operated with the current voltage. It may shutdown. Please report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000206	Error	518	Voltage	Voltage Upper Limit Error Recovered	ESMCommonService	C0000206	%5 has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
400002C0	Information	704	RPS	Power Unit Reduction Recovered	ESMCommonService	400002C0	%5 has recovered from reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
800002C1	Warning	705	RPS	Power Unit Reduction	ESMCommonService	800002C1	%5 is in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: The system is now operating with spare power supply. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
400002C3	Information	707	Fan	Cooler Reduced	ESMCommonService	400002C3	%5 has recovered from reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Information: Please collect the log data with the log collection tool and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
800002C4	Warning	708	Fan	Fan Unit Warning	ESMCommonService	800002C4	%5 is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000320	Error	800	System Error	STOP Error occurred	ESMCommonService	C0000320	System Error Information Time:%1 Dump Switch:%2 Message: %3	Fatal: The system is down because a STOP error occurred. Please report to the maintenance member.	NONE	OFF	OFF	ON(0)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000044C	Error	1100	Memory	ECC Multiple Error	ESMCommonService	C000044C	ECC Multiple bit error occurred. Date: %1 Code: %2	Fatal: It is considered a memory malfunction. Please contact with the maintenance member to exchange the memory.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000044D	Error	1101	Bus	EISA Bus Timeout	ESMCommonService	C000044D	EISA Bus Timeout(Bus) caused by one of the Bus Masters. Date: %1 Master ID: %2	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000044E	Error	1102	Bus	EISA I/O CH Error	ESMCommonService	C000044E	EISA I/O channel check error occurred. Date: %1 Master ID: %2	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000044F	Error	1103	Bus	PCI Parity error	ESMCommonService	C000044F	Parity error occurred in the PCI subsystem. Date: %1 PCI Bus ID: %2	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000450	Error	1104	Bus	PCI System error	ESMCommonService	C0000450	System error occurred on the PCI buses. Date: %1 PCI Bus ID: %2	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000451	Error	1105	CPU	CPU Internal error	ESMCommonService	C0000451	CPU internal error occurred. Date: %1 Sensor Number:%2	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

C0000452	Error	1106	Server Recovery	Failsafe-timer	ESMCommonService	C0000452	Timeout of failsafe-timer(watchdog timer). Date: %1	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000453	Error	1107	CPU	System bus error	ESMCommonService	C0000453	System error on the system buses. Date: %1 Bus ID: %2	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000454	Error	1108	CPU	CPU thermal trip event	ESMCommonService	C0000454	CPU thermal trip occurred. Date: %1 Sensor Number:%2	Fatal: The system cannot be operated with the current status. It may shutdown. Please report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000514	Error	1300	OS	Software NMI	ESMCommonService	C0000514	NMI generated by software. Date: %1	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000515	Warning	1301	Memory	POST memory resize	ESMCommonService	80000515	Adjusted memory size. Date: %1 Bank ID: %2 Bank Original Size: %3 Bank Current Size: %4		NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×
80000516	Warning	1302	Server Recovery	POST Error	ESMCommonService	80000516	Error was detected during the POST phase of system initialization. Date: %1 Error Code: %2	Warning: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000516	Error	1302	Server Recovery	POST Error	ESMCommonService	C0000516	Error was detected during the POST phase of system initialization. Date: %1 Error Code: %2	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000517	Warning	1303	System Error	Error log disabled	ESMCommonService	80000517	The error logging for specific error has been disabled. Date: %1 Error Type: %2	Warning: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000518	Warning	1304	Server Recovery	WDT Reset	ESMCommonService	80000518	Reset event caused by the watchdog timer. (%4) Date: %1 Timeout Value: %2	Warning: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000519	Information	1305	Server Recovery	System reconfig	ESMCommonService	40000519	The system configuration was altered by the configuration utility. Date: %1		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
8000051A	Warning	1306	CPU	POST cache Reduce	ESMCommonService	8000051A	Cache is running at a reduced capacity. Date: %1 DIMM ID: %2 Site Original Size: %3 Site Current Size: %4	Warning: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
8000051B	Warning	1307	CPU	Cache ECC Single	ESMCommonService	8000051B	Level 3 cache ECC single bit error occurred. Date: %1 DIMM ID: %2	Warning: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000051C	Error	1308	CPU	Cache ECC multi	ESMCommonService	C0000051C	Level 3 cache ECC multiple bit error occurred. Date: %1 DIMM ID: %2	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
8000051D	Warning	1309	CPU	BUS ECC single	ESMCommonService	8000051D	System bus ECC single bit error occurred. Date: %1 SYSTEM BUS ID: %2	Warning: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000523	Error	1315	CPU	Processor Disabled	ESMCommonService	C0000523	Processor has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a CPU malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×
40000526	Information	1318	Server Recovery	Error log disable	ESMCommonService	40000526	All the errors logging to System Event Log have been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Information: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000529	Error	1321	Bus	BUS ECC multi	ESMCommonService	C0000529	ECC Multi bit error of system bus has occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Collect the failure information by the collection tool if possible, and contact the maintenance personnel.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000052A	Error	1322	CPU	NMI	ESMCommonService	C0000052A	NMI has occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000578	Error	1400	Server Recovery	HW eventlog	ESMCommonService	C0000578	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000579	Warning	1401	Server Recovery	HW eventlog	ESMCommonService	80000579	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	Warning: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
4000057A	Information	1402	Server Recovery	HW eventlog	ESMCommonService	4000057A	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000057F	Error	1407	Server Recovery	HW eventlog	ESMCommonService	C0000057F	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
80000580	Warning	1408	Server Recovery	HW eventlog	ESMCommonService	80000580	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	Warning: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
40000581	Information	1409	Server Recovery	HW eventlog	ESMCommonService	40000581	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
40000642	Information	1602	Security	Slot State	ESMCommonService	40000642	New device has been connected to the slot or the connector device. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Information: Hardware component has been changed. Please reconstruct tree if you already have DataViewer opened for this server or have the information of this server's status and component.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000645	Information	1605	Security	Slot State	ESMCommonService	40000645	Either the slot or connector power has been off, or device has been removed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Information: Hardware component has been changed. Please reconstruct tree if you already have DataViewer opened for this server or have the information of this server's status and component.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000708	Warning	1800	Server Recovery	WDT Reset	ESMCommonService	80000708	Time out of Watch Dog Timer has occurred. (%5) Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It is considered a system (hardware or software) malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
8000070A	Warning	1802	Server Recovery	WDT Reset	ESMCommonService	8000070A	Power Down occurred as time out of Watch Dog Timer has occurred. (%5) Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It is considered a system (hardware or software) malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

8000070B	Warning	1803	Server Recovery	WDT Reset	ESMCommonService	8000070B	Power Cycle has occurred due to time out of Watch Dog Timer. (%5) Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It is considered a system (hardware or software) malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000710	Warning	1808	Server Recovery	WDT Reset	ESMCommonService	80000710	Interruption has occurred by time out of Watch Dog Timer. (%5) Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It is considered a system (hardware or software) malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000076C	Error	1900	Bus	Sensor Failure	ESMCommonService	C000076C	%5 The system might have broken down. There is no response from the sensor. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4 SEL Dump: %6	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000076D	Error	1901	Bus	Sensor Failure	ESMCommonService	C000076D	%5 Sensor Error has been detected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4 SEL Dump: %6	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000076E	Error	1902	Bus	Sensor Failure	ESMCommonService	C000076E	%5 The system might have broken down. Time out occurred in the access process to the sensor. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4 SEL Dump: %6	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
800008FF	Warning	2303	Security	Slot State	ESMCommonService	800008FF	The slot or connector device is in fault state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: Hardware component has been changed. Please reconstruct tree if you already have DataViewer opened for this server or have the information of this server's status and component.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C00008FF	Error	2303	Security	Slot or Connector State	ESMCommonService	C00008FF	The slot or connector device is in fault state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000900	Warning	2304	Memory	ECC Correctable Errors	ESMCommonService	80000900	Too many ECC Correctable Errors. Please confirm the IPMI log and specify the DIMM number. Latest ECC correctable error log generation memory number:%5	Warning: It is considered a memory malfunction. Continuous use is dangerous. Please contact with the maintenance member to exchange the memory.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000901	Warning	2305	Voltage	Voltage Warning	ESMCommonService	80000901	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000902	Information	2306	Voltage	Voltage Recover	ESMCommonService	40000902	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000903	Error	2307	Memory	ECC Uncorrectable Error	ESMCommonService	C0000903	ECC uncorrectable error occurred. Date: %1 Syndrome Byte: %2 Row Number: %5 Memory Card Number: %3 Memory Number: %4	Fatal: It is considered a memory malfunction. Please contact with the maintenance member to exchange the memory.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000904	Information	2308	Notify Switch	Notify Switch ON	ESMCommonService	40000904	Notify Switch ON. %2 Date: %1		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000906	Information	2310	Security	Slot State	ESMCommonService	40000906	The device has been removed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Hardware component has been changed. Please reconstruct tree if you already have DataViewer opened for this server.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000907	Warning	2311	Temperature	Temperature Warning	ESMCommonService	80000907	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It will malfunction if continue operating above the current temperature. Please check if the vent is not closed and the air conditioner is normally operating.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000908	Information	2312	Temperature	Temperature Recover	ESMCommonService	40000908	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000909	Information	2313	Memory	DIMM Disabled	ESMCommonService	40000909	A part of DIMM is disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000909	Warning	2313	Memory	DIMM Fault	ESMCommonService	80000909	A part of DIMM is in fault state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It is considered a memory malfunction. Please contact with the maintenance member to exchange the memory.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000909	Error	2313	Memory	DIMM Fault	ESMCommonService	C0000909	A part of DIMM is in fault state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Please report to the maintenance member and exchange memory.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000090A	Error	2314	Voltage	Voltage Error	ESMCommonService	C000090A	%5 has gone into a non-recoverable state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000090B	Error	2315	Fan	Cooling Device Failure	ESMCommonService	C000090B	All of Fans inside %5 is broken or not implemented. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
8000090C	Warning	2316	Fan	Fan Unit Warning	ESMCommonService	8000090C	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It will malfunction if continue operating with current status. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
4000090D	Information	2317	Fan	Fan Unit Recovered	ESMCommonService	4000090D	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000090E	Error	2318	Voltage	Voltage Error	ESMCommonService	C000090E	%5 is in a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
8000090F	Warning	2319	Voltage	Voltage Error Recovered	ESMCommonService	8000090F	%5 has recovered from a fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000910	Warning	2320	Fan	Fan Unit Warning	ESMCommonService	80000910	%5 has fallen below the lower limit (Warning). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Warning: It will malfunction if continue operating with current status. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000911	Information	2321	Fan	Fan Unit Recovered	ESMCommonService	40000911	%5 has recovered from its lower warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000912	Warning	2322	RPS	Power Unit Reduction	ESMCommonService	80000912	%5 Redundancy Degraded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: Check the power supply's connectivity. If there are no connectivity problems, it might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000913	Warning	2323	RPS	Power Unit Reduction	ESMCommonService	80000913	%5 Non-redundant : Sufficient Resources from Redundant Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: Check the power supply's connectivity. If there are no connectivity problems, it might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

C0000913	Error	2323	RPS	Power Unit Reduction	ESMCommonService	C0000913	%5 Non-redundant : Sufficient Resources from Redundant. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Check the power supply's connectivity. If there are no connectivity problems, it might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000914	Information	2324	RPS	Power Unit Reduction Recovered	ESMCommonService	40000914	%5 Non-redundant : Sufficient Resources from Insufficient Resources Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000914	Warning	2324	RPS	Power Unit Lack Recovered	ESMCommonService	80000914	%5 Non-redundant : Sufficient Resources from Insufficient Resources. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000915	Error	2325	RPS	Power Unit Reduction	ESMCommonService	C0000915	%5 Non-redundant : Insufficient Resources Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Check the power supply's connectivity. If there are no connectivity problems, it might be a device malfunction. Please report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000916	Warning	2326	RPS	Power Unit Reduction	ESMCommonService	80000916	%5 Redundancy Degraded from Fully Redundant Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: Check the power supply's connectivity. If there are no connectivity problems, it might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000917	Information	2327	RPS	Power Unit Reduction Recovered	ESMCommonService	40000917	%5 Redundancy Degraded from Non-Redundant Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000918	Information	2328	Security	Slot State	ESMCommonService	40000918	The slot or connector device has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000919	Information	2329	Memory	DIMM Recover	ESMCommonService	40000919	The DIMM has recovered. Sensor Number: %2 Date: %1		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000091A	Error	2330	Chipset	Chipset Error	ESMCommonService	C000091A	Chipset errors(CNB3.OHE#0) Date: %1 ErrorCode: %2	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000091B	Error	2331	Chipset	Chipset Error	ESMCommonService	C000091B	Chipset errors(CNB3.OHE#1) Date: %1 ErrorCode: %2	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000091C	Error	2332	Chipset	Chipset Error	ESMCommonService	C000091C	Chipset errors(CIOB20H0) Date: %1 ErrorCode: %2	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000091D	Error	2333	Chipset	Chipset Error	ESMCommonService	C000091D	Chipset errors(CIOB20H1) Date: %1 ErrorCode: %2	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000091E	Error	2334	Chipset	Chipset Error	ESMCommonService	C000091E	Chipset errors(AQUA80) Date: %1 ErrorCode: %2	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000091F	Error	2335	Chipset	Chipset Error	ESMCommonService	C000091F	Chipset errors(AQUA81) Date: %1 ErrorCode: %2	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000920	Error	2336	Chipset	Chipset Error	ESMCommonService	C0000920	Chipset errors(CMIC Function#0) Date: %1 ErrorCode: %2	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000921	Error	2337	Chipset	Chipset Error	ESMCommonService	C0000921	Chipset errors(CMIC Function#1-3) Date: %1 ErrorCode: %2	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000922	Error	2338	Chipset	Chipset Error	ESMCommonService	C0000922	Chipset errors(CIOB30H0) Date: %1 ErrorCode: %2	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000923	Error	2339	Chipset	Chipset Error	ESMCommonService	C0000923	Chipset errors(CIOB30H1) Date: %1 ErrorCode: %2	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000924	Error	2340	Chipset	Chipset Error	ESMCommonService	C0000924	Chipset errors(REMC) Date: %1 ErrorCode: %2	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000925	Error	2341	Chipset	Chipset Error	ESMCommonService	C0000925	Chipset errors(CSB5) Date: %1 ErrorCode: %2	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000926	Error	2342	Chipset	Chipset Error	ESMCommonService	C0000926	Chipset errors(CIOB30H2) Date: %1 ErrorCode: %2	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000092E	Error	2350	Temperature	Temperature Error	ESMCommonService	C000092E	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Check the air temperature. If there are no problems, it might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
4000092F	Information	2351	Temperature	Temperature Error Recovered	ESMCommonService	4000092F	%5 has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000930	Error	2352	Voltage	Voltage Error	ESMCommonService	C0000930	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000931	Information	2353	Voltage	Voltage Error Recovered	ESMCommonService	40000931	%5 has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000932	Error	2354	Voltage	Voltage Error	ESMCommonService	C0000932	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000938	Error	2360	Chipset	Chipset Error	ESMCommonService	C0000938	Chipset Specific Critical Interrupt Information Date: %1	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000093E	Error	2366	Temperature	Temperature Error	ESMCommonService	C000093E	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
8000093F	Warning	2367	Temperature	Temperature Error Recovered	ESMCommonService	8000093F	%5 has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000940	Warning	2368	Temperature	Temperature Warning	ESMCommonService	80000940	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: Check the surroundings temperature. If there are no problems, it might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000941	Information	2369	Temperature	Temperature Warning Recovered	ESMCommonService	40000941	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000942	Error	2370	Temperature	Temperature Error	ESMCommonService	C0000942	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000943	Information	2371	Temperature	Temperature Recovery	ESMCommonService	40000943	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000945	Information	2373	Fan	Fan Unit Reduction Recovered	ESMCommonService	40000945	%5 has recovered from a reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000946	Warning	2374	Fan	Fan Unit Reduction	ESMCommonService	80000946	%5 is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It will malfunction if continue operating with current status. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000946	Error	2374	Fan	Fan Unit Reduction	ESMCommonService	C0000946	%5 is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It will malfunction if continue operating with current status. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000947	Error	2375	CPU	Processor Error	ESMCommonService	C0000947	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

C000094A	Error	2378	CPU	CPU Configuration Error	ESMCommonService	C000094A	CPU configuration error occurred. Date: %1 Sensor Number: %2	Fatal: If the log collection tool can start, please collect the log data with it and report to the maintenance	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
8000094E	Warning	2382	RPS	Power Supply Error	ESMCommonService	8000094E	Power supply has lost the AC supply or been out-of-range. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: Check the power supply's connectivity. If there are no connectivity problems, it might be a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
8000094F	Warning	2383	Memory	Memory Reduction	ESMCommonService	8000094F	Memory has been non-redundant. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It is considered a memory malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000950	Error	2384	Server Recovery	Hardware Error	ESMCommonService	C0000950	Unspecified system hardware failure occurred. Date: %1	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000951	Error	2385	Bus	Bus Fatal Error	ESMCommonService	C0000951	Bus fatal error occurred. Date: %1	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000956	Error	2390	Fan	Fan Lower Limit Error	ESMCommonService	C0000956	%5 has fallen below the lower limit (Error). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000957	Information	2391	Memory	Memory Reduction Recovered	ESMCommonService	40000957	Memory has recovered from a reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000958	Warning	2392	Memory	Memory Warning	ESMCommonService	80000958	Memory has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It might be a memory malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000959	Error	2393	Memory	Memory Error	ESMCommonService	C0000959	Memory has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
8000095A	Warning	2394	Memory	Memory Configuration Error	ESMCommonService	8000095A	Memory configuration error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It might be a memory malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
8000095F	Warning	2399	Notify	Cable Configuration Error	ESMCommonService	8000095F	Cable/interconnect configuration error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000969	Error	2409	Notify	Drive Fault	ESMCommonService	C0000969	Device has a drive fault. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
4000096A	Information	2410	Notify	Drive Fault Recovered	ESMCommonService	4000096A	Device has recovered from drive fault. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000970	Information	2416	Notify	Cable Configuration Error Recovered	ESMCommonService	40000970	Recovered from cable/interconnect configuration error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000971	Warning	2417	Notify	Battery Warning	ESMCommonService	80000971	Battery has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It might be a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000972	Information	2418	Notify	Battery Warning Recovered	ESMCommonService	40000972	Battery has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000973	Error	2419	Notify	Battery Error	ESMCommonService	C0000973	Battery has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000974	Information	2420	Notify	Battery Error Recovered	ESMCommonService	40000974	Battery has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000A2A	Error	2602	System Error	MCA	ESMCommonService	C0000A2A	MCA has occurred. Sensor Number %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Hardware critical error was been detected. System down malfunction has been occurred. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000A8C	Error	2700	LiquidLeak	Liquid Leak Error	ESMCommonService	C0000A8C	Liquid Leak has happened. Location: %3 Sensor Number: %2 Date: %1	Fatal: It is considered a device malfunction. Please report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000A8D	Information	2701	LiquidLeak	Liquid Leak Recovered	ESMCommonService	40000A8D	Liquid Leak has recovered. Location: %3 Sensor Number: %2 Date: %1		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000AC8	Error	2760	Memory	Memory Board Error	ESMCommonService	C0000AC8	The Memory Board has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000AC9	Information	2761	Memory	Memory Board Recover	ESMCommonService	40000AC9	The Memory Board has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B01	Information	2817	Fan	Fan Unit Recovery	ESMCommonService	40000B01	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B02	Information	2818	CPU	Processor Recovery	ESMCommonService	40000B02	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B03	Warning	2819	CPU	Processor Warning	ESMCommonService	80000B03	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B04	Error	2820	CPU	CPU Self-Test Error	ESMCommonService	C0000B04	CPU self-test error occurred. Date: %1 Sensor Number: %2	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B07	Error	2823	CPU	CPU Initialize Error	ESMCommonService	C0000B07	CPU initialization error occurred. Date: %1 Sensor Number: %2	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B15	Information	2837	RPS	Power Unit Error Recovered	ESMCommonService	40000B15	Power unit has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B17	Information	2839	Memory	ECC Uncorrectable Error Recovered	ESMCommonService	40000B17	Recovered from ECC uncorrectable error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B18	Error	2840	Memory	Memory Parity Error	ESMCommonService	C0000B18	Memory parity error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a memory malfunction. Please contact with the maintenance member to exchange the memory.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B19	Warning	2841	Memory	Memory Error	ESMCommonService	80000B19	Memory scrub failed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It will malfunction if continue operating with current status. Please contact with the maintenance member to exchange the memory.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

80000B1C	Warning	2844	Memory	ECC Correctable Errors	ESMCommonService	80000B1C	The limit on ECC correctable errors has been reached. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It will malfunction if continue operating with current status. Please contact with the maintenance member to exchange the memory.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B1C	Error	2844	Memory	ECC Correctable Errors	ESMCommonService	C0000B1C	The limit on ECC correctable errors has been reached. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It will malfunction if continue operating with current status. Please contact with the maintenance member to exchange the memory.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
40000B1D	Information	2845	Memory	ECC Correctable Errors Recovered	ESMCommonService	40000B1D	Recovered from ECC correctable errors. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B24	Error	2852	Memory	Memory Temperature Error	ESMCommonService	C0000B24	Memory temperature has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a memory malfunction. Please contact with the maintenance member to exchange the memory.	SHUTDOWN	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B25	Information	2853	Memory	Memory Temperature Error Recovered	ESMCommonService	40000B25	Memory temperature has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B26	Information	2854	Notify	Module Recovered	ESMCommonService	40000B26	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B27	Warning	2855	Notify	Module Warning	ESMCommonService	80000B27	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B28	Error	2856	Notify	Module Error	ESMCommonService	C0000B28	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B29	Information	2857	Notify	Chipset Recovery	ESMCommonService	40000B29	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B2A	Warning	2858	Notify	Chipset Warning	ESMCommonService	80000B2A	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B2B	Error	2859	Notify	Chipset Error	ESMCommonService	C0000B2B	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	SHUTDOWN	OFF	OFF	ON(1)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B2C	Information	2860	Notify	Cable Recovery	ESMCommonService	40000B2C	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B2D	Warning	2861	Notify	Cable Warning	ESMCommonService	80000B2D	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B2E	Error	2862	Notify	Cable Error	ESMCommonService	C0000B2E	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B33	Warning	2867	Notify	Cell Mode	ESMCommonService	80000B33	The communication between the cell and the boot cell failed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B3F	Information	2879	Notify	Cell/Partition State	ESMCommonService	40000B3F	Cell/partition is stopped. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B47	Information	2887	Notify	Cell/Partition Reduction Recovered	ESMCommonService	40000B47	Cell/partition has recovered from a reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B48	Information	2888	Notify	Cell/Partition Reduction	ESMCommonService	40000B48	Cell/partition is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B49	Error	2889	Notify	System Validity	ESMCommonService	C0000B49	The cell is not able to be used in a partition. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B4C	Warning	2892	Notify	System Validity	ESMCommonService	80000B4C	The system serial number displayed for this cell is different than the system serial number displayed for other cells in the system. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B51	Information	2897	Notify	Partition Viability	ESMCommonService	40000B51	Partition is not viable. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B53	Information	2899	Notify	Cell/Partition State	ESMCommonService	40000B53	Cell/partition has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B54	Warning	2900	Notify	Cell/Partition State	ESMCommonService	80000B54	Cell/partition has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B55	Error	2901	Notify	Cell/Partition State	ESMCommonService	C0000B55	Cell/partition has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B56	Information	2902	Notify	Cell/Partition Software Fault	ESMCommonService	40000B56	Cell/partition software has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B57	Warning	2903	Notify	Cell/Partition Software Fault	ESMCommonService	80000B57	Cell/partition software has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B58	Error	2904	Notify	Cell/Partition Software Fault	ESMCommonService	C0000B58	Cell/partition software has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B5D	Information	2909	Notify	Service Processor for Partition Control Reduction	ESMCommonService	40000B5D	Partition has recovered from reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B5E	Warning	2910	Notify	Service Processor for Partition Control Reduction	ESMCommonService	80000B5E	Partition is running at a reduced capacity. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

80000B5F	Warning	2911	Notify	Service Processor for Partition Control Reduction	ESMCommonService	80000B5F	Partition redundancy degraded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B62	Warning	2914	Notify	Memory Mirroring Reduction	ESMCommonService	80000B62	Memory mirroring has been enabled, but Mem_Brd0 is broken. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B63	Warning	2915	Notify	Memory Mirroring Reduction	ESMCommonService	80000B63	Memory mirroring has been enabled, but Mem_Brd1 is broken. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B75	Information	2933	Notify	Chassis Recovery	ESMCommonService	40000B75	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B76	Warning	2934	Notify	Chassis Warning	ESMCommonService	80000B76	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B77	Error	2935	Notify	Chassis Error	ESMCommonService	C0000B77	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B78	Error	2936	CPU	POST Process Stall	ESMCommonService	C0000B78	Power On Self Test (POST) process stalled. Date: %1 Post Code: %2	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B79	Error	2937	Fan	Fan Unit Error	ESMCommonService	C0000B79	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B7A	Information	2938	RPS	Power Unit Error Recovered	ESMCommonService	40000B7A	The abnormal power unit signal has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B7C	Error	2940	RPS	Power Supply Error	ESMCommonService	C0000B7C	Power supply is in fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: The system is now operating with the spare power supply. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B83	Warning	2947	RPS	Power Unit Error	ESMCommonService	80000B83	An abnormal power unit signal was detected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It might be a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B84	Information	2948	Memory	Memory Parity Error Recovered	ESMCommonService	40000B84	Recovered from memory parity error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B85	Information	2949	Memory	Memory Error Recovered	ESMCommonService	40000B85	Recovered from memory scrub error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B86	Information	2950	Memory	Memory Configuration Error Recovered	ESMCommonService	40000B86	Recovered from memory configuration error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B8A	Warning	2954	RPS	Power Control Error	ESMCommonService	80000B8A	Power control has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B8B	Information	2955	RPS	Power Control Error Recovered	ESMCommonService	40000B8B	Power control has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B8C	Error	2956	RPS	Power Unit State	ESMCommonService	C0000B8C	Fan module 0 is disabled, DC power is off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B8D	Warning	2957	RPS	Power Unit State	ESMCommonService	80000B8D	Fan module 0 is disabled, 2 minutes until power off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B8E	Warning	2958	RPS	Power Unit Error	ESMCommonService	80000B8E	Loss of communication to power supply 0. Sensor Number: %2 Location: %3 Date: %1		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B8F	Warning	2959	RPS	Power Unit State	ESMCommonService	80000B8F	CPU0 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B90	Error	2960	Notify	Boot Error	ESMCommonService	C0000B90	Reboot count has been exceeded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B92	Warning	2962	Notify	PCI Card State	ESMCommonService	80000B92	PCI card has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000B93	Information	2963	Notify	PCI Card State	ESMCommonService	40000B93	PCI card has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B94	Error	2964	Notify	PCI Card State	ESMCommonService	C0000B94	PCI card has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000B9C	Warning	2972	Notify	System Validity	ESMCommonService	80000B9C	The manufacturer ID displayed for this cell is different than the manufacturer ID displayed for other cells in the system. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B9D	Error	2973	Notify	System Validity	ESMCommonService	C0000B9D	The firmware level running on the Service Processor for this cell is different from the firmware level running on other cells in the system. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000B9E	Error	2974	Notify	System Validity	ESMCommonService	C0000B9E	The cells are missing. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000BA0	Warning	2976	Notify	Memory Mirroring Reduction	ESMCommonService	80000BA0	Memory mirroring configuration error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BA1	Information	2977	RPS	Power Unit State	ESMCommonService	40000BA1	Power unit has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

C0000BA2	Error	2978	RPS	Power Unit State	ESMCommonService	C0000BA2	Fan module 1 is disabled, DC power is off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000BA3	Warning	2979	RPS	Power Unit State	ESMCommonService	80000BA3	Fan module 1 is disabled, 2 minutes until power off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000BA4	Warning	2980	RPS	Power Unit Error	ESMCommonService	80000BA4	Loss of communication to power supply 1. Sensor Number: %2 Location: %3 Date: %1		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000BA5	Warning	2981	RPS	Power Unit State	ESMCommonService	80000BA5	CPU1 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000BA6	Warning	2982	RPS	Power Unit State	ESMCommonService	80000BA6	CPU2 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000BA7	Warning	2983	RPS	Power Unit State	ESMCommonService	80000BA7	CPU3 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000BA8	Warning	2984	Notify	PCI Card State	ESMCommonService	80000BA8	PCI bus number or memory-mapped space resource allocation has been exceeded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000BA9	Warning	2985	Notify	PCI Card State	ESMCommonService	80000BA9	IO space resource allocation has been exceeded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000BAA	Warning	2986	Notify	PCI Card State	ESMCommonService	80000BAA	PCI resource has been changed to a different type. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000BAB	Warning	2987	Notify	PCI Card State	ESMCommonService	80000BAB	Unable to execute OPROM. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BAC	Information	2988	RPS	Power Unit Error Recovered	ESMCommonService	40000BAC	Power unit has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BAD	Information	2989	Voltage	Voltage Recovery	ESMCommonService	40000BAD	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000BAE	Error	2990	Voltage	Voltage Error	ESMCommonService	C0000BAE	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000BAF	Error	2991	Notify	Chipset Thermal Trip Event	ESMCommonService	C0000BAF	Chipset thermal trip occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BB1	Information	2993	Security	Slot or Connector State	ESMCommonService	40000BB1	The slot or connector device is disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000BB1	Warning	2993	Security	Slot State	ESMCommonService	80000BB1	The slot or connector device is disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000BB2	Error	2994	Notify	SMI Timeout	ESMCommonService	C0000BB2	SMI Timeout occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it. Then please send the investigation request.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000BB3	Warning	2995	Notify	Power Domain	ESMCommonService	80000BB3	Power Consumption has not recovered from Limit%5. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: It is necessary to change the upper threshold of power consumption or reduce the system load.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BB4	Information	2996	Security	Slot State	ESMCommonService	40000BB4	Either the slot or connector power has been on, or device has been connected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Information: Hardware component has been changed. Please reconstruct tree if you already have DataViewer opened for this server or have the information of this server's status and component.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000BB5	Error	2997	Notify	Management Engine Status Change	ESMCommonService	C0000BB5	Operational Firmware image error corrupted. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a motherboard malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	○	○	×	○	○	○	○	○	○	○	○
C0000BB5	Error	2997	Notify	Management Engine Status Change	ESMCommonService	C0000BB5	Operational Firmware image error corrupted. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Please report to the maintenance member and exchange motherboard or management board.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000BB6	Error	2998	Notify	Management Engine Status Change	ESMCommonService	C0000BB6	Flash ROM erase error corrupted. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a motherboard malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	○	○	×	○	○	○	○	○	○	○	○
C0000BB6	Error	2998	Notify	Management Engine Status Change	ESMCommonService	C0000BB6	Flash ROM erase error corrupted. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Please report to the maintenance member and exchange motherboard or management board.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000BB7	Error	2999	Notify	Management Engine Status Change	ESMCommonService	C0000BB7	Flash ROM error corrupted. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a motherboard malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	○	○	×	○	○	○	○	○	○	○	○
C0000BB7	Error	2999	Notify	Management Engine Status Change	ESMCommonService	C0000BB7	Flash ROM error corrupted. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Please report to the maintenance member and exchange motherboard or management board.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000BB8	Error	3000	Notify	Management Engine Status Change	ESMCommonService	C0000BB8	Firmware internal error occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a motherboard malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	○	○	×	○	○	○	○	○	○	○	○
C0000BB8	Error	3000	Notify	Management Engine Status Change	ESMCommonService	C0000BB8	Firmware internal error occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Please report to the maintenance member and exchange motherboard or management board.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000BB9	Error	3001	Notify	Management Engine Status Change	ESMCommonService	C0000BB9	BMC did not respond to cold reset request. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a motherboard malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	○	○	×	○	○	○	○	○	○	○	○

C0000BB9	Error	3001	Notify	Management Engine Status Change	ESMCommonService	C0000BB9	BMC did not respond to cold reset request. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Please report to the maintenance member and exchange motherboard or management board.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000BBA	Error	3002	Notify	Management Engine Status Change	ESMCommonService	C0000BBA	Manufacturing configuration is wrong. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a motherboard malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	○	○	×	○	○	○	○	○	○	○	○
C0000BBA	Error	3002	Notify	Management Engine Status Change	ESMCommonService	C0000BBA	Manufacturing configuration is wrong. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Please report to the maintenance member and exchange motherboard or management board.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000BBB	Error	3003	Notify	Management Engine Status Change	ESMCommonService	C0000BBB	Flash ROM File System error occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a motherboard malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	○	○	×	○	○	○	○	○	○	○	○
C0000BBB	Error	3003	Notify	Management Engine Status Change	ESMCommonService	C0000BBB	Flash ROM File System error occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Please report to the maintenance member and exchange motherboard or management board.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
80000BBC	Warning	3004	Notify	Filter Replacement Sensor Warning	ESMCommonService	80000BBC	The value of %5 has changed unusually. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4 (%5: Filter Replacement Sensor)	Warning: Please check whether the front cover is open. Please check whether the environment of the server setting place or the configuration of the server has been changed after calibrating the Filter Replacement Sensor. If they have been changed, please replace the filter to new one and calibrate the Filter Replacement Sensor again.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BBD	Information	3005	Notify	Filter Replacement Sensor Warning Recovered	ESMCommonService	40000BBD	The value of %5 has recovered. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4 (%5: Filter Replacement Sensor)		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000BBE	Error	3006	Notify	Filter Replacement Sensor Error	ESMCommonService	C0000BBE	%5 has been clogged up with dust. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4 (%5: Filter Replacement Sensor)	Fatal: The filter is clogged up with dust. Please replace the filter to a new one and calibrate the Filter Replacement Sensor.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BBF	Information	3007	Notify	Filter Replacement Sensor Error Recovered	ESMCommonService	40000BBF	%5 has recovered from the clogged up state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4 (%5: Filter Replacement Sensor)		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000BC8	Warning	3016	Voltage	Voltage Error Recovered	ESMCommonService	80000BC8	%5 has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4 (%5: Voltage)		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BC9	Information	3017	Notify	Secure Mode	ESMCommonService	40000BC9	Power button was pushed in secure mode. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BCA	Information	3018	Notify	Password violation	ESMCommonService	40000BCA	The login password to BMC is violation. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Information: Check the inputted password.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BCB	Information	3019	Notify	Processor Reduction	ESMCommonService	40000BCB	Processor is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BCC	Information	3020	Notify	Processor Reduction Recovered	ESMCommonService	40000BCC	Processor has recovered from reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BCD	Information	3021	Notify	Drive Inserted	ESMCommonService	40000BCD	Drive has been inserted. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BCE	Information	3022	Notify	Drive Removed	ESMCommonService	40000BCE	Drive has been removed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BCF	Information	3023	Notify	Drive Rebuild	ESMCommonService	40000BCF	Drive slot is in rebuild progress. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BD0	Information	3024	Notify	Drive Rebuild	ESMCommonService	40000BD0	Drive slot is not in rebuild progress. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BD3	Information	3027	Notify	Module Disabled	ESMCommonService	40000BD3	Module/Board has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BD4	Information	3028	Notify	Module Enabled	ESMCommonService	40000BD4	Module/Board has been enabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BD5	Information	3029	Notify	Module Reduction	ESMCommonService	40000BD5	Module/Board is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BD6	Information	3030	Notify	Module Reduction Recovered	ESMCommonService	40000BD6	Module/Board has recovered from reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BD7	Information	3031	Notify	System Boot	ESMCommonService	40000BD7	Initiated by power up. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BD8	Information	3032	Notify	System Boot	ESMCommonService	40000BD8	User Requested PXE Boot. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BD9	Information	3033	Notify	System Boot	ESMCommonService	40000BD9	It has started automatically by the Maintenance Utility. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000BDA	Warning	3034	Notify	Boot Error	ESMCommonService	80000BDA	Bootable media not found. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: Bootable media not found.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

80000BDB	Warning	3035	Notify	Boot Error	ESMCommonService	80000BDB	PXE Server not found. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: PXE Server not found.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BDC	Information	3036	Notify	Slot State	ESMCommonService	40000BDC	The slot or connector holds spare device. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BDD	Information	3037	Notify	Slot State	ESMCommonService	40000BDD	The slot or connector doesn't hold spare device. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BDE	Information	3038	Notify	Slot or Connector Disabled	ESMCommonService	40000BDE	The slot or connector device has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BDF	Information	3039	Notify	Slot or Connector Enabled	ESMCommonService	40000BDF	The slot or connector device has been enabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BE0	Information	3040	Notify	Slot or Connector Reduction	ESMCommonService	40000BE0	The slot or connector device is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BE1	Information	3041	Notify	Slot or Connector Reduction Recovered	ESMCommonService	40000BE1	The slot or connector device has recovered from reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000BE2	Warning	3042	Notify	BMC Access failure	ESMCommonService	80000BE2	BMC Access failure occurred on the route between BMC and the host. Date: %1	Warning: Server monitoring may have stopped. If the log collection tool can start, please collect the log data with it and report to the maintenance	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BE3	Information	3043	Notify	BMC Access failure Recovered	ESMCommonService	40000BE3	Recovered from BMC Access failure. Date: %1		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000BE4	Error	3044	Notify	Drive Fault	ESMCommonService	C0000BE4	Device has a drive fault. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BE5	Information	3045	RPS	Power Supply State	ESMCommonService	40000BE5	Power Supply has been inserted. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BE6	Information	3046	RPS	Power Supply State	ESMCommonService	40000BE6	Power Supply has been removed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BE7	Information	3047	Memory	Memory Board Disabled	ESMCommonService	40000BE7	The Memory Board is disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BE8	Information	3048	Memory	Memory Board Reduction	ESMCommonService	40000BE8	The Memory Board is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BE9	Information	3049	Memory	DIMM Reduction	ESMCommonService	40000BE9	The DIMM is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BEA	Information	3050	Memory	DIMM Reduction Recovered	ESMCommonService	40000BEA	The DIMM has recovered from reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BEB	Information	3051	Memory	Memory Board Reduction Recovered	ESMCommonService	40000BEB	The Memory Board has recovered from reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000BEC	Error	3052	Notify	Management Engine Status Change	ESMCommonService	C0000BEC	Firmware Exception occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Please report to the maintenance member and exchange motherboard.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	○	○	×	○	○	○	○	○	○	○	○
C0000BEC	Error	3052	Notify	Management Engine Status Change	ESMCommonService	C0000BEC	Firmware Exception occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Please report to the maintenance member and exchange motherboard or management board.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
80000BED	Warning	3053	Notify	Management Engine Status Change	ESMCommonService	80000BED	Flash ROM Wear-Out Protection Warning occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000BEE	Error	3054	Notify	Management Engine Status Change	ESMCommonService	C0000BEE	PECI over DMI Interface Error occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Please report to the maintenance member and exchange motherboard.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	○	○	×	○	○	○	○	○	○	○	○
C0000BEE	Error	3054	Notify	Management Engine Status Change	ESMCommonService	C0000BEE	PECI over DMI Interface Error occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Please report to the maintenance member and exchange motherboard or management board.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000BEF	Error	3055	Notify	Management Engine Status Change	ESMCommonService	C0000BEF	MCTP Interface Error occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Please report to the maintenance member and exchange motherboard.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	○	○	×	○	○	○	○	○	○	○	○
C0000BEF	Error	3055	Notify	Management Engine Status Change	ESMCommonService	C0000BEF	MCTP Interface Error occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Please report to the maintenance member and exchange motherboard or management board.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
40000BF0	Information	3056	Notify	Management Engine Status Change	ESMCommonService	40000BF0	Firmware auto configuration finished. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	○	○	×	○	○	○	○	○	○	○	○
40000BF0	Information	3056	Notify	Management Engine Status Change	ESMCommonService	40000BF0	Firmware auto configuration finished. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000BF1	Error	3057	CPU	Processor Error	ESMCommonService	C0000BF1	Machine Check Exception (Uncorrectable) occurred. Date: %1 Sensor Number: %2	Fatal: It is considered a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BF2	Information	3058	CPU	Processor Information	ESMCommonService	40000BF2	Correctable Machine Check Error occurred. Date: %1 Sensor Number: %2		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000BF3	Warning	3059	CPU	Event Logging Disabled	ESMCommonService	80000BF3	Correctable Machine Check error logging of processor has been disabled. Date: %1 Sensor Number: %2	Warning: Further use of this condition may affect the proper operation of the system. Collect the failure information by the collection tool if possible, and contact the maintenance personnel.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000BF4	Information	3060	Server Recovery	OS Shutdown	ESMCommonService	40000BF4	OS Graceful Shutdown. Date: %1 Sensor Number: %2		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

Event ID (Hex digit)	Error Type	Event ID	Type	Trap Name	KeyWord1	KeyWord2	Message	Deal Meathod	Recover Action	Manager Report	Manager Report(GIM-)	Express Report (Level)	SNMP Trap OID (Enterprise ID.Specific ID)	Version 2.2.7-0	2.2.5-0～2.2.6-0	2.2.4-0	esmsasup (2022-03-15)	2.2.3-0	2.2.2-0	2.2.0-0	2.1.3-0	2.1.2-0～2.1.1-0	2.1.0-0	2.0.9-0	2.0.8-0	2.0.7-0	2.0.6-0	2.0.5-0	2.0.3-0～2.0.4-0	2.0.1-0～2.0.2-1	2.0.0-0	1.3.0-0～1.3.1-0	1.1.3-0	1.1.0-0～1.1.2-0	1.0.0-0
C0000BF6	Error	3062	Notify	MEM_EVENT	ESMCommonService	C0000BF6	Memory overheat detected. Location: %2 Date: %1	Fatal: It is considered a memory malfunction or a fan malfunction. Please check if the air conditioner is normally operating and contact with the maintenance member to exchange the memory or the system fan.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×
C0000BF7	Error	3063	Notify	MEMHOT	ESMCommonService	C0000BF7	Memory subsytem overheat asserted by MEM_EVENT or VR_HOT (voltage regulator). Date: %1	Fatal: It is considered a memory malfunction or a fan malfunction or a motherboard malfunction. Please check if the air conditioner is normally operating and contact with the maintenance member to exchange the memory or the system fan or the motherboard.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×
C0000BF8	Error	3064	Notify	PROCHOT	ESMCommonService	C0000BF8	The processor temperature monitoring sensor detects that the processor has reached its maximum safe operating temperature. Date: %1	Fatal: It is considered a cpu malfunction or a fan malfunction. Please check if the air conditioner is normally operating and contact with the maintenance member to exchange the cpu or the system fan.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×
C0000BF9	Error	3065	Notify	CPU THERM TRIP	ESMCommonService	C0000BF9	One of two possible critical over-temperature conditions has occurred: One. the processor junction temperature has reached a level beyond which permanent silicon damage may occur and Two. the system memory interface has exceeded a critical temperature limit set by BIOS. Date: %1	Fatal: CPU thermal trip has worked. Please check if the air conditioner is normally operating and contact with the maintenance member to exchange the cpu or the system fan.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×
C0000BFA	Error	3066	Notify	CATERR	ESMCommonService	C0000BFA	The system has experienced a catastrophic error and cannot continue to operate. Date: %1	Fatal: It might be a device malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×
C0000BFB	Error	3067	Notify	VRHOT	ESMCommonService	C0000BFB	Voltage regulator overheat detected at processor. Date: %1	Fatal: It is considered a motherboard malfunction or a fan malfunction. Please check if the air conditioner is normally operating and contact with the maintenance member to exchange the motherboard or the system fan.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×
80000BFC	Warning	3068	Notify	CPU Error0	ESMCommonService	80000BFC	Hardware correctable error (no operating system or firmware action necessary). Date: %1	Warning: It is considered a cpu malfunction or a motherboard malfunction. If it still fails. Please report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×
C0000BFD	Error	3069	Notify	CPU Error1	ESMCommonService	C0000BFD	Non-fatal error (operating system or firmware action required to contain and recover) Date: %1	Fatal: It is considered a cpu malfunction or a motherboard malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×
C0000BFE	Error	3070	Notify	CPU Error2	ESMCommonService	C0000BFE	Fatal error (system reset likely required to recover). Date: %1	Fatal: It is considered a cpu malfunction or a motherboard malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×
C0000BFF	Error	3071	Notify	PCH Hot	ESMCommonService	C0000BFF	Platform controller hub overheat detected. Date: %1	Fatal: It is considered a motherboard malfunction or a fan malfunction. Please check if the air conditioner is normally operating and contact with the maintenance member to exchange the motherboard or the system fan.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×
80000C00	Warning	3072	Notify	Disk SMART Failure	ESMCommonService	80000C00	S.M.A.R.T Status Bad, Backup and Replace drive. Location: %2 Date: %1	Warning: S.M.A.R.T. predicts that disk is going to fail. Continous use is dangerous. Please contact with the maintenance member to exchange the	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×
80000C01	Warning	3073	Memory	DIMM Disabled	ESMCommonService	80000C01	A part of DIMM is disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Warning: Please report to the maintenance member and exchange memory.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×
C0000C06	Error	3078	Notify	Platform-specific Event	ESMCommonService	C0000C06	Platform detected a HW failure. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000C07	Error	3079	Notify	Platform-specific Event	ESMCommonService	C0000C07	Platform detected a HW failure when Master-BMC is in failed state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000C08	Error	3080	RPS	Power Supply State	ESMCommonService	C0000C08	Power Supply Configuration error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000C0D	Error	3085	Notify	Management Engine Status Change	ESMCommonService	C0000C0D	Firmware auto configuration failed. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Failure of motherboard or management board (MGB) is considered. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000C0E	Error	3086	Notify	Management Engine Status Change	ESMCommonService	C0000C0E	Unsupported Segment Defined Feature. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: Failure of motherboard or management board (MGB) is considered. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000C10	Error	3088	Notify	Management Engine Status Change	ESMCommonService	C0000C10	UMA operation error. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a motherboard or management board malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000C12	Error	3090	Notify	Management Engine Status Change	ESMCommonService	C0000C12	Restricted mode info. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a motherboard or management board malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000C13	Error	3091	Notify	Management Engine Status Change	ESMCommonService	C0000C13	multi PCH mode misconfiguration. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a motherboard or management board malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000C14	Error	3092	Notify	Management Engine Status Change	ESMCommonService	C0000C14	Flash Descriptor Region Verification Error. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a motherboard or management board malfunction. Please report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000C15	Error	3093	Notify	SMBus link failure	ESMCommonService	C0000C15	SMLINK0/SMLINK0B error occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000C16	Error	3094	Notify	SMBus link failure	ESMCommonService	C0000C16	SMLINK1 error occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000C17	Error	3095	Notify	SMBus link failure	ESMCommonService	C0000C17	SMLINK2 error occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000C18	Error	3096	Notify	SMBus link failure	ESMCommonService	C0000C18	SMLINK3 error occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000C19	Error	3097	Notify	SMBus link failure	ESMCommonService	C0000C19	SMLINK4 error occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×
C0000C1A	Error	3098	Voltage	Voltage	ESMCommonService	C0000C1A	Voltage has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fatal: The system will be shut down due to abnormal voltage. Please contact the maintenance personnel.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×	×	×

Source Name<SRC:>: ESMCOMMONSERVICE (iLO support model)

This event detect in information of Integrated Management Log(IML), it is a message to register. Therefore there is the event that is not detected by a server of the use. Default of "Manager Report(SNMP)" is "OFF".

C000057F	Error	1407	Server Recovery	HW eventlog	ESMCommonService	C000057F	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
80000580	Warning	1408	Server Recovery	HW eventlog	ESMCommonService	80000580	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	Warning: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
40000581	Information	1409	Server Recovery	HW eventlog	ESMCommonService	40000581	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
C0000578	Error	1400	Server Recovery	HW eventlog	ESMCommonService	C0000578	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	Fatal: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000579	Warning	1401	Server Recovery	HW eventlog	ESMCommonService	80000579	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	Warning: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000585	Information	1413	Server Recovery	HW eventlog	ESMCommonService	40000585	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	Information: It is considered a device malfunction. If the log collection tool can start, please collect the log data with it and report to the maintenance member.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C00023A0	Error	9120	Server Recovery	iLOログイン失敗	ESMCommonService	C00023A0	Login to iLO was failed. Please input an account of iLO using "iLO account registration tool". %1	Fatal: If there is no problem with the account, collect information by Server information collection tool and contact system administrator.	NONE	ON	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80008213	Warning	33299	Temperature	System Overheating	ESMCommonService	80008213	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x13 Status : Warning Description : System Overheating (Temperature Sensor %1, Location %2, Temperature %3)	Warning: If the temperature rises any higher, it will affect the proper operation of the system. Check that the air inlet is not clogged and the air conditioner is running.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80008214	Warning	33300	Temperature	External Chassis Overheating	ESMCommonService	80008214	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x14 Status : Warning Description : External Chassis Overheating (Chassis %1, Temperature Sensor %2, Location %3, Temperature %4)	Warning: If the temperature rises any higher, it will affect the proper operation of the system. Check that the air inlet is not clogged and the air conditioner is running.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80008215	Warning	33301	Temperature	Storage System Overheating	ESMCommonService	80008215	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x15 Status : Warning Description : %1 Storage System Overheating (%2Slot %3, Temperature Sensor %4, Location %5, Temperature %6)	Warning: If the temperature rises any higher, it will affect the proper operation of the system. Check that the air inlet is not clogged and the air conditioner is running.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80008216	Warning	33302	Temperature	Overheating	ESMCommonService	80008216	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x16 Status : Warning Description : %1 Overheating (Temperature Sensor %2, Location %3, Temperature %4, %5)	Warning: If the temperature rises any higher, it will affect the proper operation of the system. Check that the air inlet is not clogged and the air conditioner is running.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80008217	Warning	33303	Fan	Fan Failure	ESMCommonService	80008217	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x17 Status : Warning Description : Fan Failure (Fan %1, Location %2)	Warning: FAN fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0008217	Error	33303	Fan	Fan Failure	ESMCommonService	C0008217	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x17 Status : Critical Description : Fan Failure (Fan %1, Location %2)	Fatal: FAN fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80008218	Warning	33304	Fan	External Chassis Fan Failure	ESMCommonService	80008218	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x18 Status : Warning Description : External Chassis Fan Failure (Chassis %1, Fan %2, Location %3)	Warning: FAN fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0008218	Error	33304	Fan	External Chassis Fan Failure	ESMCommonService	C0008218	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x18 Status : Critical Description : External Chassis Fan Failure (Chassis %1, Fan %2, Location %3)	Fatal: FAN fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80008219	Warning	33305	Fan	Storage System Fan Failure	ESMCommonService	80008219	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x19 Status : Warning Description : %1 Storage System Fan Failure (%2 Slot %3, Fan %4, Location %5)	Warning: FAN fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0008219	Error	33305	Fan	Storage System Fan Failure	ESMCommonService	C0008219	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x19 Status : Critical Description : %1 Storage System Fan Failure (%2 Slot %3, Fan %4, Location %5)	Fatal: FAN fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
8000821A	Warning	33306	Fan	Fan Failure	ESMCommonService	8000821A	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x1A Status : Warning Description : %1 Fan Failure (Fan %2, Location %3, %4)	Warning: FAN fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C000821A	Error	33306	Fan	Fan Failure	ESMCommonService	C000821A	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x1A Status : Critical Description : %1 Fan Failure (Fan %2, Location %3, %4)	Fatal: FAN fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80008223	Warning	33315	Fan	System Fans Not Redundant	ESMCommonService	80008223	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x23 Status : Warning Description : System Fans Not Redundant (Location %1)	Warning: Check the FAN Connection. If there is no problem with the connection, the FAN may be faulty. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
80008223	Warning	33315	Fan	System Fans Not Redundant	ESMCommonService	80008223	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x23 Status : Warning Description : System Fans Not Redundant (Location %1)	Warning: Check the FAN Connection. If there is no problem with the connection, the FAN may be faulty. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	○	×	×	×	×	×

80008224	Warning	33316	Fan	External Chassis Fans Not Redundant	ESMCommonService	80008224	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x24 Status : Warning Description : External Chassis Fans Not Redundant (Chassis %1, Location %2)	Warning: Check the FAN Connection. If there is no problem with the connection, the FAN may be faulty. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80008225	Warning	33317	Fan	Storage System Fans Not Redundant	ESMCommonService	80008225	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x25 Status : Warning Description : %1 Storage System Fans Not Redundant (%2Slot %3, Location %4)	Warning: Check the FAN Connection. If there is no problem with the connection, the FAN may be faulty. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80008226	Warning	33318	Fan	Fans Not Redundant	ESMCommonService	80008226	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x26 Status : Warning Description : %1 Fans Not Redundant (Location %2, %3)	Warning: Check the FAN Connection. If there is no problem with the connection, the FAN may be faulty. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80008226	Warning	33318	Fan	Fans Not Redundant	ESMCommonService	80008226	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x26 Status : Warning Description : %1 Fans Not Redundant (Location %2, %3)	Warning: Check the FAN Connection. If there is no problem with the connection, the FAN may be faulty. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0008227	Error	33319	Temperature	Critical Temperature Threshold Exceeded	ESMCommonService	C0008227	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x27 Status : Critical Description : Critical Temperature Threshold Exceeded	Fatal: Abnormal temperature detected. Check that the air inlet is not clogged and the air conditioner is running. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0008228	Error	33320	Temperature	Critical Temperature Threshold Exceeded	ESMCommonService	C0008228	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x28 Status : Critical Description : Critical Temperature Threshold Exceeded (Temperature Sensor %1, Location %2, Temperature %3C %4)	Fatal: Abnormal temperature detected. Check that the air inlet is not clogged and the air conditioner is running. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0008229	Error	33321	Temperature	External Chassis Overheating	ESMCommonService	C0008229	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x29 Status : Critical Description : External Chassis Overheating (Chassis %1, Temperature Sensor %2, Location %3, Temperature %4)	Fatal: Abnormal temperature detected. Check that the air inlet is not clogged and the air conditioner is running. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C000822A	Error	33322	Temperature	Storage System Overheating	ESMCommonService	C000822A	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x2A Status : Critical Description : %1 Storage System Overheating (%2Slot %3, Temperature Sensor %4, Location %5, Temperature %6)	Fatal: Abnormal temperature detected. Check that the air inlet is not clogged and the air conditioner is running. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C000822B	Error	33323	Temperature	Overheating	ESMCommonService	C000822B	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x2B Status : Critical Description : %1 Overheating (Temperature Sensor %2, Location %3, Temperature %4, %5)	Fatal: Abnormal temperature detected. Check that the air inlet is not clogged and the air conditioner is running. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C000822C	Error	33324	Temperature	Temperature Exceeded	ESMCommonService	C000822C	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x2C Status : Critical Description : Temperature exceeded on PCIe disk %1.	Fatal: Abnormal temperature detected. Check that the air inlet is not clogged and the air conditioner is running. Collect information by Server information collection tool and contact your sales representative.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80008231	Warning	33329	Fan	Storage Enclosure Fan Failure	ESMCommonService	80008231	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x31 Status : Warning Description : %1 Storage Enclosure Fan Failure (Fan %2, Location %3, Box %4, %5)	Warning: FAN fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C0008231	Error	33329	Fan	Storage Enclosure Fan Failure	ESMCommonService	C0008231	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x31 Status : Critical Description : %1 Storage Enclosure Fan Failure (Fan %2, Location %3, Box %4, %5)	Fatal: FAN fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80008232	Warning	33330	Temperature	Storage Enclosure Overheating	ESMCommonService	80008232	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x32 Status : Warning Description : %1 Storage Enclosure Overheating (Temperature Sensor %2, Location %3, Box %4, %5)	Warning: If the temperature rises any higher, it will affect the proper operation of the system. Check that the air inlet is not clogged and the air conditioner is running.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C0008503	Error	34051	CPU	Uncorrectable Machine Check Exception	ESMCommonService	C0008503	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x05 Event Code : 0x03 Status : Critical Description : Uncorrectable Machine Check Exception (%1 %2, APIC ID 0x%3, Bank 0x%4, Status 0x%5~%6, Address 0x%7~%8, Misc 0x%9~%10).	Fatal: Uncorrectable Machine Check Exception detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0008603	Error	34307	Bus	Uncorrectable UPI Error	ESMCommonService	C0008603	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x06 Event Code : 0x03 Status : Critical Description : Uncorrectable UPI Error was detected on Processor %1	Fatal: Uncorrectable UPI Error detected on Processor. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0008802	Error	34818	Bus	Uncorrectable PCI Express Error	ESMCommonService	C0008802	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x08 Event Code : 0x02 Status : Critical Description : Uncorrectable PCI Express Error Detected. Slot %1 (Segment %2, Bus %3, Device %4, Function %5). Uncorrectable Error Status: %6	Fatal: Uncorrectable PCI Express Error detected on Processor. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	×	×	×	×	×
C0008802	Error	34818	Bus	Uncorrectable PCI Express Error	ESMCommonService	C0008802	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x08 Event Code : 0x02 Status : Critical Description : Uncorrectable PCI Express Error Detected. Slot %1 (Segment 0x%2, Bus 0x%3, Device 0x%4, Function 0x%5). Uncorrectable Error Status: 0x%6 Recommended Action : Update the firmware of the failing device. If the issue persists, replace the device.	Fatal: Uncorrectable PCI Express Error detected on Processor. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×
C0008802	Error	34818	Bus	Uncorrectable PCI Express Error	ESMCommonService	C0008802	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x08 Event Code : 0x02 Status : Critical Description : Uncorrectable PCI Express Error Detected. %1 %2 (Segment 0x%3, Bus 0x%4, Device 0x%5, Function 0x%6). Uncorrectable Error Status: 0x%7	Fatal: Uncorrectable PCI Express Error detected on Processor. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0008803	Error	34819	Bus	Uncorrectable PCI Express Error	ESMCommonService	C0008803	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x08 Event Code : 0x03 Status : Critical Description : Uncorrectable PCI Express Error Detected. Embedded %1 (Segment %2, Bus %3, Device %4, Function %5). Uncorrectable Error Status: %6	Fatal: Uncorrectable PCI Express Error detected on Processor. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	×	×	×	×	×
C0008803	Error	34819	Bus	Uncorrectable PCI Express Error	ESMCommonService	C0008803	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x08 Event Code : 0x03 Status : Critical Description : Uncorrectable PCI Express Error Detected. Embedded %1 (Segment 0x%2, Bus 0x%3, Device 0x%4, Function 0x%5). Uncorrectable Error Status: 0x%6 Recommended Action : Update the firmware of the device. If the issue	Fatal: Uncorrectable PCI Express Error detected on Processor. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×

C0008803	Error	34819	Bus	Uncorrectable PCI Express Error	ESMCommonService	C0008803	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x08 Event Code : 0x03 Status : Critical Description : Uncorrectable PCI Express Error Detected. NVMe Box %1 Bay %2 (Segment 0x%3, Bus 0x%4, Device 0x%5, Function 0x%6). Uncorrectable Error Status: 0x%7	Fatal: Uncorrectable PCI Express Error detected on Processor. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0008804	Error	34820	Bus	Uncorrectable PCI Express Error	ESMCommonService	C0008804	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x08 Event Code : 0x04 Status : Critical Description : Uncorrectable PCI Express Error Detected. Slot %1 (Segment %2, Bus %3, Device %4, Function %5).	Fatal: Uncorrectable PCI Express Error detected on Processor. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	×	×	×	×	×
C0008804	Error	34820	Bus	Uncorrectable PCI Express Error	ESMCommonService	C0008804	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x08 Event Code : 0x04 Status : Critical Description : Uncorrectable PCI Express Error Detected. Slot %1 (Segment 0x%2, Bus 0x%3, Device 0x%4, Function 0x%5). Recommended Action : Update the firmware of the failing device. If the issue persists, replace the device.	Fatal: Uncorrectable PCI Express Error detected on Processor. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	×	×	×	×	×	×	×	×	×	×	×	×
C0008804	Error	34820	Bus	Uncorrectable PCI Express Error	ESMCommonService	C0008804	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x08 Event Code : 0x04 Status : Critical Description : Uncorrectable PCI Express Error Detected. %1 %2 (Segment 0x%2, Bus 0x%3, Device 0x%4, Function 0x%5).	Fatal: Uncorrectable PCI Express Error detected on Processor. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
8001BA04	Warning	35332	Server Recovery	ASR Timer Failure	ESMCommonService	8001BA04	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x104 Status : Warning Description : ASR Timer Failure	Warning: ASR Timer failure detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0018A21	Error	35361	Server Recovery	Critical Error During Power-up	ESMCommonService	C0018A21	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x121 Status : Critical Description : A Critical Error occurred prior to this power-up.	Fatal: A Critical Error occurred prior to this power-up. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0028A18	Error	35352	Server Recovery	DIMM Initialization Error	ESMCommonService	C0028A18	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x218 Status : Critical Description : DIMM Initialization Error - All DIMMs are mapped out due to memory errors except for one to allow the system to boot. Additional errors may be present on the remaining DIMM. System is booting in a degraded state.	Fatal: DIMM initialization Error. Collect information by Server information collection tool and contact your sales representative. <Deal Meathod is blank before Ver.2.0.7-0>	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80028A24	Warning	35364	Server Recovery	Power Fault Detected	ESMCommonService	80028A24	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x224 Status : Warning Description : Power Fault Detected - FlexLOM %1	Warning: Power fault detected on FlexLOM. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80028A25	Warning	35365	Server Recovery	Power Fault Detected-Mezzanine	ESMCommonService	80028A25	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x225 Status : Warning Description : Power Fault Detected-Mezzanine %1.	Warning: Power fault detected on Mezzanine Card. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80028A26	Warning	35366	Server Recovery	Power Fault Detected	ESMCommonService	80028A26	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x226 Status : Warning Description : Power Fault Detected - Embedded Storage Controller %1.	Warning: Power fault detected on Storage Controller. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80028A68	Warning	35432	Server Recovery	UEFI Non-Volatile Variable Store Corruption Detected	ESMCommonService	80028A68	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x268 Status : Warning Description : UEFI Non-Volatile Variable Store Corruption Detected. If enabled. Secure Boot security settings may be lost.	Warning: UEFI error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C0028A68	Error	35432	Server Recovery	UEFI Non-Volatile Variable Store Corruption Detected	ESMCommonService	C0028A68	Date : YYYY-MM-DD HH:MM:SS Event Class : 0x0A Event Code : 0x268 Status : Critical Description : UEFI Non-Volatile Variable Store Corruption Detected. If enabled. Secure Boot security settings may be lost.	Fatal: The system cannot communicate with the iLO firmware. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
C0028A70	Error	35440	Server Recovery	FW Communication Issue	ESMCommonService	C0028A70	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x270 Status : Critical Description : %1 FW Communication Issue - Unable to communicate with %2 FW. Certain management functionality is not available.	Fatal: The system cannot communicate with the iLO firmware. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0028A84	Error	35460	Server Recovery	Uncorrectable Memory Error	ESMCommonService	C0028A84	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x284 Status : Critical Description : DIMM Failure - Uncorrectable Memory Error - %1 %2 Dimm %3	Fatal: Memory Uncorrectable Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	×	×	×	×
C0028A84	Error	35460	Server Recovery	Uncorrectable Memory Error	ESMCommonService	C0028A84	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x284 Status : Critical Description : DIMM Failure - Uncorrectable Memory Error (%1 %2, DIMM %3) Recommended Action : Replace Failed DIMM	Fatal: Memory Uncorrectable Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×
C0038A06	Error	35334	Server Recovery	Redundant ROM Error	ESMCommonService	C0038A06	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x306 Status : Critical Description : Redundant ROM Error: %1 FW did not set the Primary System ROM. The error has been corrected. %2 FW may have an issue.	Fatal: An error prevented the setting of the primary system ROM. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80038A12	Warning	35346	Server Recovery	Battery Communication Failure	ESMCommonService	80038A12	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x312 Status : Warning Description : %1 %2 Failure - Communication with the battery failed. Its output may not be enabled.	Warning: The Smart Storage battery is not installed correctly, degraded or has failed. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80038A12	Warning	35346	Server Recovery	Battery Communication Failure	ESMCommonService	80038A12	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x312 Status : Warning Description : %1 %2 Communication Failure - Communication with the energy pack failed. Its output may not be enabled.	Warning: The Smart Storage battery is not installed correctly, degraded or has failed. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80038A13	Warning	35347	Server Recovery	Battery Shutdown	ESMCommonService	80038A13	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x313 Status : Warning Description : %1 %2 Failure - Battery Shutdown Event Code: 0x%3.	Warning: The Smart Storage battery is degraded or has failed. The iLO firmware is not the latest version. Contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0038A15	Error	35349	Server Recovery	Uncorrectable Memory Error	ESMCommonService	C0038A15	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x315 Status : Critical Description : An uncorrectable memory error was detected prior to this system boot.	Fatal: An uncorrectable memory error occurred. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80038A23	Warning	35363	Server Recovery	Dual microSD Device Error	ESMCommonService	80038A23	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x323 Status : Warning Description : %1 Dual microSD Device Error - The microSD card in Slot %2 has failed.	Warning: The microSD card has failed. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×

C0038A24	Error	35364	Server Recovery	Dual microSD Device Error	ESMCommonService	C0038A24	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x324 Status : Critical Description : %1 Dual microSD Device Error - Both microSD cards have failed.	Fatal: The microSD card has failed. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0038A26	Error	35366	Server Recovery	Dual microSD Device Error	ESMCommonService	C0038A26	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x326 Status : Critical Description : %1 Dual microSD Device Error - The microSD card in Slot %2 has failed. A microSD card is not installed in Slot %3.	Fatal: The microSD card has failed. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
40038A28	Information	35368	Server Recovery	Power Management Controller Firmware Error	ESMCommonService	40038A28	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x328 Status : OK Description : Power Management Controller Firmware Error - The firmware is in Recovery Mode.	Information: Power Management Controller Firmware Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
40038A29	Information	35369	Server Recovery	Power Management Controller FW Error	ESMCommonService	40038A29	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x329 Status : OK Description : Power Management Controller FW Error - Unable to communicate with the FW.	Information: Power Management Controller Firmware Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0038A40	Error	35392	Server Recovery	NVDIMM Error	ESMCommonService	C0038A40	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x340 Status : Critical Description : NVDIMM Error - Backup Error - Processor %1, DIMM %2 (SN:%3-%4-%5-%6). Persistent data backup failed and data is irrecoverably lost.	Fatal: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0038A41	Error	35393	Server Recovery	NVDIMM Error	ESMCommonService	C0038A41	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x341 Status : Critical Description : NVDIMM Error - Restore Error - Processor %1, DIMM %2 (SN:%3-%4-%5-%6). Persistent data restore failed and data is not available. Data is not lost unless the issue persists.	Fatal: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0038A42	Error	35394	Server Recovery	NVDIMM Error	ESMCommonService	C0038A42	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x342 Status : Critical Description : NVDIMM Error - Uncorrectable Memory Error - Processor %1, DIMM %2 (SN:%3-%4-%5-%6). This NVDIMM will not be available to the operating system and data may have been lost.	Fatal: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0038A43	Error	35395	Server Recovery	NVDIMM Error	ESMCommonService	C0038A43	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x343 Status : Critical Description : IMPORTANT: NVDIMM backup power has been lost and a future backup is not possible. Data from the last successful backup is intact, but data modified after the last successful backup will be lost if power cannot be restored.	Fatal: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0038A43	Error	35395	Server Recovery	NVDIMM Error	ESMCommonService	C0038A43	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x343 Status : Critical Description : NVDIMM backup power has been lost and a future backup is not possible. Data from the last successful backup is intact, but data modified after the last successful backup will be lost if power cannot be restored.	Fatal: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0038A44	Error	35396	Server Recovery	NVDIMM Error	ESMCommonService	C0038A44	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x344 Status : Critical Description : NVDIMM Error - NVDIMM Controller Error - Processor %1, DIMM %2 (SN:%3-%4-%5-%6). An error was found with the NVDIMM controller. The OS will not use the NVDIMM. Data from last successful backup is still available, but will be lost if controller error persists.	Fatal: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0038A45	Error	35397	Server Recovery	NVDIMM Error	ESMCommonService	C0038A45	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x345 Status : Critical Description : NVDIMM Error - Erase Error - Processor %1, DIMM %2 (SN:%3-%4-%5-%6). NVDIMM could not be erased by the NVDIMM controller FW and future backups are not possible.	Fatal: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0038A46	Error	35398	Server Recovery	NVDIMM Error	ESMCommonService	C0038A46	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x346 Status : Critical Description : NVDIMM Error - Arming Error - Processor %1, DIMM %2 (SN:%3-%4-%5-%6). NVDIMM could not be armed and future backups are not possible.	Fatal: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0038A56	Error	35414	Server Recovery	NVDIMM Error	ESMCommonService	C0038A56	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x356 Status : Critical Description : NVDIMM Error - Sanitization Error - Processor %1, DIMM %2 (SN:%3-%4-%5-%6) - This NVDIMM-N was selected for Sanitizing/Erasing, but this process was not successful.	Fatal: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0038A64	Error	35428	Server Recovery	NVDIMM Error	ESMCommonService	C0038A64	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x364 Status : Critical Description : NVDIMM Error - NVDIMM Controller Error - Processor %1, DIMM %2. The controller firmware has been corrupted. The OS will not use the NVDIMM.	Fatal: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80038A74	Warning	35444	Server Recovery	NVDIMM Error	ESMCommonService	80038A74	Date : YYYY-MM-DD HH:MM:SS Event Class : 0x0A Event Code : 0x374 Status : Warning Description : NVDIMM Error - Processor %1, DIMM %2 (Serial no. %3-%4-%5-%6) received a memory initialization or uncorrectable error. All NVDIMMs on Proc %7 are disabled.	Warning: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
C0038A74	Error	35444	Server Recovery	NVDIMM Error	ESMCommonService	C0038A74	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x374 Status : Critical Description : NVDIMM Error - Processor %1, DIMM %2 (SN:%3-%4-%5-%6) received a memory initialization or uncorrectable error. All NVDIMMs on Proc %7 are disabled. Data on NVDIMM may have been lost	Fatal: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80038A75	Warning	35445	Server Recovery	NVDIMM Error	ESMCommonService	80038A75	Date : YYYY-MM-DD HH:MM:SS Event Class : 0x0A Event Code : 0x375 Status : Warning Description : NVDIMM Error - Processor %1, DIMM %2 (Serial no. %3-%4-%5-%6). NVDIMM has received a memory initialization or uncorrectable error. NVDIMM has been disabled.	Warning: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×

C0038A75	Error	35445	Server Recovery	NVDIMM Error	ESMCommonService	C0038A75	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x375 Status : Critical Description : NVDIMM Error - Processor %1, DIMM %2 (SN:%3-%4-%5-%6) received a memory initialization or uncorrectable error. All NVDIMMs on Proc %7 are disabled. Data on NVDIMM may have been lost.	Fatal: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80038A88	Warning	35464	Server Recovery	Uncorrectable Memory Error	ESMCommonService	80038A88	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x388 Status : Warning Description : Uncorrectable Memory Error - The failed memory module could not be determined.	Warning: An uncorrectable memory error occurred. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0038A94	Error	35476	Server Recovery	NVDIMM Error	ESMCommonService	C0038A94	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x394 Status : Critical Description : NVDIMM Error - Processor %1, DIMM %2 (SN:%3-%4-%5-%6). Unable to set event notification for this NVDIMM to generate alerts for health changes, including a loss of data persistency.	Fatal: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C0038A95	Error	35477	Server Recovery	NVDIMM Error	ESMCommonService	C0038A95	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x395 Status : Critical Description : NVDIMM Error - Processor %1, DIMM %2 (SN:%3-%4-%5-%6). NVDIMM Persistency is lost and future data backup is not available.	Fatal: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80038A97	Warning	35479	Server Recovery	NVDIMM Lifetime Reached	ESMCommonService	80038A97	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x397 Status : Warning Description : WARNING: Processor %1, DIMM %2 (SN:%3-%4-%5-%6). NVDIMM lifetime has reached.	Warning: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80038A97	Warning	35479	Server Recovery	NVDIMM Lifetime Reached	ESMCommonService	80038A97	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x397 Status : Warning Description : WARNING: Processor %1, DIMM %2 (SN:%3-%4-%5-%6). NVDIMM lifetime has been reached.	Warning: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80048A10	Warning	35344	Server Recovery	Innovation Engine Error	ESMCommonService	80048A10	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x410 Status : Warning Description : Innovation Engine Error - The Innovation Engine is not operating properly. (Error Code %1).	Warning: Innovation Engine Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0048A11	Error	35345	Server Recovery	Innovation Engine Error	ESMCommonService	C0048A11	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x411 Status : Critical Description : Innovation Engine Error - The Innovation Engine is operating in recovery mode.	Fatal: Innovation Engine Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0048A12	Error	35346	Server Recovery	Server Platform Services Firmware Error	ESMCommonService	C0048A12	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x412 Status : Critical Description : Server Platform Services Firmware Error - The Server Platform Services firmware is operating in factory mode.	Fatal: Server Platform Services Firmware Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80048A14	Warning	35348	Server Recovery	Server Platform Services Firmware Error	ESMCommonService	80048A14	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x414 Status : Warning Description : Server Platform Services Firmware Error - The SPS Firmware is not operating properly. (Error Code	Warning: The Server Platform Services firmware detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0048A30	Error	35376	Server Recovery	Logical NVDIMM-N Uncorrectable Memory Error	ESMCommonService	C0048A30	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x430 Status : Critical Description : Scalable Persistent Memory uncorrectable memory error on %1 Logical NVDIMM %2. The memory region will not be available to the OS and data may have been lost.	Fatal: NVDIMM-N Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C0048A31	Error	35377	Server Recovery	Logical NVDIMM-N Backup Failed	ESMCommonService	C0048A31	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x431 Status : Critical Description : Scalable Persistent Memory backup failed on %1 Logical NVDIMM %2. Persistent data has been lost.	Fatal: NVDIMM-N Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C0048A32	Error	35378	Server Recovery	Logical NVDIMM-N Restore Failed	ESMCommonService	C0048A32	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x432 Status : Critical Description : Scalable Persistent Memory restore failed for %1 Logical NVDIMM %2. Persistent data may have been lost.	Fatal: NVDIMM-N Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C0048A33	Error	35379	Server Recovery	Logical NVDIMM-N Backup Device Failure	ESMCommonService	C0048A33	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x433 Status : Critical Description : Scalable Persistent Memory backup device failure on Box %1 Bay %2. Persistent data may have been lost.	Fatal: NVDIMM-N Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80048A37	Warning	35383	Server Recovery	Logical NVDIMM-N Backup Media Write Error	ESMCommonService	80048A37	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x437 Status : Warning Description : Scalable Persistent Memory backup media write error on %1 Logical NVDIMM %2. Persistent data may have been been lost.	Warning: NVDIMM-N Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80048A38	Warning	35384	Server Recovery	Logical NVDIMM-N Backup Media Read Error	ESMCommonService	80048A38	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x438 Status : Warning Description : Scalable Persistent Memory backup media read error on %1 Logical NVDIMM %2. Persistent data may have been been lost.	Warning: NVDIMM-N Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C0048A40	Error	35392	Server Recovery	Persistent Memory Address Range Scrub Error	ESMCommonService	C0048A40	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x440 Status : Critical Description : Persistent Memory Address Range Scrub has detected an error at Offset %1.	Fatal: Persistent Memory Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80048A42	Warning	35394	Server Recovery	Scalable Persistent Memory Backup Media Write Error	ESMCommonService	80048A42	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x442 Status : Warning Description : Scalable Persistent Memory backup media write error on Box %1 Bay %2. Persistent data may have been lost.	Warning: Scalable Persistent Memory backup media write error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80048A43	Warning	35395	Server Recovery	Scalable Persistent Memory Backup Media Read Error	ESMCommonService	80048A43	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x443 Status : Warning Description : Scalable Persistent Memory backup media read error on Box %1 Bay %2. Persistent data may have been lost.	Warning: Scalable Persistent Memory backup media read error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×

C0048A44	Error	35396	Server Recovery	Scalable Persistent Memory Arming Error	ESMCommonService	C0048A44	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x444 Status : Critical Description : Scalable Persistent Memory arming error on %1. Logical NVDIMM %2. The Logical NVDIMM could not be armed and future backups are not possible.	Fatal: NVDIMM Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80048A45	Warning	35397	Server Recovery	Scalable Persistent Memory Backup Device Error	ESMCommonService	80048A45	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x445 Status : Warning Description : Scalable Persistent Memory backup device error on Box %1 Bay %2.	Warning: Scalable Persistent Memory backup device error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C0048A52	Error	35410	Server Recovery	FW Communication Issue	ESMCommonService	C0048A52	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x452 Status : Critical Description : %1 FW Communication Issue - Unable to communicate with %2 FW. One or more configuration settings may be used from the last system boot. One or more configuration changes since the last boot may not have taken affect.	Fatal: FW Communication Issue detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80048A60	Warning	35424	Server Recovery	Correctable Memory Error Threshold Exceeded	ESMCommonService	80048A60	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x460 Status : Warning Description : Correctable Memory Error Threshold Exceeded (%1 %2, DIMM %3).	Warning: Correctable Memory Error Threshold Exceeded detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80048A61	Warning	35425	Server Recovery	High Rate Corrected Memory Errors	ESMCommonService	80048A61	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x461 Status : Warning Description : High rate of corrected memory errors, performance may be degraded (%1 %2, DIMM %3).	Warning: Correctable Memory Error Threshold Exceeded detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80048A66	Warning	35430	Server Recovery	Memory Channel Error	ESMCommonService	80048A66	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x466 Status : Warning Description : Memory Channel Error - Correctable Memory Error Threshold Exceeded (%1 %2, Channel %3).	Warning: Correctable Memory Error Threshold Exceeded detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80048A66	Warning	35430	Server Recovery	Memory Channel Error	ESMCommonService	80048A66	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x466 Status : Warning Description : Memory Channel Error - Correctable Memory Error Threshold Exceeded on Processor %1 %2.	Warning: Correctable Memory Error Threshold Exceeded detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0048A67	Error	35431	Server Recovery	Uncorrectable Error	ESMCommonService	C0048A67	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x467 Status : Critical Description : Uncorrectable Error was detected on Processor %1.	Fatal: Uncorrectable Error was detected on Processor. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80048A70	Warning	35440	Server Recovery	SATA device Unresponse	ESMCommonService	80048A70	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x470 Status : Warning Description : SATA device on Controller %1 Port %2 is unresponsive.	Warning: SATA device is unresponsive. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80048A83	Warning	35459	Server Recovery	NVDIMM Error	ESMCommonService	80048A83	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x483 Status : Warning Description : NVDIMM Error - NVDIMM(s) cannot be initialized due to internal error (Code = %1). NVDIMM functionality might be impacted	Warning: NVDIMM initialization error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80048A83	Warning	35459	Server Recovery	NVDIMM Error	ESMCommonService	80048A83	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x483 Status : Warning Description : NVDIMM Error - NVDIMM(s) cannot be initialized due to internal error (Code = %1). NVDIMM functionality might be impacted	Warning: NVDIMM initialization error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0048A90	Error	35472	Server Recovery	System Health Error	ESMCommonService	C0048A90	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x490 Status : Critical Description : System Health Error. A critical system health error requires the system to be shutdown.	Fatal: Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C0048A91	Error	35473	Server Recovery	System Health Error	ESMCommonService	C0048A91	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x491 Status : Critical Description : System Health Error. A critical system health error has kept the system from booting. -System	Fatal: Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C0058A00	Error	35328	Server Recovery	ASR NMI	ESMCommonService	C0058A00	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x500 Status : Critical Description : ASR NMI Detected - The Automatic Server Recovery (ASR) NMI has been signaled (per the system configuration policy).	Fatal: ASR NMI Occurred. Examine the OS logs for the cause of the system hang. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80198A01	Warning	35329	Server Recovery	Smart Array Controller Failed	ESMCommonService	80198A01	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1901 Status : Warning Description : Slot %1 Smart Array - Controller failed on previous power-up due to lock up code 0x%2 Recommended Action : 1. Update the controller to the latest firmware version. 2. If the issue persists, replace the controller.	Warning: RAID Controller failure detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×
80198A01	Warning	35329	Server Recovery	Smart Array Controller Failed	ESMCommonService	80198A01	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1901 Status : Warning Description : Slot %1 Smart Array - Controller failed on previous power-up due to lock up code 0x%2 Recommended Action : 1. Update the controller to the latest firmware version. 2. If the issue persists, replace the controller.	Warning: RAID Controller failure detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80198A01	Warning	35329	Server Recovery	Storage Controller Failed	ESMCommonService	80198A01	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1901 Status : Warning Description : Slot %1 Storage - Controller failed on previous power-up (Error Code 0x%2)	Warning: RAID Controller failure detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0058A01	Error	35329	Server Recovery	IPMI Watchdog NMI	ESMCommonService	C0058A01	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x501 Status : Critical Description : IPMI Watchdog NMI Detected - The IPMI Watchdog NMI has been signaled (per the system configuration policy).	Fatal: IPMI NMI Occurred. Examine the OS logs for the cause of the system hang. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C0058A02	Error	35330	Server Recovery	Application Watchdog NMI	ESMCommonService	C0058A02	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x502 Status : Critical Description : Application Watchdog NMI Detected - The Application Watchdog NMI has been signaled (per the system configuration policy).	Fatal: Application Watchdog NMI Detected. Examine the OS logs for the cause of the system hang. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80168A36	Warning	35382	Server Recovery	Trusted Platform Module Error	ESMCommonService	80168A36	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1636 Status : Warning Description : %1 Trusted Platform Module Error.	Warning: The TPM has failed. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×

80218A05	Warning	35333	Server Recovery	Slot Error	ESMCommonService	80218A05	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2105 Status : Warning Description : %1		NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
80218A05	Warning	35333	Server Recovery	Slot Error	ESMCommonService	80218A05	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2105 Status : Warning Description : %1		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80218A08	Warning	35336	Server Recovery	Slot Error	ESMCommonService	80218A08	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2108 Status : Warning Description : %1		NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
80218A08	Warning	35336	Server Recovery	Slot Error	ESMCommonService	80218A08	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2108 Status : Warning Description : %1		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80218A10	Warning	35344	Server Recovery	Slot Error	ESMCommonService	80218A10	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2110 Status : Warning Description : %1		NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
80218A10	Warning	35344	Server Recovery	Slot Error	ESMCommonService	80218A10	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2110 Status : Warning Description : %1		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80218A16	Warning	35350	Server Recovery	Slot Error	ESMCommonService	80218A16	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2116 Status : Warning Description : %1		NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
80218A16	Warning	35350	Server Recovery	Slot Error	ESMCommonService	80218A16	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2116 Status : Warning Description : %1		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80248A04	Warning	35332	Server Recovery	SAN Error	ESMCommonService	80248A04	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2404 Status : Warning Description : Slot %1 SAN Error - Adapter restart failed. Firmware not ready. Boot from SAN not possible.	Warning: SAN Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80248A04	Warning	35332	Server Recovery	SAN Error	ESMCommonService	80248A04	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2404 Status : Warning Description : %1 %2 SAN Error - Adapter restart failed. Firmware not ready. Boot from SAN not possible.	Warning: SAN Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80248A05	Warning	35333	Server Recovery	PCI Slot Error	ESMCommonService	80248A05	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2405 Status : Warning Description : Slot %1 Error - Vital Product Data (VPD) is not available.	Warning: PCI SLOT Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80248A05	Warning	35333	Server Recovery	PCI Slot Error	ESMCommonService	80248A05	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2405 Status : Warning Description : %1 %2 Error - Vital Product Data (VPD) is not available.	Warning: PCI SLOT Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80248A06	Warning	35334	Server Recovery	NIC Error	ESMCommonService	80248A06	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2406 Status : Warning Description : Slot %1 NIC Error - NIC personality (Ethernet, iSCSI, or FCoE) could not be changed. FW may require update.	Warning: PCI SLOT Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80248A06	Warning	35334	Server Recovery	NIC Error	ESMCommonService	80248A06	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2406 Status : Warning Description : %1 %2 NIC Error - NIC personality (Ethernet, iSCSI, or FCoE) could not be changed. FW may require update.	Warning: PCI SLOT Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80248A08	Warning	35336	Server Recovery	PCI Slot Error	ESMCommonService	80248A08	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2408 Status : Warning Description : Slot %1 Error - Firmware image recovery not successful.	Warning: PCI SLOT Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80248A08	Warning	35336	Server Recovery	PCI Slot Error	ESMCommonService	80248A08	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2408 Status : Warning Description : %1 %2 Error - Firmware image recovery not successful.	Warning: PCI SLOT Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80248A10	Warning	35344	Server Recovery	PCI Slot Error	ESMCommonService	80248A10	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2410 Status : Warning Description : Slot %1 Error - Controller I/O timeout failure.	Warning: PCI SLOT Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80248A10	Warning	35344	Server Recovery	PCI Slot Error	ESMCommonService	80248A10	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2410 Status : Warning Description : %1 %2 Error - Controller I/O timeout failure.	Warning: PCI SLOT Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80248A16	Warning	35350	Server Recovery	Controller firmware Error	ESMCommonService	80248A16	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2416 Status : Warning Description : %1: Error - Controller firmware not ready.	Warning: Controller firmware is not ready. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80248A16	Warning	35350	Server Recovery	Controller firmware Error	ESMCommonService	80248A16	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2416 Status : Warning Description : %1 %2 Error - Controller firmware not ready.	Warning: Controller firmware is not ready. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0008B1B	Error	35611	Power Supply	System Board Power Protection Fault	ESMCommonService	C0008B1B	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x1B Status : Critical Description : System Board Power Protection Fault	Fatal: Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0008B1C	Error	35612	Power Supply	Power Supply Detection Error	ESMCommonService	C0008B1C	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x1C Status : Critical Description : Power Supply or Power Backplane Detection Error	Fatal: Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
8000B81E	Warning	35614	Power Supply	Smart Storage Battery Removed	ESMCommonService	8000B81E	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x1E Status : Warning Description : Smart Storage Battery Removed (Battery %1)	Warning: Smart Storage Battery removing detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	○	○	○	×	×	×	×	×	×	×	×	×
8000B81E	Warning	35614	Power Supply	Smart Storage Battery Removed	ESMCommonService	8000B81E	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x1E Status : Warning Description : Smart Storage Energy Pack Removed (Energy Pack %1) Recommended Action : Refer Smart Storage Battery issues flowchart in the Troubleshooting Guide.	Warning: Smart Storage Battery removing detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×

C0008B24	Error	35620	Power Supply	Power On Denied	ESMCommonService	C0008B24	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x24 Status : Critical Description : Power On Denied (Service Information: %1)		NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
C0008B24	Error	35620	Power Supply	Power On Denied	ESMCommonService	C0008B24	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x24 Status : Critical Description : Power On Denied (Service Information: %1)		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80008B28	Warning	35624	Power Supply	System Power Supply	ESMCommonService	80008B28	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x28 Status : Warning Description : System Power Supply: %1 (Power Supply %2)	Warning: Power Supply Unit fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0008B28	Error	35624	Power Supply	System Power Supply	ESMCommonService	C0008B28	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x28 Status : Critical Description : System Power Supply: %1 (Power Supply %2)	Fatal: Power Supply Unit fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80008B29	Warning	35625	Power Supply	External Chassis Power Supply	ESMCommonService	80008B29	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x29 Status : Warning Description : External Chassis Power Supply: %1 (Chassis %2, Power Supply %3)	Warning: Power Supply Unit fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
8000B82A	Warning	35626	Power Supply	Storage System Power Supply	ESMCommonService	8000B82A	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x2A Status : Warning Description : %1 Storage System Power Supply: %2 (%3Slot %4, Power Supply %5)	Warning: Power Supply Unit fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
8000B82B	Warning	35627	Power Supply	Power Supply	ESMCommonService	8000B82B	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x2B Status : Warning Description : %1 Power Supply: %2 (Power Supply %3, %4)	Warning: Power Supply Unit fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0008B2B	Error	35627	Power Supply	Power Supply	ESMCommonService	C0008B2B	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x2B Status : Critical Description : %1 Power Supply: %2 (Power Supply %3, %4)	Fatal: Power Supply Unit fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80008B36	Warning	35638	Power Supply	System Power Supplies Not Redundant	ESMCommonService	80008B36	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x36 Status : Warning Description : System Power Supplies Not Redundant	Warning: Check the Power Supply Unit Connection. If there is no problem with the connection, the Power Supply Unit may be faulty. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80008B37	Warning	35639	Power Supply	External Chassis Power Supplies Not Redundant	ESMCommonService	80008B37	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x37 Status : Warning Description : External Chassis Power Supplies Not Redundant (Chassis %1)	Warning: Check the Power Supply Unit Connection. If there is no problem with the connection, the Power Supply Unit may be faulty. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
80008B38	Warning	35640	Power Supply	Storage System Power Supplies Not Redundant	ESMCommonService	80008B38	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x38 Status : Warning Description : %1 Storage System Power Supplies Not Redundant (Chassis %2 Slot %3)	Warning: Check the Power Supply Unit Connection. If there is no problem with the connection, the Power Supply Unit may be faulty. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
8000B83A	Warning	35642	Power Supply	Power Supplies Not Redundant	ESMCommonService	8000B83A	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x3A Status : Warning Description : %1 Power Supplies Not Redundant (Enclosure Serial Number %2)	Warning: Check the Power Supply Unit Connection. If there is no problem with the connection, the Power Supply Unit may be faulty. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
8000B83B	Warning	35643	Power Supply	Power Supplies Not Redundant	ESMCommonService	8000B83B	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x3B Status : Warning Description : %1 Power Supplies Not Redundant (Enclosure Address %2)	Warning: Check the Power Supply Unit Connection. If there is no problem with the connection, the Power Supply Unit may be faulty. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0008B3C	Error	35644	Power Supply	System Power Fault Detected	ESMCommonService	C0008B3C	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x3C Status : Critical Description : System Power Fault Detected (XR: %1 %2 WID: %3)	Fatal: Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C0008B3D	Error	35645	Power Supply	System Power Fault Detected	ESMCommonService	C0008B3D	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x3D Status : Critical Description : System Power Fault Detected (XR: %1 %2 WID: %3)	Fatal: Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
8000B83E	Warning	35646	Power Supply	Smart Storage Battery Failure	ESMCommonService	8000B83E	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x3E Status : Warning Description : Smart Storage Battery failure (Battery %1, service information: %2)	Warning: Smart Storage Battery fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	×	×	×	×
8000B83E	Warning	35646	Power Supply	Smart Storage Battery Failure	ESMCommonService	8000B83E	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x3E Status : Warning Description : Smart Storage Energy Pack failure (Energy Pack %1, service information: %2) Recommended Action : Refer Smart Storage Battery issues flowchart in the Troubleshooting Guide.	Warning: Smart Storage Battery fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×
8000B83F	Warning	35647	Power Supply	Smart Storage Battery Not Charged	ESMCommonService	8000B83F	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x3F Status : Warning Description : Smart Storage Battery did not charge at the expected rate, indicating a faulty battery (Battery %1, service information: 0x03)	Warning: Smart Storage Battery fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	×	×	×	×
8000B83F	Warning	35647	Power Supply	Smart Storage Battery Not Charged	ESMCommonService	8000B83F	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x3F Status : Warning Description : Smart Storage Energy Pack did not charge at the expected rate, indicating a faulty energy pack (Energy Pack %1, service information: 0x03) Recommended Action : Refer Smart Storage Battery issues flowchart in the Troubleshooting Guide.	Warning: Smart Storage Battery fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×
80008B40	Warning	35648	Power Supply	Smart Storage Battery Disabled	ESMCommonService	80008B40	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x40 Status : Warning Description : Smart Storage Battery disabled due to high ambient temperature, will be re-enabled when temp is lowered (Battery %1, service information: 0x04)	Warning: Smart Storage Battery is disabled due to high temperature. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	×	×	×	×
80008B40	Warning	35648	Power Supply	Smart Storage Battery Disabled	ESMCommonService	80008B40	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x40 Status : Warning Description : Smart Storage Energy Pack disabled due to high ambient temperature, will be re-enabled when temp is lowered (Energy Pack %1, service information: 0x04) Recommended Action : Refer Smart Storage Battery issues flowchart in the Troubleshooting Guide.	Warning: Smart Storage Battery is disabled due to high temperature. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	×	×	×	×	×	×	×	×	×	×	×	×

80008B40	Warning	35648	Power Supply	Smart Storage Battery Disabled	ESMCommonService	80008B40	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x40 Status : Warning Description : Smart Storage Energy Pack disabled due to high or low ambient temperature, will be re-enabled when temp is back to normal range (Energy Pack %1, service information: 0x04)	Warning: Smart Storage Battery is disabled due to high temperature. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80008B41	Warning	35649	Power Supply	Smart Storage Battery Discharged	ESMCommonService	80008B41	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x41 Status : Warning Description : Smart Storage Battery discharged to below minimum voltage, resulting in the inability of the battery to recharge properly (Battery %1, service information: 0x05)	Warning: Smart Storage Battery fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	×	×	×	×
80008B41	Warning	35649	Power Supply	Smart Storage Battery Discharged	ESMCommonService	80008B41	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x41 Status : Warning Description : Smart Storage Energy Pack discharged to below minimum voltage, resulting in the inability of the energy pack to recharge properly (Energy Pack %1, service information: 0x05) Recommended Action : Refer Smart Storage Battery issues flowchart in the Troubleshooting Guide.	Warning: Smart Storage Battery fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×
80008B43	Warning	35651	Power Supply	Smart Storage Battery Failure	ESMCommonService	80008B43	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x43 Status : Warning Description : Smart Storage Battery failure (Battery %1)	Warning: Smart Storage Battery fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	×	×	×	×
80008B43	Warning	35651	Power Supply	Smart Storage Battery Failure	ESMCommonService	80008B43	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x43 Status : Warning Description : Smart Storage Energy Pack failure (Energy Pack %1) Recommended Action : Refer Smart Storage Battery issues flowchart in the Troubleshooting Guide.	Warning: Smart Storage Battery fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×
80008B44	Warning	35652	Power Supply	Storage Enclosure Power Supply Failure	ESMCommonService	80008B44	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x44 Status : Warning Description : %1 Storage Enclosure Power Supply Failure (Power Supply %2, Box %3, %4)	Warning: Storage Enclosure Power Supply Failure detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80008B55	警告	35669	Power Supply	Battery Backup Unit	ESMCommonService	80008B55	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x55 Status : Warning Description : Battery Backup Unit: %1 (Power Supply %2)	Warning: Battery Backup Unit Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0008B55	Error	35669	Power Supply	Battery Backup Unit	ESMCommonService	C0008B55	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x55 Status : Critical Description : Battery Backup Unit: %1 (Power Supply %2)	Fatal: Battery Backup Unit Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80008D01	Warning	36097	Server Recovery	ASR Detected	ESMCommonService	80008D01	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0D Event Code : 0x01 Status : Warning Description : ASR Detected by System	Warning: ASR detected. Refer to the Integrated Management Log and contact your sales representative if necessary.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80008D03	Warning	36099	Server Recovery	ASR Reset Limit Detected	ESMCommonService	80008D03	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0D Event Code : 0x03 Status : Warning Description : ASR Reset Limit Detected by System ROM		NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80008D03	Warning	36099	Server Recovery	ASR Reset Limit Detected	ESMCommonService	80008D03	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0D Event Code : 0x03 Status : Warning Description : ASR Reset Limit Detected by System ROM	Warning: Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0008E02	Error	36354	OS	Automatic OS Shutdown	ESMCommonService	C0008E02	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0E Event Code : 0x02 Status : Critical Description : Automatic Operating System Shutdown %1		NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
C0008E02	Error	36354	OS	Automatic OS Shutdown	ESMCommonService	C0008E02	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0E Event Code : 0x02 Status : Critical Description : Automatic Operating System Shutdown %1		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C0009312	Error	37650	Storage Device	Drive Array Controller Failure	ESMCommonService	C0009312	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x13 Event Code : 0x12 Status : Critical Description : %1 Smart Array - Controller Failure (Status: %2)	Fatal: Drive Array Controller fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C0009312	Error	37650	Storage Device	Drive Array Controller Failure	ESMCommonService	C0009312	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x13 Event Code : 0x12 Status : Critical Description : %1 Storage - Controller status changed to %2	Fatal: Drive Array Controller fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0009313	Error	37651	Storage Device	Drive Array Controller Failure	ESMCommonService	C0009313	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x13 Event Code : 0x13 Status : Critical Description : Drive Array Controller Failure (Chassis %1, Slot %2)	Fatal: Drive Array Controller fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C0009405	Error	37893	System Error	Unrecoverable I/O Error	ESMCommonService	C0009405	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x14 Event Code : 0x05 Status : Critical Description : Unrecoverable I/O Error has occurred. System Firmware will log additional details in a separate IML message entry if possible.	Fatal: Server fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
80009407	Warning	37895	System Error	Server Critical Fault	ESMCommonService	80009407	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x14 Event Code : 0x07 Status : Warning Description : Server Critical Fault (Service Information: %1)	Warning: Server fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
80009407	Warning	37895	System Error	Server Critical Fault	ESMCommonService	80009407	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x14 Event Code : 0x07 Status : Warning Description : Server Critical Fault (Service Information: %1)	Warning: Server fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	×	×	×	×	×
80009407	Warning	37895	System Error	Server Critical Fault	ESMCommonService	80009407	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x14 Event Code : 0x07 Status : Warning Description : Server Critical Fault (Service Information: %1) %2 Recommended Action : Collect the AHS log and contact #VENDA8R support.	Warning: Server fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×
C0009407	Error	37895	System Error	Server Critical Fault	ESMCommonService	C0009407	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x14 Event Code : 0x07 Status : Critical Description : Server Critical Fault (Service Information: %1)	Fatal: Server fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	×	×	×	×
C0009407	Error	37895	System Error	Server Critical Fault	ESMCommonService	C0009407	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x14 Event Code : 0x07 Status : Critical Description : Server Critical Fault (Service Information: %1) %2 Recommended Action : Collect the AHS log and contact #VENDA8R support.	Fatal: Server fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×

C0009408	Error	37896	System Error	Enclosure Induced Event	ESMCommonService	C0009408	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x14 Event Code : 0x08 Status : Critical Description : Enclosure Induced Event (Service Information: Enclosure Power Loss, %1)		NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
C0009408	Error	37896	System Error	Enclosure Induced Event	ESMCommonService	C0009408	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x14 Event Code : 0x08 Status : Critical Description : Enclosure Induced Event (Service Information: Enclosure Power Loss, %1)		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C000A003	Error	40963	Notify	Invalid Firmware	ESMCommonService	C000A003	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x20 Event Code : 0x03 Status : Critical Description : iLO detected invalid %1 firmware.	Fatal: Invalid Firmware detected. If configured for automatic recovery, the repair attempt will happen automatically. If automatic recovery is not configured or if the automatic recovery does not succeed, then manual recovery will be required. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C000A21B	Error	41499	Notify	Inadequate Power To Power On:	ESMCommonService	C000A21B	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x22 Event Code : 0x1B Status : Critical Description : %1 Inadequate Power To Power On: %2 (Enclosure Serial Number %3, Slot %4)		NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
C000A21B	Error	41499	Notify	Inadequate Power To Power On:	ESMCommonService	C000A21B	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x22 Event Code : 0x1B Status : Critical Description : %1 Inadequate Power To Power On: %2 (Enclosure Serial Number %3, Slot %4)		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C000A21C	Error	41500	Notify	Inadequate Power To Power On:	ESMCommonService	C000A21C	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x22 Event Code : 0x1C Status : Critical Description : %1 Inadequate Power To Power On: %2 (Enclosure Address %3, Slot %4)		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
C000A21C	Error	41500	Notify	Inadequate Power To Power On:	ESMCommonService	C000A21C	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x22 Event Code : 0x1C Status : Critical Description : %1 Inadequate Power To Power On: %2 (Enclosure Address %3, Slot %4)		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
8000A901	Warning	43265	System Error	Improperly Seated Or Missing Device	ESMCommonService	8000A901	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x29 Event Code : 0x01 Status : Warning Description : Improperly seated or missing device (%1, %2)	Warning: Some device may improperly seated or missing. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C000A901	Error	43265	System Error	Improperly Seated Or Missing Device	ESMCommonService	C000A901	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x29 Event Code : 0x01 Status : Critical Description : Improperly seated or missing device (%1, %2)	Fatal: Some device may improperly seated or missing. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C001B220	Error	45600	Server Recovery	System Halted	ESMCommonService	C001B220	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x120 Status : Critical Description : A Critical Error Event that has kept the system from booting. -System Halted!	Fatal: Critical Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C002B212	Error	45586	Server Recovery	Processor UPI Initialization Error	ESMCommonService	C002B212	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x212 Status : Critical Description : Processor UPI Initialization Error. A processor UPI initialization error was detected. %1 (Major Code:%2, Minor Code:%3).	Fatal: Processor UPI Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C002B215	Error	45589	Server Recovery	DIMM Initialization Error	ESMCommonService	C002B215	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x215 Status : Critical Description : DIMM Initialization Error - Processor %1 DIMM %2. The identified processor and memory failed to initialize properly. %3 (Major Code:%4, Minor Code:%5).	Fatal: DIMM initialization Error. Collect information by Server information collection tool and contact your sales representative. <Deal Meathod is blank before Ver.2.0.7-0>	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C002B216	Error	45590	Server Recovery	DIMM Initialization Error	ESMCommonService	C002B216	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x216 Status : Critical Description : DIMM Initialization Error. A fatal error was detected while initializing memory. %1 (Major Code:%2, Minor Code:%3).	Fatal: DIMM Initialization Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C002B217	Error	45591	Server Recovery	DIMM Initialization Error	ESMCommonService	C002B217	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x217 Status : Critical Description : DIMM Initialization Error - Processor %1 DIMM %2. The identified processor and memory are operating at an incorrect voltage. %3 (Major Code:%4, Minor Code:%5).	Fatal: DIMM initialization Error. Collect information by Server information collection tool and contact your sales representative. <Deal Meathod is blank before Ver.2.0.7-0>	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C002B220	Error	45600	Server Recovery	KTI Initialization Error	ESMCommonService	C002B220	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x220 Status : Critical Description : KTI Initialization Error - A fatal KTI initialization error has been detected. %1 (Major Code: %2, Minor Code: %3).	Fatal: KTI Initialization Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C002B220	Error	45600	Server Recovery	UPI Initialization Error	ESMCommonService	C002B220	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x220 Status : Critical Description : KTI Initialization Error - A fatal KTI initialization error has been detected. %1 (Major Code: %2, Minor Code: %3).	Fatal: UPI Initialization Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C002B221	Error	45601	Server Recovery	Unknown Initialization Error	ESMCommonService	C002B221	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x221 Status : Critical Description : Unknown Initialization Error. The system has experienced a fatal initialization error. %1 (Major Code: %2, Minor Code: %3).	Fatal: The system has experienced a fatal initialization error. If the issue still persists contact your sales representative if necessary.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C002B232	Error	45618	Server Recovery	DIMM Initialization Error	ESMCommonService	C002B232	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x232 Status : Critical Description : DIMM Initialization Error - A memory initialization error was detected. %1 (Major Code:%2, Minor Code:%3).	Fatal: DIMM Initialization Error. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
8002B233	Warning	45619	Server Recovery	DIMM Initialization Error	ESMCommonService	8002B233	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x233 Status : Warning Description : DIMM Initialization Error - Processor %1 Channel %2. The identified memory channel could not be properly trained and has been mapped out. (Major Code:%3, Minor Code:%4).	Warning: DIMM Initialization Error. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×

8002B234	Warning	45620	Server Recovery	DIMM Initialization Error	ESMCommonService	8002B234	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x234 Status : Warning Description : DIMM Initialization Error - Processor %1 DIMM %2. The identified DIMM could not be properly trained and has been mapped out. (Major Code:%3, Minor Code:%4)	Warning: DIMM Initialization Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
8003B205	Warning	45573	Server Recovery	Redundant ROM Error	ESMCommonService	8003B205	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x305 Status : Warning Description : Redundant ROM Error: Both the Primary and Backup System ROMs are invalid.	Warning: The primary and backup system ROMs are invalid or corrupted. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
8003B218	Warning	45592	Server Recovery	TPM Self-Test Error	ESMCommonService	8003B218	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x318 Status : Warning Description : Trusted Platform Module (TPM) Self-Test Error.	Warning: The TPM has failed. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
8003B289	Warning	45705	Server Recovery	Unexpected Shutdown and Restart	ESMCommonService	8003B289	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x389 Status : Warning Description : Unexpected Shutdown and Restart - An undetermined error type resulted in a reboot of the server.	Warning: The server shut down unexpectedly. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C004B212	Error	45586	Server Recovery	Server Platform Services Firmware Error	ESMCommonService	C004B212	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x412 Status : Critical Description : Server Platform Services Firmware Error - The Server Platform Services firmware is operating in factory mode.	Fatal: The Server Platform Services firmware detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C004B213	Error	45587	Server Recovery	Innovation Engine Image Authentication Error	ESMCommonService	C004B213	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x413 Status : Critical Description : Innovation Engine Image Authentication Error. The Innovation Engine image could not be	Fatal: Innovation engine Authentication error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C004B262	Error	45666	Server Recovery	Uncorrectable Memory Error Threshold Exceeded	ESMCommonService	C004B262	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x462 Status : Critical Description : Uncorrectable Memory Error Threshold Exceeded (%1 %2, DIMM %3). The DIMM is mapped out and is currently not available.	Fatal: Uncorrectable Memory Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×
C030B210	Error	45584	Server Recovery	MemBIST RMT	ESMCommonService	C030B210	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x3010 Status : Critical Description : MemBIST RMT: %1 margin out of range at CPU %2 DIMM %3 - Count %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×
C030B210	Error	45584	Server Recovery	MemBIST RMT	ESMCommonService	C030B210	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x3010 Status : Critical Description : MemBIST RMT: %1 margin out of range at CPU %2 DIMM %3 - Count %4		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C030B211	Error	45585	Server Recovery	MemBIST MEMTEST	ESMCommonService	C030B211	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x3011 Status : Critical Description : MemBIST MEMTEST: UnCorrectable Memory Error found at CPU %1 DIMM %2 Rank %3 - UC Count %4	Fatal: Memory Build in Self Test Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×
C030B213	Error	45587	Server Recovery	BIST Failure	ESMCommonService	C030B213	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x3013 Status : Critical Description : Processor Built-In Self-Test (BIST) Failure. Processor %1, Error Code : 0x%2.	Fatal: Processor Build in Self Test Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	○	○	○	○	○	○	○	○	×	×	×	×	×
C030B213	Error	45587	Server Recovery	BIST Failure	ESMCommonService	C030B213	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x3013 Status : Critical Description : Processor Built-In Self-Test (BIST) Failure. Processor %1, Error Code : 0x%2.	Fatal: Processor Build in Self Test Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×
80048A49	Warning	35401	Server Recovery	Persistent Memory Error	ESMCommonService	80048A49	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x449 Status : Warning Description : Scalable Persistent Memory Address Range Scrub error threshold exceeded on %1. Logical NVDIMM %2. Logical NVDIMM Persistency is lost and future data backups are not	Warning: Persistent Memory error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×
80048A54	Warning	35412	Server Recovery	NVDIMM Error	ESMCommonService	80048A54	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x454 Status : Warning Description : NVDIMM Error - Persistent Memory Address Range Scrub error threshold exceeded on Processor %1, DIMM %2 (SN:%3-%4-%5-%6). NVDIMM Persistency is lost and future data backups are not possible.	Warning: NVDIMM error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×
80048A55	Warning	35413	Server Recovery	Persistent Memory Error	ESMCommonService	80048A55	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x455 Status : Warning Description : IMPORTANT: The %1 in Bay %2 will soon be incapable of supporting the Scalable Persistent Memory backup.	Warning: Persistent Memory error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×
C0048A56	Error	35414	Server Recovery	Persistent Memory Error	ESMCommonService	C0048A56	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x456 Status : Critical Description : IMPORTANT: The %1 in Bay %2 cannot support the Scalable Persistent Memory backup. Logical NVDIMM persistency has been lost.	Fatal: Persistent Memory error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×
80008B56	Warning	35670	Power Supply	Smart Storage Battery Pre-failure	ESMCommonService	80008B56	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x56 Status : Warning Description : Smart Storage Battery pre-failure (Battery %1)	Warning: Smart Storage Battery pre-failure detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	○	○	○	×	×	○	×	×	×	×	×	×
80008B56	Warning	35670	Power Supply	Smart Storage Battery Pre-failure	ESMCommonService	80008B56	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0B Event Code : 0x56 Status : Warning Description : Smart Storage Energy Pack pre-failure (Energy Pack %1)	Warning: Smart Storage Battery pre-failure detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×
C002B270	Error	45680	Server Recovery	FW Communication Issue	ESMCommonService	C002B270	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x270 Status : Critical Description : %1 FW Communication Issue - Unable to communicate with %2 FW. Certain management functionality is not available.	Fatal: The system cannot communicate with the iLO firmware. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	○	×	×	×	×	×	×
C0198A00	Error	35328	Server Recovery	Smart Array Controller Failed	ESMCommonService	C0198A00	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1900 Status : Critical Description : Slot %1 Smart Array - Controller Failure. %2 Recommended Action : 1. Reseat the controller in the PCI slot. 2. Update the controller to the latest firmware version. 3. If the issue persists, replace the controller.	Fatal: RAID Controller Failure detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×
C0198A00	Error	35328	Server Recovery	Storage Controller Failed	ESMCommonService	C0198A00	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1900 Status : Critical Description : Slot %1 Storage - Controller status changed to Failed. %2	Fatal: RAID Controller Failure detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×

80198A03	Warning	35331	Server Recovery	Smart Array Controller Failed	ESMCommonService	80198A03	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1903 Status : Warning Description : Slot %1 Smart Array - Memory error occurred during self-test. Recommended Action : Update the firmware. If the problem persists, replace the controller.	Warning: RAID Controller Memory error occurred. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×
80198A03	Warning	35331	Server Recovery	Storage Controller Failed	ESMCommonService	80198A03	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1903 Status : Warning Description : Slot %1 Storage - Controller status changed to Failed. Memory error occurred during self-test.	Warning: RAID Controller Memory error occurred. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0198A31	Error	35377	Server Recovery	Smart Array Controller Failed	ESMCommonService	C0198A31	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1931 Status : Critical Description : Slot %1 Smart Array - Data in write-back cache has been lost. Recommended Action : 1. Verify the integrity of the data stored on the drive. 2. Perform orderly system shutdowns to avoid leaving data in the cache. 3. If the data is corrupt, restore previous backup data.	Fatal: RAID Controller Write-back cache data has been lost. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	○	○	○	×	×	×	×	×	×	×	×	×
C0198A31	Error	35377	Server Recovery	Smart Array Controller Failed	ESMCommonService	C0198A31	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1931 Status : Critical Description : Slot %1 Smart Array - Data in write cache has been lost.	Fatal: RAID Controller Write-back cache data has been lost. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×
C0198A31	Error	35377	Server Recovery	Storage Controller Failed	ESMCommonService	C0198A31	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1931 Status : Critical Description : Slot %1 Storage - Controller write cache data has been lost	Fatal: RAID Controller Write-back cache data has been lost. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80198A34	Warning	35380	Server Recovery	Smart Array Battery Not Present	ESMCommonService	80198A34	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1934 Status : Warning Description : Slot %1 Smart Array - Battery is not present. Caching is disabled. Recommended Action : Install cache module battery.	Warning: Smart Array Battery is not present. Caching is disabled. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×	×	×	×	×	×
80198A34	Warning	35380	Server Recovery	Smart Array Battery Not Present	ESMCommonService	80198A34	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1934 Status : Warning Description : Slot %1 Smart Array - Cache Status: Disabled (Error Code: Missing Energy Pack) Recommended Action : Install cache module battery.	Warning: Smart Array Battery is not present. Caching is disabled. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×
80198A34	Warning	35380	Server Recovery	Storage Controller Failed	ESMCommonService	80198A34	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1934 Status : Warning Description : Slot %1 Storage - Controller write cache status changed to Degraded (Error Code: Missing Energy Pack)	Warning: Smart Array Battery is not present. Caching is disabled. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0198A36	Error	35382	Server Recovery	Smart Array Controller Failed	ESMCommonService	C0198A36	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1936 Status : Critical Description : Slot %1 Smart Array - Cache Self-Test Error Occurred. %2 Recommended Action : Replace the controller.	Fatal: RAID Controller Cache Module Self-Test Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×
C0198A36	Error	35382	Server Recovery	Storage Controller Failed	ESMCommonService	C0198A36	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1936 Status : Critical Description : Slot %1 Storage - Controller status changed to Failed. %2	Fatal: RAID Controller Cache Module Self-Test Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80009317	Warning	37655	Storage Device	Smart Array Controller Failed	ESMCommonService	80009317	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x13 Event Code : 0x17 Status : Warning Description : %1 Smart Array - Cache Failure (Status: %2. Error Code: %3)	Warning: RAID Controller Cache failure detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	×	×	○	×	×	×	×	×	×	×	×	×
80009317	Warning	37655	Storage Device	Smart Array Controller Failed	ESMCommonService	80009317	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x13 Event Code : 0x17 Status : Warning Description : %1 Smart Array - Cache Status: %2 (Error Code: %3)	Warning: RAID Controller Cache failure detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×
80009317	Warning	37655	Storage Device	Storage Controller Failed	ESMCommonService	80009317	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x13 Event Code : 0x17 Status : Warning Description : %1 Storage - Controller Write cache status changed to %2	Warning: RAID Controller Cache failure detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C004B252	Error	45650	Server Recovery	FW Communication Issue	ESMCommonService	C004B252	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x452 Status : Critical Description : %1 FW Communication Issue - Unable to communicate with %2 FW. One or more configuration settings may be used from the last system boot. One or more configuration changes since the last boot may not have taken affect.	Fatal: The iLO Firmware cannot communicate with the anothrer firmware. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	○	○	○	○	×	×	×	×	×	×	×	×	×
C004B252	Error	45650	Server Recovery	FW Communication Issue	ESMCommonService	C004B252	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x452 Status : Critical Description : %1 FW Communication Issue - Unable to communicate with %2 FW. One or more configuration settings may be used from the last system boot. One or more configuration changes since the last boot may not have taken affect.	Fatal: The iLO Firmware cannot communicate with the another firmware. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×
C004B257	Error	45655	Server Recovery	FW Communication Issue	ESMCommonService	C004B257	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x457 Status : Critical Description : %1 FW Communication Issue - Unable to communicate with %2 FW (Error Code 0x%3). Unexpected %4 behavior may occur.	Fatal: The iLO Firmware cannot communicate with the another firmware. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	○	○	○	○	×	×	×	×	×	×	×	×	×
C004B257	Error	45655	Server Recovery	FW Communication Issue	ESMCommonService	C004B257	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x457 Status : Critical Description : %1 FW Communication Issue - Unable to communicate with %2 FW (Error Code 0x%3). Unexpected %4 behavior may occur.	Fatal: The iLO Firmware cannot communicate with the another firmware. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×
C030B217	Error	45591	Server Recovery	Server Platform Services Authentication Failure	ESMCommonService	C030B217	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x3017 Status : Critical Description : Server Platform Services Authentication Failure - The Server Platform Services (SPS) firmware image failed authentication and may be compromised. -System Halted!	Fatal: The Server Platform Services firmware detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×
C030B217	Error	45591	Server Recovery	Server Platform Services Authentication Failure	ESMCommonService	C030B217	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x3017 Status : Critical Description : Server Platform Services Authentication Failure - The Server Platform Services (SPS) firmware image failed authentication and may be compromised.	Fatal: The Server Platform Services firmware detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C030B219	Error	45593	Server Recovery	Server Platform Services Firmware Error	ESMCommonService	C030B219	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x3019 Status : Critical Description : Server Platform Services Firmware in Recovery Mode. SPS firmware image is corrupted. -System	Fatal: The Server Platform Services firmware is working under Recovery Mode. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×

C000B301	Error	45825	Storage Device	Temperature Exceeded	ESMCommonService	C000B301	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x33 Event Code : 0x01 Status : Critical Description : Temperature exceeded on PCIe disk %1.	Fatal: If the temperature of PCIeSSD rises any higher, it will affect the proper operation of the system. Check that the air inlet is not clogged and the air conditioner is running.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×
C000B301	Error	45825	Storage Device	Temperature Exceeded	ESMCommonService	C000B301	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x33 Event Code : 0x01 Status : Critical Description : NVMe Storage - Drive at %1 exceeded max temperature	Fatal: If the temperature of PCIeSSD rises any higher, it will affect the proper operation of the system. Check that the air inlet is not clogged and the air conditioner is running.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C000B302	Error	45826	Storage Device	Disk Drive Status Changed	ESMCommonService	C000B302	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x33 Event Code : 0x02 Status : Critical Description : The status of the PCIe disk at location %1 is %1.	Fatal: Status change was detected on PCIeSSD. Collect information by Server information collection tool and contact your sales representative if needed.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	○	○	○	×	×	×	×	×	×	×	×	×
C000B302	Error	45826	Storage Device	Disk Drive Status Changed	ESMCommonService	C000B302	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x33 Event Code : 0x02 Status : Critical Description : The status of the PCIe disk at location %1 is %2.	Fatal: Status change was detected on PCIeSSD. Collect information by Server information collection tool and contact your sales representative if needed.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×
C000B302	Error	45826	Storage Device	Disk Drive Status Changed	ESMCommonService	C000B302	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x33 Event Code : 0x02 Status : Critical Description : NVMe Storage - Drive at %1 status changed to %2.	Fatal: Status change was detected on PCIeSSD. Collect information by Server information collection tool and contact your sales representative if needed.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C000B303	Error	45827	Storage Device	Disk Drive Status Changed	ESMCommonService	C000B303	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x33 Event Code : 0x03 Status : Critical Description : The PCIe disk wear status for the disk at location %1 is %2.	Fatal: PCIeSSD Wear Status Change was detected. Check IML and determine the necessity of maintenance. Collect information by Server information collection tool and contact your sales representative if needed.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	○	○	○	○	×	×	×	×	×	×	×	×	×
C000B303	Error	45827	Storage Device	Disk Drive Status Changed	ESMCommonService	C000B303	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x33 Event Code : 0x03 Status : Critical Description : The PCIe disk wear status for the disk at location %1 is %2.	Fatal: PCIeSSD Wear Status Change was detected. Check IML and determine the necessity of maintenance. Collect information by Server information collection tool and contact your sales representative if needed.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×
C000B303	Error	45827	Storage Device	Disk Drive Status Changed	ESMCommonService	C000B303	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x33 Event Code : 0x03 Status : Critical Description : NVMe Storage - Drive at %1 SSD wear status changed to %2.	Fatal: PCIeSSD Wear Status Change was detected. Check IML and determine the necessity of maintenance. Collect information by Server information collection tool and contact your sales representative if needed.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80048A68	Warning	35432	Server Recovery	Memory Channel Error	ESMCommonService	80048A68	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x468 Status : Warning Description : Memory Channel Error - Correctable Memory Error Threshold Exceeded (%1 %2 Channel %3).	Warning: Correctable Memory Error Threshold Exceeded detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×
8002B223	Warning	45603	Server Recovery	DIMM Initialization Error	ESMCommonService	8002B223	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x223 Status : Warning Description : DIMM Initialization Error - Processor %1 Channel %2. The identified memory channel could not be properly trained and has been mapped out. (Major Code:%3, Minor Code:%4)	Warning: DIMM initialization Error. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×
8002B223	Warning	45603	Server Recovery	DIMM Initialization Error	ESMCommonService	8002B223	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x223 Status : Warning Description : DIMM Initialization Error - Processor %1 %2. The identified memory channel could not be properly trained and has been mapped out. The indicated DIMMs will not be available. (Major Code:%3, Minor Code:%4)	Warning: DIMM initialization Error. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80058A22	Warning	35362	Server Recovery	PCIe Isolation Event	ESMCommonService	80058A22	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x522 Status : Warning Description : PCIe Isolation Event Detected - A PCIe device signaled an error and was disabled.	Warning: PCIe device failure detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×
C0318A19	Error	35353	Server Recovery	NVMDIMM Spare Blocks Alert	ESMCommonService	C0318A19	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3119 Status : Critical Description : NVMDIMM Spare Blocks Alert - Processor %1 DIMM %2 - The NVMDIMM has 1 percent of its spare blocks remaining. Future errors on this NVMDIMM may result in loss of	Fatal: The NVMDIMM has 1 percent of its spare blocks remaining. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	○	○	×	×	×	×	×	×	×	×	×	×	×
C0318A19	Error	35353	Server Recovery	NVMDIMM Spare Blocks Alert	ESMCommonService	C0318A19	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3119 Status : Critical Description : Intel Optane DC Persistent Memory Spare Blocks Alert - Processor %1 DIMM %2 - The Intel Optane Memory Module has 1 percent of its spare blocks remaining. Future errors on this Intel Optane Memory Module may result in loss of data.	Fatal: The NVMDIMM has 1 percent of its spare blocks remaining. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A19	Error	35353	Server Recovery	Memory Percentage Remaining Alert	ESMCommonService	C0318A19	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3119 Status : Critical Description : Intel Optane DC Persistent Memory Spare Blocks Alert - Processor %1 DIMM %2 - The Intel Optane Memory Module has 1 percent of its spare blocks remaining. Future errors on this Intel Optane Memory Module may result in loss of data.	Fatal: The HPE Persistent Memory has 1 percent of its spare blocks remaining. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A19	Error	35353	Server Recovery	Memory Percentage Remaining Alert	ESMCommonService	C0318A19	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3119 Status : Critical Description : Intel Optane PMem for HPE Percentage Remaining Alert - Processor %1 DIMM %2 (SN: %3) - The Persistent Memory Module has %4 percent or less specified life remaining. Future errors on this PMEM may result in loss of data.	Fatal: The HPE Persistent Memory has 1 percent of its spare blocks remaining. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A21	Error	35361	Server Recovery	Transaction Timeout Error	ESMCommonService	C0318A21	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3121 Status : Critical Description : Transaction Timeout Error Detected. Slot %1 (Segment %2, Bus %3, Device %4, Function %5).	Fatal: PCI Slot Transaction Timeout Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	○	○	×	×	×	×	×	×	×	×	×	×	×
C0318A21	Error	35361	Server Recovery	Transaction Timeout Error	ESMCommonService	C0318A21	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3121 Status : Critical Description : Transaction Timeout Error Detected. Slot %1 (Segment 0x%2, Bus 0x%3, Device 0x%4, Function 0x%5).	Fatal: PCI Slot Transaction Timeout Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A21	Error	35361	Server Recovery	Transaction Timeout Error	ESMCommonService	C0318A21	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3121 Status : Critical Description : Transaction Timeout Error Detected. %1 %2 (Segment 0x%3, Bus 0x%4, Device 0x%5, Function 0x%6).	Fatal: PCI Slot Transaction Timeout Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A27	Error	35367	Server Recovery	Transaction Timeout Error	ESMCommonService	C0318A27	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3127 Status : Critical Description : Transaction Timeout Error Detected. Embedded %1 (Segment %2, Bus %3, Device %4, Function %5).	Fatal: PCI Slot Transaction Timeout Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	×	○	○	×	×	×	×	×	×	×	×	×	×	×
C0318A27	Error	35367	Server Recovery	Transaction Timeout Error	ESMCommonService	C0318A27	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3127 Status : Critical Description : Transaction Timeout Error Detected. Embedded %1 (Segment 0x%2, Bus 0x%3, Device 0x%4, Function 0x%5).	Fatal: PCI Slot Transaction Timeout Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×

C0318A27	Error	35367	Server Recovery	Transaction Timeout Error	ESMCommonService	C0318A27	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3127 Status : Critical Description : Transaction Timeout Error Detected. NVMe Box %1 Bay %2 (Segment 0x%3, Bus 0x%4, Device 0x%5, Function 0x%6).	Fatal: PCI Slot Transaction Timeout Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
8030B220	Warning	45600	Server Recovery	PCIe Slot Error	ESMCommonService	8030B220	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x3020 Status : Warning Description : PCIe Slot %1 failed to train at Gen %2 speed and x%3 width.	Warning: PCI Slot Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×
8030B221	Warning	45601	Server Recovery	PCIe Slot Error	ESMCommonService	8030B221	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x3021 Status : Warning Description : PCIe Slot %1 failed to train.	Warning: PCI Slot Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×
8030B223	Warning	45603	Server Recovery	FlexibleLOM Error	ESMCommonService	8030B223	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x3023 Status : Warning Description : FlexibleLOM %1 failed to train.	Warning: PCI Slot Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	×	○	○	○	×	×	×	×	×	×	×	×	×	×
8030B223	Warning	45603	Server Recovery	FlexibleLOM Error	ESMCommonService	8030B223	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x3023 Status : Warning Description : FlexibleLOM %1 failed to train.	Warning: FlexibleLOM Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×
8030B224	Warning	45604	Server Recovery	FlexibleLOM Error	ESMCommonService	8030B224	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x3024 Status : Warning Description : FlexibleLOM %1 failed to train at Gen %2 speed and x%3 width.	Warning: FlexibleLOM Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×
C000B401	Error	46081	Power Supply	Power Supply Error	ESMCommonService	C000B401	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x34 Event Code : 0x01 Status : Critical Description : Power supply %1 has exceeded the current limit. Power Supply output will be disabled.	Fatal: Power Supply has exceeded the current limit. Power Supply output will be disabled. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×
80318A13	Warning	35347	Server Recovery	Memory Health Error	ESMCommonService	80318A13	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3113 Status : Warning Description : Intel Optane DC Persistent Memory Health Error - Processor %1 DIMM %2 - The Intel Optane Memory Module is approaching the end of its usable wear leveling.	Warning: Intel Optane Memory is approaching the end of its usable wear leveling. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	×	×	×	×	×	×	×	×	×	×	×	×	×
80318A13	Warning	35347	Server Recovery	Memory Health Error	ESMCommonService	80318A13	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3113 Status : Warning Description : Intel Optane DC Persistent Memory Health Error - Processor %1 DIMM %2 - The Intel Optane Memory Module is approaching the end of its usable wear leveling.	Warning: HPE Persistent Memory is approaching the end of its usable wear leveling. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80318A13	Warning	35347	Server Recovery	Memory Health Error	ESMCommonService	80318A13	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3113 Status : Warning Description : Intel Optane PMem for HPE Health Error - Processor %1 DIMM %2 (SN: %3) - The Persistent Memory Module is approaching the end of its usable wear leveling.	Warning: HPE Persistent Memory is approaching the end of its usable wear leveling. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A15	Error	35349	Server Recovery	Memory Health Error	ESMCommonService	C0318A15	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3115 Status : Critical Description : Intel Optane DC Persistent Memory Health Error - Processor %1 DIMM %2 - The Intel Optane Memory Module has experienced an issue and is no longer resilient.	Fatal: Intel Optane Memory Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A15	Error	35349	Server Recovery	Memory Health Error	ESMCommonService	C0318A15	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3115 Status : Critical Description : Intel Optane DC Persistent Memory Health Error - Processor %1 DIMM %2 - The Intel Optane Memory Module has experienced an issue and is no longer resilient.	Fatal: HPE Persistent Memory Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A15	Error	35349	Server Recovery	Memory Health Error	ESMCommonService	C0318A15	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3115 Status : Critical Description : Intel Optane PMem for HPE Health Error - Processor %1 DIMM %2 (SN: %3) - The Persistent Memory Module has experienced an issue and is no longer resilient.	Fatal: HPE Persistent Memory Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A16	Error	35350	Server Recovery	Memory Health Error	ESMCommonService	C0318A16	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3116 Status : Critical Description : Intel Optane DC Persistent Memory Health Error - Processor %1 DIMM %2 - The Intel Optane Memory Module has experienced a critical error and may no longer be	Fatal: Intel Optane Memory Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A16	Error	35350	Server Recovery	Memory Health Error	ESMCommonService	C0318A16	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3116 Status : Critical Description : Intel Optane DC Persistent Memory Health Error - Processor %1 DIMM %2 - The Intel Optane Memory Module has experienced a critical error and may no longer be	Fatal: HPE Persistent Memory Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A16	Error	35350	Server Recovery	Memory Health Error	ESMCommonService	C0318A16	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3116 Status : Critical Description : Intel Optane PMem for HPE Health Error - Processor %1 DIMM %2 (SN: %3) - The Persistent Memory Module has experienced a critical error and may no longer be operational.	Fatal: HPE Persistent Memory Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80318A17	Error	35351	Server Recovery	Memory Spare Blocks Alert	ESMCommonService	80318A17	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3117 Status : Warning Description : Intel Optane DC Persistent Memory Spare Blocks Alert - Processor %1 DIMM %2 - The Intel Optane Memory Module has %3 percent or less of its spare blocks remaining.	Warning: Remaining spare blocks of Intel Optane Memory is low or less. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	×	×	×	×	×	×	×	×	×	×	×	×	×
80318A17	Error	35351	Server Recovery	Memory Percentage Remaining Alert	ESMCommonService	80318A17	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3117 Status : Warning Description : Intel Optane DC Persistent Memory Spare Blocks Alert - Processor %1 DIMM %2 - The Intel Optane Memory Module has %3 percent or less of its spare blocks remaining.	Warning: Remaining spare blocks of HPE Persistent Memory is low or less. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80318A17	Error	35351	Server Recovery	Memory Percentage Remaining Alert	ESMCommonService	80318A17	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3117 Status : Warning Description : Intel Optane PMem for HPE Percentage Remaining Alert - Processor %1 DIMM %2 (SN: %3) - The Persistent Memory Module has %4 percent or less of its specified life remaining.	Warning: Remaining spare blocks of HPE Persistent Memory is low or less. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A37	Error	35383	Server Recovery	Memory Error	ESMCommonService	C0318A37	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3137 Status : Critical Description : Intel Optane DC Persistent Memory Secure Erase has Failed - Processor %1, DIMM %2 (SN :	Fatal: Intel Optane Memory Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	×	×	×	×	×	×	×	×	×	×	×	×	×

C0318A37	Error	35383	Server Recovery	Memory Error	ESMCommonService	C0318A37	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3137 Status : Critical Description : Intel Optane DC Persistent Memory Secure Erase has Failed - Processor %1, DIMM %2 (SN :	Fatal: HPE Persistent Memory Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A37	Error	35383	Server Recovery	Memory Error	ESMCommonService	C0318A37	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3137 Status : Critical Description : Intel Optane PMem for HPE %1 Failure - Processor %2, DIMM %3 (SN : %4)	Fatal: HPE Persistent Memory Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A58	Error	35416	Server Recovery	PCI Controller Error	ESMCommonService	C0318A58	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3158 Status : Critical Description : Resetting the configuration for PCI controller : %1 failed.	Fatal: Resetting the PCI Controller Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×
C0318A60	Error	35424	Server Recovery	Innovation Engine Error	ESMCommonService	C0318A60	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3160 Status : Critical Description : Innovation Engine Error - The Innovation Engine is operating in Diagnostic mode.	Fatal: Innovation Engine Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×
C0009409	Error	37897	System Error	Degraded Power	ESMCommonService	C0009409	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x14 Event Code : 0x09 Status : Critical Description : A degraded power event has been detected and the server should be replaced.	Fatal: Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	×	×	○	×	×	×	×	×	×	×	×	×	×	×	×
C0009409	Error	37897	System Error	Degraded Power	ESMCommonService	C0009409	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x14 Event Code : 0x09 Status : Critical Description : A degraded power event has been detected and the server system board should be replaced.	Fatal: Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A62	Error	35426	Server Recovery	Server Configuration Lock	ESMCommonService	C0318A62	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3162 Status : Critical Description : Server Configuration Lock has encountered an unexpected error (code 0x%1).	Fatal: Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A65	Error	35429	Server Recovery	Innovation Engine Error	ESMCommonService	C0318A65	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3165 Status : Critical Description : Innovation Engine Firmware Error - The Innovation Engine firmware is corrupt or not operating	Fatal: Innovation Engine Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×
C0008504	Error	34052	CPU	Uncorrectable Machine Check Exception	ESMCommonService	C0008504	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x05 Event Code : 0x04 Status : Critical Description : Uncorrectable Machine Check Exception Extended Registers (Conf 0x%1`%2, Ipid 0x%3`%4, Synd 0x%5`%6, DeStat 0x%7`%8, DeAddr 0x%9`%10 Misc1 0x%11%12.	Fatal: Uncorrectable Machine Check Exception detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0058A79	Error	35449	Server Recovery	Memory Error	ESMCommonService	C0058A79	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x579 Status : Critical Description : HPE Persistent Memory Error - Processor %1 DIMM %2 (SN: %3) - The HPE Memory Module reported a failure on the previous boot (Boot Status Register: 0x%4).	Fatal: HPE Persistent Memory Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0058A79	Error	35449	Server Recovery	Memory Error	ESMCommonService	C0058A79	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x579 Status : Critical Description : Intel Optane PMem for HPE Error - Processor %1 DIMM %2 (SN: %3) - The HPE Memory Module reported a failure on the previous boot (Boot Status Register: 0x%4).	Fatal: HPE Persistent Memory Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A68	Error	35432	Server Recovery	Device Encryption Error	ESMCommonService	C0318A68	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3168 Status : Critical Description : Device Encryption Error: Enabling encryption for Self Encrypted Drive (SED) at location : [%1] has failed.	Fatal: Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A69	Error	35433	Server Recovery	Device Encryption Error	ESMCommonService	C0318A69	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3169 Status : Critical Description : Device Encryption Error: Disabling encryption for Self Encrypted Drive (SED) at location : [%1] has failed.	Fatal: Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A6A	Error	35434	Server Recovery	Device Encryption Error	ESMCommonService	C0318A6A	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x316A Status : Critical Description : Device Encryption Error: Modifying passphrase for Self Encrypted Drive (SED) at location : [%1]	Fatal: Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318A99	Error	35481	Server Recovery	Memory Error	ESMCommonService	C0318A99	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x3199 Status : Critical Description : PMM Error - Processor %1, DIMM %2. PMM will experience or has already experienced an overflow of uncorrectable errors. Loss of persistency imminent. Error Count: %3, Error Status: 0x%4	Fatal: HPE Persistent Memory Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80008239	Warning	33337	Temperature	Temperature Threshold Exceeded	ESMCommonService	80008239	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x39 Status : Warning Description : Inlet Ambient temperature sensor Pre-Caution threshold exceeded.	Warning: If the temperature rises any higher, it will affect the proper operation of the system. Check that the air inlet is not clogged and the air conditioner is running.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	×	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×
80008239	Warning	33337	Temperature	Temperature Threshold Exceeded	ESMCommonService	80008239	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x39 Status : Warning Description : Inlet ambient temperature sensor : %1C, exceeded the user defined pre-caution threshold : %2C.	Warning: If the temperature rises any higher, it will affect the proper operation of the system. Check that the air inlet is not clogged and the air conditioner is running.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0008805	Error	34821	Bus	PCI Express Error	ESMCommonService	C0008805	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x08 Event Code : 0x05 Status : Critical Description : Uncorrectable PCI Express Error Detected. NVMe Box %1 Bay %2 (Segment 0x%3, Bus 0x%4, Device 0x%5, Function 0x%6).	Fatal: Uncorrectable PCI Express Error detected on Processor. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80028A40	Warning	35392	Server Recovery	DIMM Initialization Warning	ESMCommonService	80028A40	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x240 Status : Warning Description : DIMM Initialization Warning - Processor %1 DIMM %2. A correctable memory initialization error was detected. (Major Code:%3, Minor Code:%4).	Warning: DIMM initialization Error. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80248A23	Warning	35363	Server Recovery	PCI Slot Error	ESMCommonService	80248A23	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2423 Status : Warning Description : %1 %2 Error - Firmware recovery mode detected. Initialization failed.	Warning: PCI SLOT Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0248A24	Error	35364	Server Recovery	PCI Slot Error	ESMCommonService	C0248A24	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x2424 Status : Critical Description : %1 %2 Error - Critical Firmware data has been corrupted.	Fatal: PCI SLOT Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×

80318A8E	Warning	35470	Server Recovery	Memory Channel Error	ESMCommonService	80318A8E	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x318E Status : Warning Description : Memory Channel Error - Correctable Memory Error Threshold Exceeded (Processor %1, DIMM %2).	Warning: Correctable Memory Error Threshold Exceeded detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318AAA	Error	35498	Server Recovery	Server Platform Services Firmware Error	ESMCommonService	C0318AAA	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x31AA Status : Critical Description : Server Platform Services Firmware in Recovery Mode. SPS firmware image is corrupted.	Fatal: The Server Platform Services firmware is working under Recovery Mode. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318AAD	Error	35501	Server Recovery	Downstream Port	ESMCommonService	C0318AAD	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x31AD Status : Critical Description : PCIe Enhanced Downstream Port Containment (EDPC) Event detected on NVMe Box %1 Bay %2. EDPC Status: 0x%3.		NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
8030B235	Warning	45621	Server Recovery	DIMM Initialization Error	ESMCommonService	8030B235	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x3035 Status : Warning Description : DIMM Initialization Error - Processor %1 DIMM %2 could not be trained properly and has been mapped out.	Warning: DIMM initialization Error. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C030B238	Error	45624	Server Recovery	Server Platform Services Firmware Error	ESMCommonService	C030B238	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x3038 Status : Critical Description : Server Platform Services Firmware in Recovery Mode. System Halted! Please update your firmware using an SPS image recovery package.	Fatal: The Server Platform Services firmware is working under Recovery Mode. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
0030B238	Error	45624	Server Recovery	Server Platform Services Firmware Error	ESMCommonService	0030B238	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x3038 Status : Critical Description : Server Platform Services Firmware is in Recovery Mode. System Halted!	Fatal: The Server Platform Services firmware is working under Recovery Mode. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
8030B23A	Warning	45626	Server Recovery	Intel Trusted Execution Error	ESMCommonService	8030B23A	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x303A Status : Warning Description : Intel Trusted Execution Error - Intel TXT BIOS ACM has reported an error (code:0x%1).	Warning: Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
8030B23B	Warning	45627	Server Recovery	Intel Trusted Execution Error	ESMCommonService	8030B23B	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x303B Status : Warning Description : Intel Trusted Execution Error - Intel TXT SINITACM has reported an error (code:0x%1).	Warning: Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
40198A01	Information	35329	Server Recovery	Smart Array Controller Failed	ESMCommonService	40198A01	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1901 Status : OK Description : Slot %1 Smart Array - Controller failed on previous power-up due to lock up code 0x%2	Information: RAID Controller failure detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	×	×	×	×	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×
40198A01	Information	35329	Server Recovery	Storage Controller Failed	ESMCommonService	40198A01	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1901 Status : OK Description : Slot %1 Storage - Controller failed on previous power-up (Error Code:0x%2)	Information: RAID Controller failure detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
8002B240	Warning	45632	Server Recovery	DIMM Initialization Warning	ESMCommonService	8002B240	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x32 Event Code : 0x240 Status : Warning Description : DIMM Initialization Warning - Processor %1 DIMM %2. A correctable memory initialization error was detected. (Major Code:%3, Minor Code:%4)	Warning: DIMM initialization Error. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0008505	Error	34053	CPU	Internal Processor Error	ESMCommonService	C0008505	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x05 Event Code : 0x05 Status : Critical Description : Internal processor error occurred - primary processor is unable to boot. System halted.	Fatal: Error was detected on Processor. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
40008506	Information	34054	CPU	System Processor Error	ESMCommonService	40008506	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x05 Event Code : 0x06 Status : OK Description : System processor property is unexpected (%1)	Information: Error was detected on Processor. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80318ABD	Warning	35517	Server Recovery	PCIe Correctable Error	ESMCommonService	80318ABD	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x31BD Status : Warning Description : PCIe correctable error threshold exceeded. Bus 0x%1 Device 0x%2 Function 0x%3	Warning: Correctable PCI Express Error Threshold Exceeded detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
8000823F	Warning	33343	Temperature	Temperature Threshold Exceeded	ESMCommonService	8000823F	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x23F Status : Warning Description : User Defined Caution Temperature Threshold Exceeded (Temperature Sensor %1 (%2), Threshold %3C, Temperature %4C)	Warning: If the temperature rises any higher, it will affect the proper operation of the system. Check that the air inlet is not clogged and the air conditioner is running.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0008240	Error	33344	Temperature	Temperature Threshold Exceeded	ESMCommonService	C0008240	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x02 Event Code : 0x40 Status : Critical Description : User Defined Critical Temperature Threshold Exceeded (Temperature Sensor %1 (%2), Threshold %3C, Temperature %4C)	Fatal: Abnormal temperature detected. Check that the air inlet is not clogged and the air conditioner is running. Collect information by Server information collection tool and contact your sales representative.	SHUTDOWN	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80008507	Warning	34055	CPU	CPU Throttling Triggered	ESMCommonService	80008507	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x05 Event Code : 0x07 Status : Warning Description : CPU Throttling Triggered. CPU may be operating at reduced performance.	Warning: Throttling was detected on Processor. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C000940A	Error	37898	System Error	Server Critical Fault	ESMCommonService	C000940A	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x14 Event Code : 0x0A Status : Critical Description : Server Critical Fault (Service Information: %1) %2	Fatal: Server fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C000940B	Error	37899	System Error	Server Critical Fault	ESMCommonService	C000940B	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x14 Event Code : 0x0B Status : Critical Description : Server Critical Fault (Service Information: %1) %2	Fatal: Server fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C000940C	Error	37900	System Error	Server Critical Fault	ESMCommonService	C000940C	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x14 Event Code : 0x0C Status : Critical Description : Server Critical Fault (Service Information: %1) %2	Fatal: Server fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C000910B	Error	37131	Network	Fibre Channel Host Controller Status Changed	ESMCommonService	C000910B	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x11 Event Code : 0x0B Status : Critical Description : Fibre Channel Host Controller has a new Status %1	Fatal: The PCI Controller Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0009320	Error	37664	Storage Device	Disk Drive Status Changed	ESMCommonService	C0009320	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x13 Event Code : 0x20 Status : Critical Description : Embedded SATA Storage - Drive at %1 status changed to %2	Fatal: ATA Disk Drive fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80198A15	Warning	35349	Server Recovery	Drive Media Error	ESMCommonService	80198A15	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1915 Status : Warning Description : Slot %1 Storage - Drive media errors could not be recovered by RAID protection	Warning: Storage Drive fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×

80198A45	Warning	35397	Server Recovery	Logical Drives Degraded	ESMCommonService	80198A45	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1945 Status : Warning Description : Slot %1 Storage - Volume %2 status changed to degraded.	Warning: Storage Drive fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80198A46	Warning	35398	Server Recovery	Logical Drives Disabled	ESMCommonService	80198A46	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1946 Status : Warning Description : Slot %1 Storage - Volume %2 status changed to disabled. %3	Warning: Storage Drive fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80198A07	Warning	35335	Server Recovery	Storage Controller Failed	ESMCommonService	80198A07	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1907 Status : Warning Description : Slot %1 Storage - Controller status changed to Degraded. %2	Warning: RAID Controller error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80198A04	Warning	35332	Server Recovery	Storage Controller Failed	ESMCommonService	80198A04	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1904 Status : Warning Description : Slot %1 Storage - Controller status changed to Degraded. Redundant ROM programming failure.	Warning: RAID Controller error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80198A14	Warning	35348	Server Recovery	Storage Error	ESMCommonService	80198A14	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1914 Status : Warning Description : Slot %1 Storage - Drive(s) at %2 status changed to predictive failure.	Warning: Storage Drive fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0009323	Error	37667	Storage Device	Storage Controller Failed	ESMCommonService	C0009323	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x13 Event Code : 0x23 Status : Critical Description : %1 Storage - Controller write cache data has been lost.	Fatal: The Flash Backup Unit is degraded or has failed. Contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0009330	Error	37680	Storage Device	Disk Drive Status Changed	ESMCommonService	C0009330	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x13 Event Code : 0x30 Status : Critical Description : Embedded SATA Storage - Drive at %1 status changed to %2	Fatal: ATA Disk Drive fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80198A33	Warning	35379	Server Recovery	Flash Backup Unit Failed	ESMCommonService	80198A33	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x1933 Status : Warning Description : Slot %1 Smart Array - Consecutive power loss during I/O transactions on degraded write-back volumes. This might have resulted in data integrity issues.	Warning: The Flash Backup Unit is degraded or has failed. Contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C000931E	Error	37662	Storage Device	Disk Drive Status Changed	ESMCommonService	C000931E	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x13 Event Code : 0x1E Status : Critical Description : %1 Smart Array - Drive status changed. Status is : %2	Fatal: Storage Drive fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C000931E	Error	37662	Storage Device	Disk Drive Status Changed	ESMCommonService	C000931E	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x13 Event Code : 0x1E Status : Critical Description : %1 Storage - Drive at %2 status changed to %3 (AMS).	Fatal: Storage Drive fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C000932C	Error	37676	Storage Device	Disk Drive Status Changed	ESMCommonService	C000932C	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x13 Event Code : 0x2C Status : Critical Description : %1 Smart Array - Spare status is changed to %2	Fatal: Storage Spare Drive fault detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318AC3	Error	35523	Server Recovery	Memory Error	ESMCommonService	C0318AC3	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x31C3 Status : Critical Description : Intel Optane PMem for HPE Error - Processor %1 DIMM %2 (SN: %3) - The HPE Persistent Memory Module reported a failure on the current boot (Current Boot Status Register: 0x%4).	Fatal: HPE Persistent Memory Error Detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80318AC7	Warning	35527	Server Recovery	NIC Error	ESMCommonService	80318AC7	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x31C7 Status : Warning Description : Smart NIC Timeout Error (Slot %1)	Warning: Network device failure detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	×	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
80318AC7	Warning	35527	Server Recovery	NIC Error	ESMCommonService	80318AC7	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x31C7 Status : Warning Description : SmartIO Timeout Error (Slot %1, Error Code %2). Device did not report initialization completion in time. Some functionality may not be available.	Warning: Network device failure detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0318ACB	Error	35531	Server Recovery	PCIe Event	ESMCommonService	C0318ACB	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x0A Event Code : 0x31CB Status : Critical Description : PCIe Enhanced Downstream Port Containment (EDPC) Event detected on Slot %1. EDPC Status: 0x%2.	Fatal: PCI Express Error detected on Processor. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
C0008306	Error	33542	Memory	Innovation Engine	ESMCommonService	C0008306	Date : YYYY-MM-DD hh:mm:ss Event Class : 0x03 Event Code : 0x06 Status : Critical Description : Innovation Engine not responding to MCTP Requests, please AC Cycle the server to recover IE.	Fatal: Innovation Engine Error detected. Collect information by Server information collection tool and contact your sales representative.	NONE	OFF	OFF	ON(3)	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×

Source Name<SRC:>: ESMSYSTEMMANAGEMENTSERVICE (iLO support model)

When Hardware Log Monitoring Service failed, it is a message to register.

Event ID (Hex digit)	Error Type	Event ID	Type	Trap Name	KeyWord1	KeyWord2	Message	Deal Meathod	Recover Action	Manager Report	Manager Report(CIM ~	Express Report (Level)	SNMP Trap OID (Enterprise ID.Specific ID)	バージョン																					
														2.2.7-0	2.2.5-0~ 2.2.6-0	2.2.4-0	esmsasup (2022-03-15)	2.2.3-0	2.2.2-0	2.2.0-0	2.1.3-0	2.1.2-0~ 2.1.1-0	2.1.0-0	2.0.9-0	2.0.8-0	2.0.7-0	2.0.6-0	2.0.5-0	2.0.3-0 ~2.0.4-0	2.0.1-0 ~2.0.2-1	2.0.0-0	1.3.0-0 ~1.3.1-0	1.1.3-0	1.1.0-0 ~1.1.2-0	1.0.0-0
C000238D	Error	9101	AM	ESMsmsrv Inner Error	ESMSystemManagementService	C000238D	Internal Error (System Management Service) [%1]		NONE	OFF	OFF	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	×	×	×	×

Syslog Event list of software monitoring

When Esmpro-Omsrv package is installed, this event registers an event, this event becomes a target of the report.

Source Name<SRC:>: ESMCPUPERF

When CPU load changed in "Fatal", "Warning", "Information", it is a message to register. Default of "Manager Report(SNMP)" is "OFF".

Event ID (Hex digit)	Error Type	Event ID	Type	Trap Name	KeyWord1	KeyWord2	Message	Deal Meathod	Recover Action	Manager Report	Manager Report(CIM ~	Express Report (Level)	SNMP Trap OID (Enterprise ID.Specific ID)	Version																					
														2.2.7-0	2.2.5-0~ 2.2.6-0	2.2.4-0	esmsasup (2022-03-15)	2.2.3-0	2.2.2-0	2.2.0-0	2.1.3-0	2.1.2-0~ 2.1.1-0	2.1.0-0	2.0.9-0	2.0.8-0	2.0.7-0	2.0.6-0	2.0.5-0	2.0.3-0 ~2.0.4-0	2.0.1-0 ~2.0.2-1	2.0.0-0	1.3.0-0 ~1.3.1-0	1.1.3-0	1.1.0-0 ~1.1.2-0	1.0.0-0
C0000064	Error	100	CPU	CPU Load Error	ESMCpuPerf	C0000064	CPU total load factor has exceeded the upper threshold(Error).	Fatal: Please kill the process which occupies the CPU.	NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000065	Warning	101	CPU	CPU Error Recovered	ESMCpuPerf	80000065	CPU total load factor has recovered from its error state.		NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000066	Warning	102	CPU	CPU Load Warning	ESMCpuPerf	80000066	CPU total load factor has exceeded the upper threshold(Warning).		NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
40000067	Information	103	CPU	CPU Warning Recovered	ESMCpuPerf	40000067	CPU total load factor has recovered from its warning state.		NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000068	Error	104	CPU	CPU Load Error	ESMCpuPerf	C0000068	CPU %1 load factor has exceeded the upper threshold(Error).	Fatal: Please kill the process which occupies the CPU.	NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000069	Warning	105	CPU	CPU Error Recovered	ESMCpuPerf	80000069	CPU %1 load factor has recovered from its error state.		NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
8000006A	Warning	106	CPU	CPU Load Warning	ESMCpuPerf	8000006A	CPU %1 load factor has exceeded the upper threshold(Warning).		NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
4000006B	Information	107	CPU	CPU Warning Recovered	ESMCpuPerf	4000006B	CPU %1 load factor has recovered from its warning state.		NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

Source Name<SRC:>: ESMMEMORYUSAGE

When file system free changed in "Fatal", "Warning", "Information", it is a message to register. Default of "Manager Report(SNMP)" is "OFF".

Event ID (Hex digit)	Error Type	Event ID	Type	Trap Name	KeyWord1	KeyWord2	Message	Deal Meathod	Recover Action	Manager Report	Manager Report(CIM ~	Express Report (Level)	SNMP Trap OID (Enterprise ID.Specific ID)	Version																					
														2.2.7-0	2.2.5-0~ 2.2.6-0	2.2.4-0	esmsasup (2022-03-15)	2.2.3-0	2.2.2-0	2.2.0-0	2.1.3-0	2.1.2-0~ 2.1.1-0	2.1.0-0	2.0.9-0	2.0.8-0	2.0.7-0	2.0.6-0	2.0.5-0	2.0.3-0 ~2.0.4-0	2.0.1-0 ~2.0.2-1	2.0.0-0	1.3.0-0 ~1.3.1-0	1.1.3-0	1.1.0-0 ~1.1.2-0	1.0.0-0
C0000064	Error	100	Memory	Physical Memory Usage Error	ESMMemoryUsage	C0000064	Physical Memory usage exceeds the upper threshold(Error) %1KB Current Memory Usage %2KB	Fatal: Identify the process which occupy the physical memory by using top command and remove the cause.	NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000065	Warning	101	Memory	Physical Memory Usage Error Recovered	ESMMemoryUsage	80000065	Physical Memory usage has recovered from its error state. Upper Threshold Recovered(Error) %1KB Current Memory Usage %2KB		NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000066	Warning	102	Memory	Physical Memory Usage Warning	ESMMemoryUsage	80000066	Physical Memory usage exceeds the upper threshold(Warning). Upper Threshold(Warning) %1KB Current Memory Usage %2KB		NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

40000067	Information	103	Memory	Physical Memory Usage Recovery	ESMMemoryUsage	40000067	Physical Memory usage has recovered from its warning state. Upper Threshold Recovered(Warning) %1KB Current Memory Usage %2KB		NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C0000068	Error	104	Memory	Virtual Memory Usage Error	ESMMemoryUsage	C0000068	Virtual Memory usage exceeds the upper threshold(Error). Upper Threshold(Error) %1KB Current Memory Usage %2KB	Fatal: Identify the process which occupy the virtual memory by using top command and remove the cause.	NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
80000069	Warning	105	Memory	Virtual Memory Usage Error Recovered	ESMMemoryUsage	80000069	Virtual Memory usage has recovered from its error state. Upper Threshold Recovered(Error) %1KB Current Memory Usage %2KB		NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
8000006A	Warning	106	Memory	Virtual Memory Usage Warning	ESMMemoryUsage	8000006A	Virtual Memory usage exceeds the upper threshold(Warning). Upper Threshold(Warning) %1KB Current Memory Usage %2KB		NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
4000006B	Information	107	Memory	Virtual Memory Usage Recovery	ESMMemoryUsage	4000006B	Virtual Memory usage has recovered from its warning state. Upper Threshold Recovered(Warning) %1KB Current Memory Usage %2KB		NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C000006C	Error	108	Memory	Page File Usage Error	ESMMemoryUsage	C000006C	Page File usage exceeds the upper threshold(Error). Upper Threshold(Error) %1KB Current Memory Usage %2KB	Fatal: Identify the process which occupy the page file by using top command and remove the cause.	NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
8000006D	Warning	109	Memory	Page File Usage Recovered	ESMMemoryUsage	8000006D	Page File usage has recovered from its error state. Upper Threshold Recovered(Error) %1KB Current Memory Usage %2KB		NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
8000006E	Warning	110	Memory	Page File Usage Warning	ESMMemoryUsage	8000006E	Page File usage exceeds the upper threshold(Warning). Upper Threshold(Warning) %1KB Current Memory Usage %2KB		NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
4000006F	Information	111	Memory	Page File Usage Recovery	ESMMemoryUsage	4000006F	Page File usage has recovered from its warning state. Upper Threshold Recovered(Warning) %1KB Current Memory Usage %2KB		NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

Source Name<SRC:>: ESMFSSERVICE

When file system free changed in "Fatal", "Warning", "Information", it is a message to register. Default of "Manager Report(SNMP)" is "OFF".

Event ID (Hex digit)	Error Type	Event ID	Type	Trap Name	KeyWord1	KeyWord2	Message	Deal Meathod	Recover Action	Manager Report	Manager Report(CIM)	Express Report (Level)	SNMP Trap OID (Enterprise ID.Specific ID)	Version																					
														2.2.7-0	2.2.5-0~2.2.6-0	2.2.4-0	esmsasup (2022-03-15)	2.2.3-0	2.2.2-0	2.2.0-0	2.1.3-0	2.1.2-0~2.1.1-0	2.1.0-0	2.0.9-0	2.0.8-0	2.0.7-0	2.0.6-0	2.0.5-0	2.0.3-0~2.0.4-0	2.0.1-0~2.0.2-1	2.0.0-0	1.3.0-0~1.3.1-0	1.1.3-0	1.1.0-0~1.1.2-0	1.0.0-0
C00403E8	Error	1000	File System	File system free capacity:Fatal	ESMFSSService	C00403E8	The free capacity of this file system is less than "Fatal" level. File System : %1 (%2) Free Space / Capacity : %3 / %4 MB Threshold(Fatal) : %5 MB	Fatal: You should remove unnecessary directories and files on this drive. If there are no unnecessary files then you should add a new drive and move several files to it. If the threshold value was not appropriate, please change it.	NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
800403E9	Warning	1001	File System	File system free capacity:Warning	ESMFSSService	800403E9	The free capacity of this file system is less than "Warning" level. File System : %1 (%2) Free Space / Capacity : %3 / %4 MB Threshold(Warning) : %5 MB	Warning: This drive s free block amount may be at a fatal level. You should delete unnecessary directories and files on this drive. If threshold value was not appropriate, please change it.	NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
400403EA	Information	1002	File System	File system free capacity:Normal	ESMFSSService	400403EA	The free capacity comes back "Normal" level. File System : %1 (%2) Free Space / Capacity : %3 / %4 MB		NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
400407D0	Information	2000	File System	File system configuration change	ESMFSSService	400407D0	Configuration of the file system has changed.		NONE	OFF	ON	OFF	.1.3.6.1.4.1.119.2.2.4.4.18.3.1	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○