Express5800/R320c-E4, R320c-M4 Precautions

Read and follow the precautions below before using.
Keep this document for future use.

1. Precaution for replacing CPU/IO module

If you replace the CPU/IO module in working system, Duplexing does not end correctly depending on the system load.
In that case, reduce the system load, wait for a while, and then install the module again.

## 2. Precaution for operating with the keyboard

If you continue to press a key while the CPU module is made duplex or PCI module is separated, the system keeps the key pressing.
In that case, pressing another key releases the key pressing.

3. Precaution for AC ON

Turn on the AC power of one CPU/IO module within 180 seconds after turning on the AC power of another CPU/IO module.
If the time between turnings on the CPU/IO modules is 180 seconds or more, the HDD mirroring will be broken because the only one CPU/IO module tries to start OS.

.

CPU/IO module0   AC ON

CPU/IO module1   AC ON

                                less than 180 seconds

4. Precaution for instruction manuals

See User's Guide, Installation Guide and Maintenance Guide provided as book without using the EXPRESSBUILDER DVD.