

---

## **Supplement of Using N8104-208/212 on Windows Server**

---

When using the N8104-208/212 on Windows Server, installing Starter Pack at the server, the event log below may be recorded.

This event does not affect system operation.

**Level : Warning**

**Source : icea**

**ID:101**

**HPE Ethernet xGb x-port xxxx Adapter**

**PROBLEM:** Flow Control disabled on this interface. For RDMA traffic, it is recommended that flow control be enabled end to end on all network interfaces and switches to avoid performance degradation from dropped packets.

**ACTION:** Enable link level flow control or priority flow control for network direct port 445 on this interface.

\* "x" depends on the system environment.