
Express5800/R120h-1M, R120h-2M, R120h-1E, R120h-2E, T120h

Supplement of RESTful Interface Tool

1. Version Upgrade

The following RESTful Interface Tool is included in the Starter Pack S8.10-003.01.

RESTful Interface Tool: Version 2.2.0.0

This version supports the iLO5 Firmware: Version 1.20. Update the RESTful Interface Tool when installing "Standard Program Package" of this Starter Pack or updating to the iLO5 Firmware: Version 1.20.

To install the RESTful Interface Tool, refer to the installation guide of the server or README.txt included in the installation package.

2. Location

The file location of the RESTful Interface Tool Linux version is changed at the Starter Pack S8.10-003.01 as follows:

[Express5800/R120h-1M, R120h-2M]

/software/001/lrx/pp/restful

[Express5800/R120h-1E, R120h-2E, T120h]

/software/002/lrx/pp/restful

Revision history

2018/03/06 RESTful Interface Tool: Version 2.2.0.0

- iLO5 Firmware: Version 1.20 supported.

2017/08/23 RESTful Interface Tool: Version 2.0.0.0

- Initial release.