

---

## **Caution of using N8190-163/164/171/172**

---

In a multipathing Fibre Channel environment using N8190-163/164/171/172 on Windows, if you disable N8190-163/164/171/172 from Device Manager during disk heavy I/O, and then enable N8190-163/164/171/172 again, you could not enable it.

In this case, stop the disk heavy I/O. You can enable N8190-163/164/171/172.