
Supplement of Using N8104-208/212 on Windows Server

When using the N8104-208/212 on Windows Server, installing Starter Pack at the server, the event log below may be recorded.

This event does not affect system operation.

About ID:272, event may be registered in large numbers, and this can be suppress in the following method:

- Avoid intentionally disconnecting cables
- Do not mount the SFP+/SFP28 module (N8104-189/190) in unused slots
- Do not connect DA cable with unconnected opposite side

Level : Warning

Source : icea

ID:101

Intel(R) Ethernet Network Adapter E810-XXV-2 xxxxx

PROBLEM: Flow Control disabled on this interface. For RDMA traffic, it is recommended that flow control be enabled end to end on all network interfaces and switches to avoid performance degradation from dropped packets.

ACTION: Enable link level flow control or priority flow control for network direct port 445 on this interface.

* "x" depends on the system environment.

Level : Error

Source : icea

ID:272

Intel(R) Ethernet Network Adapter E810-XXV-2 xxxxx

PROBLEM: A parallel fault was detected.

Possible Solution: Change link partner connection and configuration.

* "x" depends on the system environment.