

Notes on LAN Firmware Updating for N8104-208(LOM),N8104-212/221(NIC)

If updating to the firmware version 4.20 included in this Starter Pack and the firmware version before application is 4.10, please follow the procedure below. If the firmware version of the target card is 4.01 or earlier, the following procedure is not necessary.

[Target products]

<Option LAN(Network Interface Card;NIC)>

N8104-208 Dual Port 10/25GBASE SFP+ LOM Card

N8104-212 Dual Port 10/25GBASE SFP28 Adapter

N8104-221 Dual Port 100GBASE QSFP28 Adapter

[Procedue]

Apply the following package individually by offline application.

When applying, click on "Select (gray)" or "Force (gray)" to the left of the package name and change it to "Selected (blue)" or "Forced (blue)".

After applying, turn off the power of the server and disconnect the AC cable.



[Package Name]

N8104-208 : Intel Firmware Package For E810-XXVDA2 Ethernet 10/25Gb 2-port SFP28 OCP3 Adapter

(HPE_E810_XXVDA2_SD_OCP_4p10_NCSIwPLDMoMCTP_8001518D)

N8104-212 : Intel Firmware Package For E810-XXVDA2 Ethernet 10/25Gb 2-port SFP28 Adapter (HPE_E810_XXVDA2_SD_4p10_PLDMoMCTP_80015188)

N8104-221 : Intel Firmware Package For E810-CQDA2 Ethernet 100Gb 2-port QSFP28 Adapter (HPE_E810_CQDA2_4p10_PLDMoMCTP_8001518E)

[Screen image (example N8104-212)]

