


UBM6(Backplane)

Notes on Firmware Updating

When updating firmware from this Starter Pack(Ver S8.10-010.08) by offline mode, UBM6(Backplane) firmware cannot update to Ver.1.02.

It is ignorable since it is compatible with Ver.1.00, it does not affect the operation of the system.



[Target products and target version]

Products:

- Products
 - UBM6 Backplane
- Firmware version
 - 1.02

[Target System]

Express5800/ R120h-1M (3rd-Gen) [2022 release model]

Express5800/ R120h-1M (3rd-Gen) [2022 release model]

Express5800/ Express5800/R120i-1M

Express5800/ Express5800/R120i-2M

[How to confirm the UBM6 Firmware version]

Confirm the firmware version by either of the following procedures:

< System Utilities >

- 1) Startup System Utilities by pressing the F9 key during POST.
- 2) Select System Information.
- 3) Select the Firmware Information.
- 4) Confirm the firmware version of UBM6.

The firmware name for the UBM6 is displayed as

Example : "UBM6 Universal Backplane Manager 1 Firmware".

< iLO web interface >

- 1) Connect to the target Server via iLO web interface and log in.
- 2) Select [Firmware & OS Software] -> [Installed Firmware].
- 3) Confirm the [Firmware Name] and [Firmware Version] of UBM6.

The [Firmware Name] for the UBM6 is displayed as

Example : "8 SFF 24G x1 NVMe/SAS UBM6 BC BP".