

Notes on using N8104-208/212/221 under VMware ESXi environment

**This guide is intended only for those using VMware ESXi.
In the case of Windows Server/Red Hat Enterprise Linux environment, the following support is not required.**

If you are updating to firmware version 4.20 included in this StarterPack and your OS is VMware ESXi, after applying StarterPack and updating to firmware version 4.20, follow the instructions below to update to firmware version 4.30.

If you are using an OS other than VMware ESXi, there is no need to update to firmware version 4.30. Please apply StarterPack and use firmware version 4.20.

1 Target products

N-code	Product Name	Display Name (On System Utilities)
N8104-208	Dual Port 10/25GBASE SFP+ LOM Card	Intel Ethernet Adapter E810-XXV-2 for OCP 3.0
N8104-212	Dual Port 10/25GBASE SFP28 Adapter	Intel Ethernet Network Adapter E810-XXV-2
N8104-221	Dual Port 100GBASE QSFP28 Adapter	Intel Ethernet Network Adapter E810-C-Q2

2 Target OS

VMware ESXi

3 Where to get firmware and how to apply it

Firmware Version	Where to get & How to apply
4.30	<ul style="list-style-type: none">● Where to get Firmware data files and application instructions are stored in the following folder of this StarterPack. Folder : /LAN_FW/N8104-208+212+221_FWDATA● How to apply<ol style="list-style-type: none">1. Apply StarterPack and update to firmware version 4.202. Update to firmware version 4.30 according to the application instructions