

ESMFSService

This service monitors configuration and free space of file system.

In case alert about this service occurred, confirm the free space of file system.

Event Viewer			AlertViewer				Destination(Default)	Others	SNMP Trap OID	
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Remarks	Enterprise ID	Specific ID
1000	Error	The free capacity of this file system is less than "Fatal" level. File System : %1 (Index %2) Free Space / Capacity : %3 / %4 MB Threshold(Fatal) : %5 MB	The free capacity of this file system is less than "Fatal" level. File System : %1 (Index %2) Free Space / Capacity : %3 / %4 MB Threshold(Fatal) : %5 MB	You should remove unnecessary directories and files on this drive. If there are no unnecessary files then you should add a new drive and move several files to it. If the threshold value was not appropriate, please change it.	Red	File System	✓	Make free space by deleting unnecessary file and others or by moving file to another file system. In case the threshold is not suitable for free space monitoring of file system, change the threshold to the value most suitable to the used system.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
1001	Warning	The free capacity of this file system is less than "Warning" level. File System : %1 (Index %2) Free Space / Capacity : %3 / %4 MB Threshold(Warning) : %5 MB	The free capacity of this file system is less than "Warning" level. File System : %1 (Index %2) Free Space / Capacity : %3 / %4 MB Threshold(Warning) : %5 MB	This drive's free block amount may be at a fatal level. You should delete unnecessary directories and files on this drive. If threshold value was not appropriate, please change it.	Yellow	File System	✓	Make free space by deleting unnecessary file and others or by moving file to another file system. In case the threshold is not suitable for free space monitoring of file system, change the threshold to the value most suitable to the used system.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
1002	Information	The free capacity comes back "Normal" level. File System : %1 (Index %2) Free Space / Capacity : %3 / %4 MB	The free capacity comes back "Normal" level. File System : %1 (Index %2) Free Space / Capacity : %3 / %4 MB	-	Green	File System	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
8201	Error	An internal fatal error of the ESMFSService has occurred. Error Code:(%1, %2, %3)	-	-	-	-	-	-		
8202	Information	An internal informational of the ESMFSService has occurred. Code:(%1, %2, %3)	-	-	-	-	-	-		
8203	Warning	An internal warning error of ESMFSService has occurred(Service setting). Error Code:(%1, %2, %3)	-	-	-	-	-	-		

ESMStorageService

This service monitors configuration and status of storage-related devices.

In case alert about this service occurred, confirm the storage-related device.

[Caution] The service name of this service differs from the displayed name. The service name is 「ESMStorageService」, while the displayed name is 「ESM_Storage_Service」(" " is one space character)

Event Viewer			AlertViewer				Destination(Default)	Others	SNMP Trap OID	
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Remarks	Enterprise ID	Specific ID
1000	Warning	The total count of errors on the hard disk exceeds the threshold value. %1 %2 %3 : %4 (Threshold %5)	The total count of errors on the hard disk exceeds the threshold value. %1 %2 %3 : %4 (Threshold %5)	The total count of errors on the hard disk exceeds the threshold value. Contact your hardware vendor for a replacement.	Yellow	Storage HD Unit	✓	Number of occurrences of hard disk error exceeded threshold. As continuous use of this hard disk is risky from the viewpoint of preventive maintenance, contact maintenance staff to replace the hard disk. After the replacement, make sure to reset.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
1001	Warning	S.M.A.R.T. predicts that your hard disk is going to fail. %1 %2	S.M.A.R.T. predicts that your hard disk is going to fail. %1 %2	S.M.A.R.T. predicts that your hard disk is going to fail. Contact your hardware vendor for a replacement.	Yellow	Storage HD Unit	✓	Error was detected by hard disk pre-failure prediction using S.M.A.R.T. function of hard disk. As continuous use of this hard disk is risky from the viewpoint of preventive maintenance, contact maintenance staff to replace the hard disk. After the replacement, make sure to reset.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
9201	Error	An internal fatal error of the ESM Storage Service has occurred. Error Code : (%1, %2, %3)	-	-	-	-	-	-	-	-
9202	Warning	An internal informational of the ESM Storage Service has occurred. Error Code : (%1, %2, %3)	-	-	-	-	-	-	-	-
9204	Warning	Failed to reset the hard disk. Please restart the ESM Storage Service and reset the hard disk again. Error Code : (%1, %2, %3)	-	-	-	-	-	-	-	-
9205	Warning	Failed to get the Pre-failure Prediction function setting. It does not work.	-	-	-	-	-	-	-	-
9206	Warning	An internal warning error of the ESM Storage Service has occurred(Service setting). Error Code : (%1, %2, %3)	-	-	-	-	-	-	-	-

ESMDiskArray

This service monitors configuration and status of disk array controller of the object which NEC ESMDiskArray function watches.
In case alert about this service occurred, confirm monitored disk array-related items of ESMPRO disk array monitoring.

Event Viewer			AlertViewer				Destination(Default)	Others	SNMP Trap OID	
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Remarks	Enterprise ID	Specific ID
1000	Information	Logical Device changed to %1. Disk Array: %2 Logical Device ID: %3	Logical Device changed to %1. Disk Array: %2 Logical Device ID: %3	-	Green	Disk Array Logical Device	✓	For %1, set "Online". In case there is vendor-specific expression, set creating character string like "Online(xxxx)". For %2, set controller name logical device is configured. For %3, set ID of logical device.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
1001	Warning			Replace the failed Physical Device.	Yellow	Disk Array Logical Device	✓	For %1, set "Critical". In case there is vendor-specific expression, set creating character string like "Critical(xxxx)". For %2, set controller name logical device is configured. For %3, set ID of logical device.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
1002	Error			Replace the failed Physical Device and reconstruct the Logical Device.	Red	Disk Array Logical Device	✓	For %1, set "Offline". In case there is vendor-specific expression, set creating character string like "Offline(xxxx)". For %2, set controller name logical device is configured. For %3, set ID of logical device.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
1003	Information			-	Green	Disk Array Logical Device	✓	For %1, set "Consistency Check". In case there is vendor-specific expression, set creating character string like "Consistency Check(xxxx)". For %2, set controller name logical device is configured. For %3, set ID of logical device.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
1004	Error	Logical Device might change to Offline. Disk Array: %1 Logical Device ID: %2	Logical Device might change to Offline. Disk Array: %1 Logical Device ID: %2	Check the utility for this disk array, eventlog or hardware. If this Logical Device has some trouble, replace the failed Physical Device and reconstruct the Logical Device.	Red	Disk Array Logical Device	✓	For %1, set controller name logical device is configured. For %2, set ID of logical device.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
1010	Information	Physical Device changed to %1. Disk Array: %2 Disk ID: %3 Model: %4	Physical Device changed to %1. Disk Array: %2 Disk ID: %3 Model: %4	-	Green	Disk Array Physical Device	✓	For %1, set "Online". In case there is vendor-specific expression, set creating character string like "Offline(xxxx)". For %2, set controller name logical device is configured. For %3, set ID of logical device. For %4, set model of physical device.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

1011	Error			Replace this Physical Device.	Red	Disk Array Physical Device	✓	For %1, set "Dead". In case there is vendor-specific expression, set creating character string like "Dead(xxxx)". For %2, set controller name logical device is configured. %For %3, set ID of logical device. For %4, set model of physical device.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
1012	Information			-	Green	Disk Array Physical Device	✓	For %1, set "Rebuild". In case there is vendor-specific expression, set creating character string like "Rebuild(xxxx)". For %2, set controller name to which physical device is connected. For %3, set ID of logical device. For %4, set model of physical device.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
1013	Information			-	Green	Disk Array Physical Device	✓	For %1, set "Hot Spare", or in case expression depends on vendor, set creating character string like "Hot Spare(XXXX)". For %2, set controller name to which physical device is connected. For %3, set ID of logical device. For %4, set model of physical device.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
1014	Information			-	Green	Disk Array Physical Device	✓	For %1, set "Ready". In case there is vendor-specific expression, set creating character string like "Ready(xxxx)". For %2, set controller name logical device is configured. For %3, set ID of logical device. For %4, set model of physical device.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
1015	Error	Physical Device might change to Dead. Disk Array: %1 Disk ID: %2 Model: %3	Physical Device might change to Dead. Disk Array: %1 Disk ID: %2 Model: %3	Check the utility for this disk array, eventlog or hardware. If this Physical Device has some trouble, replace it with another one.	Red	Disk Array Physical Device	✓	For %1, set controller name to which physical device is connected. For %2, set ID of physical device. For %3, set model of physical device.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
1020	Warning	S.M.A.R.T. feature considered the Physical Device to be in Warning state. Disk Array: %1 Disk ID: %2 Model: %3 Reset: %4	S.M.A.R.T. feature considered the Physical Device to be in Warning state. Disk Array: %1 Disk ID: %2 Model: %3 Reset: %4	Continuation use of this physical device is dangerous. Contact your hardware vendor for a replacement. When this Physical Device needs reset, reset the Device after replacement devices using the Manager or ESMDiskArray Console of an Agent.	Yellow	Disk Array Physical Device	✓	For %1, set controller name to which physical device is connected. For %2, set ID of physical device. For %3, set model of physical device. For %4, set whether reset is necessary.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
1030	Information	%1	%1	-	Green	Disk Array Option	✓	Use by optional feature. For %1, optional character string is inserted.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

1031	Warning	%1	%1	-	Yellow	Disk Array Option	✓	Use by optional feature. For %1, optional character string is inserted.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
1032	Error	%1	%1	-	Red	Disk Array Option	✓	Use by optional feature. For %1, optional character string is inserted.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4

ESMCommonService

This service consists of multiple monitoring services.

ESRAS system failure monitoring

monitors various information of server chassis such as temperature/FAN/power voltage/power supply in collaboration with OS/firmware/hardware/expansion board, etc. and rapidly detects failure information and alerts

In addition, it supports function of collecting error log at the time of detection of failure and automatic shut down of server and others in accordance with degree of failure.

Source name of Eventlog at the time of alert is registered as "ESMCommonService".

Monitoring of CPU load

collects performance information of system on a regular basis and sends alert about CPU loading factor.

Source name of Eventlog at the time of alert is registered as "ESMCpuPerf".

Local porting

monitors optional items not supported by DataView

You can set thresould/reflect status color of server and generate alert based on set information but special knowledge and information of MIB for monitored items are required for setting.

Source name of Eventlog at the time of alert is registered as "ESMLocalPolling".

Event Source [ESMCommonService]

Event Viewer			AlertViewer				Destination (Default)	Others	SNMP Trap OID	
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Remarks	Enterprise ID	Specific ID
100	Error	The temperature has exceeded the upper threshold (Error). Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	The temperature has exceeded the upper threshold setting(Error). Location:%2 Temperature:%3%6	Started system shutdown. Please check the air temperature.	Red	Temperature	✓	shuts down because operation at this temperature is risky. Confirm whether duct does not stop up or conditioning is working.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	3
101	Warning	The temperature has exceeded the upper threshold (Warning). Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	The temperature has exceeded the upper threshold setting(Warning). Location:%2 Temperature:%3%6	Please check the air temperature.	Yellow	Temperature	✓	If temperature rises more than this, operation is disturbed. Confirm whether duct does not stop up or conditioning is working.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	1
102	Error	The temperature has fallen below the lower threshold (Error). Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	The temperature is below the lower threshold setting(Error). Location:%2 Temperature:%3%6	Started system shutdown. Please check the air temperature.	Red	Temperature	✓	shuts down because operation at this temperature is risky. Confirm rapidly whether duct does not stop up or conditioning is working.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	8
103	Warning	The temperature has fallen below the lower threshold (Warning). Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	The temperature is below the lower threshold setting(Warning). Location:%2 Temperature:%3%6	Please check the air temperature.	Yellow	Temperature	✓	If temperature falls below than this, operation is disturbed. Confirm operation of conditioning.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	6

104	Information	The temperature has recovered from its lower warning status. Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	The temperature has recovered from its upper warning state. Location:%2 Temperature:%3%6	-	Green	Temperature	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	2
105	Information	The temperature has recovered from its lower warning status. Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	The temperature has recovered from its lower warning state. Location:%2 Temperature:%3%6	-	Green	Temperature	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	5
106	Warning	The temperature has recovered from a high temperature fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	The temperature has recovered from its upper fatal state. Location:%2 Temperature:%3%6	-	Yellow	Temperature	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	4
107	Warning	The temperature has recovered from a lower temperature fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	The temperature has recovered from its lower fatal state. Location:%2 Temperature:%3%6	-	Yellow	Temperature	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	7
113	Error	%5 has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings %4	The temperature has recovered from a non-recoverable state and gone into a fatal state. Location: %2 Temperature: %3%6	-	Red	Temperature	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	34
114	Error	%5 has exceeded the upper threshold (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The temperature has exceeded the upper threshold (Non recoverable). Location: %2 Temperature: %3%6	The system can not be operated with the current temperature. It may shut down. Please check if the vent is not closed and the air conditioner is normally operating.	Red	Temperature	✓	You can not operate tat this temperature. There is a risk that system goes down. Confirm whether duct does not stop up or conditioning is working.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	32

115	Error	%5 has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The temperature has recovered from a non-recoverable state and gone into a fatal state. Location: %2 Temperature: %3%6	-	Red	Temperature	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	33
200	Error	Fan Unit is malfunctioning. Location: %3 Unit Number: %2 Date: %1	%2 Fan is malfunctioning. The system has gone into a fatal state.	Started system shutdown.	Red	Fan	✓	Confirm connection of device and others. If there is no problem with connection, failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	23
201	Warning	Fan Unit is in warning status. Location: %3 Unit Number: %2 Date: %1	%2 Fan is malfunctioning. The system has gone into a warning state.	-	Yellow	Fan	✓	Confirm connection of device and others. If there is no problem with connection, failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	17
202	Information	Fan Unit has recovered from its warning state. Location: %3 Unit Number: %2 Date: %1	%2 Fan has recovered from its warning state.	-	Green	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	18
205	Information	%5 has recovered from the failure. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%2 fan has recovered from the failure.	-	Green	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	50
206	Warning	%5 has fallen below the lower limit (Warning). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has fallen below the lower limit (Warning).	-	Yellow	Fan	✓	If you continue to operate, there is a risk that operation may be disturbed because temperature in chassis becomes high.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	56

207	Information	%5 has recovered from its lower warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has recovered from its lower warning state.	-	Green	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	55
208	Error	%5 has fallen below the lower limit (Error). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has fallen below the lower limit (Error).	If you continue operating the system, the temperature inside the chassis may rise critically. It may shut down.	Red	Fan	✓	shuts down because temperature in chassis becomes high and risky if you continue to operate.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	58
209	Warning	%5 has recovered from a fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has recovered from a fatal state and gone into a warning state.	-	Yellow	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	57
210	Error	%5 has fallen below the lower limit (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has fallen below the lower limit (Non recoverable).	This fan may have broken down. Please confirm the fan state and replace it.	Red	Fan	✓	There is a risk that fan was broken. Confirm the status of fan and replace it accordingly.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	62
211	Error	%5 has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has recovered from a non-recoverable state and gone into a fatal state.	-	Red	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	61
212	Warning	%5 has exceeded the upper limit (Warning). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has exceeded the upper limit (Warning).	-	Yellow	Fan	✓	If you continue to operate, there is a risk that fan will be broken.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	51

213	Information	%5 has recovered from its upper warning state Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has recovered from its upper warning state.	-	Green	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	52
214	Error	%5 has exceeded the upper limit (Error). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has exceeded the upper limit (Error).	This fan may be damaged if you continue operating the system. It may shut down.	Red	Fan	✓	If you continue to operate, fan will be broken. Shuts down.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	53
215	Warning	%5 has recovered from a fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has recovered from a fatal state and gone into a warning state.	-	Yellow	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	54
216	Error	%5 has exceeded the upper limit (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has exceeded the upper limit (Non recoverable).	This fan may be damaged if you continue operating the system.	Red	Fan	✓	f you continue to operate, fan will be broken.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	59
217	Error	%5 has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has recovered from a non-recoverable state and gone into a fatal state.	-	Red	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	60
302	Information	Power Unit has recovered from its warning status. Unit Number: %2 Date: %1	Power unit has recovered from its warning state.	-	Green	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.11.3	6

304	Information	Power Unit was connected. Unit Number: %2 Date: %1	Power unit %1 was connected.	-	Green	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.11.3	8
306	Warning	Power Supply has lost the AC supply. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power Supply %1 has lost the AC supply.	-	Yellow	RPS	✓	Confirm connection of device and others. If there is no problem with connection, failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.11.3	10
309	Error	Power supply to the system has been stopped because Power Unit error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power supply to the system has been stopped because Power Unit error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	RPS	✓	Confirm connection of device and others. If there is no problem with connection, failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
310	Error	The system has been forced to be power down, because the side cover was opened. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The system has been forced to be power down, because the side cover was opened. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	RPS	✓	Confirm that side cover is closed. If there is no problem with cover, failure of device is considered. From the viewpoint of preventive maintenance, collect information by collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
311	Warning	Power Unit has lost the AC supply. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power Unit has lost the AC supply. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	Confirm connection of device and others. If there is no problem with connection, failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
313	Warning	Power Unit error has been found. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power Unit error has been found. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	Confirm connection of device and others. If there is no problem with connection, failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
314	Warning	Power Supply is in fatal state. Sensor Number: %2 Location: %3 Date: %1 IDStrings: %4	Power Supply %1 is in fatal state.	-	Yellow	RPS	✓	Confirm connection of device and others. If there is no problem with connection, failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.11.3	14

315	Warning	Power Supply is in warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power Supply %1 is in warning state.	-	Yellow	RPS	✓	Confirm conection of device and others. If there is no problem with connection, failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.11.3	13
500	Error	The %2 voltage exceeds the upper limit (Error). Present Voltage Level: %3 Threshold: %4 Date: %1	The %2 voltage exceeds the upper limit (Error). Present Voltage Level: %3 Threshold: %4 Date: %1	Started system shutdown.	Red	Voltage	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
501	Error	The %2 voltage is below the lower limit (Error). Present Voltage Level: %3 Threshold: %4 Date: %1	The %2 voltage is below the lower limit (Error). Present Voltage Level: %3 Threshold: %4 Date: %1	Started system shutdown.	Red	Voltage	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
504	Error	A failure has occurred in the voltage sensor. Date: %1 Sensor infomation: %2	The voltage sensor has been malfunctioning. Location:%2	-	Red	Voltage	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	28
506	Information	%5 has recovered from a fatal state Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The voltage has recovered from a fatal state.	-	Green	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	37
507	Warning	%5 has fallen below the lower limit (Warning). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has fallen below the lower limit (Warning). Nominal Level: %2 Level: %3	-	Yellow	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	43
508	Information	%5 has recovered from its lower warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has recovered from its lower warning state. Nominal Level: %2 Level: %3	-	Green	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	42

509	Error	%5 has fallen below the lower limit (Error). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has fallen below the lower limit (Error). Nominal Level: %2 Level: %3	It is dangerous to operate the system with the current voltage. It may shut down.	Red	Voltage	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	45
510	Warning	%5 has recovered from a fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has recovered from a fatal state and gone into a warning state. Nominal Level: %2 Level: %3	-	Yellow	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	44
511	Error	%5 has fallen below the lower limit (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has fallen below the lower limit (Non recoverable). Nominal Level: %2 Level: %3	The system can not be operated with the current voltage. It may shut down.	Red	Voltage	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	49
512	Error	%5 has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has recovered from a non-recoverable state and gone into a fatal state. Nominal Level: %2 Level: %3	-	Red	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	48
513	Warning	%5 has exceeded the upper limit (Warning). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has exceeded the upper limit (Warning). Nominal Level: %2 Level: %3	-	Yellow	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	38
514	Information	%5 has recovered from its upper warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has recovered from its upper warning state. Nominal Level: %2 Level: %3	-	Green	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	39

515	Error	%5 has exceeded the upper limit (Error). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has exceeded the upper limit (Error). Nominal Level: %2 Level: %3	It is dangerous to operate the system with the current voltage. It may shut down.	Red	Voltage	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	40
516	Warning	%5 has recovered from a fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has recovered from a fatal state and gone into a warning state. Nominal Level: %2 Level: %3	-	Yellow	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	41
517	Error	%5 has exceeded the upper limit (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has exceeded the upper limit (Non recoverable). Nominal Level: %2 Level: %3	The system can not be operated with the current voltage state. It may shut down.	Red	Voltage	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	46
518	Error	%5 has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has recovered from a non-recoverable state and gone into a fatal state. Nominal Level: %2 Level: %3	-	Red	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	47
600	Error	DC Voltage Alert reported in [%1] +5V: %2 -5V: %3 +12V: %4 -12V: %5 +3.3V: %6	DC voltage has exceeded the upper threshold setting(Error).	Started system shutdown.	Red	Voltage	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.15.3	4
601	Warning	DC Voltage Alert reported in [%1] +5Vs: %2 +5V Adapter: %3 +3V battery: %4	DC voltage has exceeded the upper threshold setting(Warning).	-	Yellow	Voltage	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.15.3	2

602	Warning	Error Detected on Server Management Board.	The Server Management Board is malfunctioning.	-	Yellow	SMB	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.15.3	10
701	Warning	CPU subsystem is running in a reduced capacity.	The CPU subsystem is running in a reduced capacity.	-	Yellow	CPU	✓	Failure of CPU is considered. From the viewpoint of preventive maintenance, as continuous use is risky, after contact with system administrator, replace CPU.	.1.3.6.1.4.1.119.2.2.4 .4.21.3	2
702	Warning	Memory subsystem is running in a reduced capacity.	The Memory subsystem is running with a reduced capacity.	-	Yellow	Memory	✓	Failure of memory is considered. From the viewpoint of preventive maintenance, as continuous use is risky, after contact with system administrator, replace memory.	.1.3.6.1.4.1.119.2.2.4 .4.21.3	1
703	Warning	CPU subsystem is running in a reduced capacity. CPU Number: %1	Physical CPU%1 was degraded and is in no use.	A part of Processor has stopped. Please report to the maintenance member and exchange Processor.	Yellow	CPU	✓	Failure of CPU is considered. From the viewpoint of preventive maintenance, as continuous use is risky, after contact with system administrator, replace CPU.	.1.3.6.1.4.1.119.2.2.4 .4.21.3	3
704	Information	%5 has recovered from reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The power unit has recovered from reduced capacity state.	-	Green	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.11.3	12
705	Warning	%5 is in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The power unit is in reduced capacity state.	The system is now operating with spare Power Supply. Please check out malfunctioning power supply.	Yellow	RPS	✓	Failure of power supply is considered. From the viewpoint of preventive maintenance, as continuous use is risky, after contact with system administrator, replace power supply.	.1.3.6.1.4.1.119.2.2.4 .4.11.3	11
707	Information	%5 has recovered from reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered from reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
708	Warning	%5 is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1

710	Warning	A memory is a degenerate state. Date: %1 Memory ID: %2	A memory is a degenerate state. Bank ID: %1 Memory ID: %2	A part of memory is a degenerate state. Please report to the maintenance member and exchange memory.	Yellow	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.4.3	4
800	Error	System Error Information Time:%1 Dump Switch:%2 Message: %3	System Error Information	The system is down because a STOP error occurred. Contact your customer support.	Red	System Error	✓	System went down due to system error. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.14.3	1
802	Warning	ECC Single bit Error occurred. Latest ECC 1bit error log: Error Address: %1 When Happened: %2 Syndrome: %3 Specified Group: %4 Specified Simm: %5	A ECC single bit error has occurred.	-	Yellow	Memory	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.4.3	1
911	Warning	Requested system shutdown (or reboot).	Requested system shutdown (or reboot).	-	-	Server Recovery	-	-	.1.3.6.1.4.1.119.2.2.4 .4.15.3	1
1000	Warning	Chassis Intrusion. %2 was opened on Date: %1	The Front cover was opened.	-	Yellow	Security	-	-	.1.3.6.1.4.1.119.2.2.4 .4.9.3	1
1001	Information	%2 was closed on Date: %1	The Front cover is now closed.	-	Green	Security	-	-	.1.3.6.1.4.1.119.2.2.4 .4.9.3	2
1002	Warning	Chassis Intrusion. %3 was opened Date: %1	Cover%2 was opened.	-	Yellow	Security	-	-	.1.3.6.1.4.1.119.2.2.4 .4.9.3	3
1003	Information	%3 was closed Date: %1	Cover%2 is now closed.	-	Green	Security	-	-	.1.3.6.1.4.1.119.2.2.4 .4.9.3	4
1100	Error	ECC Multiple bit error occurred. Date: %1 Code: %2	A ECC multiple bit error has occurred.	-	Red	Memory	✓	Failure of memory is considered. From the viewpoint of preventive maintenance, as continuous use is risky, after contact with system administrator, replace memory.	.1.3.6.1.4.1.119.2.2.4 .4.4.3	2
1101	Error	EISA Bus Timeout(8us) caused by one of the Bus Masters. Date: %1 Master ID: %2	A EISA Bus Timeout was caused by one of the Bus Masters. Slot number: %1	-	Red	Bus	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.8.3	1

1102	Error	EISA I/O channel check error occurred. Date: %1 Master ID: %2	A EISA I/O channel check error occurred. Slot number: %1	-	Red	Bus	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.8.3	2
1103	Error	Parity error occurred in the PCI subsystem. Date: %1 PCI Bus ID: %2	A Parity error occurred on the PCI bus.	-	Red	Bus	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.8.3	3
1104	Error	System error occurred on the PCI buses. Date: %1 PCI Bus ID: %2	A System error occurred on the PCI bus.	-	Red	Bus	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.8.3	4
1105	Error	CPU internal error occurred. Date: %1 CPU Number:%2	CPU %1 internal error occurred.	-	Red	CPU	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.2.3	9
1106	Error	Timeout of failsafe-timer(watchdog timer). Date: %1	Timeout of failsafe-timer(watchdog timer).	-	Red	Server Recovery	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.15.3	12
1107	Error	System error on the system buses. Date: %1 Bus ID: %2	A System error has occurred on the system bus.	-	Red	CPU	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.2.3	11
1108	Error	CPU thermal trip occurred. Date: %1 CPU Number:%2	CPU %1 thermal trip event has occurred.	-	Red	CPU	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.2.3	10
1300	Warning	NMI event generated by software. Date: %1	A NMI event was generated by software.	-	Yellow	OS	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.16.3	17
1301	Warning	Adjusted memory size. Date: %1 Bank ID: %2 Bank Original Size: %3 Bank Current Size: %4	The Memory size was adjusted.	-	Yellow	Memory	-	-	.1.3.6.1.4.1.119.2.2.4 .4.4.3	3

1302	Warning	Error was detected during the POST phase of system initialization. Date: %1 Error Code: %2	An Error was detected during the POST phase of system initialization. Error code: %1	-	Yellow	Server Recovery	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.15.3	14
1303	Warning	The error logging for specific errors have been disabled. Date: %1 Error Type: %2	The error logging for this specific error has been disabled. Time: %1 Error Type: %2	-	Yellow	System Error	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.14.3	3
1304	Warning	Reset event caused by the watchdog timer. Date: %1 Timeout Value: %2	A Reset event was generated by the watchdog timer. Timeout value: %1	-	Yellow	Server Recovery	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.15.3	13
1305	Warning	The system configuration was altered by the configuration utility. Date: %1	The system configuration was altered with the configuration utility.	-	Yellow	Server Recovery	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.15.3	15
1306	Warning	A cache is a degenerate state. Date: %1 DIMM ID: %2 Site Original Size: %3 Site Current Size: %4	The External cache size was adjusted.	A cache is a degenerate state. Please report to the maintenance member and exchange cache.	Yellow	CPU	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.2.3	13
1307	Warning	Level 3 cache ECC single bit error occurred. Date: %1 DIMM ID: %2	A Level 3 cache ECC single bit error occurred.	-	Yellow	CPU	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.2.3	14
1308	Error	Level 3 cache ECC multiple bit error occurred. Date: %1 DIMM ID: %2	A Level 3 cache ECC multiple bit error occurred.	-	Red	CPU	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.2.3	15
1309	Warning	System bus ECC single bit error occurred. Date: %1 SYSTEM BUS ID: %2	A System bus ECC single bit error has occurred.	-	Yellow	CPU	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.2.3	12

1315	Error	Processor has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Processor has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	CPU	-	Failure of CPU is considered. From the viewpoint of preventive maintenance, as continuous use is risky, after contact with system administrator, replace CPU.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1317	Information	System Event Log has been cleared. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	-	-	Server Recovery	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1318	Warning	All the errors logging to System Event Log have been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	All the errors logging to System Event Log have been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Server Recovery	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1321	Error	ECC Multi bit error of system bus has occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	ECC Multi bit error of system bus has occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	Bus	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1322	Error	NMI has occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	NMI has occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	CPU	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1323	Information	System watch program started. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	System watch program started. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Server Recovery	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1400	Error	This is the event which occurred between this system start-up %nand the last system stop or system shutdown %2 %3 %4 %5	This is the event which occurred between this system start-up %nand the last system stop or system shutdown %2 %3 %4 %5	-	Red	Server Recovery	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1

1401	Warning	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	-	Yellow	Server Recovery	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1402	Information	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	-	Green	Server Recovery	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1407	Error	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	-	Red	Server Recovery	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1408	Warning	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	-	Yellow	Server Recovery	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1409	Information	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	-	Green	Server Recovery	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1410	Error	%1 Date: %2 %3	%1 Date: %2 %3	-	Red	Server Recovery	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1411	Warning	%1 Date: %2 %3	%1 Date: %2 %3	-	Yellow	Server Recovery	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1412	Information	%1 Date: %2 %3	%1 Date: %2 %3	-	Green	Server Recovery	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1

1500	Information	Power button was pushed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	-	-	Security	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1501	Information	Sleep button was pushed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	-	-	Security	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1502	Information	Reset button was pushed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	-	-	Security	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1600	Warning	The slot or connector device is in fault state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The slot or connector device is in fault state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Hardware component has been changed. Please reconstruct tree if you already have DataViewer opened for this server.	Yellow	Security	✓	Hardware configuration was changed. In case you open DataViewer, execute rebuild of tree.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1602	Information	New device has been connected to the slot or the connector device. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Hardware component has been changed. Please reconstruct tree if you already have DataViewer opened for this server.	Green	Security	✓	Hardware configuration was changed. In case you open DataViewer, execute rebuild of tree.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1605	Information	Either the slot or connector power has been off, or device has been removed. SensorNumber: %2 Location: %3 Date: %1 ID Strings: %4	-	Hardware component has been changed. Please reconstruct tree if you already have DataViewer opened for this server.	Green	Security	✓	Hardware configuration was changed. In case you open DataViewer, execute rebuild of tree.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1700	Information	The system is now in active state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	-	-	Server Recovery	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1705	Information	The system is now in software-off state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	-	-	Server Recovery	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1

1707	Information	The system is now in hardware-off state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	-	-	Server Recovery	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1709	Information	The system is now in sleep state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	-	-	Server Recovery	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1800	Warning	Time out of Watch Dog Timer has occurred.(%5) Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Time out of Watch Dog Timer has occurred.(%5) Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Server Recovery	✓	Failure of system is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1802	Warning	Power Down occurred as time out of Watch Dog Timer has occurred.(%5) Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power Down occurred as time out of Watch Dog Timer has occurred.(%5) Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Server Recovery	✓	Failure of system is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1803	Warning	Power Cycle has occurred due to time out of Watch Dog Timer.(%5) Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power Cycle has occurred due to time out of Watch Dog Timer.(%5) Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Server Recovery	✓	Failure of system is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1808	Warning	Interruption has occurred by time out of Watch Dog Timer. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Interruption has occurred by time out of Watch Dog Timer. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Server Recovery	✓	Failure of system is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1900	Error	%5 The system might have broken down. There is no response from the sensor. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 The system might have broken down. There is no response from the sensor. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	Bus	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1

1901	Error	%5 Sensor Error has been detected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 Sensor Error has been detected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	Bus	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1902	Error	%5 The system might have broken down. Time out occurred in the access process to the sensor. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 The system might have broken down. Time out occurred in the access process to the sensor. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	Bus	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
2000	Information	The system is not set to extract memory dump(debug information). It is recommended to setup to extract memory dump(debug information).	The system is not set to extract memory dump(debug information). It is recommended to setup to extract memory dump(debug information).	Please check a setup of memory dump.	Green	OS	✓	Collection of memory dump (debug information) is not set. Setting of memory dump (debug information) is recommendable.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
2001	Warning	Memory dump may not be able to extract normally. %1 Dump setting Dump type: %2 Writing setup: %3 Dump file name: %4 Initial size of the virtual memory: %5 Physical memory size: %6	Memory dump may not be able to extract normally. %1 Dump setting Dump type: %2 Writing setup: %3 Dump file name: %4 Initial size of the virtual memory: %5 Physical memory size: %6	Please check a setup of memory dump.	Yellow	OS	✓	Collection of memory dump (debug information) is not set. Setting of memory dump (debug information) is recommendable.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
2100	Information	%3 presence status changed. Date: %1 Sensor Number: %2 ID Strings: %4	%3 presence status changed. Date: %1 Sensor Number: %2 ID Strings: %4	-	Green	FT Server	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
2101	Information	%3 power status changed. Date: %1 Sensor Number: %2 ID Strings: %4	%3 power status changed. Date: %1 Sensor Number: %2 ID Strings: %4	-	Green	FT Server	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
2102	Information	%3 reset released. Date: %1 Sensor Number: %2 ID Strings: %4	%3 reset released. Date: %1 Sensor Number: %2 ID Strings: %4	-	Green	FT Server	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1

2103	Information	%3 broken. Date: %1 Sensor Number: %2 ID Strings: %4	%3 broken. Date: %1 Sensor Number: %2 ID Strings: %4	-	Green	FT Server	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
2104	Error	%3 redundancy degraded (boot pair of CPU module/PCI module changed). Date: %1 Sensor Number: %2 ID Strings: %4	%3 redundancy degraded (boot pair of CPU module/PCI module changed). Date: %1 Sensor Number: %2 ID Strings: %4	-	Red	FT Server	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
2105	Warning	%3 BMC(Baseboard Management Controller) ready off. Date: %1 Sensor Number: %2 ID Strings: %4	%3 BMC(Baseboard Management Controller) ready off. Date: %1 Sensor Number: %2 ID Strings: %4	-	Green	FT Server	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
2106	Warning	%3 power control command failed. Date: %1 Sensor Number: %2 ID Strings: %4	%3 power control command failed. Date: %1 Sensor Number: %2 ID Strings: %4	-	Red	FT Server	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
2107	Information	%3 Communication I2C bus failure detected. Date: %1 Sensor Number: %2 ID Strings: %4	%3 Communication I2C bus failure detected. Date: %1 Sensor Number: %2 ID Strings: %4	-	Green	FT Server	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
2108	Information	%3 BMC synchronization failed. Date: %1 Sensor Number: %2 ID Strings: %4	%3 BMC synchronization failed. Date: %1 Sensor Number: %2 ID Strings: %4	-	Green	FT Server	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
2109	Information	%3 Primary BMC error detected. Date: %1 Sensor Number: %2 ID Strings: %4	%3 Primary BMC error detected. Date: %1 Sensor Number: %2 ID Strings: %4	-	Green	FT Server	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
2110	Information	%3 BMC failover occurred. Date: %1 Sensor Number: %2 ID Strings: %4	%3 BMC failover occurred. Date: %1 Sensor Number: %2 ID Strings: %4	-	Green	FT Server	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1

2300	Error	ECC Uncorrectable error occurred. Date: %1 Syndrome Byte: %2 Memory Card Number: %3 DIMM Number: %4	ECC Uncorrectable error occurred. Date: %1 Syndrome Byte: %2 Memory Card Number: %3 DIMM Number: %4	Exchange the memory.	Red	Memory	✓	Failure of memory is considered. From the viewpoint of preventive maintenance, as continuous use is risky, after contact with system administrator, replace memory.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2301	Error	Requested system shutdown via SMS. Date:%1	Requested system shutdown via SMS. Date:%1	-	Red	Server Recovery	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2302	Error	Requested system reboot via SMS. Date:%1	Requested system reboot via SMS. Date:%1	-	Red	Server Recovery	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2303	Warning	The slot or connector device is in fault state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The slot or connector device is in fault state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Security	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2304	Warning	Too many ECC Correctable Errors. Latest ECC correctable error log: Error Address: %1 When Happened: %2 Syndrome: %3 Specified Group: %4 Memory Number: %5	Too many ECC Correctable Errors. Latest ECC correctable error log: Error Address: %1 When Happened: %2 Syndrome: %3 Specified Group: %4 Memory Number: %5	Exchange the memory.	Yellow	Memory	✓	Failure of memory is considered. From the viewpoint of preventive maintenance, as continuous use is risky, after contact with system administrator, replace memory.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2305	Warning	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2306	Information	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2307	Error	ECC uncorrectable error occurred. Date: %1 Syndrome Byte: %2 Row Number: %5 Memory Card Number: %3 Memory Number: %4	ECC uncorrectable error occurred. Date: %1 Syndrome Byte: %2 Row Number: %5 Memory Card Number: %3 Memory Number: %4	Please report to the System Administrator or Support Center and then exchange the system memory.	Red	Memory	✓	Failure of memory is considered. From the viewpoint of preventive maintenance, as continuous use is risky, after contact with system administrator, replace memory.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2308	Information	Notify Switch ON. %2 Date: %1	Notify Switch ON. %2 Date: %1	-	Green	Notify Switch	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2309	Information	Notify Switch OFF. %2 Date: %1	Notify Switch OFF. %2 Date: %1	-	Green	Notify Switch	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2310	Information	The device has been removed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The device has been removed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Hardware component has been changed. Please reconstruct tree if you already have DataViewer opened for this server.	Green	Security	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2311	Warning	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Temperature	✓	If temperature rises more than this, operation is disturbed. Confirm whether duct does not stop up or conditioning is working.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2312	Information	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Temperature	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2313	Warning	The memory error occurred. A part of DIMM is released. DIMM Number: %2 Date: %1	The memory error occurred. A part of DIMM is released. DIMM Number: %2 Date: %1	Please report to the maintenance member and exchange memory.	Yellow	Memory	✓	Failure of memory is considered. From the viewpoint of preventive maintenance, as continuous use is risky, after contact with system administrator, replace memory.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2314	Error	%5 has gone into a non-recoverable state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a non-recoverable state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2315	Warning	All of Fans inside %5 is broken or not implemented. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	All of Fans inside %5 is broken or not implemented. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3

2316	Warning	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2317	Information	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2318	Error	%5 is in a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%5 is in a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	-	Red	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2319	Warning	%5 has recovered from a fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%5 has recovered from a fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	-	Yellow	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2320	Warning	%5 has fallen below the lower limit (Warning). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%5 has fallen below the lower limit (Warning). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	-	Yellow	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2321	Information	%5 has recovered from its lower warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%5 has recovered from its lower warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	-	Green	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2322	Warning	%5 Redundancy Degraded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 Redundancy Degraded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2323	Warning	%5 Non-redundant : Sufficient Resources from Redundant Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 Non-redundant : Sufficient Resources from Redundant Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2324	Information	%5 Non-redundant : Sufficient Resources from Insufficient Resources Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 Non-redundant : Sufficient Resources from Insufficient Resources Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2325	Error	%5 Non-redundant : Insufficient Resources Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 Non-redundant : Insufficient Resources Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2326	Warning	%5 Redundancy Degraded from Fully Redundant Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 Redundancy Degraded from Fully Redundant Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2327	Information	%5 Redundancy Degraded from Non-Redundant Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 Redundancy Degraded from Non-Redundant Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2328	Information	The slot or connector device has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The slot or connector device has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Security	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3

2329	Information	The DIMM has recovered. DIMM Number: %2 Date: %1	The DIMM has recovered. DIMM Number: %2 Date: %1	-	Green	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2330	Error	Chipset errors(CNB3.0HE#0) Date: %1 ErrorCode: %2	Chipset errors(CNB3.0HE#0) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2331	Error	Chipset errors(CNB3.0HE#1) Date: %1 ErrorCode: %2	Chipset errors(CNB3.0HE#1) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2332	Error	Chipset errors(CIOB20#0) Date: %1 ErrorCode: %2	Chipset errors(CIOB20#0) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2333	Error	Chipset errors(CIOB20#1) Date: %1 ErrorCode: %2	Chipset errors(CIOB20#1) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2334	Error	Chipset errors(AQUA#0) Date: %1 ErrorCode: %2	Chipset errors(AQUA#0) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2335	Error	Chipset errors(AQUA#1) Date: %1 ErrorCode: %2	Chipset errors(AQUA#1) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2336	Error	Chipset errors(CMIC Function#0) Date: %1 ErrorCode: %2	Chipset errors(CMIC Function#0) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2337	Error	Chipset errors(CMIC Function#1-3) Date: %1 ErrorCode: %2	Chipset errors(CMIC Function#1-3) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2338	Error	Chipset errors(CIOB30#0) Date: %1 ErrorCode: %2	Chipset errors(CIOB30#0) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3

2339	Error	Chipset errors(CIOB30#1) Date: %1 ErrorCode: %2	Chipset errors(CIOB30#1) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2340	Error	Chipset errors(REMC) Date: %1 ErrorCode: %2	Chipset errors(REMC) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2341	Error	Chipset errors(CSB5) Date: %1 ErrorCode: %2	Chipset errors(CSB5) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2342	Error	Chipset errors(CIOB30#2) Date: %1 ErrorCode: %2	Chipset errors(CIOB30#2) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2350	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member and exchange motherboard.	Red	Temperature	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2351	Information	%5 has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Temperature	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2352	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member and exchange motherboard.	Red	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2353	Information	%5 has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2354	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Red	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4

2360	Error	Chipset Specific Critical Interrupt Information Date: %1	Chipset Specific Critical Interrupt Information Date: %1	Please report to the maintenance member.	Red	Chipset	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2366	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Red	Temperature	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2367	Warning	%5 has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Temperature	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2368	Warning	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Yellow	Temperature	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2369	Information	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Temperature	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2370	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Temperature	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2371	Information	%5 has recovered.%nSensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered.%nSensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Temperature	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2373	Information	%5 has recovered from a reduced capacity state. Sensor Number: %2 Location: %3 %n Date: %1 ID Strings: %4	%5 has recovered from a reduced capacity state. Sensor Number: %2 Location: %3 %n Date: %1 ID Strings: %4	-	Green	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2374	Warning	%5 is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Yellow	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2375	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	CPU	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2376	Information	Recovered from internal CPU error. Date: %1 CPU Number:%2	Recovered from internal CPU error. Date: %1 CPU Number:%2	-	Green	CPU	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2377	Information	Recovered from CPU thermal trip. Date: %1 CPU Number:%2			Green	CPU	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2378	Warning	CPU configuration error occurred. Date: %1 CPU Number:%2	CPU configuration error occurred. Date: %1 CPU Number:%2	Please report to the System Administrator or Support Center.	Yellow	CPU	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2379	Information	Recovered from CPU configuration error. Date: %1 CPU Number:%2	Recovered from CPU configuration error. Date: %1 CPU Number:%2	-	Green	CPU	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2380	Information	Processor automatic throttle occurred. Date: %1 CPU Number:%2	Processor automatic throttle occurred. Date: %1 CPU Number:%2	-	Green	CPU	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2381	Information	Recovered from processor automatic throttle. Date: %1 CPU Number:%2	Recovered from processor automatic throttle. Date: %1 CPU Number:%2	-	Green	CPU	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2382	Warning	Power supply has lost the AC supply or been out-of-range. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power supply has lost the AC supply or been out-of-range. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Yellow	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2383	Warning	Memory has been non-redundant. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory has been non-redundant. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Yellow	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2384	Error	Unspecified system hardware failure occurred. Date: %1	Unspecified system hardware failure occurred. Date: %1	Please report to the maintenance member.	Red	Server Recovery	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2385	Error	Bus fatal error occurred. Date: %1	Bus fatal error occurred. Date: %1	Please report to the maintenance member.	Red	Bus	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2386	Information	Module/Board has been removed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Module/Board has been removed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2387	Information	Module/Board has been inserted. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Module/Board has been inserted. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2388	Information	Cable/Interconnect has been removed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cable/Interconnect has been removed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2389	Information	Cable/Interconnect has been inserted. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cable/Interconnect has been inserted. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2390	Error	%5 has fallen below the lower limit (Error). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%5 has fallen below the lower limit (Error). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Please report to the maintenance member.	Red	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2391	Information	Memory has recovered from a reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory has recovered from a reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2392	Warning	Memory has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Yellow	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2393	Error	Memory has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Red	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2394	Warning	Memory configuration error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory configuration error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2395	Warning	SEL is full. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	SEL is full. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Yellow	Server Recovery	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2396	Information	SEL is almost full. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	SEL is almost full. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Server Recovery	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2397	Information	Cable/interconnect has been connected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cable/interconnect has been connected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-		Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2398	Information	Cable/interconnect has been disconnected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cable/interconnect has been disconnected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2399	Warning	Cable/interconnect configuration error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cable/interconnect configuration error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2409	Error	Device has a drive fault. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Device has a drive fault. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Red	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2410	Information	Device has recovered from drive fault. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Device has recovered from drive fault. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2416	Information	Recovered from cable/interconnect configuration error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from cable/interconnect configuration error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2417	Warning	Battery has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Battery has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3

2418	Information	Battery has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Battery has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2419	Error	Battery has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Battery has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Red	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2420	Information	Battery has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Battery has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2421	Information	Recovered from timeout of watch dog timer. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from timeout of watch dog timer. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Server Recovery	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2422	Information	Recovered from reset event caused by the watch dog timer. Date: %1 Timeout Value: %2	Recovered from reset event caused by the watch dog timer. Date: %1 Timeout Value: %2	-	Green	Server Recovery	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2423	Information	Recovered from power down that occurred as time out of watch dog timer. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from power down that occurred as time out of watch dog timer. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Server Recovery	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2424	Information	Recovered from power cycle that occurred due to time out of watch dog timer. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from power cycle that occurred due to time out of watch dog timer. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Server Recovery	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2500	Error	The temperature has fallen below the lower threshold (Error). Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	The temperature has fallen below the lower threshold (Error). Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	Please check the air temperature.	Red	Temperature	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2501	Error	The temperature has exceeded the upper threshold (Error). Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	The temperature has exceeded the upper threshold (Error). Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	Please check the air temperature.	Red	Temperature	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2602	Error	MCA has occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	MCA has occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Machine Check Abort error has occurred. Please check the System Event Log and HW log for details, and replace the doubtful components.	Red	System Error	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2700	Error	Liquid Leak has happened. Location: %3 Sensor Number: %2 Date: %1	Liquid Leak has happened. Location: %3 Sensor Number: %2 Date: %1	Please report to the maintenance member.	Red	LiquidLeak	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2701	Information	Liquid Leak has recovered. Location: %3 Sensor Number: %2 Date: %1	Liquid Leak has recovered. Location: %3 Sensor Number: %2 Date: %1	-	Green	LiquidLeak	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2760	Error	The Memory Board has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The Memory Board has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member and exchange memoryboard.	Red	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2761	Information	The Memory Board has recoverd. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The Memory Board has recoverd. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2817	Information	%5 has recovered. Sensor Number:%2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered. Sensor Number:%2 Location: %3 Date: %1 ID Strings: %4	-	Green	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2818	Information	%5 has recovered. Sensor Number:%2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered. Sensor Number:%2 Location: %3 Date: %1 ID Strings: %4	-	Green	CPU	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2819	Warning	%5 has gone into a warning state. Sensor Number:%2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a warning state. Sensor Number:%2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	CPU	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2820	Error	CPU self-test error occurred. Date: %1 CPU Number:%2	CPU self-test error occurred. Date: %1 CPU Number:%2	Please report to the System Administrator or Support Center.	Red	CPU	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2821	Information	Recovered from CPU self-test error. Date: %1 CPU Number: %2	Recovered from CPU self-test error. Date: %1 CPU Number: %2	-	Green	CPU	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2822	Information	Recovered from Power On Self Test (POST) process stalled. Date: %1	Recovered from Power On Self Test (POST) process stalled. Date: %1	-	Green	CPU	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2823	Error	CPU initialization error occurred. Date: %1 CPU Number: %2	CPU initialization error occurred. Date: %1 CPU Number: %2	Please report to the System Administrator or Support Center.	Red	CPU	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2824	Information	Recovered from CPU initialization error. Date: %1 CPU Number: %2	Recovered from CPU initialization error. Date: %1 CPU Number: %2	-	Green	CPU	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2825	Information	Recovered from system error on the system buses. Date: %1 Bus ID: %2	Recovered from system error on the system buses. Date: %1 Bus ID: %2	-	Green	CPU	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2828	Information	Processor has been enabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Processor has been enabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	CPU	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2831	Information	Power unit is in D0 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit is in D0 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2832	Information	Power unit is not in D0 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit is not in D0 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2833	Information	Power unit is in D1 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit is in D1 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2834	Information	Power unit is not in D1 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit is not in D1 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2835	Information	Power unit is in D2 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit is in D2 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2836	Information	Power unit is in D3 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit is in D3 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2837	Information	Power unit has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2839	Information	Recovered from ECC uncorrectable error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from ECC uncorrectable error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2840	Error	Memory parity error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory parity error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2841	Warning	Memory scrub failed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory scrub failed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2842	Information	Memory has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2843	Information	Memory has been enabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory has been enabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2844	Warning	The limit on ECC correctable errors has been reached. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The limit on ECC correctable errors has been reached. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2845	Information	Recovered from ECC correctable errors. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from ECC correctable errors. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2850	Information	Memory automatic throttle occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory automatic throttle occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2851	Information	Recovered from Memory automatic throttle. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from Memory automatic throttle. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2852	Error	Memory temperature has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory temperature has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2853	Information	Memory temperature has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory temperature has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2854	Information	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2855	Warning	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2856	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please collect the trouble information with the collection tool and report to the System Administrator or Support Center.	Red	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2857	Information	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2858	Warning	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3

2859	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2860	Information	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2861	Warning	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2862	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2865	Information	Dynamic partitioning action is in progress. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Dynamic partitioning action is in progress. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2866	Information	Dynamic partitioning action has completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Dynamic partitioning action has completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2867	Warning	The communication between the cell and the boot cell failed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The communication between the cell and the boot cell failed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2869	Information	Cell was paused. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell was paused. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2871	Information	Cell is in use. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell is in use. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2872	Information	The cell entered an unused state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The cell entered an unused state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2873	Information	Cell firmware update is in progress. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell firmware update is in progress. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2874	Information	Cell firmware update has completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell firmware update has completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2875	Information	Cell diagnostic is being executed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell diagnostic is being executed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2877	Information	The partition composition is being changed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The partition composition is being changed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2878	Information	The change in the partition composition was completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The change in the partition composition was completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2879	Information	Cell/partition is stopped. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition is stopped. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2880	Information	Cell hardware is being initialized. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell hardware is being initialized. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2881	Information	Cell BIOS started initialization. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell BIOS started initialization. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2882	Information	Cell BIOS completed initialization. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell BIOS completed initialization. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2883	Information	Partition BIOS started initialization. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Partition BIOS started initialization. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2884	Information	Operating system is being started. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Operating system is being started. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2885	Information	Cell/partition is running. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition is running. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2886	Information	Cell/partition is being stopped. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition is being stopped. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2887	Information	Cell/partition has recovered from a reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition has recovered from a reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2888	Information	Cell/partition is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2889	Error	The cell is not able to be used in a partition. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The cell is not able to be used in a partition. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2890	Information	The validity of the cell is being verified. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The validity of the cell is being verified. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2892	Warning	The system serial number displayed for this cell is different than the system serial number displayed for other cells in the system. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The system serial number displayed for this cell is different than the system serial number displayed for other cells in the system. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2894	Information	Cell is not viable. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell is not viable. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2895	Information	Cell is viable as a non-boot cell in a partition. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell is viable as a non-boot cell in a partition. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2896	Information	Cell is viable as a boot cell in a partition. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell is viable as a boot cell in a partition. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2897	Information	Partition is not viable. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Partition is not viable. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2898	Information	Partition is viable. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Partition is viable. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2899	Information	Cell/partition has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2900	Warning	Cell/partition has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2901	Error	Cell/partition has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2902	Information	Cell/partition software has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition software has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2903	Warning	Cell/partition software has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition software has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3

2904	Error	Cell/partition software has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition software has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2909	Information	Partition has recovered from reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Partition has recovered from reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2910	Warning	Partition is running at a reduced capacity. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Partition is running at a reduced capacity. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2911	Warning	Partition redundancy degraded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Partition redundancy degraded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2912	Information	Memory mirroring has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory mirroring has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2913	Information	Memory mirroring has been enabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory mirroring has been enabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2914	Warning	Memory mirroring has been enabled, but Mem_Brd0 is broken. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory mirroring has been enabled, but Mem_Brd0 is broken. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3

2915	Warning	Memory mirroring has been enabled, but Mem_Brd1 is broken. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory mirroring has been enabled, but Mem_Brd1 is broken. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2928	Information	Power unit is not in D2 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit is not in D2 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2929	Information	Power unit is not in D3 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit is not in D3 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2930	Information	The communication between the cell and the boot cell has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The communication between the cell and the boot cell has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2931	Information	Cell has recovered from pause. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell has recovered from pause. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2932	Information	Cell diagnostic was completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell diagnostic was completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2933	Information	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2934	Warning	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2935	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2936	Error	Power On Self Test (POST) process stalled. Date: %1 Post Code: %2	Power On Self Test (POST) process stalled. Date: %1 Post Code: %2	Please report to the System Administrator or Support Center.	Red	CPU	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2937	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please collect the trouble information with the collection tool and report to the System Administrator or Support Center.	Red	Fan	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2938	Information	The abnormal power unit signal has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The abnormal power unit signal has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2940	Error	Power supply is in fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power supply is in fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The system is now operating with the spare power supply. Please inspect the primary power supply, which is malfunctioning.	Red	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2947	Warning	An abnormal power unit signal was detected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	An abnormal power unit signal was detected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please collect the trouble information with the collection tool and report to the System Administrator or Support Center.	Yellow	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3

2948	Information	Recovered from memory parity error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from memory parity error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2949	Information	Recovered from memory scrub error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from memory scrub error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2950	Information	Recovered from memory configuration error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from memory configuration error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2951	Information	Device has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Device has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2952	Information	Device has been enabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Device has been enabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2954	Warning	Power control has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power control has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2955	Information	Power control has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power control has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2956	Error	Fan module 0 is disabled, DC power is off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fan module 0 is disabled, DC power is off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4

2957	Warning	Fan module 0 is disabled, 2 minutes until power off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fan module 0 is disabled, 2 minutes until power off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2958	Warning	Loss of communication to power supply 0. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Loss of communication to power supply 0. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2959	Warning	CPU0 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	CPU0 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2960	Error	Reboot count has been exceeded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Reboot count has been exceeded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2961	Information	Boot has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Boot has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2962	Warning	PCI card has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	PCI card has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2963	Information	PCI card has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	PCI card has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2964	Error	PCI card has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	PCI card has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4

2965	Information	Partition completed hard reset. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Partition completed hard reset. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2966	Information	Partition completed power down. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Partition completed power down. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2967	Information	Dynamic partitioning is being initialized. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Dynamic partitioning is being initialized. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2968	Information	Dynamic partitioning has started. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Dynamic partitioning has started. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2969	Information	The cell has been used in a partition. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The cell has been used in a partition. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2970	Information	Dynamic partitioning has completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Dynamic partitioning has completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2971	Information	The validation of the cell is in progress. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The validation of the cell is in progress. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2972	Warning	The manufacturer ID displayed for this cell is different than the manufacturer ID displayed for other cells in the system. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The manufacturer ID displayed for this cell is different than the manufacturer ID displayed for other cells in the system. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2973	Error	The firmware level running on the Service Processor for this cell is different from the firmware level running on other cells in the system. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The firmware level running on the Service Processor for this cell is different from the firmware level running on other cells in the system. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2974	Error	The cells are missing. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The cells are missing. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2975	Information	Memory mirroring has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory mirroring has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2976	Warning	Memory mirroring configuration error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory mirroring configuration error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2977	Information	Power unit has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2978	Error	Fan module 1 is disabled, DC power is off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fan module 1 is disabled, DC power is off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4

2979	Warning	Fan module 1 is disabled, 2 minutes until power off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fan module 1 is disabled, 2 minutes until power off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2980	Warning	Loss of communication to power supply 1. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Loss of communication to power supply 1. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2981	Warning	CPU1 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	CPU1 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2982	Warning	CPU2 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	CPU2 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2983	Warning	CPU3 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	CPU3 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2984	Warning	PCI bus number or memory-mapped space resource allocation has been exceeded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	PCI bus number or memory-mapped space resource allocation has been exceeded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2985	Warning	IO space resource allocation has been exceeded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	IO space resource allocation has been exceeded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3

2986	Warning	PCI resource has been changed to a different type. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	PCI resource has been changed to a different type. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2987	Warning	Unable to execute OPROM. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Unable to execute OPROM. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2988	Information	Power unit has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2989	Information	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2990	Information	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Voltage	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2991	Error	Chipset thermal trip occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Chipset thermal trip occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Red	Notify	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
3008	Error	Memory utilization exceeds the upper threshold(Error).	Memory utilization exceeds the upper threshold(Error).	-	Red	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
3009	Warning	Memory utilization has recovered from its error state.	Memory utilization has recovered from its error state.	-	Yellow	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
3010	Warning	Memory utilization exceeds the upper threshold(Warning).	Memory utilization exceeds the upper threshold(Warning).	-	Yellow	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3

3011	Information	Memory utilization has recovered from its warning state.	Memory utilization has recovered from its warning state.	-	Green	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3012	Error	Page faults exceed the upper threshold(Error).	Page faults exceed the upper threshold(Error).	-	Red	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
3013	Warning	Page faults have recovered from their error state.	Page faults have recovered from their error state.	-	Yellow	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
3014	Warning	Page faults exceed the upper threshold(Warning).	Page faults exceed the upper threshold(Warning).	-	Yellow	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
3015	Information	Page faults have recovered from their warning state.	Page faults have recovered from their warning state.	-	Green	Memory	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
9000	Information	Modify system configuration info. Date: %1	-	-	-	-	-	-	-	-
9003	Error	Internal Error (HW Eventlog Monitoring Function) Error Code = %1 Function Name = %2 Library Name = %3 Function Address = %4	-	-	-	-	-	Because some error in ESMCommonService happene, there is a possibility that some monitored items can not be monitored. Reboot service. In case message is displayed, collect information by Collect.exe and contact system administrator.	-	-
9101	Error	Internal Error (Common Service) [%1 %2]	-	-	-	-	-	Because some error in ESMCommonService happene, there is a possibility that some monitored items can not be monitored. Reboot service. In case message is displayed, collect information by Collect.exe and contact system administrator.	-	-
9102	Error	Internal Error (Monitoring DLL) Error Code = %1 Library Name = %2 Function Name = %3	-	-	-	-	-	Because some error in ESMCommonService happene, there is a possibility that some monitored items can not be monitored. Reboot service. In case message is displayed, collect information by Collect.exe and contact system administrator.	-	-

9103	Error	Internal Error (Monitoring DLL's Thread) Error Code = %1 Error Address = %2	-	-	-	-	-	Because some error in ESMCommonService happene, there is a possibility that some monitored items can not be monitored. Reboot service. In case message is displayed, collect information by Collect.exe and contact system administrator.	-	-
9104	Error	Internal Error (Report Function DLL) Error Code = %1 EventLog Type = %2 Source Name = %3 Event ID = %4	-	-	-	-	-	Because some error in ESMCommonService happene, there is a possibility that some monitored items can not be monitored. Reboot service. In case message is displayed, collect information by Collect.exe and contact system administrator.	-	-
9005	Information	%1	-	-	-	-	-	Collect information by Collect.exe.	-	-

Event Source [ESMCpuPerf]

Event Viewer			AlertViewer				Destination (Default)	Others	SNMP Trap OID	
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Remarks	Enterprise ID	Specific ID
100	Error	CPU %1 load has exceeded the upper threshold(Error).	CPU total load factor has exceeded the upper threshold(Error).	-	Red	CPU	✓	System load becomes extremely high. Confirm whether it is appropriate.	.1.3.6.1.4.1.119.2.2.4.4.2.3	3
101	Warning	CPU %1 load factor has recovered from its error state.	CPU total load factor has recovered from its error state.	-	Yellow	CPU	✓	-	.1.3.6.1.4.1.119.2.2.4.4.2.3	4
102	Warning	CPU %1 load has exceeded the upper threshold(Warning).	CPU total load factor has exceeded the upper threshold(Warning).	-	Yellow	CPU	✓	System load becomes extremely high. Confirm whether it is appropriate.	.1.3.6.1.4.1.119.2.2.4.4.2.3	1
103	Information	CPU %1 load factor has recovered from its warning state.	CPU total load factor has recovered from its warning state.	-	Green	CPU	✓	-	.1.3.6.1.4.1.119.2.2.4.4.2.3	2
104	Error	CPU %1 load has exceeded the upper threshold(Error).	CPU %1 load factor has exceeded the upper threshold(Error).	-	Red	CPU	✓	System load becomes extremely high. Confirm whether it is appropriate.	.1.3.6.1.4.1.119.2.2.4.4.2.3	7
105	Warning	CPU %1 load factor has recovered from its error state.	CPU %1 load factor has recovered from its error state.	-	Yellow	CPU	✓	-	.1.3.6.1.4.1.119.2.2.4.4.2.3	8
106	Warning	CPU %1 load has exceeded the upper threshold(Warning).	CPU %1 load factor has exceeded the upper threshold(Warning).	-	Yellow	CPU	✓	System load becomes extremely high. Confirm whether it is appropriate.	.1.3.6.1.4.1.119.2.2.4.4.2.3	5
107	Information	CPU %1 load factor has recovered from its warning state.	CPU %1 load factor has recovered from its warning state.	-	Green	CPU	✓	-	.1.3.6.1.4.1.119.2.2.4.4.2.3	6

9000	Error	ESMCpuPerf Internal Error [%1]	-	-	-	-	-	Because some error in ESMCommonService happene, there is a possibility that some monitored items can not be monitored. Reboot service. In case message is displayed, collect information by Collect.exe and contact system administrator.	-	-
9001	Warning	ESMCpuPerf Invalid threshold Minimum Value [%1] Established Value [%2]	-	-	-	-	-	Confirm threshold of CPU loading factor.	-	-
9002	Warning	ESMCpuPerf Invalid threshold%n Maximum Value [%1] Established Value [%2]	-	-	-	-	-	Confirm threshold of CPU loading factor.	-	-
9003	Warning	ESMCpuPerf Invalid threshold Use Default Value	-	-	-	-	-	Confirm threshold of CPU loading factor.	-	-
9004	Warning	Warning condition was detected with ESMCpuPerf. [%1]	-	-	-	-	-	Collect information by Collect.exe.	-	-
9005	Information	%1	-	-	-	-	-	Collect information by Collect.exe.	-	-

Event Source [ESMLocalPolling]

Event Viewer			AlertViewer				Destination (Default)	Others	SNMP Trap OID	
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Remarks	Enterprise ID	Specific ID
110	Error	Polling Data has exceeded the upper fatal Limit Polling ID [%1] OID [%2] OID Data [%3] Threshold [%4]	The Polling Data has exceeded the upper fatal limit. OID:%2 Value:%3	-	Red	User Defined	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.19.3	11
111	Warning	Polling Data has fallen below the upper fatal limit Polling ID [%1] OID [%2] OID Data [%3] Threshold [%4]	The Polling Data has fallen below the upper fatal limit. OID:%2 Value:%3	-	Yellow	User Defined	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.19.3	12
112	Warning	Polling Data has exceeded the upper warning limit Polling ID [%1] OID [%2] OID Data [%3] Threshold [%4]	The Polling Data has exceeded the upper warning limit. OID:%2 Value:%3	-	Yellow	User Defined	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.19.3	9
113	Information	Polling Data has fallen below the upper warning limit Polling ID [%1] OID [%2] OID Data [%3] Threshold [%4]	The Polling Data has fallen below the upper warning limit. OID:%2 Value:%3	-	Green	User Defined	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.19.3	10
114	Error	Polling Data has fallen below the lower fatal limit Polling ID [%1] OID [%2] OID Data [%3] Threshold [%4]	The Polling Data has fallen below the lower fatal limit. OID:%2 Value:%3	-	Red	User Defined	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.19.3	16
115	Warning	Polling Data has exceeded the lower fatal limit Polling ID [%1] OID [%2] OID Data [%3] Threshold [%4]	The Polling Data has exceeded the lower fatal limit. OID:%2 Value:%3	-	Yellow	User Defined	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.19.3	15

116	Warning	Polling Data has fallen below the lower warning limit Polling ID [%1] OID [%2] OID Data [%3] Threshold [%4]	The Polling Data has fallen below the lower warning limit. OID:%2 Value:%3	-	Yellow	User Defined	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.19.3	14
117	Information	Polling Data has exceeded the lower warning limit Polling ID [%1] OID [%2] OID Data [%3] Threshold [%4]	The Polling Data has exceeded the lower warning limit. OID:%2 Value:%3	-	Green	User Defined	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.19.3	13
900	Error	ESMLocalPolling Internal Error [%1]	-	-	-	-	-	Confirm that SNMP service is normally operating. In case it operates, confirm whether or not there is a problem with setting of SNMP and local polling.	-	-
901	Error	Polling Threshold Value Error. Polling ID [%1] Threshold [%2]	-	-	-	-	-	Confirm threshold of local polling.	-	-

ESMSystemManagementService

This service is the one for monitoring of ESRAS-related failure.

In case alert about this service occurred, confirm whether selection of models for NEC ESMPRO Agent is not mistaken.

Event Viewer			AlertViewer				Destination (Default)	Others	SNMP Trap OID	
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Remarks	Enterprise ID	Specific ID
9101	Error	Internal Error (System Management Service) [%1 %2]	-	-	-	-	-	Because some error in ESMSystemManagementService happened, service could not be started. In case the same message is displayed, collect information by Collect.exe and contact system administrator.	-	-
9104	Error	Internal Error (Report Function DLL) Error Code = %1 EventLog Type = %2 Source Name = %3 Event ID = %4	-	-	-	-	-	Because some error in ESMSystemManagementService happened, alert could not be processed. Reboot service. In case the same message is displayed, collect information by Collect.exe and contact system administrator.	-	-

ESMLANService

This service monitors load and failure of network line.

In case alert about this service occurred, confirm around network line.

Event Viewer			AlertViewer				Destination (Default)	Others	SNMP Trap OID	
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Remarks	Enterprise ID	Specific ID
301	Warning	A Network Hardware failure may have occurred. Device: %1 Error No.: %2,%3,%4 Alignment Errors = %5 FCS Errors = %6 Carrier Sense Errors = %7	There is a possibility of Network hardware trouble. Device Name: %1 Error Type: %2	Please check that the network cables are tightly connected and that the HUB power switch is on.	Yellow	Network	✓	Confirm whether network cable is plugged off or power of HUB is on. Because there is a possibility that there is some failure on line, confirm network environment. Alert sends by warning for ESMPRO/SA Ver3.8 and the succeeding versions and by abnormal before Ver3.7.	.1.3.6.1.4.1.119.2.2.4 .4.13.3	1
302	Warning	Network is under heavy load. Device: %1 Error No.: %2,%3 Total Transmitted Packets = %4 Late Collisions = %5 Single-Collisions = %6 Multiple-Collisions = %7 Delayed Frames = %8 Excess Collisions = %9 MAC transmitted Errors = %10	The Network is under heavy load. Device Name: %1 Error Type: %2	Heavy network traffic to this server was detected. Please attempt to reduce the network traffic to this server.	Yellow	Network	✓	Lighten access to server and alleviate the load.	.1.3.6.1.4.1.119.2.2.4 .4.13.3	2
303	Warning	Possible transmit and receive errors detected. Total Received Packets = %1 Disposed Received Packets = %2 Total Transmitted Packets = %3 Disposed Transmitted Packets = %4	There is a possibility that this server is short of network transmission and receiving buffer.	A high load of networking is detected. Please reduce the net access on the server.	Yellow	Network	✓	Lighten access to server and alleviate the load.	.1.3.6.1.4.1.119.2.2.4 .4.13.3	3
305	Information	Network error conditions were recovered. Device: %1 EventID: %2,%3,%4	Network condition has recovered from the following trouble. Device Name: %1 Error Category: %2	-	Green	Network	✓	Status of line is restored to normal status.	.1.3.6.1.4.1.119.2.2.4 .4.13.3	4
399	Information	%1	-	-	-	-	-	In case character string of "Memory allocation failed." for %1 is displayed, confirm status of free area of memory. In case "SNMP Service is not started." or "SNMP Service does not accept a request." is displayed, confirm operating status of SNMP service.	-	-

301	Error	A Network Hardware failure may have occurred. Device: %1 Error No.: %2,%3,%4 Alignment Errors = %5 FCS Errors =%6 Carrier Sense Errors = %7	There is a possibility of Network hardware trouble. Device Name: %1 Error Type: %2	Please check that the network cables are tightly connected and that the HUB power switch is on.	Red	Network	✓	Confirm whether network cable is plugged off or power of HUB is on. Because there is a possibility that there is some failure on line, confirm network environment. Alert sends by warning for ESM/PRO/SA Ver3.8 and the succeeding versions and by abnormal before Ver3.7.	.1.3.6.1.4.1.119.2.2.4 .4.13.3	1
-----	-------	--	--	---	-----	---------	---	---	-----------------------------------	---

ESRAS Utility Service

This service is to collect information displayed by ESRAS utility.

In case alert about this service occurred, confirm whether selection of models for NEC ESMPRO Agent is not mistaken.

Source name of Eventlog is registered as "ESRAS_Utl".

Event Viewer			AlertViewer				Destination (Default)	Others	SNMP Trap OID	
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Remarks	Enterprise ID	Specific ID
1000	Error	The ESRAS Utility Service failed to open the NVRAM.	-	-	-	-	-	-	-	-
1001	Error	Could not read from NVRAM.	-	-	-	-	-	-	-	-
1002	Error	Could not write to NVRAM.	-	-	-	-	-	-	-	-
1003	Error	Service internal processing error.	-	-	-	-	-	-	-	-
1004	Error	ervice internal processing error.	-	-	-	-	-	-	-	-
1005	Error	Service internal processing error.	-	-	-	-	-	-	-	-
1006	Error	Service internal fatal error.	-	-	-	-	-	-	-	-
1007	Error	Service internal processing error.	-	-	-	-	-	-	-	-
1008	Error	Service internal fatal error.	-	-	-	-	-	-	-	-
1011	Error	Could not initialize by IO control.	-	-	-	-	-	-	-	-

ESMAgentDMIService

This service is to collect information by DMI.

Event Viewer			AlertViewer				Destination (Default)	Others
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Remarks
8003	Warning	ESMAgentDMIService Internal Error. Address = %1 Code = %2 Detail1 = %3 Detail2 = %4	-	-	-	-	-	Reboot "ESMAgentDMIService" in "Service" of "Control Panel".
8004	Warning	ESMAgentDMIService tempthmo.dmm Error. Address = %1	-	-	-	-	-	In case you do not change threshold of temeparature, there is no problem. In case you want to change the threshold of temperature, reboot "ESMAgentDMIService" in "Service" of "Control Panel" and change it.
8005	Warning	ESMAgentDMIService DMM Internal Error. Dmm = %1 Address = %2 Code = %3 Detail1 = %4 Detail2 = %5	-	-	-	-	-	Confirm whether RAS information (temperature/power supply/power voltage/fan) is normal on DataView.

AlertManagerMainService

This service is to alert failure.

In case event about this service occurred, confirm around alert.

Event Viewer			AlertViewer				Destination (Default)	Others	SNMP Trap OID	
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Remarks	Enterprise ID	Specific ID
100	Information	Event Source Name: %3%n Event ID:(%4) %5%n Time: %6 %n %n AlertManager succeeded in reporting with the method of "%1".%n %2%n	-	-	-	-	-	The alert that failed to report has been reported again and the reporting succeeded at last.	-	-
101	Information	Event Source Name: %3%n Event ID:(%4) %5%n Time: %6 %n %n AlertManager failed in reporting with the method of "%1".%n %2%n	-	-	-	-	-	There is a possibility that there is a problem in the setting of the reporting method. Please check the "Base Setting" and the "Destination Setting" of the reporting method.	-	-
102	Information	Event Source Name: %3%n Event ID:(%4) %5%n Time: %6 %n %n AlertManager failed in reporting with the method of "%1". It will retry.%n %2%n	-	-	-	-	-	The alert reporting failed and will be tried to send again and again until success. You can click the "Schedule" button on the reporting "Destination ID" dialog to change the "Retry Interval" .	-	-
103	Warning	Event Source Name: %3%n Event ID:(%4) %5%n Time: %6 %n %n The alert request was removed because it couldn't be sent successfully within the retry time limit.%n %2%n	-	-	-	-	-	The alert reporting failed repeatedly, and the "Whole Retry Time" has elapsed. This alert reporting was abandoned. There is a possibility that there is a problem in the setting of the reporting method. Please check the "Base Setting" and the "Destination Setting" of the reporting method.	-	-
104	Error	Summary: %1%n Time: %2 %n %n The alert request was removed because it couldn't be sent successfully within the retry time limit.%n %3%n	-	-	-	-	-	Error happened in service. Collect information by Collect(m).exe.	-	-

800	Error	Fatal error occurred at watching %1 eventlog.%n %2%n	-	-	-	-	-	Error happened in service. Collect information by Collect(m).exe.	-	-
801	Error	Error occurred at watching %1 eventlog.%n %2%n	-	-	-	-	-	Error happened in service. Collect information by Collect(m).exe.	-	-
900	Error	Fatal error occurred.%n %1%n	-	-	-	-	-	Error happened in service. Collect information by Collect(m).exe.	-	-
901	Error	AlertManager failed to execute the following module.%n Module name: %1%n	-	-	-	-	-	Collect information by Collect(m).exe.	-	-
802	Information	The past event was detected. There is the possibility of the following cause.%n - System time was changed into the past time from the time of the future.%n - A shutdown was not normal.%n - Event log was corrupt.%n .	The past event was detected. There is the possibility of the following cause. - System time was changed into the past time from the time of the future. - A shutdown was not normal. - Event log was corrupt.	1.When System Time is changed, Please set 0 as all value of '{log name }Time' key shown below. HKEY_LOCAL_MACHINE\SOFTWARE\NEC\ESMAlertMan\AMMNEV 2. When a shutdown is automatic, you need to increase the value of a timer. 3. Please clear the corrupted log and reboot AlertManagerMainService.	Green	Service	✓		1.3.6.1.4.1.119.2.2.4.4.18.3	1
803	Error	Failure of read of event log. It stops watching %1 log. The following code is error information.(%2)%n .	Failure of read of event log. It stops watching %1 log. The following code is error information.(%2)	-	Red	Service	✓	Error happened in service. Collect information by Collect(m).exe.	1.3.6.1.4.1.119.2.2.4.4.18.3	1
1000	Information	This server is shutting down or rebooting in %1 second(s).%n .	This server is shutting down or rebooting in %1 second(s).	-	Green	Server Recovery	✓	shutting down or rebooting has happened.	1.3.6.1.4.1.119.2.2.4.4.18.3	1
1001	Information	The request of shutting down or rebooting was canceled by user.%n .	The request of shutting down or rebooting was canceled by user.	-	Green	Server Recovery	✓	shutting down or rebooting has happened,but it was canceled by user.	1.3.6.1.4.1.119.2.2.4.4.18.3	1
1100	Error	Critical error occurred while subscribing to channel %1. It stops watching the channel. %nErrorCode = %2%n	Critical error occurred while subscribing to channel %1. It stops watching the channel. %nErrorCode = %2%n	-	Red	Service	✓	Error happened in service. Collect information by Collect(m).exe.	1.3.6.1.4.1.119.2.2.4.4.18.3	1

1101	Warning	Error occurred while subscribing to channel %1. It stops watching the channel temporarily. %nErrorCode = %2%n	Error occurred while subscribing to channel %1. It stops watching the channel temporarily. %nErrorCode = %2%n	-	Yellow	Service	✓	Error happened in service. Collect information by Collect(m).exe.	1.3.6.1.4.1.119.2.2.4.4.18.3	1
1102	Information	Subscribing to channel %1 succeeded. It starts watching the channel.%n	Subscribing to channel %1 succeeded. It starts watching the channel.%n	-	Green	Service	✓		1.3.6.1.4.1.119.2.2.4.4.18.3	1

AlertManager ReportTableUpdater

This service is to update alert table.

In case alert about this service occurred, confirm status of installation of related products.

In the case of less than 4.09 of the version of the alert manager, these events occur.

In the case of more than 4.09 of the version of the alert manager, these events do not occur.

1. Click on the NEC ESMPRO Agent icon in the Control Panel and select Report Settings in the General sheet.
2. Click on the [Help]-[About Alert Mangaer] in the Alert Manager.
3. Check Alert Manager Version.

Event Viewer			AlertViewer				Destination (Default)	Others
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Remarks
0	Information	Add monitoring events.%n Product name : %1 %n	-	-	-	-	-	None
1	Information	Finish adding monitoring events.%n Product name : %1 %n	-	-	-	-	-	None
2	Information	Update monitoring events.%n Product name : %1 %n	-	-	-	-	-	None
3	Information	Finish updating monitoring events.%n Product name : %1 %n	-	-	-	-	-	None
4	Information	Remove monitoring events.%n Product name : %1 %n	-	-	-	-	-	None
5	Information	Finish removing monitoring events.%n Product name : %1 %n	-	-	-	-	-	None
6	Information	Re-adding compatible monitoring events.%n %n	-	-	-	-	-	None
7	Information	Finish re-adding compatible monitoring events.%n %n	-	-	-	-	-	None

AlertManagerALIVESendService

This service is to send ALIVE alert.

In case alert about this service occurred, confirm around modem and SMB.

Event Viewer			AlertViewer				Destination (Default)	Others
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Remarks
401	Information	Service started.	-	-	-	-	-	
402	Information	Service stopped.	-	-	-	-	-	
403	Information	Service paused.	-	-	-	-	-	
404	Information	ALIVE Service continued.	-	-	-	-	-	
405	Error	Alert Manager failed to send the following event with the SMB Board.%n %n To : %6 %n [report] %n DATE : %1 Time : %2 Computer : %3 %n Source : %4 EventID : %5 %n	-	-	-	-	-	Collect information by Collect(m).exe.
406	Information	It reported successfully.%n %n To : %6 %n [report] %n DATE : %1 Time : %2 Computer : %3 %n Source : %4 EventID : %5 %n	-	-	-	-	-	
407	Error	Serial port is busy. %n %n %1%n	-	-	-	-	-	Collect information by Collect(m).exe.
408	Error	Telephone line is busy. %n %n %1%n	-	-	-	-	-	Collect information by Collect(m).exe.

409	Error	The message transmitted by SMB has not been acknowledged by the receiver of the message. %n %1%n	-	-	-	-	-	Collect information by Collect(m).exe.
410	Error	Telephone line was cut off.%n %n %1%n	-	-	-	-	-	Collect information by Collect(m).exe.
411	Error	It couldn't communicate with the modem.%n %n %1%n	-	-	-	-	-	Collect information by Collect(m).exe.
412	Error	An error occurred in the registry access.%n %n %1%n	-	-	-	-	-	Collect information by Collect(m).exe.
413	Error	An error occurred in the service control.%n %n %1%n	-	-	-	-	-	Collect information by Collect(m).exe.
414	Information	Remote Access Service was started.%n	-	-	-	-	-	
415	Information	Remote Access Service was stopped.	-	-	-	-	-	
416	Error	Specified DLL wasn't found. %n %1%n	-	-	-	-	-	Collect information by Collect(m).exe.
417	Error	Alert Manager failed to report.%n %n %1%n	-	-	-	-	-	Collect information by Collect(m).exe.
418	Error	Alert Manager failed to send an alert because the Socket Send Service has not started.%n	-	-	-	-	-	Collect information by Collect(m).exe.
419	Warning	It failed to acquire the data inside the queue.	-	-	-	-	-	Collect information by Collect(m).exe.
420	Warning	Could not set the device control block.	-	-	-	-	-	Collect information by Collect(m).exe.
421	Warning	Could not initialize the modem.	-	-	-	-	-	Collect information by Collect(m).exe.
422	Warning	An error occurred during the message communication.	-	-	-	-	-	Collect information by Collect(m).exe.

423	Warning	A retry error occurred while trying to get the result of test report.	-	-	-	-	-	Collect information by Collect(m).exe.
424	Warning	An error occurred while trying to get the result of test report.	-	-	-	-	-	Collect information by Collect(m).exe.
425	Warning	It wasn't connected with the destination of the test report.	-	-	-	-	-	Collect information by Collect(m).exe.
426	Warning	A line error occurred during test report and then it could not connect with the destination again.	-	-	-	-	-	Collect information by Collect(m).exe.
427	Warning	The setting of the automatic report is wrong in the report test.	-	-	-	-	-	Collect information by Collect(m).exe.
428	Warning	A time out or a line cutting was detected in the report test.	-	-	-	-	-	Collect information by Collect(m).exe.
429	Warning	he parity error occurred in the report test.	-	-	-	-	-	Collect information by Collect(m).exe.
430	Warning	The overrun error occurred in the report test.	-	-	-	-	-	Collect information by Collect(m).exe.
501	Error	The following event couldn't be transmitted with the Socket Send Service.%n %n %1%n	-	-	-	-	-	Collect information by Collect(m).exe.
502	Information	It failed to control of Remote Access Server.%n %n %1%n	-	-	-	-	-	Collect information by Collect(m).exe.
503	Error	A WinSock error occurred in the service.%n %n %1%n	-	-	-	-	-	Collect information by Collect(m).exe.
9401	Error	A fatal error occurred in the service specified with the event source name.%n %n %1%n	-	-	-	-	-	Collect information by Collect(m).exe.
9403	Error	An error occurred in the service specified with the event source name.%n %n %1%n	-	-	-	-	-	Collect information by Collect(m).exe.

mainte/necras

This driver collects various model-specific information from sensor, register BIOS and others on hardware.

This driver depends on equipment to be installed.

In case warning/abnormal Eventlog from this driver was displayed, confirm the followings:

-whether selection of models for ESM/ServerAgent is not mistaken.

-whether setting of BIOS Setup is not mistaken /whether BMC-FW is normally operating.

Event Viewer			AlertViewer				Destination (Default)	Others
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Remarks
1	Error	IPMI driver can not get a required resource (%2).	-	-	-	-	-	Collect information by Collect.exe.
2	Error	IPMI driver can not found SMBIOS structures.	-	-	-	-	-	Collect information by Collect.exe.
3	Error	It is possible that you missed a selection at ESM setup.	-	-	-	-	-	Collect information by Collect.exe.
7	Error	IPMI driver detected a serious error at setup phase. Cause = (%2)	-	-	-	-	-	Collect information by Collect.exe. There is a possibility that you have to replace device.
8	Error	IPMI driver detected an internal error. Cause = (%2)	-	-	-	-	-	Collect information by Collect.exe.
10	Error	Requested data exceeds a max length. Command = (%2) Data length = (%3)	-	-	-	-	-	Collect information by Collect.exe.
11	Error	Response data exceeds a max length.	-	-	-	-	-	Collect information by Collect.exe.
12	Warning	IPMI Driver can not access FRU device.	-	-	-	-	-	Collect information by Collect.exe.
16	Error	IPMI driver detected a serious error of BMC. Completion Code = (%2) Parameter1 = (%3) Parameter2 = (%4)	-	-	-	-	-	Collect information by Collect.exe. There is a possibility that you have to replace device.

18	Warning	An IPMI command error occurred at driver setup phase. Cause = (%2)	-	-	-	-	-	Collect information by Collect.exe. There is a possibility that you have to replace device.
19	Warning	IPMI driver detected a warning error of BMC. Cause = (%2) Parameter1 = (%3) Parameter2 = (%4)	-	-	-	-	-	Collect information by Collect.exe. There is a possibility that you have to replace device.
20	Information	IPMI Driver changed the interrupt-mode to polling-mode.	-	-	-	-	-	Collect information by Collect.exe.

Event Viewer			AlertViewer				Destination (Default)	Others
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Remarks
4098	Error	ESRAS driver failed an exclusion of NVRAM area. Reboot system for safety. Or it is possible that you missed a selection at ESM setup.	-	-	-	-	-	Collect information by Collect.exe.
4099	Warning	ESRAS driver found an illegal RecordType in SMI-LOG area. SMI-LOG area is formatted by force.	-	-	-	-	-	Collect information by Collect.exe.
4100	Error	Registry values for WDT controls are illegal values.	-	-	-	-	-	Collect information by Collect.exe.
4101	Error	ESRAS driver failed to format SMI-LOG area. Please reboot system for safety.	-	-	-	-	-	Collect information by Collect.exe.
4102	Error	ESRAS driver failed to allocate free spaces when formatting. Please reboot system for safety.	-	-	-	-	-	Collect information by Collect.exe.
4103	Information	ESRAS driver formatted SMI-LOG area because used area reached 70%.	-	-	-	-	-	Collect information by Collect.exe.

4104	Information	ESRAS driver formatted SMI-LOG area by force because used area reached 90%.	-	-	-	-	-	Collect information by Collect.exe.
4106	Error	ESRAS driver found an illegal Read Pointer in SMI-LOG Header. SMI-LOG handling abort.	-	-	-	-	-	Collect information by Collect.exe.
4107	Error	ESRAS driver found an illegal Write Pointer in SMI-LOG Header. SMI-LOG handling abort.	-	-	-	-	-	Collect information by Collect.exe.
4108	Error	It is possible that you missed a selection at ESM setup.	-	-	-	-	-	Collect information by Collect.exe.
4110	Error	ESRAS driver detected an error on accessing hardware devices.	-	-	-	-	-	Collect information by Collect.exe.
4111	Error	ESRAS driver can not find OEM-STRINGS structures. It is possible that you missed a selection at ESM setup.	-	-	-	-	-	Collect information by Collect.exe.
4114	Information	ESRAS driver detected a recovery on accessing hardware devices.	-	-	-	-	-	Collect information by Collect.exe.
4117	Information	ESRAS driver detected a recovery on accessing hardware devices.	-	-	-	-	-	Collect information by Collect.exe.
4119	Warning	ESRAS Driver failed SMBus access. Access = (%2) SlaveAddress = (%3) Offset = (%4) Code = (%5)	-	-	-	-	-	Collect information by Collect.exe.
4122	Error	NECRAS driver do not support this model. Please check the installation model.	-	-	-	-	-	Collect information by Collect.exe.

4123	Error	ESRAS driver detected Host Busy.	-	-	-	-	-	Collect information by Collect.exe.
------	-------	----------------------------------	---	---	---	---	---	-------------------------------------