

## ESMFSService

This service monitors configuration and free space of file system.  
In case alert about this service occurred, confirm the free space of file system.

Event Viewer				AlertViewer				Destination(Default)		Others	SNMP Trap OID		
Event ID	Event ID(Hex)	Type	Description	Summary(TrapName)	Detail	Action	Status Color	Type	Manager	Express	Remarks	Enterprise ID	Specific ID
1000	C00403E8	Error	The free capacity of this file system is less than "Fatal" level. File System : %1 (Index %2) Free Space / Capacity : %3 / %4 MB Threshold(Fatal) : %5 MB	File system free capacity:Fatal	The free capacity of this file system is less than "Fatal" level. File System : %1 (Index %2) Free Space / Capacity : %3 / %4 MB Threshold(Fatal) : %5 MB	You should remove unnecessary directories and files on this drive. If there are no unnecessary files then you should add a new drive and move several files to it. If the threshold value was not appropriate, please change it.	Red	File System	✓	-	Make free space by deleting unnecessary file and others or by moving file to another file system. In case the threshold is not suitable for free space monitoring of file system, change the threshold to the value most suitable to the used system.	.1.3.6.1.4.1 .119.2.2.4. 4.18.3	4
1001	800403E9	Warning	The free capacity of this file system is less than "Warning" level. File System : %1 (Index %2) Free Space / Capacity : %3 / %4 MB Threshold(Warning) : %5 MB	File system free capacity:Warning	The free capacity of this file system is less than "Warning" level. File System : %1 (Index %2) Free Space / Capacity : %3 / %4 MB Threshold(Warning) : %5 MB	This drive's free block amount may be at a fatal level. You should delete unnecessary directories and files on this drive. If threshold value was not appropriate, please change it.	Yellow	File System	✓	-	Make free space by deleting unnecessary file and others or by moving file to another file system. In case the threshold is not suitable for free space monitoring of file system, change the threshold to the value most suitable to the used system.	.1.3.6.1.4.1 .119.2.2.4. 4.18.3	3
1002	400403EA	Information	The free capacity comes back "Normal" level. File System : %1 (Index %2) Free Space / Capacity : %3 / %4 MB	File system free capacity:Normal	The free capacity comes back "Normal" level. File System : %1 (Index %2) Free Space / Capacity : %3 / %4 MB	-	Green	File System	✓	-	-	.1.3.6.1.4.1 .119.2.2.4. 4.18.3	2
8201	C0042009	Error	An internal fatal error of the ESMFSService has occurred. Error Code:(%1, %2, %3)	-	-	-	-	-	-	-	-	-	-
8202	4004200A	Information	An internal informational of the ESMFSService has occurred. Code:(%1, %2, %3)	-	-	-	-	-	-	-	-	-	-
8203	8004200B	Warning	An internal warning error of ESMFSService has occurred(Service setting). Error Code:(%1, %2, %3)	-	-	-	-	-	-	-	-	-	-

## ESMStorageService

This service monitors configuration and status of storage-related devices.

In case alert about this service occurred, confirm the storage-related device.

[Caution] The service name of this service differs from the displayed name. The service name is 「ESMStorageService」, while the displayed name is 「ESM\_Storage\_Service」(" " is one space character)

Event Viewer				AlertViewer					Destination(Default)		Others	SNMP Trap OID	
Event ID	Event ID(Hex)	Type	Description	Summary(TrapName)	Detail	Action	Status Color	Type	Manager	Express	Remarks	Enterprise ID	Specific ID
1000	800403E8	Warning	The total count of errors on the hard disk exceeds the threshold value. %1 %2 %3 : %4 (Threshold %5)	Hard Disk Failure Prediction:Exceed Threshold	The total count of errors on the hard disk exceeds the threshold value. %1 %2 %3 : %4 (Threshold %5)	The total count of errors on the hard disk exceeds the threshold value. Contact your hardware vendor for a replacement.	Yellow	Storage HD Unit	✓	✓	Number of occurrences of hard disk error exceeded threshold. As continuous use of this hard disk is risky from the viewpoint of preventive maintenance, contact maintenancance staff to replace the hard disk. After the replacement, make sure to reset.	.1.3.6.1.4.1.119.2.2.4.4.18.3	3
1001	800403E9	Warning	S.M.A.R.T. predicts that your hard disk is going to fail. %1 %2	Hard Disk Failure Prediction:S.M.A.R.T. Error	S.M.A.R.T. predicts that your hard disk is going to fail. %1 %2	S.M.A.R.T. predicts that your hard disk is going to fail. Contact your hardware vendor for a replacement.	Yellow	Storage HD Unit	✓	✓	Error was detected by hard disk pre-failure predicton using S.M.A.R.T. function of hard disk. As continuous use of this hard disk is risky from the viewpoint of preventive maintenance, contact maintenancance staff to replace the hard disk. After the replacement, make sure to reset.	.1.3.6.1.4.1.119.2.2.4.4.18.3	3
9201	C00423F1	Error	An internal fatal error of the ESM Storage Service has occurred. Error Code : (%1, %2, %3)	-	-	-	-	-	-	-	-	-	-
9202	800423F2	Warning	An internal informational of the ESM Storage Service has occurred. Error Code : (%1, %2, %3)	-	-	-	-	-	-	-	-	-	-
9204	800423F4	Warning	Failed to reset the hard disk. Please restart the ESM Storage Service and reset the hard disk again. Error Code : (%1, %2, %3)	-	-	-	-	-	-	-	-	-	-
9205	800423F5	Warning	Failed to get the Pre-failure Prediction function setting. It does not works.	-	-	-	-	-	-	-	-	-	-
9206	800423F6	Warning	An internal warning error of the ESM Storage Service has occurred(Service setting). Error Code : (%1, %2, %3)	-	-	-	-	-	-	-	-	-	-

# ESMDiskArray

This service monitors configuration and status of disk array controller of the object which NEC ESMDiskArray function watches.  
In case alert about this service occurred, confirm monitored disk array-related items of ESMPRO disk array monitoring.

Event Viewer				AlertViewer					Destination(Default)		Others	SNMP Trap OID	
Event ID	Event ID(Hex)	Type	Description	Summary(TrapName)	Detail	Action	Status Color	Type	Manager	Express	Remarks	Enterprise ID	Specific ID
1000	400403E8	Information	Logical Device changed to %1. Disk Array: %2 Logical Device ID: %3	Disk Array Logical Device Online	Logical Device changed to %1. Disk Array: %2 Logical Device ID: %3	-	Green	Disk Array Logical Device	✓	-	For %1, set "Online". In case there is vendor-specific expression, set creating character string like "Online(xxxx)". For %2, set controller name logical device is configured. For %3, set ID of logical device.	.1.3.6.1.4.1.119.2.2.4.4.18.3	2
1001	800403E9	Warning		Disk Array Logical Device Critical		Replace the failed Physical Device.	Yellow	Disk Array Logical Device	✓	✓	For %1, set "Critical". In case there is vendor-specific expression, set creating character string like "Critical(xxxx)". For %2, set controller name logical device is configured. For %3, set ID of logical device.	.1.3.6.1.4.1.119.2.2.4.4.18.3	3
1002	C00403EA	Error		Disk Array Logical Device Offline		Replace the failed Physical Device and reconstruct the Logical Device.	Red	Disk Array Logical Device	✓	✓	For %1, set "Offline". In case there is vendor-specific expression, set creating character string like "Offline(xxxx)". For %2, set controller name logical device is configured. For %3, set ID of logical device.	.1.3.6.1.4.1.119.2.2.4.4.18.3	4
1003	400403EB	Information		Disk Array Logical Device Consistency Check		-	Green	Disk Array Logical Device	✓	-	For %1, set "Consistency Check". In case there is vendor-specific expression, set creating character string like "Consistency Check(xxxx)". For %2, set controller name logical device is configured. For %3, set ID of logical device.	.1.3.6.1.4.1.119.2.2.4.4.18.3	2
1004	C00403EC	Error	Logical Device might change to Offline. Disk Array: %1 Logical Device ID: %2	Disk Array Logical Device Offline	Logical Device might change to Offline. Disk Array: %1 Logical Device ID: %2	Check the utility for this disk array, eventlog or hardware. If this Logical Device has some trouble, replace the failed Physical Device and reconstruct the Logical Device.	Red	Disk Array Logical Device	✓	✓	For %1, set controller name logical device is configured. For %2, set ID of logical device.	.1.3.6.1.4.1.119.2.2.4.4.18.3	4
1010	400403F2	Information	Physical Device changed to %1. Disk Array: %2 Disk ID: %3 Model: %4	Disk Array Physical Device Online	Physical Device changed to %1. Disk Array: %2 Disk ID: %3 Model: %4	-	Green	Disk Array Physical Device	✓	-	For %1, set "Online". In case there is vendor-specific expression, set creating character string like "Offline(xxxx)". For %2, set controller name logical device is configured. For %3, set ID of logical device. For %4, set model of physical device.	.1.3.6.1.4.1.119.2.2.4.4.18.3	2

1011	C00403F3	Error		Disk Array Physical Device Dead		Replace this Physical Device.	Red	Disk Array Physical Device	✓	✓	For %1, set "Dead". In case there is vendor-specific expression, set creating character string like "Dead(xxxx)". For %2, set controller name logical device is configured. %For %3, set ID of logical device. For %4, set model of physical device.	.1.3.6.1.4. 1.119.2.2.4 .4.18.3	4
1012	400403F4	Information		Disk Array Physical Device Rebuild		-	Green	Disk Array Physical Device	✓	-	For %1, set "Rebuild". In case there is vendor-specific expression, set creating character string like "Rebuild(xxxx)". For %2, set controller name to which physical device is connected. For %3, set ID of logical device. For %4, set model of physical device.	.1.3.6.1.4. 1.119.2.2.4 .4.18.3	2
1013	400403F5	Information		Disk Array Physical Device Hot Spare		-	Green	Disk Array Physical Device	✓	-	For %1, set "Hot Spare", or in case expression depends on vendor, set creating character string like "Hot Spare(XXXX)". For %2, set controller name to which physical device is connected. For %3, set ID of logical device. For %4, set model of physical device.	.1.3.6.1.4. 1.119.2.2.4 .4.18.3	2
1014	400403F6	Information		Disk Array Physical Device Ready		-	Green	Disk Array Physical Device	✓	-	For %1, set "Ready". In case there is vendor-specific expression, set creating character string like "Ready(xxxx)". For %2, set controller name logical device is configured. For %3, set ID of logical device. For %4, set model of physical device.	.1.3.6.1.4. 1.119.2.2.4 .4.18.3	2
1015	C00403F7	Error	Physical Device might change to Dead. Disk Array: %1 Disk ID: %2 Model: %3	Disk Array Physical Device Dead	Physical Device might change to Dead. Disk Array: %1 Disk ID: %2 Model: %3	Check the utility for this disk array, eventlog or hardware. If this Physical Device has some trouble, replace it with another one.	Red	Disk Array Physical Device	✓	✓	For %1, set controller name to which physical device is connected. For %2, set ID of physical device. For %3, set model of physical device.	.1.3.6.1.4. 1.119.2.2.4 .4.18.3	4
1020	800403FC	Warning	The S.M.A.R.T. feature considered the Physical Device to be in Warning state. Disk Array: %1 Disk ID: %2 Model: %3 Reset: %4	Disk Array Physical Device S.M.A.R.T. Error	The S.M.A.R.T. feature considered the Physical Device to be in Warning state. Disk Array: %1 Disk ID: %2 Model: %3 Reset: %4	Continuation use of this physical device is dangerous. Contact your hardware vendor for a replacement. When this Physical Device needs reset, reset the Device after replacement devices using the Manager or ESMDiskArray Console of an Agent.	Yellow	Disk Array Physical Device	✓	✓	For %1, set controller name to which physical device is connected. For %2, set ID of physical device. For %3, set model of physical device. For %4, set whether reset is necessary.	.1.3.6.1.4. 1.119.2.2.4 .4.18.3	3
1030	40040406	Information	%1	Disk Array Option report Normal	%1	-	Green	Disk Array Option	✓	-	Use by optional feature. For %1, optional character string is inserted.	.1.3.6.1.4. 1.119.2.2.4 .4.18.3	2
1031	80040407	Warning	%1	Disk Array Option report Warning	%1	-	Yellow	Disk Array Option	✓	-	Use by optional feature. For %1, optional character string is inserted.	.1.3.6.1.4. 1.119.2.2.4 .4.18.3	3

1032	C0040408	Error	%1	Disk Array Option report Fatal	%1	-	Red	Disk Array Option	✓	-	Use by optional feature. For %1, optional character string is inserted.	.1.3.6.1.4. 1.119.2.2.4 .4.18.3	4
9401	C00424B9	Error	Some feature of ESMDiskArray Service is not available. Please restart ESMDiskArray service. %1	-	-	-	-	-	-	-	-	-	-
9402	800424BA	Warning	Some feature of ESMDiskArray Service is not available. Please restart ESMDiskArray service. %1	-	-	-	-	-	-	-	-	-	-
9403	400424BB	Information	Do monitoring as right after installing. %1	-	-	-	-	-	-	-	-	-	-

## ESMCommonService

This service consists of multiple monitoring services.

### ESRAS system failure monitoring

monitors various information of server chassis such as temperature/FAN/power voltage/power supply in collaboration with OS/firmware/hardware/expansion board, etc. and rapidly detects failure information and alerts  
In addition, it supports function of collecting error log at the time of detection of failure and automatic shut down of server and others in accordance with degree of failure.

Source name of Eventlog at the time of alert is registered as "ESMCommonService".

### Monitoring of CPU load

collects performance information of system on a regular basis and sends alert about CPU loading factor.

Source name of Eventlog at the time of alert is registered as "ESMCpuPerf".

### Local porting

monitors optional items not supported by DataView

You can set threshold/reflect status color of server and generate alert based on set information but special knowledge and information of MIB for monitored items are required for setting.

Source name of Eventlog at the time of alert is registered as "ESMLocalPolling".

### Event Source [ESMCommonService]

Event Viewer				AlertViewer				Destination(Default)		Others	SNMP Trap OID	
Event ID	Event ID(Hex)	Type	Description	Detail	Action	Status Color	Type	Manager	Express	Remakrs	Enterprise ID	Specific ID
100	C0000064	Error	The temperature has exceeded the upper threshold (Error). Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	The temperature has exceeded the upper threshold setting(Error). Location:%2 Temperature:%3%6	Started system shutdown. Please check the air temperature.	Red	Temperature	✓	✓	shuts down because opeation at this temperature is risky. Confirm whether duct does not stop up or conditioning is working.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	3
101	80000065	Warning	The temperature has exceeded the upper threshold (Warning). Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	The temperature has exceeded the upper threshold (Warning). Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	Please check the air temperature.	Yellow	Temperature	✓	✓	If temperature rises more than this, operation is disturbed. Confirm whether duct does not stop up or conditioning is working.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	1
102	C0000066	Error	The temperature has fallen below the lower threshold (Error). Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	The temperature is below the lower threshold setting(Error). Location:%2 Temperature:%3%6	Started system shutdown. Please check the air temperature.	Red	Temperature	✓	✓	shuts down because opeation at this temperature is risky. Confirm rapidly whether duct does not stop up or conditioning is working.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	8
103	80000067	Warning	The temperature has fallen below the lower threshold (Warning). Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	The temperature is below the lower threshold setting(Warning). Location:%2 Temperature:%3%6	Please check the air temperature.	Yellow	Temperature	✓	-	If temperature falls belower than this, operation is disturbed. Confirm operation of conditioning.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	6
104	40000068	Information	The temperature has recovered from its lower warning status. Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	The temperature has recovered from its upper warning state. Location:%2 Temperature:%3%6	-	Green	Temperature	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	2

105	40000069	Information	The temperature has recovered from its lower warning status. Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	The temperature has recovered from its lower warning state. Location:%2 Temperature:%3%6	-	Green	Temperature	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	5
106	8000006A	Warning	The temperature has recovered from a high temperature fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	The temperature has recovered from its upper fatal state. Location:%2 Temperature:%3%6	-	Yellow	Temperature	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	4
107	8000006B	Warning	The temperature has recovered from a lower temperature fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Temperature %1 Threshold: %4	The temperature has recovered from its lower fatal state. Location:%2 Temperature:%3%6	-	Yellow	Temperature	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	7
112	C0000070	Error	%5 has fallen below the lower threshold (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%5 has fallen below the lower threshold (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The system can not be operated with the current temperature. It may shut down. Please check if the air conditioner is normally operating.	Red	Temperature	✓	✓	You can not operate tat this temperature. There is a risk that system goes down. Confirm whether duct does not stop up or conditioning is working.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	35
113	C0000071	Error	%5 has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings %4	%5 has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings %4	-	Red	Temperature	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	34
114	C0000072	Error	%5 has exceeded the upper threshold (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%5 has exceeded the upper threshold (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The system can not be operated with the current temperature. It may shut down. Please check if the vent is not closed and the air conditioner is normally operating.	Red	Temperature	✓	✓	You can not operate tat this temperature. There is a risk that system goes down. Confirm whether duct does not stop up or conditioning is working.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	32
115	C0000073	Error	%5 has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%5 has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	-	Red	Temperature	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	33

200	C00000C8	Error	Fan Unit is malfunctioning. Location: %3 Unit Number: %2 Date: %1	%2 Fan is malfunctioning. The system has gone into a fatal state.	Started system shutdown.	Red	Fan	✓	✓	Confirm connection of device and others. If there is no problem with connection, failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	23
201	800000C9	Warning	Fan Unit is in warning status. Location: %3 Unit Number: %2 Date: %1	%2 Fan is malfunctioning. The system has gone into a warning state.	-	Yellow	Fan	✓	-	Confirm connection of device and others. If there is no problem with connection, failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	17
202	400000CA	Information	Fan Unit has recovered from its warning state. Location: %3 Unit Number: %2 Date: %1	%2 Fan has recovered from its warning state.	-	Green	Fan	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	18
205	400000CD	Information	%5 has recovered from the failure. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%2 fan has recovered from the failure.	-	Green	Fan	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	50
206	800000CE	Warning	%5 has fallen below the lower limit (Warning). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%5 has fallen below the lower limit (Warning). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	-	Yellow	Fan	✓	✓	If you continue to operate, there is a risk that operation may be disturbed because temperature in chassis becomes high.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	56
207	400000CF	Information	%5 has recovered from its lower warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has recovered from its lower warning state.	-	Green	Fan	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	55
208	C00000D0	Error	%5 has fallen below the lower limit (Error). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has fallen below the lower limit (Error).	If you continue operating the system, the temperature inside the chassis may rise critically. It may shut down.	Red	Fan	✓	✓	shuts down because temperature in chassis becomes high and risky if you continue to operate.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	58
209	800000D1	Warning	%5 has recovered from a fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has recovered from a fatal state and gone into a warning state.	-	Yellow	Fan	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	57



210	C00000D2	Error	%5 has fallen below the lower limit (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has fallen below the lower limit (Non recoverable).	This fan may have broken down. Please confirm the fan state and replace it.	Red	Fan	✓	✓	There is a risk that fan was broken. Confirm the status of fan and replace it accordingly.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	62
211	C00000D3	Error	%5 has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has recovered from a non-recoverable state and gone into a fatal state.	-	Red	Fan	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	61
212	800000D4	Warning	%5 has exceeded the upper limit (Warning). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has exceeded the upper limit (Warning).	-	Yellow	Fan	✓	-	If you continue to operate, there is a risk that fan will be broken.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	51
213	400000D5	Information	%5 has recovered from its upper warning state Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has recovered from its upper warning state.	-	Green	Fan	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	52
214	C00000D6	Error	%5 has exceeded the upper limit (Error). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has exceeded the upper limit (Error).	This fan may be damaged if you continue operating the system. It may shut down.	Red	Fan	✓	✓	If you continue to operate, fan will be broken. Shuts down.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	53
215	800000D7	Warning	%5 has recovered from a fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has recovered from a fatal state and gone into a warning state.	-	Yellow	Fan	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	54

216	C00000D8	Error	%5 has exceeded the upper limit (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has exceeded the upper limit (Non recoverable).	This fan may be damaged if you continue operating the system.	Red	Fan	✓	✓	f you continue to operate, fan will be broken.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	59
217	C00000D9	Error	%5 has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%2 fan speed has recovered from a non-recoverable state and gone into a fatal state.	-	Red	Fan	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	60
302	4000012E	Information	Power Unit has recovered from its warning status. Unit Number: %2 Date: %1	Power unit has recovered from its warning state.	-	Green	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.11.3	6
304	40000130	Information	Power Unit was connected. Unit Number: %2 Date: %1	Power unit %1 was connected.	-	Green	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.11.3	8
306	80000132	Warning	Power Supply has lost the AC supply. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power Supply %1 has lost the AC supply.	-	Yellow	RPS	✓	-	Confirm conection of device and others. If there is no problem with connection, failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.11.3	10
306	C0000132	Error	Power Supply has lost the AC supply. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Power Supply has lost the AC supply. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Fatal: Please report to the maintenance member.	Red	RPS	✓	✓		.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
309	C0000135	Error	Power supply to the system has been stopped because Power Unit error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power supply to the system has been stopped because Power Unit error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	RPS	✓	✓	Confirm conection of device and others. If there is no problem with connection, failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
310	C0000136	Error	The system has been forced to be power down, because the side cover was opened. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The system has been forced to be power down, because the side cover was opened. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	RPS	✓	✓	Confirm that side cover is closed. If there is no problem with cover, failure of device is considered. From the viewpoint of preventive maintenance, collect information by collect.exe and conatct system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1

311	80000137	Warning	Power Unit has lost the AC supply. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power Unit has lost the AC supply. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	Confirm conection of device and others. If there is no problem with connection, failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
313	80000139	Warning	Power Unit error has been found. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power Unit error has been found. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	✓	Confirm conection of device and others. If there is no problem with connection, failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
314	8000013A	Warning	Power Supply is in fatal state. Sensor Number: %2 Location: %3 Date: %1 IDStrings: %4	Power Supply %1 is in fatal state.	-	Yellow	RPS	✓	✓	Confirm conection of device and others. If there is no problem with connection, failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.11.3	14
315	8000013B	Warning	Power Supply is in warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power Supply is in warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The system is now operating with spare Power Supply. Please check out malfunctioning power supply.	Yellow	RPS	✓	✓	Confirm conection of device and others. If there is no problem with connection, failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.11.3	13
500	C00001F4	Error	The %2 voltage exceeds the upper limit (Error). Present Voltage Level: %3 Threshold: %4 Date: %1	The %2 voltage exceeds the upper limit (Error). Present Voltage Level: %3 Threshold: %4 Date: %1	Started system shutdown.	Red	Voltage	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
501	C00001F5	Error	The %2 voltage is below the lower limit (Error). Present Voltage Level: %3 Threshold: %4 Date: %1	The %2 voltage is below the lower limit (Error). Present Voltage Level: %3 Threshold: %4 Date: %1	Started system shutdown.	Red	Voltage	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
504	C00001F8	Error	A failure has occurred in the voltage sensor. Date: %1 Sensor infomation: %2	The voltage sensor has been malfunctioning. Location:%2	-	Red	Voltage	✓	-	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	28
506	400001FA	Information	%5 has recovered from a fatal state Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The voltage has recovered from a fatal state.	-	Green	Voltage	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	37
507	800001FB	Warning	%5 has fallen below the lower limit (Warning). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has fallen below the lower limit (Warning). Nominal Level: %2 Level: %3	-	Yellow	Voltage	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	43

508	400001FC	Information	%5 has recovered from its lower warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has recovered from its lower warning state. Nominal Level: %2 Level: %3	-	Green	Voltage	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	42
509	C00001FD	Error	%5 has fallen below the lower limit (Error). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has fallen below the lower limit (Error). Nominal Level: %2 Level: %3	It is dangerous to operate the system with the current voltage. It may shut down.	Red	Voltage	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	45
510	800001FE	Warning	%5 has recovered from a fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has recovered from a fatal state and gone into a warning state. Nominal Level: %2 Level: %3	-	Yellow	Voltage	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	44
511	C00001FF	Error	%5 has fallen below the lower limit (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has fallen below the lower limit (Non recoverable). Nominal Level: %2 Level: %3	The system can not be operated with the current voltage. It may shut down.	Red	Voltage	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	49
512	C0000200	Error	%5 has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has recovered from a non-recoverable state and gone into a fatal state. Nominal Level: %2 Level: %3	-	Red	Voltage	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	48
513	80000201	Warning	%5 has exceeded the upper limit (Warning). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has exceeded the upper limit (Warning). Nominal Level: %2 Level: %3	-	Yellow	Voltage	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	38

514	40000202	Information	%5 has recovered from its upper warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has recovered from its upper warning state. Nominal Level: %2 Level: %3	-	Green	Voltage	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	39
515	C0000203	Error	%5 has exceeded the upper limit (Error). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has exceeded the upper limit (Error). Nominal Level: %2 Level: %3	It is dangerous to operate the system with the current voltage. It may shut down.	Red	Voltage	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	40
516	80000204	Warning	%5 has recovered from a fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has recovered from a fatal state and gone into a warning state. Nominal Level: %2 Level: %3	-	Yellow	Voltage	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	41
517	C0000205	Error	%5 has exceeded the upper limit (Non recoverable). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has exceeded the upper limit (Non recoverable). Nominal Level: %2 Level: %3	The system can not be operated with the current voltage state. It may shut down.	Red	Voltage	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.10.3	46
518	C0000206	Error	%5 has recovered from a non-recoverable state and gone into a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The voltage has recovered from a non-recoverable state and gone into a fatal state. Nominal Level: %2 Level: %3	-	Red	Voltage	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.10.3	47
703	800002BF	Warning	CPU subsystem is running in a reduced capacity. CPU Number: %1	CPU subsystem is running in a reduced capacity. CPU Number: %1	A part of Processor has stopped. Please report to the maintenance member and exchange Processor.	Yellow	CPU	✓	✓	Failure of CPU is considered. From the viewpoint of preventive maintenance, as continuous use is risky, after contact with system administrator, replace CPU.	.1.3.6.1.4.1.119.2.2.4 .4.21.3	3
704	400002C0	Information	%5 has recovered from reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The power unit has recovered from reduced capacity state.	-	Green	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.11.3	12

705	800002C1	Warning	%5 is in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The power unit is in reduced capacity state.	The system is now operating with spare Power Supply. Please check out malfunctioning power supply.	Yellow	RPS	✓	✓	Failure of power supply is considered. From the viewpoint of preventive maintenance, as continuous use is risky, after contact with system administrator, replace power supply.	.1.3.6.1.4.1.119.2.2.4 .4.11.3	11
707	400002C3	Information	%5 has recovered from reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered from reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Fan	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
708	800002C4	Warning	%5 is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Fan	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
710	800002C6	Warning	A memory is a degenerate state. Date: %1 Memory ID: %2	A memory is a degenerate state. Date: %1 Memory ID: %2	A part of memory is a degenerate state. Please report to the maintenance member and exchange memory.	Yellow	Memory	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.4.3	4
800	C0000320	Error	System Error Information Time:%1 Dump Switch:%2 Message: %3	System Error Information	The system is down because a STOP error occurred. Contact your customer support.	Red	System Error	✓	✓	System went down due to system error. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.14.3	1
802	80000322	Warning	ECC Single bit Error occurred. Latest ECC 1bit error log: Error Address: %1 When Happened: %2 Syndrome: %3 Specified Group: %4 Specified Simm: %5	A ECC single bit error has occurred.	-	Yellow	Memory	✓	-	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.4.3	1
911	8000038F	Warning	Requested system shutdown (or reboot).	Requested system shutdown (or reboot).	-	-	Server Recovery	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.15.3	1
1002	800003EA	Warning	Chassis Intrusion. %3 was opened Date: %1	Chassis Intrusion. %3 was opened Date: %1	-	Yellow	Security	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.9.3	3
1003	400003EB	Information	%3 was closed Date: %1	%3 was closed Date: %1	-	Green	Security	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.9.3	4
1100	C000044C	Error	ECC Multiple bit error occurred. Date: %1 Code: %2	A ECC multiple bit error has occurred.	-	Red	Memory	✓	✓	Failure of memory is considered. From the viewpoint of preventive maintenance, as continuous use is risky, after contact with system administrator, replace memory.	.1.3.6.1.4.1.119.2.2.4 .4.4.3	2

1101	C000044D	Error	EISA Bus Timeout(8us) caused by one of the Bus Masters. Date: %1 Master ID: %2	A EISA Bus Timeout was caused by one of the Bus Masters. Slot number: %1	-	Red	Bus	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.8.3	1
1102	C000044E	Error	EISA I/O channel check error occurred. Date: %1 Master ID: %2	A EISA I/O channel check error occurred. Slot number: %1	-	Red	Bus	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.8.3	2
1103	C000044F	Error	Parity error occurred in the PCI subsystem. Date: %1 PCI Bus ID: %2	A Parity error occurred on the PCI bus.	-	Red	Bus	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.8.3	3
1104	C0000450	Error	System error occurred on the PCI buses. Date: %1 PCI Bus ID: %2	A System error occurred on the PCI bus.	-	Red	Bus	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.8.3	4
1105	C0000451	Error	CPU internal error occurred. Date: %1 CPU Number:%2	CPU %1 internal error occurred.	-	Red	CPU	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.2.3	9
1106	C0000452	Error	Timeout of failsafe-timer(watchdog timer). Date: %1	Timeout of failsafe-timer(watchdog timer).	-	Red	Server Recovery	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.15.3	12
1107	C0000453	Error	System error on the system buses. Date: %1 Bus ID: %2	A System error has occurred on the system bus.	-	Red	CPU	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.2.3	11
1108	C0000454	Error	CPU thermal trip occurred. Date: %1 CPU Number:%2	CPU %1 thermal trip event has occurred.	-	Red	CPU	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.2.3	10
1300	80000514	Warning	NMI event generated by software. Date: %1	A NMI event was generated by software.	-	Yellow	OS	✓	-	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.16.3	17
1301	80000515	Warning	Adjusted memory size. Date: %1 Bank ID: %2 Bank Original Size: %3 Bank Current Size: %4	Adjusted memory size. Date: %1 Bank ID: %2 Bank Original Size: %3 Bank Current Size: %4	-	Yellow	Memory	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.4.3	3
1302	80000516	Warning	Error was detected during the POST phase of system initialization. Date: %1 Error Code: %2	Error was detected during the POST phase of system initialization. Date: %1 Error Code: %2	-	Yellow	Server Recovery	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.15.3	14

1303	80000517	Warning	The error logging for specific errors have been disabled. Date: %1 Error Type: %2	The error logging for this specific error has been disabled. Time: %1 Error Type: %2	-	Yellow	System Error	✓	-	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.14.3	3
1304	80000518	Warning	Reset event caused by the watchdog timer. Date: %1 Timeout Value: %2	Reset event caused by the watchdog timer.(%4) Date: %1 Timeout Value: %2	-	Yellow	Server Recovery	✓	-	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.15.3	13
1305	80000519	Warning	The system configuration was altered by the configuration utility. Date: %1	The system configuration was altered with the configuration utility.	-	Yellow	Server Recovery	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.15.3	15
1306	8000051A	Warning	A cache is a degenerate state. Date: %1 DIMM ID: %2 Site Original Size: %3 Site Current Size: %4	A cache is a degenerate state. Date: %1 DIMM ID: %2 Site Original Size: %3 Site Current Size: %4	A cache is a degenerate state. Please report to the maintenance member and exchange cache.	Yellow	CPU	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.2.3	13
1307	8000051B	Warning	Level 3 cache ECC single bit error occurred. Date: %1 DIMM ID: %2	A Level 3 cache ECC single bit error occurred.	-	Yellow	CPU	✓	-	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.2.3	14
1308	C000051C	Error	Level 3 cache ECC multiple bit error occurred. Date: %1 DIMM ID: %2	A Level 3 cache ECC multiple bit error occurred.	-	Red	CPU	✓	-	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.2.3	15
1309	8000051D	Warning	System bus ECC single bit error occurred. Date: %1 SYSTEM BUS ID: %2	A System bus ECC single bit error has occurred.	-	Yellow	CPU	✓	-	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.2.3	12
1315	40000523	Information	Processor has been disabled.%n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Processor has been disabled.%n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	CPU	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
1315	C0000523	Error	Processor has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Processor has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	CPU	-	-	Failure of CPU is considered. From the viewpoint of preventive maintenance, as continuous use is risky, after contact with system administrator, replace CPU.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1317	40000525	Information	System Event Log has been cleared. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	-	-	Server Recovery	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1



1318	80000526	Warning	All the errors logging to System Event Log have been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	All the errors logging to System Event Log have been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Server Recovery	✓	-	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1321	C0000529	Error	ECC Multi bit error of system bus has occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	ECC Multi bit error of system bus has occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	Bus	✓	-	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1322	C000052A	Error	NMI has occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	NMI has occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	CPU	✓	-	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1323	4000052B	Information	System watch program started. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	System watch program started. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Server Recovery	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1400	C0000578	Error	This is the event which occurred between this system start-up and the last system stop or system shutdown %2 %3 %4 %5	This is the event which occurred between this system start-up and the last system stop or system shutdown %2 %3 %4 %5	-	Red	Server Recovery	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1401	80000579	Warning	This is the event which occurred between this system start-up %nand the last system stop or system shutdown. %2 %3 %4 %5	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	-	Yellow	Server Recovery	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1402	4000057A	Information	This is the event which occurred between this system start-up %nand the last system stop or system shutdown. %2 %3 %4 %5	This is the event which occurred between this system start-up %nand the last system stop or system shutdown. %2 %3 %4 %5	-	Green	Server Recovery	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1407	C000057F	Error	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	-	Red	Server Recovery	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1

1408	80000580	Warning	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	-	Yellow	Server Recovery	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1409	40000581	Information	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	This is the event which occurred between this system start-up and the last system stop or system shutdown. %2 %3 %4 %5	-	Green	Server Recovery	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1500	400005DC	Information	Power button was pushed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	-	-	Security	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1501	400005DD	Information	Sleep button was pushed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	-	-	Security	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1502	400005DE	Information	Reset button was pushed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	-	-	Security	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1602	40000642	Information	New device has been connected to the slot or the connector device. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Hardware component has been changed. Please reconstruct tree if you already have DataViewer opened for this server.	Green	Security	✓	-	Hardware configuration was changed. In case you open DataViewer, execute rebuild of tree.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1605	40000645	Information	Either the slot or connector power has been off, or device has been removed. SensorNumber: %2 Location: %3 Date: %1 ID Strings: %4	-	Hardware component has been changed. Please reconstruct tree if you already have DataViewer opened for this server.	Green	Security	✓	-	Hardware configuration was changed. In case you open DataViewer, execute rebuild of tree.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1700	400006A4	Information	The system is now in active state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	-	-	Server Recovery	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1

1705	400006A9	Information	The system is now in software-off state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	-	-	Server Recovery	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1707	400006AB	Information	The system is now in hardware-off state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	-	-	Server Recovery	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1709	400006AD	Information	The system is now in sleep state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	-	-	Server Recovery	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1800	80000708	Warning	Time out of Watch Dog Timer has occurred.(%5) Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Time out of Watch Dog Timer has occurred.(%5) Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Server Recovery	✓	-	Failure of system is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1802	8000070A	Warning	Power Down occurred as time out of Watch Dog Timer has occurred.(%5) Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power Down occurred as time out of Watch Dog Timer has occurred.(%5) Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Server Recovery	✓	-	Failure of system is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1803	8000070B	Warning	Power Cycle has occurred due to time out of Watch Dog Timer.(%5) Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power Cycle has occurred due to time out of Watch Dog Timer.(%5) Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Server Recovery	✓	-	Failure of system is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1808	80000710	Warning	Interruption has occurred by time out of Watch Dog Timer. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Interruption has occurred by time out of Watch Dog Timer. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Server Recovery	✓	-	Failure of system is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1900	C000076C	Error	%5 The system might have broken down. There is no response from the sensor. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 The system might have broken down. There is no response from the sensor. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	Bus	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1

1901	C000076D	Error	%5 Sensor Error has been detected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 Sensor Error has been detected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	Bus	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
1902	C000076E	Error	%5 The system might have broken down. Time out occurred in the access process to the sensor. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 The system might have broken down. Time out occurred in the access process to the sensor. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	Bus	✓	✓	Failure of device is considered. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
2301	C00008FD	Error	Requested system shutdown via SMS. Date:%1	Requested system shutdown via SMS. Date:%1	-	Red	Server Recovery	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2302	C00008FE	Error	Requested system reboot via SMS. Date:%1	Requested system reboot via SMS. Date:%1	-	Red	Server Recovery	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2303	800008FF	Warning	The slot or connector device is in fault state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The slot or connector device is in fault state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Security	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2303	C00008FF	Error	The slot or connector device is in fault state.%n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	The slot or connector device is in fault state.%n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Fatal: Please report to the maintenance member.	Red	Security	✓	✓		.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2304	80000900	Warning	Too many ECC Correctable Errors. Latest ECC correctable error log: Error Address: %1 When Happened: %2 Syndrome: %3 Specified Group: %4 Memory Number: %5	Too many ECC Correctable Errors. Please confirm the IPMI log and specify the DIMM number. Latest ECC correctable error log generation memory number:%5	Exchange the memory.	Yellow	Memory	✓	✓	Failure of memory is considered. From the viewpoint of preventive maintenance, as continuous use is risky, after contact with system administrator, replace memory.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2305	80000901	Warning	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Voltage	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2306	40000902	Information	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Voltage	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2307	C0000903	Error	ECC uncorrectable error occurred. Date: %1 Syndrome Byte: %2 Row Number: %5 Memory Card Number: %3 Memory Number: %4	ECC uncorrectable error occurred. Date: %1 Syndrome Byte: %2 Row Number: %5 Memory Card Number: %3 Memory Number: %4	Please report to the System Administrator or Support Center and then exchange the system memory.	Red	Memory	✓	✓	Failure of memory is considered. From the viewpoint of preventive maintenance, as continuous use is risky, after contact with system administrator, replace memory.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2308	40000904	Information	Notify Switch ON. %2 Date: %1	Notify Switch ON. %2 Date: %1	-	Green	Notify Switch	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2309	40000905	Information	Notify Switch OFF. %2 Date: %1	Notify Switch OFF. %2 Date: %1	-	Green	Notify Switch	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2310	40000906	Information	The device has been removed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The device has been removed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Hardware component has been changed. Please reconstruct tree if you already have DataViewer opened for this server.	Green	Security	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2311	80000907	Warning	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Temperature	✓	✓	If temperature rises more than this, operation is disturbed. Confirm whether duct does not stop up or conditioning is working.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2312	40000908	Information	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Temperature	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2313	40000909	Information	A part of DIMM is released.%n DIMM Number: %2 %n Date: %1 %n	A part of DIMM is released.%n DIMM Number: %2 %n Date: %1 %n	-	Green	Memory	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2313	80000909	Warning	The memory error occurred. A part of DIMM is released. DIMM Number: %2 Date: %1	The memory error occurred. A part of DIMM is released. DIMM Number: %2 Date: %1	Please report to the maintenance member and exchange memory.	Yellow	Memory	✓	✓	Failure of memory is considered. From the viewpoint of preventive maintenance, as continuous use is risky, after contact with system administrator, replace memory.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2313	C0000909	Error	The memory error occurred. %n A part of DIMM is released.%n DIMM Number: %2 %n Date: %1 %n	The memory error occurred. %n A part of DIMM is released.%n DIMM Number: %2 %n Date: %1 %n	Fatal: Please report to the maintenance member and exchange memory.	Red	Memory	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2314	C000090A	Error	%5 has gone into a non-recoverable state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a non-recoverable state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	Voltage	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4

2315	8000090B	Warning	All of Fans inside %5 is broken or not implemented. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	All of Fans inside %5 is broken or not implemented. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Fan	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2316	8000090C	Warning	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Fan	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2317	4000090D	Information	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Fan	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2318	C000090E	Error	%5 is in a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%5 is in a fatal state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	-	Red	Voltage	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2319	8000090F	Warning	%5 has recovered from a fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%5 has recovered from a fatal state and gone into a warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	-	Yellow	Voltage	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2320	80000910	Warning	%5 has fallen below the lower limit (Warning). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%5 has fallen below the lower limit (Warning). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	-	Yellow	Fan	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2321	40000911	Information	%5 has recovered from its lower warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%5 has recovered from its lower warning state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	-	Green	Fan	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2322	80000912	Warning	%5 Redundancy Degraded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 Redundancy Degraded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3

2323	80000913	Warning	%5 Non-redundant : Sufficient Resources from Redundant Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 Non-redundant : Sufficient Resources from Redundant Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2323	C0000913	Error	%5 Non-redundant : Sufficient Resources from Redundant. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	%5 Non-redundant : Sufficient Resources from Redundant. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Fatal: Please report to the maintenance member.	Red	RPS	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2324	40000914	Information	%5 Non-redundant : Sufficient Resources from Insufficient Resources Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 Non-redundant : Sufficient Resources from Insufficient Resources Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2324	80000914	Warning	%5 Non-redundant : Sufficient Resources from Insufficient Resources. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	%5 Non-redundant : Sufficient Resources from Insufficient Resources. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Yellow	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2325	C0000915	Error	%5 Non-redundant : Insufficient Resources Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 Non-redundant : Insufficient Resources Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	RPS	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2326	80000916	Warning	%5 Redundancy Degraded from Fully Redundant Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 Redundancy Degraded from Fully Redundant Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2327	40000917	Information	%5 Redundancy Degraded from Non-Redundant Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 Redundancy Degraded from Non-Redundant Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2328	40000918	Information	The slot or connector device has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The slot or connector device has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Security	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2329	40000919	Information	The DIMM has recovered. DIMM Number: %2 Date: %1	The DIMM has recovered. DIMM Number: %2 Date: %1	-	Green	Memory	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2330	C000091A	Error	Chipset errors(CNB3.0HE#0) Date: %1 ErrorCode: %2	Chipset errors(CNB3.0HE#0) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2331	C000091B	Error	Chipset errors(CNB3.0HE#1) Date: %1 ErrorCode: %2	Chipset errors(CNB3.0HE#1) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2332	C000091C	Error	Chipset errors(CIOB20#0) Date: %1 ErrorCode: %2	Chipset errors(CIOB20#0) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2333	C000091D	Error	Chipset errors(CIOB20#1) Date: %1 ErrorCode: %2	Chipset errors(CIOB20#1) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2334	C000091E	Error	Chipset errors(AQUA#0) Date: %1 ErrorCode: %2	Chipset errors(AQUA#0) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2335	C000091F	Error	Chipset errors(AQUA#1) Date: %1 ErrorCode: %2	Chipset errors(AQUA#1) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2336	C0000920	Error	Chipset errors(CMIC Function#0) Date: %1 ErrorCode: %2	Chipset errors(CMIC Function#0) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2337	C0000921	Error	Chipset errors(CMIC Function#1-3) Date: %1 ErrorCode: %2	Chipset errors(CMIC Function#1-3) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2338	C0000922	Error	Chipset errors(CIOB30#0) Date: %1 ErrorCode: %2	Chipset errors(CIOB30#0) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2339	C0000923	Error	Chipset errors(CIOB30#1) Date: %1 ErrorCode: %2	Chipset errors(CIOB30#1) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2340	C0000924	Error	Chipset errors(REMC) Date: %1 ErrorCode: %2	Chipset errors(REMC) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4



2341	C0000925	Error	Chipset errors(CSB5) Date: %1 ErrorCode: %2	Chipset errors(CSB5) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2342	C0000926	Error	Chipset errors(CIOB30#2) Date: %1 ErrorCode: %2	Chipset errors(CIOB30#2) Date: %1 ErrorCode: %2	-	Red	Chipset	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2350	C000092E	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please check whether the air temperature is normal. If it is normal, please replace motherboard/CPU/FAN to new one according to the message.	Red	Temperature	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2351	4000092F	Information	%5 has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Temperature	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2352	C0000930	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member and exchange motherboard.	Red	Voltage	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2353	40000931	Information	%5 has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Voltage	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2354	C0000932	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Red	Voltage	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2360	C0000938	Error	Chipset Specific Critical Interrupt Information Date: %1	Chipset Specific Critical Interrupt Information Date: %1	Please report to the maintenance member.	Red	Chipset	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2366	C000093E	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Red	Temperature	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2367	8000093F	Warning	%5 has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Temperature	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3

2368	80000940	Warning	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Yellow	Temperature	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2369	40000941	Information	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Temperature	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2370	C0000942	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Temperature	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2371	40000943	Information	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Temperature	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2373	40000945	Information	%5 has recovered from a reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered from a reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Fan	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2374	80000946	Warning	%5 is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Yellow	Fan	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2374	C0000946	Error	%5 is now in reduced capacity state.%n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	%5 is now in reduced capacity state.%n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Fatal: Please report to the maintenance member.	Red	Fan	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2375	C0000947	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	CPU	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2376	40000948	Information	Recovered from internal CPU error. Date: %1 CPU Number:%2	Recovered from internal CPU error. Date: %1 CPU Number:%2	-	Green	CPU	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2377	40000949	Information	Recovered from CPU thermal trip Date: %1 CPU Number:%2	Recovered from CPU thermal trip Date: %1 CPU Number:%2		Green	CPU	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2378	8000094A	Warning	CPU configuration error occurred. Date: %1 CPU Number:%2	CPU configuration error occurred. Date: %1 CPU Number:%2	Please report to the System Administrator or Support Center.	Yellow	CPU	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2379	4000094B	Information	Recovered from CPU configuration error. Date: %1 CPU Number:%2	Recovered from CPU configuration error. Date: %1 CPU Number:%2	-	Green	CPU	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2380	4000094C	Information	Processor automatic throttle occurred. Date: %1 CPU Number:%2	Processor automatic throttle occurred. Date: %1 CPU Number:%2	-	Green	CPU	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2381	4000094D	Information	Recovered from processor automatic throttle. Date: %1 CPU Number:%2	Recovered from processor automatic throttle. Date: %1 CPU Number:%2	-	Green	CPU	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2382	8000094E	Warning	Power supply has lost the AC supply or been out-of-range. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power supply has lost the AC supply or been out-of-range. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Yellow	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2383	8000094F	Warning	Memory has been non-redundant. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory has been non-redundant. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Yellow	Memory	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2384	C0000950	Error	Unspecified system hardware failure occurred. Date: %1	Unspecified system hardware failure occurred. Date: %1	Please report to the maintenance member.	Red	Server Recovery	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2385	C0000951	Error	Bus fatal error occurred. Date: %1	Bus fatal error occurred. Date: %1	Please report to the maintenance member.	Red	Bus	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2386	40000952	Information	Module/Board has been removed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Module/Board has been removed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2387	40000953	Information	Module/Board has been inserted. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Module/Board has been inserted. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2388	40000954	Information	Cable/Interconnect has been removed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cable/Interconnect has been removed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2389	40000955	Information	Cable/Interconnect has been inserted. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cable/Interconnect has been inserted. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2390	C0000956	Error	%5 has fallen below the lower limit (Error). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%5 has fallen below the lower limit (Error). Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Please report to the maintenance member.	Red	Fan	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2391	40000957	Information	Memory has recovered from a reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory has recovered from a reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2392	80000958	Warning	Memory has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Yellow	Memory	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2393	C0000959	Error	Memory has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Red	Memory	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2394	8000095A	Warning	Memory configuration error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory configuration error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Memory	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2395	8000095B	Warning	SEL is full. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	SEL is full. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Yellow	Server Recovery	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2397	4000095D	Information	Cable/interconnect has been connected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cable/interconnect has been connected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-		Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2398	4000095E	Information	Cable/interconnect has been disconnected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cable/interconnect has been disconnected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2399	8000095F	Warning	Cable/interconnect configuration error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cable/interconnect configuration error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2409	C0000969	Error	Device has a drive fault. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Device has a drive fault. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Red	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2410	4000096A	Information	Device has recovered from drive fault. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Device has recovered from drive fault. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2416	40000970	Information	Recovered from cable/interconnect configuration error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from cable/interconnect configuration error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2417	80000971	Warning	Battery has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Battery has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2418	40000972	Information	Battery has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Battery has recovered from a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2419	C0000973	Error	Battery has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Battery has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2420	40000974	Information	Battery has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Battery has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2421	40000975	Information	Recovered from timeout of watch dog timer. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from timeout of watch dog timer. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Server Recovery	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2422	40000976	Information	Recovered from reset event caused by the watch dog timer. Date: %1 Timeout Value: %2	Recovered from reset event caused by the watch dog timer. Date: %1 Timeout Value: %2	-	Green	Server Recovery	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2423	40000977	Information	Recovered from power down that occurred as time out of watch dog timer. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from power down that occurred as time out of watch dog timer. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Server Recovery	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2424	40000978	Information	Recovered from power cycle that occurred due to time out of watch dog timer. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from power cycle that occurred due to time out of watch dog timer. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Server Recovery	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2602	C0000A2A	Error	MCA has occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	MCA has occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Machine Check Abort error has occurred. Please check the System Event Log and HW log for details, and replace the doubtful components.	Red	System Error	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2700	C0000A8C	Error	Liquid Leak has happened. Location: %3 Sensor Number: %2 Date: %1	Liquid Leak has happened. Location: %3 Sensor Number: %2 Date: %1	Please report to the maintenance member.	Red	LiquidLeak	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2701	40000A8D	Information	Liquid Leak has recovered. Location: %3 Sensor Number: %2 Date: %1	Liquid Leak has recovered. Location: %3 Sensor Number: %2 Date: %1	-	Green	LiquidLeak	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2760	C0000AC8	Error	The Memory Board has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The Memory Board has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member and exchange memoryboard.	Red	Memory	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2761	40000AC9	Information	The Memory Board has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The Memory Board has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2817	40000B01	Information	%5 has recovered. Sensor Number:%2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered. Sensor Number:%2 Location: %3 Date: %1 ID Strings: %4	-	Green	Fan	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2818	40000B02	Information	%5 has recovered. Sensor Number:%2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered. Sensor Number:%2 Location: %3 Date: %1 ID Strings: %4	-	Green	CPU	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2819	80000B03	Warning	%5 has gone into a warning state. Sensor Number:%2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a warning state. Sensor Number:%2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	CPU	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2820	C0000B04	Error	CPU self-test error occurred. Date: %1 CPU Number:%2	CPU self-test error occurred. Date: %1 CPU Number:%2	Please report to the System Administrator or Support Center.	Red	CPU	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2821	40000B05	Information	Recovered from CPU self-test error. Date: %1 CPU Number: %2	Recovered from CPU self-test error. Date: %1 CPU Number: %2	-	Green	CPU	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2822	40000B06	Information	Recovered from Power On Self Test (POST) process stalled. Date: %1	Recovered from Power On Self Test (POST) process stalled. Date: %1	-	Green	CPU	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2823	C0000B07	Error	CPU initialization error occurred. Date: %1 CPU Number: %2	CPU initialization error occurred. Date: %1 CPU Number: %2	Please report to the System Administrator or Support Center.	Red	CPU	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2824	40000B08	Information	Recovered from CPU initialization error. Date: %1 CPU Number: %2	Recovered from CPU initialization error. Date: %1 CPU Number: %2	-	Green	CPU	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2825	40000B09	Information	Recovered from system error on the system buses. Date: %1 Bus ID: %2	Recovered from system error on the system buses. Date: %1 Bus ID: %2	-	Green	CPU	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2828	40000B0C	Information	Processor has been enabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Processor has been enabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	CPU	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2831	40000B0F	Information	Power unit is in D0 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit is in D0 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2832	40000B10	Information	Power unit is not in D0 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit is not in D0 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2833	40000B11	Information	Power unit is in D1 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit is in D1 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2834	40000B12	Information	Power unit is not in D1 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit is not in D1 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2835	40000B13	Information	Power unit is in D2 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit is in D2 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2836	40000B14	Information	Power unit is in D3 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit is in D3 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2837	40000B15	Information	Power unit has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2839	40000B17	Information	Recovered from ECC uncorrectable error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from ECC uncorrectable error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2840	C0000B18	Error	Memory parity error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory parity error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Memory	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2841	80000B19	Warning	Memory scrub failed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory scrub failed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Memory	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2842	40000B1A	Information	Memory has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2843	40000B1B	Information	Memory has been enabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory has been enabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2



2844	80000B1C	Warning	The limit on ECC correctable errors has been reached. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The limit on ECC correctable errors has been reached. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Memory	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2845	40000B1D	Information	Recovered from ECC correctable errors. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from ECC correctable errors. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2850	40000B22	Information	Memory automatic throttle occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory automatic throttle occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2851	40000B23	Information	Recovered from Memory automatic throttle. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from Memory automatic throttle. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2852	C0000B24	Error	Memory temperature has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory temperature has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Memory	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2853	40000B25	Information	Memory temperature has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory temperature has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2854	40000B26	Information	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2855	80000B27	Warning	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3

2856	C0000B28	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please collect the trouble information with the collection tool and report to the System Administrator or Support Center.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2857	40000B29	Information	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2858	80000B2A	Warning	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2859	C0000B2B	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2860	40000B2C	Information	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2861	80000B2D	Warning	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2862	C0000B2E	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2865	40000B31	Information	Dynamic partitioning action is in progress. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Dynamic partitioning action is in progress. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2866	40000B32	Information	Dynamic partitioning action has completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Dynamic partitioning action has completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2867	80000B33	Warning	The communication between the cell and the boot cell failed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The communication between the cell and the boot cell failed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2869	40000B35	Information	Cell was paused. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell was paused. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2871	40000B37	Information	Cell is in use. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell is in use. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2872	40000B38	Information	The cell entered an unused state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The cell entered an unused state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2873	40000B39	Information	Cell firmware update is in progress. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell firmware update is in progress. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2874	40000B3A	Information	Cell firmware update has completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell firmware update has completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2875	40000B3B	Information	Cell diagnostic is being executed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell diagnostic is being executed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2877	40000B3D	Information	The partition composition is being changed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The partition composition is being changed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2878	40000B3E	Information	The change in the partition composition was completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The change in the partition composition was completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2879	40000B3F	Information	Cell/partition is stopped. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition is stopped. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2880	40000B40	Information	Cell hardware is being initialized. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell hardware is being initialized. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2881	40000B41	Information	Cell BIOS started initialization. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell BIOS started initialization. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2882	40000B42	Information	Cell BIOS completed initialization. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell BIOS completed initialization. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2883	40000B43	Information	Partition BIOS started initialization. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Partition BIOS started initialization. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2884	40000B44	Information	Operating system is being started. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Operating system is being started. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2885	40000B45	Information	Cell/partition is running. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition is running. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2886	40000B46	Information	Cell/partition is being stopped. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition is being stopped. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2887	40000B47	Information	Cell/partition has recovered from a reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition has recovered from a reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2888	40000B48	Information	Cell/partition is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2889	C0000B49	Error	The cell is not able to be used in a partition. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The cell is not able to be used in a partition. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2890	40000B4A	Information	The validity of the cell is being verified. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The validity of the cell is being verified. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2892	80000B4C	Warning	The system serial number displayed for this cell is different than the system serial number displayed for other cells in the system. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The system serial number displayed for this cell is different than the system serial number displayed for other cells in the system. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2894	40000B4E	Information	Cell is not viable. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell is not viable. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2895	40000B4F	Information	Cell is viable as a non-boot cell in a partition. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell is viable as a non-boot cell in a partition. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2896	40000B50	Information	Cell is viable as a boot cell in a partition. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell is viable as a boot cell in a partition. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2897	40000B51	Information	Partition is not viable. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Partition is not viable. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2898	40000B52	Information	Partition is viable. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Partition is viable. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2899	40000B53	Information	Cell/partition has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2900	80000B54	Warning	Cell/partition has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2901	C0000B55	Error	Cell/partition has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2902	40000B56	Information	Cell/partition software has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition software has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2903	80000B57	Warning	Cell/partition software has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition software has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2904	C0000B58	Error	Cell/partition software has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell/partition software has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2909	40000B5D	Information	Partition has recovered from reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Partition has recovered from reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2910	80000B5E	Warning	Partition is running at a reduced capacity. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Partition is running at a reduced capacity. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2911	80000B5F	Warning	Partition redundancy degraded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Partition redundancy degraded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2912	40000B60	Information	Memory mirroring has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory mirroring has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2913	40000B61	Information	Memory mirroring has been enabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory mirroring has been enabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2914	80000B62	Warning	Memory mirroring has been enabled, but Mem_Brd0 is broken. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory mirroring has been enabled, but Mem_Brd0 is broken. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2915	80000B63	Warning	Memory mirroring has been enabled, but Mem_Brd1 is broken. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory mirroring has been enabled, but Mem_Brd1 is broken. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2928	40000B70	Information	Power unit is not in D2 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit is not in D2 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2929	40000B71	Information	Power unit is not in D3 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit is not in D3 state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2930	40000B72	Information	The communication between the cell and the boot cell has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The communication between the cell and the boot cell has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2931	40000B73	Information	Cell has recovered from pause. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell has recovered from pause. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2932	40000B74	Information	Cell diagnostic was completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Cell diagnostic was completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2933	40000B75	Information	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2934	80000B76	Warning	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2935	C0000B77	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2936	C0000B78	Error	Power On Self Test (POST) process stalled. Date: %1 Post Code: %2	Power On Self Test (POST) process stalled. Date: %1 Post Code: %2	Please report to the System Administrator or Support Center.	Red	CPU	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2937	C0000B79	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please collect the trouble information with the collection tool and report to the System Administrator or Support Center.	Red	Fan	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2938	40000B7A	Information	The abnormal power unit signal has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The abnormal power unit signal has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2940	C0000B7C	Error	Power supply is in fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power supply is in fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The system is now operating with the spare power supply. Please inspect the primary power supply, which is malfunctioning.	Red	RPS	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2947	80000B83	Warning	An abnormal power unit signal was detected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	An abnormal power unit signal was detected. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please collect the trouble information with the collection tool and report to the System Administrator or Support Center.	Yellow	RPS	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2948	40000B84	Information	Recovered from memory parity error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from memory parity error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2949	40000B85	Information	Recovered from memory scrub error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from memory scrub error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2



2950	40000B86	Information	Recovered from memory configuration error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Recovered from memory configuration error. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Memory	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2951	40000B87	Information	Device has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Device has been disabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2952	40000B88	Information	Device has been enabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Device has been enabled. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2954	80000B8A	Warning	Power control has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power control has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2955	40000B8B	Information	Power control has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power control has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2956	C0000B8C	Error	Fan module 0 is disabled, DC power is off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fan module 0 is disabled, DC power is off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	RPS	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2957	80000B8D	Warning	Fan module 0 is disabled, 2 minutes until power off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fan module 0 is disabled, 2 minutes until power off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2958	80000B8E	Warning	Loss of communication to power supply 0. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Loss of communication to power supply 0. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2959	80000B8F	Warning	CPU0 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	CPU0 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3

2960	C0000B90	Error	Reboot count has been exceeded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Reboot count has been exceeded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Red	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2961	40000B91	Information	Boot has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Boot has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2962	80000B92	Warning	PCI card has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	PCI card has gone into a warning state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2963	40000B93	Information	PCI card has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	PCI card has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2964	C0000B94	Error	PCI card has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	PCI card has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2965	40000B95	Information	Partition completed hard reset. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Partition completed hard reset. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2966	40000B96	Information	Partition completed power down. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Partition completed power down. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2967	40000B97	Information	Dynamic partitioning is being initialized. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Dynamic partitioning is being initialized. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2968	40000B98	Information	Dynamic partitioning has started. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Dynamic partitioning has started. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

2969	40000B99	Information	The cell has been used in a partition. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The cell has been used in a partition. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2970	40000B9A	Information	Dynamic partitioning has completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Dynamic partitioning has completed. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2971	40000B9B	Information	The validation of the cell is in progress. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The validation of the cell is in progress. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2972	80000B9C	Warning	The manufacturer ID displayed for this cell is different than the manufacturer ID displayed for other cells in the system. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The manufacturer ID displayed for this cell is different than the manufacturer ID displayed for other cells in the system. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2973	C0000B9D	Error	The firmware level running on the Service Processor for this cell is different from the firmware level running on other cells in the system. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The firmware level running on the Service Processor for this cell is different from the firmware level running on other cells in the system. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2974	C0000B9E	Error	The cells are missing. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The cells are missing. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2975	40000B9F	Information	Memory mirroring has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory mirroring has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	-	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2976	80000BA0	Warning	Memory mirroring configuration error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Memory mirroring configuration error occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3

2977	40000BA1	Information	Power unit has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2978	C0000BA2	Error	Fan module 1 is disabled, DC power is off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fan module 1 is disabled, DC power is off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	RPS	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2979	80000BA3	Warning	Fan module 1 is disabled, 2 minutes until power off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Fan module 1 is disabled, 2 minutes until power off. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2980	80000BA4	Warning	Loss of communication to power supply 1. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Loss of communication to power supply 1. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2981	80000BA5	Warning	CPU1 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	CPU1 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2982	80000BA6	Warning	CPU2 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	CPU2 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2983	80000BA7	Warning	CPU3 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	CPU3 thermal alert has occurred, thermal throttling has not yet been invoked. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3

2984	80000BA8	Warning	PCI bus number or memory-mapped space resource allocation has been exceeded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	PCI bus number or memory-mapped space resource allocation has been exceeded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 4.18.3	3
2985	80000BA9	Warning	IO space resource allocation has been exceeded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	IO space resource allocation has been exceeded. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 4.18.3	3
2986	80000BAA	Warning	PCI resource has been changed to a different type. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	PCI resource has been changed to a different type. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 4.18.3	3
2987	80000BAB	Warning	Unable to execute OPROM. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Unable to execute OPROM. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 4.18.3	3
2988	40000BAC	Information	Power unit has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power unit has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	RPS	✓	-	-	.1.3.6.1.4.1.119.2.2.4 4.18.3	2
2989	40000BAD	Information	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has recovered. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Voltage	✓	-	-	.1.3.6.1.4.1.119.2.2.4 4.18.3	2
2990	C0000BAE	Error	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	%5 has gone into a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the System Administrator or Support Center.	Red	Voltage	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 4.18.3	2
2991	C0000BAF	Error	Chipset thermal trip occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Chipset thermal trip occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 4.18.3	4

2993	40000BB1	Information	The slot or connector device is released.%n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	The slot or connector device is released.%n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Security	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2993	80000BB1	Warning	The slot or connector device is released. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The slot or connector device is released. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Yellow	Security	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2994	C0000BB2	Error	SMI Timeout occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	SMI Timeout occurred. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please collect the trouble information with the collection tool and report to the System Administrator or Support Center.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2995	80000BB3	Warning	Power Consumption has not recovered from Limit%5. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power Consumption has not recovered from Limit%5. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	It is necessary to change the upper threshold of Power Consumption or reduce the system load.	Yellow	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
2996	40000BB4	Information	Either the slot or connector power has been on, or device has been connected. SensorNumber: %2 Location: %3 Date: %1 ID Strings: %4	Either the slot or connector power has been on, or device has been connected. SensorNumber: %2 Location: %3 Date: %1 ID Strings: %4	Hardware component has been changed. Please reconstruct tree if you already have DataViewer opened for this server.	Green	Security	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
2997	C0000BB5	Error	Operational Firmware image error occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Operational Firmware image error occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member and exchange motherboard.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
2998	C0000BB6	Error	Flash ROM erase error occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Flash ROM erase error occurred. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member and exchange motherboard.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4

2999	C0000BB7	Error	Flash ROM error occurred. Extended Error Code: %5 Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Flash ROM error occurred. Extended Error Code: %5 Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member and exchange motherboard.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
3000	C0000BB8	Error	Firmware internal error occurred. Extended Error Code: %5 Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Firmware internal error occurred. Extended Error Code: %5 Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member and exchange motherboard.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
3001	C0000BB9	Error	BMC did not respond to cold reset request. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	BMC did not respond to cold reset request. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member and exchange motherboard.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
3002	C0000BBA	Error	Manufacturing configuration is wrong. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Manufacturing configuration is wrong. Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member and exchange motherboard.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
3003	C0000BBB	Error	Flash ROM File System error occurred. Extended Error Code: %5 Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Flash ROM File System error occurred. Extended Error Code: %5 Extended Error Code: %5 Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Please report to the maintenance member and exchange motherboard.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
3004	80000BBC	Warning	The value of %5 has changed unusually. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The value of %5 has changed unusually. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	Please check whether the front cover is open. Please check whether the environment of the server setting place or the configuration of the server has been changed after calibrating the Filter Replacement Sensor. If they have been changed, please replace the filter to new one and calibrate the Filter Replacement Sensor again.	Yellow	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3

3005	40000BBD	Information	The value of %5 has recovered. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The value of %5 has recovered. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3006	C0000BBE	Error	%5 has been clogged up with dust. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%5 has been clogged up with dust. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	The filter is clogged up with dust. Please replace the filter to new one and calibrate the Filter Replacement Sensor.	Red	Notify	✓	✓	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
3007	40000BBF	Information	%5 has recovered from the clogged up state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	%5 has recovered from the clogged up state. Sensor Number: %2 Location: %3 Current Value: %6 Threshold: %7 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3016	80000BC8	Warning	%5 has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4  (%5 is Voltage)	%5 has recovered from a fatal state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4  (%5 is Voltage)	-	Yellow	Voltage	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
3017	40000BC9	Information	Power button was pushed in secure mode. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Power button was pushed in secure mode. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3018	40000BCA	Information	The login password to BMC is violation. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	The login password to BMC is violation. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Information: Check the inputted password.	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3019	40000BCB	Information	Processor is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	Processor is now in reduced capacity state. Sensor Number: %2 Location: %3 Date: %1 ID Strings: %4	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2



3020	40000BCC	Information	Processor has recovered from reduced capacity state. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Processor has recovered from reduced capacity state. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3021	40000BCD	Information	Drive has been inserted. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Drive has been inserted. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3022	40000BCE	Information	Drive has been removed. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Drive has been removed. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3023	40000BCF	Information	Drive slot is in rebuild progress. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Drive slot is in rebuild progress. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3024	40000BD0	Information	Drive slot has been stopped rebuilding or rebuilding has been completed. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Drive slot has been stopped rebuilding or rebuilding has been completed. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	✓	-	This event is information level. If an error occurs, other events (Event ID[C0000969] or [C0000BE4]) will be reported.	.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3025	40000BD1	Information	Cold Reset or Warm Reset has been executed. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Cold Reset or Warm Reset has been executed. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	-	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3026	40000BD2	Information	BMCFW's Timestamp Clock was updated. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	BMCFW's Timestamp Clock was updated. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	-	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3027	40000BD3	Information	Module/Board has been disabled. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Module/Board has been disabled. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

3028	40000BD4	Information	Module/Board has been enabled. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Module/Board has been enabled. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3029	40000BD5	Information	Module/Board is now in reduced capacity state. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Module/Board is now in reduced capacity state. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3030	40000BD6	Information	Module/Board has recovered from reduced capacity state. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Module/Board has recovered from reduced capacity state. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3031	40000BD7	Information	Initiated by power up. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Initiated by power up. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3032	40000BD8	Information	User Requested PXE Boot. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	User Requested PXE Boot. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3033	40000BD9	Information	It has started automatically by the Maintenance Utility. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	It has started automatically by the Maintenance Utility. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3034	80000BDA	Warning	Bootable media not found. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Bootable media not found. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Warning: Bootable media not found.	Yellow	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
3035	80000BDB	Warning	PXE Server not found. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	PXE Server not found. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Warning: PXE Server not found.	Yellow	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	3

3036	40000BDC	Information	At least one Spare Rank exists in DIMM. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	At least one Spare Rank exists in DIMM. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3037	40000BDD	Information	None Spare Rank exists in the DIMM. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	None Spare Rank exists in the DIMM. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3038	40000BDE	Information	The slot or connector device has been disabled. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	The slot or connector device has been disabled. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3039	40000BDF	Information	The slot or connector device has been enabled. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	The slot or connector device has been enabled. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3040	40000BE0	Information	The slot or connector device is now in reduced capacity state. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	The slot or connector device is now in reduced capacity state. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3041	40000BE1	Information	The slot or connector device has recovered from reduced capacity state. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	The slot or connector device has recovered from reduced capacity state. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3042	80000BE2	Warning	BMC Access failure occurred on the route between BMC and the host %n Date: %1%n	BMC Access failure occurred on the route between BMC and the host %n Date: %1%n	Warning: Server monitoring may have stopped. From the viewpoint of preventive maintenance, collect information by Collect.exe and contact system administrator.	Yellow	Notify	✓	✓		.1.3.6.1.4.1.119.2.2.4 .4.18.3	3
3043	40000BE3	Information	Recovered from BMC Access failure. %n Date: %1%n	Recovered from BMC Access failure. %n Date: %1%n	-	Green	Notify	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2

3044	C0000BE4	Error	Device has a drive fault. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Device has a drive fault. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Fatal: Please report to the maintenance member.	Red	Notify	✓	✓		.1.3.6.1.4.1.119.2.2.4 .4.18.3	4
3045	40000BE5	Information	Power Supply has been inserted. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Power Supply has been inserted. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	RPS	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3046	40000BE6	Information	Power Supply has been removed. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	Power Supply has been removed. %n Sensor Number: %2 %n Location: %3 %n Date: %1 %n ID Strings: %4 %n	-	Green	RPS	✓	-		.1.3.6.1.4.1.119.2.2.4 .4.18.3	2
3100	40000C1C	Information	BMC config was saved.	BMC config was saved.	-	Green	Notify	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
3101	80000C1D	Warning	Failed saving BMC config. %1	Failed saving BMC config. %1	The retry will be made automatic. When a retry seems to continue, there is a possibility that failures have occurred. Please report to the maintenance member.	Yellow	Yellow	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.18.3	1
9101	C000238D	Error	Internal Error (Common Service) [ %1 %2 ]	-	-	-	-	-	-	Because some error in ESMCommonService happene, there is a possibility that some monitored items can not be monitored. Reboot service. In case message is displayed, collect information by Collect.exe and contact system administrator.	-	-
9102	C000238E	Error	Internal Error (Monitoring DLL) Error Code = %1 Library Name = %2 Function Name = %3	-	-	-	-	-	-	Because some error in ESMCommonService happene, there is a possibility that some monitored items can not be monitored. Reboot service. In case message is displayed, collect information by Collect.exe and contact system administrator.	-	-
9103	C000238F	Error	Internal Error (Monitoring DLL's Thread) Error Code = %1 Error Address = %2	-	-	-	-	-	-	Because some error in ESMCommonService happene, there is a possibility that some monitored items can not be monitored. Reboot service. In case message is displayed, collect information by Collect.exe and contact system administrator.	-	-

9104	C0002390	Error	Internal Error (Report Function DLL) Error Code = %1 EventLog Type = %2 Source Name = %3 Event ID = %4	-	-	-	-	-	-	Because some error in ESMCommonService happene, there is a possibility that some monitered items can not be monitored. Reboot service. In case message is displayed, collect information by Collect.exe and contact system administrator.	-	-
------	----------	-------	--	---	---	---	---	---	---	---	---	---

**Event Source [ESMCpuPerf]**

Event Viewer				AlertViewer				Destination(Default)		Others	SNMP Trap OID	
Event ID	Event ID(Hex)	Type	Description	Detail	Action	Status Color	Type	Manager	Express	Remarks	Enterprise ID	Specific ID
100	C0000064	Error	CPU %1 load has exceeded the upper threshold(Error).	CPU total load factor has exceeded the upper threshold(Error).	-	Red	CPU	✓	-	System load becomes extremely high. Confirm whether it is appropriate.	.1.3.6.1.4.1.119.2.2.4.4.2.3	3
101	80000065	Warning	CPU %1 load factor has recovered from its error state.	CPU total load factor has recovered from its error state.	-	Yellow	CPU	✓	-	-	.1.3.6.1.4.1.119.2.2.4.4.2.3	4
102	80000066	Warning	CPU %1 load has exceeded the upper threshold(Warning).	CPU total load factor has exceeded the upper threshold(Warning).	-	Yellow	CPU	✓	-	System load becomes extremely high. Confirm whether it is appropriate.	.1.3.6.1.4.1.119.2.2.4.4.2.3	1
103	40000067	Information	CPU %1 load factor has recovered from its warning state.	CPU total load factor has recovered from its warning state.	-	Green	CPU	✓	-	-	.1.3.6.1.4.1.119.2.2.4.4.2.3	2
104	C0000068	Error	CPU %1 load has exceeded the upper threshold(Error).	CPU %1 load factor has exceeded the upper threshold(Error).	-	Red	CPU	✓	-	System load becomes extremely high. Confirm whether it is appropriate.	.1.3.6.1.4.1.119.2.2.4.4.2.3	7
105	80000069	Warning	CPU %1 load factor has recovered from its error state.	CPU %1 load factor has recovered from its error state.	-	Yellow	CPU	✓	-	-	.1.3.6.1.4.1.119.2.2.4.4.2.3	8
106	8000006A	Warning	CPU %1 load has exceeded the upper threshold(Warning).	CPU %1 load factor has exceeded the upper threshold(Warning).	-	Yellow	CPU	✓	-	System load becomes extremely high. Confirm whether it is appropriate.	.1.3.6.1.4.1.119.2.2.4.4.2.3	5
107	4000006B	Information	CPU %1 load factor has recovered from its warning state.	CPU %1 load factor has recovered from its warning state.	-	Green	CPU	✓	-	-	.1.3.6.1.4.1.119.2.2.4.4.2.3	6
9000	C0002328	Error	ESMCpuPerf Internal Error [ %1 ]	-	-	-	-	-	-	Because some error in ESMCommonService happens, there is a possibility that some monitored items can not be monitored. Reboot service. In case message is displayed, collect information by Collect.exe and contact system administrator.	-	-
9001	80002329	Warning	ESMCpuPerf Invalid threshold Minimum Value [ %1 ] Established Value [ %2 ]	-	-	-	-	-	-	Confirm threshold of CPU loading factor.	-	-
9002	8000232A	Warning	ESMCpuPerf Invalid threshold Maximum Value [ %1 ] Established Value [ %2 ]	-	-	-	-	-	-	Confirm threshold of CPU loading factor.	-	-
9003	8000232B	Warning	ESMCpuPerf Invalid threshold Use Default Value	-	-	-	-	-	-	Confirm threshold of CPU loading factor.	-	-
9004	8000232C	Warning	Warning condition was detected with ESMCpuPerf. [ %1 ]	-	-	-	-	-	-	Collect information by Collect.exe.	-	-
9005	4000232D	Information	%1	-	-	-	-	-	-	Collect information by Collect.exe.	-	-

**Event Source [ESMLocalPolling]**

Event Viewer				AlertViewer				Destination(Default)		Others	SNMP Trap OID	
Event ID	Event ID(Hex)	Type	Description	Detail	Action	Status Color	Type	Manager	Express	Remarks	Enterprise ID	Specific ID
110	C000006E	Error	Polling Data has exceeded the upper fatal Limit Polling ID [%1] OID [%2] OID Data [%3] Threshold [%4]	The Polling Data has exceeded the upper fatal limit. OID:%2 Value:%3	-	Red	User Defined	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.19.3	11
111	8000006F	Warning	Polling Data has fallen below the upper fatal limit Polling ID [%1] OID [%2] OID Data [%3] Threshold [%4]	The Polling Data has fallen below the upper fatal limit. OID:%2 Value:%3	-	Yellow	User Defined	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.19.3	12
112	80000070	Warning	Polling Data has exceeded the upper warning limit Polling ID [%1] OID [%2] OID Data [%3] Threshold [%4]	The Polling Data has exceeded the upper warning limit. OID:%2 Value:%3	-	Yellow	User Defined	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.19.3	9
113	40000071	Information	Polling Data has fallen below the upper warning limit Polling ID [%1] OID [%2] OID Data [%3] Threshold [%4]	The Polling Data has fallen below the upper warning limit. OID:%2 Value:%3	-	Green	User Defined	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.19.3	10
114	C0000072	Error	Polling Data has fallen below the lower fatal limit Polling ID [%1] OID [%2] OID Data [%3] Threshold [%4]	The Polling Data has fallen below the lower fatal limit. OID:%2 Value:%3	-	Red	User Defined	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.19.3	16
115	80000073	Warning	Polling Data has exceeded the lower fatal limit Polling ID [%1] OID [%2] OID Data [%3] Threshold [%4]	The Polling Data has exceeded the lower fatal limit. OID:%2 Value:%3	-	Yellow	User Defined	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.19.3	15
116	80000074	Warning	Polling Data has fallen below the lower warning limit Polling ID [%1] OID [%2] OID Data [%3] Threshold [%4]	The Polling Data has fallen below the lower warning limit. OID:%2 Value:%3	-	Yellow	User Defined	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.19.3	14
117	40000075	Information	Polling Data has exceeded the lower warning limit Polling ID [%1] OID [%2] OID Data [%3] Threshold [%4]	The Polling Data has exceeded the lower warning limit. OID:%2 Value:%3	-	Green	User Defined	✓	-	-	.1.3.6.1.4.1.119.2.2.4 .4.19.3	13

900	C0000384	Error	ESMLocalPolling Internal Error [ %1 ]	-	-	-	-	-	-	Confirm that SNMP service is normally operating. In case it operates, confirm whether or not there is a problem with setting of SNMP and local polling.	-	-
901	C0000385	Error	Polling Threshold Value Error. Polling ID [%1] Threshold [%2]	-	-	-	-	-	-	Confirm thresold of local polling.	-	-



# EsmSaWmi

This event will be registered into event log and be reported when you run a maintenance operation of FT server.

Event Viewer				AlertViewer				Destination(Default)		Others	SNMP Trap OID	
Event ID	Event ID(Hex)	Type	Description	Detail	Action	Status Color	Type	Manager	Express	Remarks	Enterprise ID	Specific ID
100	40000064	Information	To clear MTBF information of %1 succeeded.	To clear MTBF information of %1 succeeded.	-	Green	Server Recovery	✓	-	-	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
101	40000065	Information	To start to bring up %1 succeeded.	To start to bring up %1 succeeded.	-	Green	Server Recovery	✓	-	-	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
102	40000066	Information	To start to bring down %1 succeeded.	To start to bring down %1 succeeded.	-	Green	Server Recovery	✓	-	-	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
103	40000067	Information	To start to execute diagnostics of %1 succeeded.	To start to execute diagnostics of %1 succeeded.	-	Green	Server Recovery	✓	-	-	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
104	40000068	Information	To start to update firmware of %1 succeeded. (%2)	To start to update firmware of %1 succeeded. (%2)	-	Green	Server Recovery	✓	-	-	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
105	40000069	Information	To start to save dump of %1 succeeded.	To start to save dump of %1 succeeded.	-	Green	Server Recovery	✓	-	-	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
106	4000006A	Information	To start to save dump of %1 and restart succeeded.	To start to save dump of %1 and restart succeeded.	-	Green	Server Recovery	✓	-	-	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
107	4000006B	Information	To start to set %1 to primary succeeded.	To start to set %1 to primary succeeded.	-	Green	Server Recovery	✓	-	-	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
108	4000006C	Information	To reset %1 succeeded.	To reset %1 succeeded.	-	Green	Server Recovery	✓	-	-	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
109	4000006D	Information	To set %1 to primary succeeded.	To set %1 to primary succeeded.	-	Green	Server Recovery	✓	-	-	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
900	40000384	Information	Method was completed normally. Class Name : %1 Method Name : %2 Instance : %3	Method was completed normally. Class Name : %1 Method Name : %2 Instance : %3	-	Green	Server Recovery	✓	-	-	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
1000	800003E8	Warning	To clear MTBF information of %1 failed. Error Code : %2	To clear MTBF information of %1 failed. Error Code : %2	The operation to the device failed. ☐Please check if the state of the device allows the operation to be executed and then try the operation again.	Yellow	Server Recovery	✓	-	Collect information by Collect.exe.	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
1001	800003E9	Warning	To start to bring up %1 failed. Error Code : %2	To start to bring up %1 failed. Error Code : %2	The operation to the device failed. ☐Please check if the state of the device allows the operation to be executed and then try the operation again.	Yellow	Server Recovery	✓	-	Collect information by Collect.exe.	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
1002	800003EA	Warning	To start to bring down %1 failed. Error Code : %2	To start to bring down %1 failed. Error Code : %2	The operation to the device failed. ☐Please check if the state of the device allows the operation to be executed and then try the operation again.	Yellow	Server Recovery	✓	-	Collect information by Collect.exe.	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
1003	800003EB	Warning	To start to execute diagnostics of %1 failed. Error Code : %2	To start to execute diagnostics of %1 failed. Error Code : %2	The operation to the device failed. ☐Please check if the state of the device allows the operation to be executed and then try the operation again.	Yellow	Server Recovery	✓	-	Collect information by Collect.exe.	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
1004	800003EC	Warning	To start to update firmware of %1 failed. (%2) Error Code : %3	To start to update firmware of %1 failed. (%2) Error Code : %3	The operation to the device failed. ☐Please check if the state of the device allows the operation to be executed and then try the operation again.	Yellow	Server Recovery	✓	-	Collect information by Collect.exe.	.1.3.6.1.4.1.119.2.2.4.4.18.3	1

1005	800003ED	Warning	To start to save dump of %1 failed. Error Code : %2	To start to save dump of %1 failed. Error Code : %2	The operation to the device failed. Please check if the state of the device allows the operation to be executed and then try the operation again.	Yellow	Server Recovery	✓	-	Collect information by Collect.exe.	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
1006	800003EE	Warning	To start to save dump of %1 and restart failed. Error Code : %2	To start to save dump of %1 and restart failed. Error Code : %2	The operation to the device failed. Please check if the state of the device allows the operation to be executed and then try the operation again.	Yellow	Server Recovery	✓	-	Collect information by Collect.exe.	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
1007	800003EF	Warning	To start to set %1 to primary failed. Error Code : %2	To start to set %1 to primary failed. Error Code : %2	The operation to the device failed. Please check if the state of the device allows the operation to be executed and then try the operation again.	Yellow	Server Recovery	✓	-	Collect information by Collect.exe.	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
1008	800003F0	Warning	To reset %1 failed. Error Code : %2	To reset %1 failed. Error Code : %2	The operation to the device failed. Please check if the state of the device allows the operation to be executed and then try the operation again.	Yellow	Server Recovery	✓	-	Collect information by Collect.exe.	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
1009	800003F1	Warning	To set %1 to primary failed. Error Code : %2	To set %1 to primary failed. Error Code : %2	The operation to the device failed. Please check if the state of the device allows the operation to be executed and then try the operation again.	Yellow	Server Recovery	✓	-	Collect information by Collect.exe.	.1.3.6.1.4.1.119.2.2.4.4.18.3	1
1900	8000076C	Warning	Method was failed. Class Name : %1 Method Name : %2 Instance : %3 Error Code : %4	Method was failed. Class Name : %1 Method Name : %2 Instance : %3 Error Code : %4	The operation to the device failed. Please check if the state of the device allows the operation to be executed and then try the operation again.	Yellow	Server Recovery	✓	-	Collect information by Collect.exe.	.1.3.6.1.4.1.119.2.2.4.4.18.3	1

## ESMSystemManagementService

This service is the one for monitoring of ESRAS-related failure.

In case alert about this service occurred, confirm whether selection of models for NEC ESMPRO Agent is not mistaken.

Event Viewer			AlertViewer				Destination(Default)		Others	SNMP Trap OID	
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Express	Remarks	Enterprise ID	Specific ID
9101	Error	Internal Error (System Management Service) [ %1 %2 ]	-	-	-	-	-	-	Because some error in ESMSystemManagementService happened, service could not be started. In case the same message is displayed, collect information by Collect.exe and contact system administrator.	-	-
9104	Error	Internal Error (Report Function DLL) Error Code = %1 EventLog Type = %2 Source Name = %3 Event ID = %4	-	-	-	-	-	-	Because some error in ESMSystemManagementService happened, alert could not be processed. Reboot service. In case the same message is displayed, collect information by Collect.exe and contact system administrator.	-	-

## ESMLANService

This service monitors load and failure of network line.

In case alert about this service occurred, confirm around network line.

Event Viewer			AlertViewer				Destination(Default)		Others	SNMP Trap OID	
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Express	Remarks	Enterprise ID	Specific ID
301	Warning	A Network Hardware failure may have occurred. Device: %1 Error No.: %2,%3,%4 Alignment Errors = %5 FCS Errors = %6 Carrier Sense Errors = %7	A Network Hardware failure may have occurred. Device: %1 Error No.: %2,%3,%4	Please check that the network cables are tightly connected and that the HUB power switch is on.	Yellow	Network	✓	-	Confirm whether network cable is plugged off or power of HUB is on. Because there is a possibility that there is some failure on line, confirm network environment. Alert sends by warning for ESMPRO/SA Ver3.8 and the succeeding versions and by abnormal before Ver3.7.	.1.3.6.1.4.1.119.2.2.4.4.13.3	1
302	Warning	Network is under heavy load. Device: %1 Error No.: %2,%3 Total Transmitted Packets = %4 Late Collisions = %5 Single-Collisions = %6 Multiple-Collisions = %7 Delayed Frames = %8 Excess Collisions = %9 MAC transmitted Errors = %10	The Network is under heavy load. Device Name: %1 Error Type: %2	Heavy network traffic to this server was detected. Please attempt to reduce the network traffic to this server.	Yellow	Network	✓	-	Lighten access to server and alleviate the load.	.1.3.6.1.4.1.119.2.2.4.4.13.3	2
303	Warning	Possible transmit and receive errors detected. Total Received Packets = %1 Disposed Received Packets = %2 Total Transmitted Packets = %3 Disposed Transmitted Packets = %4	There is a possibility that this server is short of network transmission and receiving buffer.	A high load of networking is detected. Please reduce the net access on the server.	Yellow	Network	✓	-	Lighten access to server and alleviate the load.	.1.3.6.1.4.1.119.2.2.4.4.13.3	3
305	Information	Network error conditions were recovered. Device: %1 EventID: %2,%3,%4	Network condition has recovered from the following trouble. Device Name: %1 Error Category: %2	-	Green	Network	✓	-	Status of line is restored to normal status.	.1.3.6.1.4.1.119.2.2.4.4.13.3	4
399	Information	%1	-	-	-	-	-	-	In case character string of "Memory allocation failed." for %1 is displayed, confirm status of free area of memory. In case "SNMP Service is not started." or "SNMP Service does not accept a request." is displayed, confirm operating status of SNMP service.	-	-
301	Error	A Network Hardware failure may have occurred. Device: %1 Error No.: %2,%3,%4 Alignment Errors = %5 FCS Errors = %6 Carrier Sense Errors = %7	There is a possibility of Network hardware trouble. Device Name: %1 Error Type: %2	Please check that the network cables are tightly connected and that the HUB power switch is on.	Red	Network	✓	-	Confirm whether network cable is plugged off or power of HUB is on. Because there is a possibility that there is some failure on line, confirm network environment. Alert sends by warning for ESMPRO/SA Ver3.8 and the succeeding versions and by abnormal before Ver3.7.	.1.3.6.1.4.1.119.2.2.4.4.13.3	1

## ESRAS Utility Service

This service is to collect information displayed by ESRAS utility.

In case alert about this service occurred, confirm whether selection of models for NEC ESMPRO Agent is not mistaken.

Source name of Eventlog is registered as "ESRAS\_Utl".

Event Viewer			AlertViewer				Destination(Default)		Others	SNMP Trap OID	
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Express	Remarks	Enterprise ID	Specific ID
1000	Error	The ESRAS Utility Service failed to open the NVRAM.	-	-	-	-	-	-	-	-	-
1001	Error	Could not read from NVRAM.	-	-	-	-	-	-	-	-	-
1002	Error	Could not write to NVRAM.	-	-	-	-	-	-	-	-	-
1003	Error	Service internal processing error.	-	-	-	-	-	-	-	-	-
1004	Error	ervice internal processing error.	-	-	-	-	-	-	-	-	-
1005	Error	Service internal processing error.	-	-	-	-	-	-	-	-	-
1006	Error	Service internal fatal error.	-	-	-	-	-	-	-	-	-
1007	Error	Service internal processing error.	-	-	-	-	-	-	-	-	-
1008	Error	Service internal fatal error.	-	-	-	-	-	-	-	-	-
1011	Error	Could not initialize by IO control.	-	-	-	-	-	-	-	-	-

# ESMAgentDMIService

This service is to collect information by DMI.

Event Viewer			AlertViewer				Destination(Default)		Others
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Express	Remarks
8003	Warning	ESMAgentDMIService Internal Error. Address = %1 Code = %2 Detail1 = %3 Detail2 = %4	-	-	-	-	-	-	Reboot "ESMAgentDMIService" in "Service" of "Control Panel".
8004	Warning	ESMAgentDMIService tempthmo.dmm Error. Address = %1	-	-	-	-	-	-	In case you do not change threshold of temeparature, there is no problem. In case you want to change the threshold of temperature, reboot "ESMAgentDMIService" in "Service" of "Control Panel" and change it.
8005	Warning	ESMAgentDMIService DMM Internal Error. Dmm = %1 Address = %2 Code = %3 Detail1 = %4 Detail2 = %5	-	-	-	-	-	-	Confirm whether RAS information (temperature/power supply/power voltage/fan) is normal on DataViewer.

## AlertManagerMainService

This service is to alert failure.

In case event about this service occurred, confirm around alert.

Event Viewer			AlertViewer				Destination(Default)		Others	SNMP Trap OID	
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Express	Remarks	Enterprise ID	Specific ID
100	Information	Event Source Name: %3%n Event ID:(%4) %5%n Time: %6 %n %n AlertManager succeeded in reporting with the method of "%1".%n %2%n	-	-	-	-	-	-	The alert that failed to report has been reported again and the reporting succeeded at last.	-	-
101	Information	Event Source Name: %3%n Event ID:(%4) %5%n Time: %6 %n %n AlertManager failed in reporting with the method of "%1".%n %2%n	-	-	-	-	-	-	There is a possibility that there is a problem in the setting of the reporting method. Please check the "Base Setting" and the "Destination Setting" of the reporting method.	-	-
102	Information	Event Source Name: %3%n Event ID:(%4) %5%n Time: %6 %n %n AlertManager failed in reporting with the method of "%1". It will retry.%n %2%n	-	-	-	-	-	-	The alert reporting failed and will be tried to send again and again until success. You can click the "Schedule" button on the reporting "Destination ID" dialog to change the "Retry Interval" .	-	-
103	Warning	Event Source Name: %3%n Event ID:(%4) %5%n Time: %6 %n %n The alert request was removed because it couldn't be sent successfully within the retry time limit.%n %2%n	-	-	-	-	-	-	The alert reporting failed repeatedly, and the "Whole Retry Time" has elapsed. This alert reporting was abandoned. There is a possibility that there is a problem in the setting of the reporting method. Please check the "Base Setting" and the "Destination Setting" of the reporting method.	-	-
104	Error	Summary: %1%n Time: %2 %n %n The alert request was removed because it couldn't be sent successfully within the retry time limit.%n %3%n	-	-	-	-	-	-	Error happened in service. Collect information by Collect(m).exe.	-	-
800	Error	Fatal error occurred at watching %1 eventlog.%n %2%n	-	-	-	-	-	-	Error happened in service. Collect information by Collect(m).exe.	-	-

801	Error	Error occurred at watching %1 eventlog.%n %2%n	-	-	-	-	-	-	Error happened in service. Collect information by Collect(m).exe.	-	-
900	Error	Fatal error occurred.%n %1%n	-	-	-	-	-	-	Error happened in service. Collect information by Collect(m).exe.	-	-
901	Warning	AlertManager failed to execute the following module.%n Module name: %1%n	-	-	-	-	-	-	Collect information by Collect(m).exe.	-	-
802	Information	The past event was detected. There is the possibility of the following cause.%n - System time was changed into the past time from the time of the future.%n - A shutdown was not normal.%n - Event log was corrupt.%n	The past event was detected. There is the possibility of the following cause.%n - System time was changed into the past time from the time of the future.%n - A shutdown was not normal.%n - Event log was corrupt.%n	1.When System Time is changed, Please set 0 as all value of '{log name }Time' key shown below. HKEY_LOCAL_MACHINE\SOFTWARE\NEC\ESMAAlertMan\AMMNEV 2. When a shutdown is automatic, you need to increase the value of a timer. 3. Please clear the corrupted log and reboot AlertManagerMainService.	Green	Service	✓	-		1.3.6.1.4.1.119.2.2.4.4.18.3	1
803	Error	Failure of read of event log. It stops watching %1 log. The following code is error information.(%2)%n	Failure of read of event log. It stops watching %1 log. The following code is error information.(%2)%n	-	Red	Service	✓	-	Error happened in service. Collect information by Collect(m).exe.	1.3.6.1.4.1.119.2.2.4.4.18.3	1
1000	Information	This server is shutting down or rebooting in %1 second(s).%n	This server is shutting down or rebooting in %1 second(s).%n	-	Green	Server Recovery	✓	-	shutting down or rebooting has happened.	1.3.6.1.4.1.119.2.2.4.4.18.3	1
1001	Information	The request of shutting down or rebooting was canceled by user.%n	The request of shutting down or rebooting was canceled by user.%n	-	Green	Server Recovery	✓	-	shutting down or rebooting has happened,but it was canceled by user.	1.3.6.1.4.1.119.2.2.4.4.18.3	1
1100	Error	Critical error occurred while subscribing to channel %1. It stops watching the channel. %nErrorCode = %2%n	Critical error occurred while subscribing to channel %1. It stops watching the channel. %nErrorCode = %2%n	-	Red	Service	✓	-	Error happened in service. Collect information by Collect(m).exe.	1.3.6.1.4.1.119.2.2.4.4.18.3	1
1101	Warning	Error occurred while subscribing to channel %1. It stops watching the channel temporarily. %nErrorCode = %2%n	Error occurred while subscribing to channel %1. It stops watching the channel temporarily. %nErrorCode = %2%n	-	Yellow	Service	✓	-	Error happened in service. Collect information by Collect(m).exe.	1.3.6.1.4.1.119.2.2.4.4.18.3	1
1102	Information	Subscribing to channel %1 succeeded. It starts watching the channel.%n	Subscribing to channel %1 succeeded. It starts watching the channel.%n	-	Green	Service	✓	-		1.3.6.1.4.1.119.2.2.4.4.18.3	1



## AlertManagerALIVESendService

This service is to send ALIVE alert.

In case alert about this service occurred, confirm around modem and SMB.

Event Viewer			AlertViewer				Destination(Default)		Others
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Express	Remarks
401	Information	Service started.	-	-	-	-	-	-	
402	Information	Service stopped.	-	-	-	-	-	-	
403	Information	Service paused.	-	-	-	-	-	-	
404	Information	ALIVE Service continued.	-	-	-	-	-	-	
405	Error	Alert Manager failed to send the following event with the SMB Board.%n %n To : %6 %n [report] %n DATE : %1 Time : %2 Computer : %3 %n Source : %4 EventID : %5 %n	-	-	-	-	-	-	Collect information by Collect(m).exe.
406	Information	It reported successfully.%n %n To : %6 %n [report] %n DATE : %1 Time : %2 Computer : %3 %n Source : %4 EventID : %5 %n	-	-	-	-	-	-	
407	Error	Serial port is busy.%n %n %1%n	-	-	-	-	-	-	Collect information by Collect(m).exe.
408	Error	Telephone line is busy. %n %n %1%n	-	-	-	-	-	-	Collect information by Collect(m).exe.

409	Error	The message transmitted by SMB has not been acknowledged by the receiver of the message. %n %1%n	-	-	-	-	-	-	Collect information by Collect(m).exe.
410	Error	Telephone line was cut off.%n %n %1%n	-	-	-	-	-	-	Collect information by Collect(m).exe.
411	Error	It couldn't communicate with the modem.%n %n %1%n	-	-	-	-	-	-	Collect information by Collect(m).exe.
412	Error	An error occurred in the registry access.%n %n %1%n	-	-	-	-	-	-	Collect information by Collect(m).exe.
413	Error	An error occurred in the service control.%n %n %1%n	-	-	-	-	-	-	Collect information by Collect(m).exe.
414	Information	Remote Access Service was started.%n	-	-	-	-	-	-	
415	Information	Remote Access Service was stopped.	-	-	-	-	-	-	
416	Error	Specified DLL wasn't found. %n %1%n	-	-	-	-	-	-	Collect information by Collect(m).exe.
417	Error	Alert Manager failed to report.%n %n %1%n	-	-	-	-	-	-	Collect information by Collect(m).exe.
418	Error	Alert Manager failed to send an alert because the Socket Send Service has not started.%n	-	-	-	-	-	-	Collect information by Collect(m).exe.
419	Warning	It failed to acquire the data inside the queue.	-	-	-	-	-	-	Collect information by Collect(m).exe.
420	Warning	Could not set the device control block.	-	-	-	-	-	-	Collect information by Collect(m).exe.
421	Warning	Could not initialize the modem.	-	-	-	-	-	-	Collect information by Collect(m).exe.

422	Warning	An error occurred during the message communication.	-	-	-	-	-	-	Collect information by Collect(m).exe.
423	Warning	A retry error occurred while trying to get the result of test report.	-	-	-	-	-	-	Collect information by Collect(m).exe.
424	Warning	An error occurred while trying to get the result of test report.	-	-	-	-	-	-	Collect information by Collect(m).exe.
425	Warning	It wasn't connected with the destination of the test report.	-	-	-	-	-	-	Collect information by Collect(m).exe.
426	Warning	A line error occurred during test report and then it could not connect with the destination again.	-	-	-	-	-	-	Collect information by Collect(m).exe.
427	Warning	The setting of the automatic report is wrong in the report test.	-	-	-	-	-	-	Collect information by Collect(m).exe.
428	Warning	A time out or a line cutting was detected in the report test.	-	-	-	-	-	-	Collect information by Collect(m).exe.
429	Warning	he parity error occurred in the report test.	-	-	-	-	-	-	Collect information by Collect(m).exe.
430	Warning	The overrun error occurred in the report test.	-	-	-	-	-	-	Collect information by Collect(m).exe.
501	Error	The following event couldn't be transmitted with the Socket Send Service.%n %n %1%n	-	-	-	-	-	-	Collect information by Collect(m).exe.
502	Information	It failed to control of Remote Access Server.%n %n %1%n	-	-	-	-	-	-	Collect information by Collect(m).exe.
503	Error	A WinSock error occurred in the service.%n %n %1%n	-	-	-	-	-	-	Collect information by Collect(m).exe.
9401	Error	A fatal error occurred in the service specified with the event source name.%n %n %1%n	-	-	-	-	-	-	Collect information by Collect(m).exe.

9403	Error	An error occurred in the service specified with the event source name.%n%n%1%n	-	-	-	-	-	-	Collect information by Collect(m).exe.
------	-------	--	---	---	---	---	---	---	--

## mainte/necras

This driver collects various model-specific information from sensor, register BIOS and others on hardware.

This driver depends on equipment to be installed.

In case warning/abnormal Eventlog from this driver was displayed, confirm the followings:

-whether selection of models for ESMPRO/ServerAgent is not mistaken.

-whether setting of BIOS Setup is not mistaken /whether BMC-FW is normally operating.

Event Viewer			AlertViewer				Destination(Default)		Others
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Express	Remarks
1	Error	IPMI driver can not get a required resource (%2).	-	-	-	-	-	-	Collect information by Collect.exe.
2	Error	IPMI driver can not found SMBIOS structures.	-	-	-	-	-	-	Collect information by Collect.exe.
3	Error	It is possible that you missed a selection at ESM setup.	-	-	-	-	-	-	Collect information by Collect.exe.
7	Error	IPMI driver detected a serious error at setup phase. Cause = (%2)	-	-	-	-	-	-	Collect information by Collect.exe. There is a possibility that you have to replace device.
8	Error	IPMI driver detected an internal error. Cause = (%2)	-	-	-	-	-	-	Collect information by Collect.exe.
10	Error	Requested data exceeds a max length. Command = (%2) Data length = (%3)	-	-	-	-	-	-	Collect information by Collect.exe.
11	Error	Response data exceeds a max length.	-	-	-	-	-	-	Collect information by Collect.exe.
12	Warning	IPMI Driver can not access FRU device.	-	-	-	-	-	-	Collect information by Collect.exe.

16	Error	IPMI driver detected a serious error of BMC. Completion Code = (%2) Parameter1 = (%3) Parameter2 = (%4)	-	-	-	-	-	-	Collect information by Collect.exe. There is a possibility that you have to replace device.
18	Warning	An IPMI command error occurred at driver setup phase. Cause = (%2)	-	-	-	-	-	-	Collect information by Collect.exe. There is a possibility that you have to replace device.
19	Warning	IPMI driver detected a warning error of BMC. Cause = (%2) Parameter1 = (%3) Parameter2 = (%4)	-	-	-	-	-	-	Collect information by Collect.exe. There is a possibility that you have to replace device.
20	Information	IPMI Driver changed the interrupt-mode to polling-mode.	-	-	-	-	-	-	Collect information by Collect.exe.

Event Viewer			AlertViewer				Destination(Default)		Others
Event ID	Type	Description	Detail	Action	Status Color	Type	Manager	Express	Remarks
4098	Error	ESRAS driver failed an exclusion of NVRAM area. Reboot system for safety. Or it is possible that you missed a selection at ESM setup.	-	-	-	-	-	-	Collect information by Collect.exe.
4099	Warning	ESRAS driver found an illegal RecordType in SMI-LOG area. SMI-LOG area is formatted by force.	-	-	-	-	-	-	Collect information by Collect.exe.
4100	Error	Registry values for WDT controls are illegal values.	-	-	-	-	-	-	Collect information by Collect.exe.
4101	Error	ESRAS driver failed to format SMI-LOG area. Please reboot system for safety.	-	-	-	-	-	-	Collect information by Collect.exe.
4102	Error	ESRAS driver failed to allocate free spaces when formatting. Please reboot system for safety.	-	-	-	-	-	-	Collect information by Collect.exe.

4103	Information	ESRAS driver formatted SMI-LOG area because used area reached 70%.	-	-	-	-	-	-	Collect information by Collect.exe.
4104	Information	ESRAS driver formatted SMI-LOG area by force because used area reached 90%.	-	-	-	-	-	-	Collect information by Collect.exe.
4106	Error	ESRAS driver found an illegal Read Pointer in SMI-LOG Header. SMI-LOG handling abort.	-	-	-	-	-	-	Collect information by Collect.exe.
4107	Error	ESRAS driver found an illegal Write Pointer in SMI-LOG Header. SMI-LOG handling abort.	-	-	-	-	-	-	Collect information by Collect.exe.
4108	Error	It is possible that you missed a selection at ESM setup.	-	-	-	-	-	-	Collect information by Collect.exe.
4110	Error	ESRAS driver detected an error on accessing hardware devices.	-	-	-	-	-	-	Collect information by Collect.exe.
4111	Error	ESRAS driver can not find OEM-STRINGS structures. It is possible that you missed a selection at ESM setup.	-	-	-	-	-	-	Collect information by Collect.exe.
4114	Information	ESRAS driver detected a recovery on accessing hardware devices.	-	-	-	-	-	-	Collect information by Collect.exe.
4117	Information	ESRAS driver detected a recovery on accessing hardware devices.	-	-	-	-	-	-	Collect information by Collect.exe.

4119	Warning	ESRAS Driver failed SMBus access. Access = (%2) SlaveAddress = (%3) Offset = (%4) Code = (%5)	-	-	-	-	-	-	Collect information by Collect.exe.
4122	Error	NECRAS driver do not support this model. Please check the installation model.	-	-	-	-	-	-	Collect information by Collect.exe.
4123	Error	ESRAS driver detected Host Busy.	-	-	-	-	-	-	Collect information by Collect.exe.