

Appendix C : Logs/Events

The lists of log and event, alert messages that Universal RAID Utility logs to RAID Log and OS Log are described in this section.

[Event Source, Alert Type]

OS event source name : raidsrv
Source Name on NEC ESMPRO Manager (Windows) : raidsrv
Source Name on NEC ESMPRO Manager (Linux, VMware) : RAIDSRV
Alert Type : URAIDUTL

[Log]

Mark	Description
R	Universal RAID Utility logs this event to RAID Log.
O	Universal RAID Utility logs this event to OS log.

[Alert]

Mark	Description
M and MA	Universal RAID Utility sends this event to NEC ESMPRO Manager as alert.

[Address] description in [Description]

The [Address] description is different from the category of event.

Category of Event	Type	Description
RAID Controller Battery Flash Backup Unit	1	[CTRL:%1(ID=%2)] %1 : Number of RAID Controller %2 : ID of RAID Controller
Physical Device	2	[CTRL:%1(ID=%2) PD:%3(ID=%4) %5%6] %1 : Number of RAID Controller %2 : ID of RAID Controller %3 : Number of Physical Device %4 : ID of Physical Device %5 : Vendor and Model of Physical Device %6 : Firmware Version of Physical Device
Logical Drive	3	[CTRL:%1(ID=%2) LD:%3(ID=%4)] %1 : Number of RAID Controller %2 : ID of RAID Controller %3 : Number of Logical Drive %4 : ID of Logical Drive
Enclosure	4	[CTRL:%1(ID=%2) ENC:%3] %1 : Number of RAID Controller %2 : ID of RAID Controller %3 : Number of Enclosure
Power Supply Unit in Enclosure	5	[CTRL:%1(ID=%2) ENC:%3 POW:%4] %1 : Number of RAID Controller %2 : ID of RAID Controller %3 : Number of Enclosure %4 : Number of Power Supply Unit
Fan Unit in Enclosure	6	[CTRL:%1(ID=%2) ENC:%3 FAN:%4] %1 : Number of RAID Controller %2 : ID of RAID Controller %3 : Number of Enclosure %4 : Number of Fan Unit

[priority, facility]

The messages of Universal RAID Utility have the following priority and facility on Linux or VMware ESX.

kind	priority	facility
information	info	daemon
warning	warning	daemon
error	err	daemon

Event ID (hex digit)	Severity	Description	Log	Alert	Summary	Deal Method
0201 (400000C9)	Information	[Address Type 1] The buzzer of RAID Controller is enable.	R			
0202 (400000CA)	Information	[Address Type 1] The buzzer of RAID Controller is disable.	R			
0203 (400000CB)	Information	[Address Type 1] The Rebuild Priority of RAID Controller was changed. (Value : %1)	R			
0204 (400000CC)	Information	[Address Type 1] The Consistency Check Priority of RAID Controller was changed. (Value : %1)	R			
0205 (400000CD)	Information	[Address Type 1] The Initialize Priority of RAID Controller was changed. (Value : %1)	R			
0206 (400000CE)	Information	[Address Type 1] Auto Patrol Read function is enable.	R			
0207 (400000CF)	Information	[Address Type 1] Auto Patrol Read function is disable.	R			
0208 (400000D0)	Information	[Address Type 1] A Patrol Read Priority of RAID Controller was changed. (Value : %1)	R			
0209 (400000D1)	Information	[Address Type 1] Patrol Read was started.	R			
0210 (400000D2)	Information	[Address Type 1] Patrol Read completed.	R			
0211 (800000D3)	Warning	[Address Type 1] A Warning Error happened to RAID Controller. Detail : %1	RO	M	RAID Controller Warning	Please check the RAID Controller. If some kind of problem happens to the RAID Controller repeatedly, please replace it.
0212 (C00000D4)	Fatal	[Address Type 1] A Fatal Error happened to RAID Controller. Detail : %1	RO	MA	RAID Controller Fatal	Please replace the RAID Controller.
0213 (400000D5)	Information	[Address Type 1] Patrol Read was paused.	R			
0214 (400000D6)	Information	[Address Type 1] Patrol Read was resumed.	R			
0215 (400000D7)	Information	[Address Type 1] Patrol Read was queued.	R			
0216 (400000D8)	Information	[Address Type 1] Patrol Read was stopped.	R			
0217 (C00000D9)	Fatal	[Address Type 1] Patrol Read failed.	RO	MA	Patrol Read Failed	Verify if there are any other error/warning messages regarding RAID system. If you found the other messages, deal with the problem for the messages. If you don't find any other messages regarding RAID system, the RAID Controller may be faulty. Collect log files with the NEC Product Info Collection Utility and contact your service representative. Refer to the Maintenance Guide that comes with the server for how to use the NEC Product Info Collection Utility.

Event ID (hex digit)	Severity	Description	Log	Alert	Summary	Deal Method
0218 (C00000DA)	Fatal	[Address Type 1] A Fatal Firmware Error happened to RAID Controller. %1	RO	MA	RAID Controller Firmware Error	Fatal Please replace the RAID Controller.
0219 (400000DB)	Information	[Address Type 1] RAID Controller property was changed.	RO			
0220 (800000DC)	Warning	[Address Type 1] SAS wide port lost link on SAS Expander or SAS Device. %1 %1 : Detail information	RO	MA	SAS Port link lost	Verify if the Mini-SAS cable between a RAID controller and a drive bay is connected properly. If the connection is correct, replace the Mini-SAS cable. If the same error persists after replacing the cable, replace the RAID controller or the expander board(or SAS device). If you can not solve this issue by these measures, contact your service representative and gather system information with NEC Product Info Collection Utility(collect.exe tool) and send him/her the information.
0221 (400000DD)	Information	[Address Type 1] SAS wide port restored link on SAS Expander or SAS Device. %1 %1 : Detail information	RO	M	SAS Port link restored	None
0222 (800000DE)	Warning	[Address Type 1] Failed to get RAID system information to change Logical Drive(s) parameters automatically.	RO	M	Get RAID System Information Failed	Please restart raidsrv service.
0223 (800000DF)	Warning	[Address Type 1] RAID System is unstable by inconsistency in the Status of Physical Device.	RO	M	RAID System unstable	Please check whether problem does not occur to the configuration of the RAID System. If the Physical Device of which the RAID System is not configured exists though it is Online, please replace the RAID Controller and the Physical Device.
0224 (400000E0)	Information	[Address Type 1] The temperature of RAID Controller is normal.	RO	M	RAID Controller Temperature is Normal	None
0225 (800000E1)	Warning	[Address Type 1] The temperature of RAID Controller is high.	RO	M	RAID Controller Temperature is High	Please check if cooling unit is working normally and the ambient temperature is in normal condition (10 - 40 degree C). If you do not find any problem and this warning message persists repetitively, please replace the RAID controller.
0226 (C00000E2)	Fatal	[Address Type 1] The temperature of RAID Controller is abnormal.	RO	MA	RAID Controller Temperature is Abnormal	The RAID controller halted because its temperature reached fatal level. Please check if cooling unit is working normally and the ambient temperature is in normal condition (10 - 40 degree C). If you will not find any problem and this fatal message persists repetitively, please replace the RAID controller.
0301 (4000012D)	Information	[Address Type 2] Physical Device is Online.	RO	M	Physical Device Online	None
0302 (4000012E)	Information	[Address Type 2] Physical Device is Ready.	RO	M	Physical Device Ready	None
0303 (4000012F)	Information	[Address Type 2] Physical Device is Hot Spare.	RO	M	Physical Device Hot Spare	None

Event ID (hex digit)	Severity	Description	Log	Alert	Summary	Deal Method
0304 (C0000130)	Fatal	[Address Type 2] Physical Device is Failed.	RO	MA	Physical Device Failed	Please replace the Physical Device.
0305 (80000131)	Warning	[Address Type 2] Detected S.M.A.R.T. Error.	RO	MA	S.M.A.R.T. Error	Please replace the Physical Device.
0306 (40000132)	Information	[Address Type 2] Rebuild was started.	RO	MA	Rebuild Started	None
0307 (40000133)	Information	[Address Type 2] Rebuild completed.	RO	MA	Rebuild Completed	None
0308 (C0000134)	Fatal	[Address Type 2] Rebuild failed.	RO	MA	Rebuild Failed	Please replace the Physical Device.
0309 (40000135)	Information	[Address Type 2] Rebuild was stopped.	RO	MA	Rebuild Stopped	None
0311 (40000137)	Information	[Address Type 2] Physical Device was inserted.	RO	M	Physical Device Inserted	None
0312 (40000138)	Information	[Address Type 2] Physical Device was removed.	RO	M	Physical Device Removed	None
0313 (40000139)	Information	[Address Type 2] Global Hot Spare created.	R			
0314 (4000013A)	Information	[Address Type 2] Dedicated Hot Spare created.	R			
0315 (4000013B)	Information	[Address Type 2] Global Hot Spare removed.	R			
0316 (4000013C)	Information	[Address Type 2] Dedicated Hot Spare removed.	R			
0317 (8000013D)	Warning	[Address Type 2] A Warning Error happened to Physical Device. Detail : %1	RO	M	Physical Device Warning	Please check the Physical Device. If some kind of problem happens to the Physical Device repeatedly, please replace it.
0318 (C000013E)	Fatal	[Address Type 2] A Fatal Error happened to Physical Device. Detail : %1	RO	MA	Physical Device Fatal	Please replace the Physical Device.
0319 (4000013F)	Information	[Address Type 2] Medium Error was detected in Physical Device and corrected. %1	RO	M	Physical Device Medium Error(Correctable)	Please replace the Physical Device if too many errors are detected on a Physical Device. * : Replace the Physical Device if an error is detected equal to or more than 20 times a week on a Physical Device.
0320 (C0000140)	Fatal	[Address Type 2] Medium Error was detected in Physical Device but could not correct. %1 %1 : Logical Block Address	RO	MA	Physical Device Medium Error(Uncorrectable)	An error was detected in Logical Drive. There was a read error in Multiple Devices or a write error in single Device Please replace the Physical Device. If A read error occurred in Devices, please remake Logical Drive.
0321 (40000141)	Information	[Address Type 2] Rebuild was paused.	R			

Event ID (hex digit)	Severity	Description	Log	Alert	Summary	Deal Method
0322 (40000142)	Information	[Address Type 2] Rebuild was resumed.	R			
0323 (40000143)	Information	[Address Type 2] Rebuild was queued.	R			
0324 (80000144)	Warning	[Address Type 2] Medium Error was detected in Physical Device. %1 %1 : Logical Block Address	RO	M	Physical Device Medium Error Detected	Please replace the Physical Device if too many errors are detected on a Physical Device. * : Replace the Physical Device if an error is detected equal to or more than 20 times a week on a Physical Device.
0325 (40000145)	Information	[Address Type 2] Physical Device Power Status is Transitioning.	RO			
0326 (40000146)	Information	[Address Type 2] Physical Device Power Status is On.	RO			
0327 (40000147)	Information	[Address Type 2] Physical Device Power Status is Power Saving.	RO			
0328 (C0000148)	Fatal	[Address Type 2] Physical Device Power Status Change failed.	RO	MA	Physical Device Power Status Change Failed	Please replace the Physical Device.
0329 (80000149)	Warning	[Address Type 2] A Medium Error was detected frequently on the Physical Device. If Patrol Read or Consistency Check are running, these functions are stopped.	RO	MA	A Medium Error was Frequently Detected	Please replace the Physical Device. * : Physical Devices with a sector size of 512 emulation (512e) have different guidelines for replacing Physical Devices. For details, see "Monitoring a Medium Error to see if they occur frequently" section in this User's Guide.
0330 (8000014A)	Warning	[Address Type 2] A Medium Error was detected intermittently on the Physical Device.	RO	MA	A Medium Error was Intermittently Detected	Please replace the Physical Device. * : Physical Devices with a sector size of 512 emulation (512e) have different guidelines for replacing Physical Devices. For details, see "Monitoring a Medium Error to see if they occur frequently" section in this User's Guide.
0332 (4000014C)	Information	[Address Type 2] Physical Device Endurance Remaining is Safe (100-51%).	RO			
0333 (4000014D)	Information	[Address Type 2] Physical Device Endurance Remaining is Reducing (50-21%).	RO			
0334 (4000014E)	Warning	[Address Type 2] Physical Device Endurance Remaining is Running out (50-21%).	RO			
0335 (4000014F)	Warning	[Address Type 2] Physical Device Endurance Remaining is Need to replace (10% or less).	RO	MA	Physical Device Endurance Remaining Warning	Please replace the Physical Device.
0336 (C0000150)	Fatal	[Address Type 2] Physical Device Endurance Remaining is End of life.	RO	MA	Physical Device Endurance Remaining Error	Please replace the Physical Device.
0401 (40000191)	Information	[Address Type 3] Logical Drive is Online.	RO	M	Logical Drive Online	None

Event ID (hex digit)	Severity	Description	Log	Alert	Summary	Deal Method
0402 (80000192)	Warning	[Address Type 3] Logical Drive is Degraded.	RO	MA	Logical Drive Degraded	If there is Hot Spare, RAID System will rebuild automatically. If there is not it, please replace the Physical Device and rebuild it.
0403 (C0000193)	Fatal	[Address Type 3] Logical Drive is Offline.	RO	MA	Logical Drive Offline	Please replace the Physical Device and remake the Logical Drive. Next restore the backup data to the Logical Drive.
0404 (40000194)	Information	[Address Type 3] Initialization was started.	R			
0405 (40000195)	Information	[Address Type 3] Initialization completed.	R			
0406 (C0000196)	Fatal	[Address Type 3] Initialization failed.	RO	MA	Initialization Failed	Try to initialize again. If it fails again, verify if there are any other error/warning messages regarding RAID system. If you found the other messages, deal with the problem for the messages. After you deal with the problem, try to initialize again. If you don't find any other messages regarding RAID system, the RAID Controller may be faulty. Collect log files with the NEC Product Info Collection Utility(collect.exe tool) and contact your service representative.
0407 (40000197)	Information	[Address Type 3] Initialization was stopped.	R			
0409 (40000199)	Information	[Address Type 3] Consistency Check was started.	R			
0410 (4000019A)	Information	[Address Type 3] Consistency Check completed.	R			
0411 (C000019B)	Fatal	[Address Type 3] Consistency Check failed.	RO	MA	Consistency Check Failed	Verify if there are any other error/warning messages regarding RAID system. If you found the other messages, deal with the problem for the messages. After you deal with the problem, execute the Consistency Check again. If you don't find any other messages regarding RAID system, the RAID Controller may be faulty. Collect log files with the NEC Product Info Collection Utility(collect.exe tool) and contact your service representative.
0412 (4000019C)	Information	[Address Type 3] Consistency Check was stopped.	R			

Event ID (hex digit)	Severity	Description	Log	Alert	Summary	Deal Method
0413 (C000019D)	Fatal	[Address Type 3] Data Inconsistency was detected in Logical Drive by Consistency Check and corrected.	RO	MA	Data Inconsistency Error Corrected	Please execute Consistency Check again when the load of the system is low. If the error does not occur on the second time of Consistency Check, the Physical Device does not have any problems. If the same error occurs, please replace the Physical Device for the preventive maintenance (please be sure to ask NEC customer service before the replacement to identify which Physical Device has a failure). After replacing the Physical Device, restore the backup data to the Logical Drive.
0415 (4000019F)	Information	[Address Type 3] Logical Drive was created.	R			
0416 (400001A0)	Information	[Address Type 3] Logical Drive was deleted.	R			
0417 (400001A1)	Information	[Address Type 3] The Cache Mode of Logical Drive was changed. (Value : %1) %1 : Changed value *1	RO	M	Cache Mode Changed	None
0418 (400001A2)	Information	[Address Type 3] Background Initialization was started.	R			
0419 (400001A3)	Information	[Address Type 3] Background Initialization completed.	R			
0420 (800001A4)	Warning	[Address Type 3] Background Initialization failed.	RO	MA	Background Initialization Failed	The RAID Controller may be faulty. Collect log files with the NEC Product Info Collection Utility and contact your service representative. Refer to the Maintenance Guide that comes with the server for how to use the NEC Product Info Collection Utility.
0421 (400001A5)	Information	[Address Type 3] Background Initialization was stopped.	R			
0422 (C00001A6)	Fatal	[Address Type 3] An error was detected in Logical Drive but could not correct.	RO	MA	Logical Drive Uncorrectable Error	Please replace the Physical Device (You need to ask it which Physical Device do you replace). After replacement of Physical Device, remake the Logical Drive and restore the backup data to it.
0423 (400001A7)	Information	[Address Type 3] An error was detected in Logical Drive and corrected.	RO	MA	Logical Drive Corrected Error	Please replace the Physical Device for the prevention of failure(You need to ask it which Physical Device do you replace). Next restore the backup data to the Logical Drive after replacement of Physical Device.
0424 (800001A8)	Warning	[Address Type 3] A Warning Error happened to Logical Drive. Detail : %1 %1 : Detail Information	RO	M	Logical Drive Warning	The RAID Controller and/or the Physical Device may have some kind of problem. You need to ask it which component has broken.
0425 (C00001A9)	Fatal	[Address Type 3] A Fatal Error happened to Logical Drive. Detail : %1 %1 : Detail information	RO	MA	Logical Drive Fatal	The RAID Controller and/or the Physical Device may have some kind of problem. You need to ask it which component has broken.

Event ID (hex digit)	Severity	Description	Log	Alert	Summary	Deal Method
0426 (400001AA)	Information	[Address Type 3] Initialization was paused.	R			
0427 (400001AB)	Information	[Address Type 3] Initialization was resumed.	R			
0428 (400001AC)	Information	[Address Type 3] Initialization was queued.	R			
0429 (400001AD)	Information	[Address Type 3] Consistency Check was paused.	R			
0430 (400001AE)	Information	[Address Type 3] Consistency Check was resumed.	R			
0431 (400001AF)	Information	[Address Type 3] Consistency Check was queued.	R			
0432 (400001B0)	Information	[Address Type 3] Background Initialization was paused.	R			
0433 (400001B1)	Information	[Address Type 3] Background Initialization was resumed.	R			
0434 (400001B2)	Information	[Address Type 3] Background Initialization was queued.	R			
0435 (400001B3)	Information	[Address Type 3] Power Save Mode of Logical Drive was changed.	RO			
0436 (400001B4)	Information	[Address Type 3] SSD Cache Drive was created.	RO	M	SSD Cache Drive Created	None
0437 (400001B5)	Information	[Address Type 3] SSD Cache Drive Capacity was changed.	RO	M	SSD Cache Drive Capacity Changed	None
0438 (800001B6)	Warning	[Address Type 3] Failed to change Logical Drive parameters automatically.	RO	M	Auto Change Logical Drive Parameters Failed	Please restart raidsrv service.
0501 (400001F5)	Information	[Address Type 1] Battery was detected.	R			
0502 (800001F6)	Warning	[Address Type 1] Battery was disconnected.	RO	MA	Battery Disconnect	Please check the Battery. If some kind of problem happen to the Battery repeatedly, please replace it.
0503 (400001F7)	Information	[Address Type 1] Battery was replaced.	R			
0504 (400001F8)	Information	[Address Type 1] The temperature of Battery is normal.	RO	M	Battery Temperature Normal	None
0505 (800001F9)	Warning	[Address Type 1] The temperature of Battery is high.	RO	M	Battery Temperature High	Please check the Battery. If some kind of problem happens to the Battery repeatedly, please replace it.
0506 (800001FA)	Warning	[Address Type 1] The voltage of Battery is low.	RO	M	Battery Voltage Low	Please check the Battery. If some kind of problem happens to the Battery repeatedly, please replace it.
0507 (800001FB)	Warning	[Address Type 1] A Fatal Error happened to Battery.	RO	MA	Battery Fatal	Please replace the Battery.

Event ID (hex digit)	Severity	Description	Log	Alert	Summary	Deal Method
0508 (800001FC)	Warning	[Address Type 1] The Battery state is unstable.	RO			
0509 (400001FD)	Information	[Address Type 1] The voltage of Battery is normal.	RO	M	Battery Voltage Normal	None
0510 (800001FE)	Warning	[Address Type 1] Battery Refresh required.	RO	M	Battery Refresh Required	Please start the Battery Refreshing.
0511 (400001FF)	Information	[Address Type 1] Flash Backup Unit was detected.	R			
0512 (80000200)	Warning	[Address Type 1] Flash Backup Unit was disconnected.	RO	MA	Flash Backup Unit Disconnect	Please check the Flash Backup Unit. If some kind of problem happens to the Flash Backup Unit repeatedly, please replace it.
0513 (40000201)	Information	[Address Type 1] Flash Backup Unit was replaced.	R			
0514 (40000202)	Information	[Address Type 1] The temperature of Flash Backup Unit is normal.	RO	M	Flash Backup Unit Temperature Normal	None
0515 (80000203)	Warning	[Address Type 1] The temperature of Flash Backup Unit is high.	RO	M	Flash Backup Unit Temperature High	Please check the Flash Backup Unit. If some kind of problem happens to the Flash Backup Unit repeatedly, please replace it.
0516 (80000204)	Warning	[Address Type 1] The voltage of Flash Backup Unit is low.	RO	M	Flash Backup Unit Voltage Low	Please check the Flash Backup Unit. If some kind of problem happens to the Flash Backup Unit repeatedly, please replace it.
0517 (80000205)	Warning	[Address Type 1] A Fatal Error happened to Flash Backup Unit.	RO	MA	Flash Backup Unit Fatal	Please replace the Flash Backup Unit.
0601 (80000259)	Warning	[Address Type 4] A Warning Error happened to Enclosure.	RO	M	Enclosure Warning	Check if the FAULT LED on an adapter in the SAS JBOD Enclosure is lit up. Replace the adapter in the SAS JBOD Enclosure if the FAULT LED is lit up, otherwise collect log files with the NEC Product Info Collection Utility and contact your service representative. Refer to the Maintenance Guide that comes with the server for how to use the NEC Product Info Collection Utility.
0602 (C000025A)	Fatal	[Address Type 4] A Fatal Error happened to Enclosure.	RO	MA	Enclosure Fatal	Check if the FAULT LED on an adapter in the SAS JBOD Enclosure is lit up. Replace the adapter in the SAS JBOD Enclosure if the FAULT LED is lit up, otherwise collect log files with the NEC Product Info Collection Utility and contact your service representative. Refer to the Maintenance Guide that comes with the server for how to use the NEC Product Info Collection Utility.

Event ID (hex digit)	Severity	Description	Log	Alert	Summary		Deal Method
0603 (8000025B)	Warning	[Address Type 4] The temperature of Enclosure is Warning level.	RO	MA	Enclosure Warning	Temperature	Check if the POWER FAULT LED or FAN FAULT LED on a power unit in the SAS JBOD Enclosure is lit up. If the either of LEDs is not lit up, check if ambient temperature is beyond normal condition (5 - 35 degree C). If the ambient temperature is in normal condition, collect log files with the NEC Product Info Collection Utility and contact your service representative. Refer to the Maintenance Guide that comes with the server for how to use the NEC Product Info Collection Utility.
0604 (C000025C)	Fatal	[Address Type 4] The temperature of Enclosure is Fatal level.	RO	MA	Enclosure Fatal	Temperature	Check if the POWER FAULT LED or FAN FAULT LED on a power unit in the SAS JBOD Enclosure is lit up. If the either of LEDs is not lit up, check if ambient temperature is beyond normal condition (5 - 35 degree C). If the ambient temperature is in normal condition, collect log files with the NEC Product Info Collection Utility and contact your service representative. Refer to the Maintenance Guide that comes with the server for how to use the NEC Product Info Collection Utility.
0605 (8000025D)	Warning	[Address Type 5] An error happened to the Power Supply Unit of Enclosure.	RO	MA	Enclosure Unit Error	Power Supply	Check if the POWER FAULT LED on a power unit in the SAS JBOD Enclosure is lit up. Replace the power unit in the SAS JBOD Enclosure if the POWER FAULT LED is lit up. Otherwise collect log files with the NEC Product Info Collection Utility and contact your service representative. Refer to the Maintenance Guide that comes with the server for how to use the NEC Product Info Collection Utility.
0606 (8000025E)	Warning	[Address Type 6] An error happened to the Fan Unit of Enclosure.	RO	MA	Enclosure Fan Unit Error		Check if the POWER FAULT LED or FAN FAULT LED on a power unit in the SAS JBOD Enclosure is lit up. Replace the power unit in the SAS JBOD Enclosure if the POWER FAULT LED or the FAN FAULT LED is lit up. Otherwise collect log files with the NEC Product Info Collection Utility and contact your service representative. Refer to the Maintenance Guide that comes with the server for how to use the NEC Product Info Collection Utility.
0607 (4000025F)	Information	[Address Type 4] The temperature of Enclosure is Normal level.	RO	MA	Enclosure Normal	Temperature	None
0701 (400002BD)	Information	[Address Type 1] The Configuration was cleared.	RO	M	Configuration Cleared		None

Event ID (hex digit)	Severity	Description	Log	Alert	Summary			Deal Method
0702 (400002BE)	Information	raidsrv Configuration [CTRL : %1(ID=%2)] Vendor Product Firmware Version [LD : %3(ID=%4)] RAID:RAIDlevel PD : X,Y,Z (count of LD STS : Status [PD : %5(ID=%6)] Vendor/Model Firmware Version STS : Status PWR : Power Status %1 : Number of RAID Controller %2 : ID of RAID Controller %3 : Number of Logical Drive %4 : ID of Logical Drive %5 : Number of Physical Device %6 : ID of Physical Device X, Y, Z : Number of Physical Device used in Logical Drive. There is not the STS of PD when the device type is not HDD or SSD.	0					
0801 (C0000321)	Fatal	It became unable to manage the RAID System due to a fatal error on the operating system.	RO	MA	Operating Error	System	Fatal	Please solve the fatal error on operating system. This event is reported by insufficient free memory space, insufficient free disk space or any other causes. Please refer Universal RAID Utility User's Guide for detail.

*1 : This item may not include in log message by the type of RAID Controller